

# 2002



Discover more ebooks! Visit our website:  
[fordshopmanual.com](http://fordshopmanual.com)

# Wiring Diagrams



**DEMO**

This DEMO contains only a few pages of the entire manual/product.

Not all Bookmarks work on the Demo, but they do on the full version.

Features:

- Searchable text
- Printable pages
- Bookmarked for easy navigation
- High Resolution images
- Zoom to see exact details
- Money back Guarantee
- Transfer to USB flash drive support

# MUSTANG

*Ford Motor Company*

Copyright © 2024, Forel Publishing Company, LLC, Woodbridge, Virginia

All Rights Reserved. No part of this book may be used or reproduced in any manner whatsoever without written permission of Forel Publishing Company, LLC. For information write to Forel Publishing Company, LLC, Woodbridge, VA 22192

## **2002 Mustang Wiring Diagrams**

**EAN: 978-1-60371-437-2**

**ISBN: 1-60371-437-5**

Forel Publishing Company, LLC  
Woodbridge, VA 22192



License #84356800

This publication contains material that is reproduced and distributed under a license from Ford Motor Company. No further reproduction or distribution of the Ford Motor Company material is allowed without the express written permission of Ford Motor Company.

---

## **Note from the Publisher**

This product was created from the original Ford Motor Company's publication. Every effort has been made to use the original scanned images, however, due to the condition of the material; some pages have been modified to remove imperfections.

---

## **Disclaimer**

Although every effort was made to ensure the accuracy of this book, no representations or warranties of any kind are made concerning the accuracy, completeness or suitability of the information, either expressed or implied. As a result, the information contained within this book should be used as general information only. The author and Forel Publishing Company, LLC shall have neither liability nor responsibility to any person or entity with respect to any loss or damage caused, or alleged to be caused, directly or indirectly by the information contained in this book. Further, the publisher and author are not engaged in rendering legal or other professional services. If legal, mechanical, electrical, or other expert assistance is required, the services of a competent professional should be sought.

---

**FORD CUSTOMER SERVICE DIVISION****Quality is Job 1**

Ford Customer Service Division has developed a new format for 2002 model year Wiring Diagrams. The features have been outlined below. It is important that you read the introduction to obtain a complete understanding of these features.

**2002 Wiring Diagrams Features**

- Pages are now presented in **landscape format**, 11 x 8 1/2.
- **Cell numbering** system is utilized.
- A **system overview** page now appears at the beginning of the cell of each major system. This page contains a high level overview of the connectivity of all components that make up a complete system.
- **Component operational information** now appears for components on each page of the system overview. This provides a brief description of how the component works.
- **Simplified component internal information** now appears on the system overview and schematic pages for solid state devices, as it is available from engineering.
- **Diagnostic test information** such as voltage and resistances values now appear on the system overview and schematic pages for solid state devices and sensors, as it is available from engineering.
- **Service base part numbers** now appear with all components.
- **Component location referencing** now appears where a component is shown complete on the schematic pages to provide a reference to the component location view.
- **Schematic page referencing** has been enhanced to provide a reference to where a splice or ground is shown complete. Additionally, in-cell referencing has been enhanced with letters to indicate that a circuit continues from one page to another within the same cell.
- All **connector views** are shown complete and located in Cell 150.
- **Component location views** are located in Cell 151 and are more specific, concentrating on select wiring and components for the area of the vehicle shown.

**NOTE:**The descriptions and specifications contained in this manual were in effect at the time this manual was approved for printing. Ford Motor Company reserves the right to discontinue models at any time, or change specifications or design without notice and without incurring any obligation.

**ORDERING INFORMATION**

To obtain information about ordering additional copies of this publication or to order any other Ford or Lincoln/Mercury publications, call 1-800-782-4356.

Available publications include workshop manuals, wiring diagrams, PC/ED Manuals and Owner Guides.

In addition, you can obtain a publications order form by writing to:

Ford Publications  
care of Helm Inc.  
P.O. Box 07150  
Detroit, MI 48207.

All rights reserved. Reproduction by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system or translation in whole or part is not permitted without written authorization from Ford Motor Company.

Copyright © 2001, Ford Motor Company

---

# Mustang Wiring Diagrams

---

Table of Contents	1-1	Instrument Cluster	60-1
Index	2-1	Warning Devices	66-1
Introduction	3-1	Illumination	71-1
Symbols	4-1	Wipers and Washers	81-1
Connector Repair Procedures	5-1	Headlamps	85-1
Systems Overview	8-1	Fog Lamps	86-1
Wiring Harness Overview	9-1	Courtesy Lamps	89-1
Grounds	10-1	Turn/Stop/Hazard Lamps	90-1
Fuse and Relay Information	11-1	Exterior Lamps	92-1
Charging System	12-1	Reversing Lamps	93-1
Power Distribution	13-1	Daytime Running Lamps	97-1
Module Communications Network	14-1	Power Windows	100-1
Starting System	20-1	Convertible Top	103-1
Engine Ignition	21-1	Power Door Locks	110-1
Engine Controls – 3.8L	23-1	Remote Keyless Entry (RKE)	111-1
Engine Controls – 4.6L	24-1	Anti-Theft	112-1
Transmission Controls	29-1	Luggage Compartment Lid Release	113-1
Vehicle Speed Control	31-1	Power Seats	120-1
Cooling Fan	33-1	Power Lumbar Seats	122-1
Shift Lock	37-1	Power Mirrors	124-1
ABS	42-1	Radio	130-1
Horn/Cigar Lighter	44-1	Component Testing	149-1
Air Bags	46-1	Connector Views	150-1
Air Conditioner/Heater	54-1	Component Location Views	151-1
Rear Window Defrost	56-1	Component Location Charts	152-1
Multifunction Electronic Control Modules	59-1	Vehicle Repair Location Charts	160-1

- A/C clutch cycling pressure switch (19D594), N412 ..... 54-2
- A/C clutch field coil (19D798), Y52 - 3.8L ..... 54-3
- A/C clutch field coil (19D798), Y52 - 4.6L ..... 54-4
- A/C clutch relay, K107 - 3.8L ..... 54-3
- A/C clutch relay, K107 - 4.6L ..... 54-4
- A/C high pressure switch (19D594), N126 - 3.8L ..... 54-3
- A/C high pressure switch (19D594), N126 - 4.6L ..... 54-4
- ABS control module (2C219), A7 ..... 42-2
- Air bag sliding contact (14A664), P140 ..... 31-4
- Air bag sliding contact (14A664), P140 ..... 44-2
- Air bag sliding contact (14A664), P140 ..... 46-2
- Air bag sliding contact (14A664), P140 ..... 66-1
- Auxiliary fuse box, P92 ..... 33-2
- Battery (10655), O1 ..... 13-1
- Battery Junction Box (BJB) (14A003), P93 ..... 13-1
- Blower motor resistor, R116 ..... 54-2
- Brake fluid level switch (2L414), N1 ..... 59-2
- Brake pedal position switch (13480), N82 ..... 90-2
- Brake pressure switch (2B264), N249 ..... 31-3
- Brake shift interlock (3Z719), Y215 ..... 37-1
- Camshaft position sensor (6B288), B41 ..... 21-3
- Central Junction Box (CJB) (14A068), P91 ..... 13-7
- Cigar lighter, front (15055), R42 ..... 44-1
- Clutch pedal position switch, N81 ..... 20-2
- Coil On Plug (COP) 1 (12029), P66 - 4.6L ..... 21-5
- Coil On Plug (COP) 2 (12029), P67 - 4.6L ..... 21-5
- Coil On Plug (COP) 3 (12029), P68 - 4.6L ..... 21-5
- Coil On Plug (COP) 4 (12029), P69 - 4.6L ..... 21-5
- Coil On Plug (COP) 5 (12029), P70 - 4.6L ..... 21-5
- Coil On Plug (COP) 6 (12029), P71 - 4.6L ..... 21-5
- Coil On Plug (COP) 7 (12029), P72 - 4.6L ..... 21-5
- Coil On Plug (COP) 8 (12029), P73 - 4.6L ..... 21-5
- Constant Control Relay Module (CCRM), A426 - 3.8L ..... 23-10
- Constant Control Relay Module (CCRM), A426 - 3.8L ..... 23-11
- Constant Control Relay Module (CCRM), A426 - 4.6L ..... 24-10
- Constant Control Relay Module (CCRM), A426 - 4.6L ..... 24-11
- Convertible top lower relay, K367 ..... 103-1
- Convertible top motor, M271 ..... 103-1
- Convertible top raise relay, K366 ..... 103-1
- Convertible top switch, N489 ..... 103-1
- Crankshaft position sensor (6C315), B43 ..... 21-3
- Cylinder-head temperature sensor (6G004), B135 - 3.8L ..... 23-7
- Data Link Connector (DLC) (14489), D20 ..... 14-1
- Daytime Running Lamps (DRL) module, A253 ..... 97-1
- Deactivator switch, N423 ..... 31-3
- Deactivator switch jumper, P151 ..... 31-3
- Differential pressure feedback EGR (DPFE) sensor (9J460), B257 -  
3.8L ..... 23-7
- Differential pressure feedback EGR (DPFE) sensor (9J460), B257 -  
4.6L ..... 24-6
- Digital Transmission Range (DTR) sensor (7F293), B234 ..... 29-2
- Door ajar switch, left front, N84 ..... 59-1
- Door ajar switch, right front, N85 ..... 59-1
- Door lock actuator, left front, M241 ..... 110-1
- Door lock actuator, left front, M241 ..... 111-2
- Door lock actuator, right front, M242 ..... 110-1
- Door lock actuator, right front, M242 ..... 111-2
- Driver air bag unit (78043B13), A42 ..... 46-2
- Driver seat front height motor, M229 ..... 120-1
- Driver seat horizontal motor, M227 ..... 120-1
- Driver seat lumbar compressor motor (65500), M231 ..... 122-1
- Driver seat rear height motor, M228 ..... 120-1
- EGR vacuum regulator solenoid (9J459), Y205 - 3.8L ..... 23-9
- Electronic flasher module, A17 ..... 90-2
- Engine Coolant Temperature (ECT) sensor (12A648), B10 - 4.6L ..... 24-6
- Engine cooling fan motor, M37 - 3.8L ..... 33-1
- Engine cooling fan motor, M37 - 4.6L ..... 33-2
- EVAP canister purge valve, Y134 - 3.8L ..... 23-9
- EVAP canister purge valve, Y134 - 4.6L ..... 24-7
- EVAP canister vent control solenoid, Y202 - 3.8L ..... 23-9
- EVAP canister vent control solenoid, Y202 - 4.6L ..... 24-7
- Exterior rear view mirror, left, M259 ..... 124-1

Exterior rear view mirror, right, M260 .....	124-1	F2.17 .....	13-11
Exterior rear view mirror switch (17B676), N409 .....	124-1	F2.18 .....	13-12
F1.1 .....	13-1	F2.19 .....	13-7
F1.2 .....	13-2	F2.20 .....	13-10
F1.3 .....	13-2	F2.21 .....	13-8
F1.4 .....	13-2	F2.23 .....	13-11
F1.5 .....	13-2	F2.24 .....	13-12
F1.6 .....	13-4	F2.25 .....	13-8
F1.8 .....	13-3	F2.26 .....	13-10
F1.9 .....	13-3	F2.27 .....	13-9
F1.10 .....	13-2	F2.28 .....	13-12
F1.11 .....	13-1	F2.29 .....	13-11
F1.12 .....	13-4	F2.30 .....	13-12
F1.13 .....	13-3	F2.31 .....	13-8
F1.14 .....	13-1	F2.32 .....	13-10
F1.15 .....	13-3	F2.33 .....	13-9
F1.16 .....	13-4	F2.34 .....	13-12
F1.17 .....	13-3	F2.35 .....	90-2
F1.18 .....	13-4	F2.36 .....	13-12
F1.20 .....	13-1	F2.37 .....	13-13
F1.24 .....	13-1	F2.38 .....	85-1
F1.26 .....	13-2	F2.39 .....	13-9
F1.27 .....	13-4	F2.41 .....	90-2
F1.28 .....	13-3	F2.43 .....	13-6
F1.31 .....	33-2	Fog lamp, left front (15200), E43 .....	86-1
F2.1 .....	13-7	Fog lamp, right front (15200), E42 .....	86-1
F2.2 .....	21-3	Fog lamp relay, K26 .....	86-1
F2.4 .....	85-1	Fog lamp switch, N114 .....	86-1
F2.5 .....	13-11	Front blower motor, M124 .....	54-2
F2.6 .....	13-15	Front fog lamp cutoff relay, K105 .....	86-1
F2.7 .....	13-7	Front passenger window/door lock switch, N627 - Convertible ..	100-2
F2.8 .....	21-3	Front passenger window/door lock switch, N627 - coupe .....	100-5
F2.10 .....	85-1	Front passenger window/door lock switch, N627 .....	110-1
F2.11 .....	13-11	Front passenger window/door lock switch, N627 .....	111-2
F2.13 .....	13-7	Fuel pump, M12 - 3.8L .....	23-8
F2.15 .....	13-8	Fuel pump, M12 - 4.6L .....	24-8

## 2-3 Index

Fuel pump driver module (9H307), A195 – 3.8L	23–8	Heated Oxygen Sensor (HO2S) #22 (9F472), B87 – 4.6L	24–9
Fuel pump driver module (9H307), A195 – 4.6L	24–8	High mounted stoplamp (13A613), E174	90–6
Fuel pump relay, K4 – 3.8L	23–10	High pitch horn, H3	44–2
Fuel pump relay, K4 – 4.6L	24–10	High speed fan control relay, K305 – 3.8L	23–11
Fuel rail pressure transducer sensor, B225 – 3.8L	23–7	High speed fan control relay, K305 – 4.6L	24–11
Fuel rail pressure transducer sensor, B225 – 4.6L	24–6	Horn relay, K33	44–2
Fuel sender (9H307), B19 – 3.8L	23–8	Idle air control valve (IAC) (9F715), Y133 – 3.8L	23–5
Fuel sender (9H307), B19 – 4.6L	24–8	Idle air control valve (IAC) (9F715), Y133 – 4.6L	24–5
Fuel tank pressure transducer sensor (9C968), B113 – 3.8L	23–8	Ignition coil, T1 – 3.8L	21–4
Fuel tank pressure transducer sensor (9C968), B113 – 4.6L	24–8	Ignition switch (11572), N278	13–5
Function selector switch assembly, P76	54–2	Ignition transformer capacitor, U1 – 3.8L	21–4
Fusible link A, O26	13–1	Ignition transformer capacitor 1 (18801), U10 – 4.6L	21–5
Fusible link B, O27	13–1	Ignition transformer capacitor 2 (18801), U11 – 4.6L	21–5
G101	10–3	Inertia Fuel Shutoff (IFS) switch (9D362), N316 – 3.8L	23–8
G102	10–1	Inertia Fuel Shutoff (IFS) switch (9D362), N316 – 4.6L	24–8
G103	10–3	Injector 1 (9F593), Y108 – 3.8L	23–5
G104	10–2	Injector 1 (9F593), Y108 – 4.6L	24–5
G105	10–2	Injector 2 (9F593), Y109 – 3.8L	23–5
G201	10–4	Injector 2 (9F593), Y109 – 4.6L	24–5
G203	10–5	Injector 3 (9F593), Y110 – 3.8L	23–5
G204	10–5	Injector 3 (9F593), Y110 – 4.6L	24–5
G300	10–8	Injector 4 (9F593), Y111 – 3.8L	23–4
G400	10–6	Injector 4 (9F593), Y111 – 4.6L	24–5
G402	56–1	Injector 5 (9F593), Y112 – 3.8L	23–4
G403	10–9	Injector 5 (9F593), Y112 – 4.6L	24–4
Generator, O5	12–1	Injector 6 (9F593), Y113 – 3.8L	23–4
Generic Electronic Module (GEM) (14B205), A112	59–1	Injector 6 (9F593), Y113 – 4.6L	24–4
Headlamp, left (13008), E1	85–1	Injector 7 (9F593), Y207 – 4.6L	24–4
Headlamp, right (13008), E7	85–1	Injector 8 (9F593), Y209 – 4.6L	24–4
Heated Oxygen Sensor (HO2S) #11 (9G444), B48 – 3.8L	23–6	Inlet Manifold Runner Control (IMRC) module, A149 – 3.8L	23–5
Heated Oxygen Sensor (HO2S) #11 (9G444), B48 – 4.6L	24–9	Instrument cluster, A30	60–2
Heated Oxygen Sensor (HO2S) #12 (9F472), B88 – 3.8L	23–6	Interior/map lamps assembly, front, E238 – coupe	89–3
Heated Oxygen Sensor (HO2S) #12 (9F472), B88 – 4.6L	24–9	Key warning switch (11A127), N65	66–1
Heated Oxygen Sensor (HO2S) #21 (9G444), B47 – 3.8L	23–6	License plate lamp, left, E34	92–1
Heated Oxygen Sensor (HO2S) #21 (9G444), B47 – 4.6L	24–9	License plate lamp, right, E35	92–1
Heated Oxygen Sensor (HO2S) #22 (9F472), B87 – 3.8L	23–6	Low pitch horn, H2	44–2

Low speed fan control relay, K309 – 3.8L	23–11	Passenger air bag module (15044A74), A43	46–2
Low speed fan control relay, K309 – 4.6L	24–11	Passive anti-theft transceiver module (15607), A102	112–1
Luggage compartment lamp (13A756), E57	89–5	PCM power relay, K163	21–3
Luggage compartment lid release relay, K330	113–1	Power point (19N236), N251	44–1
Luggage compartment lid release solenoid (5443252), Y212	113–1	Powertrain Control Module (PCM) (12A650), A147 – 3.8L	23–3
Luggage compartment lid release switch, N434	113–1	Powertrain Control Module (PCM) (12A650), A147 – 4.6L	24–3
Lumbar adjust switch, left front (14B691), N445	122–1	Power window motor, left front, M243 – Convertible	100–2
Main light switch (11654), N113	13–13	Power window motor, left front, M243 – coupe	100–4
Map reading lamps, E208 – Convertible	89–4	Power window motor, left rear (23394), M116	100–3
Mass Air Flow (MAF) sensor (12B579), B22 – 3.8L	23–3	Power window motor, right front, M244 – Convertible	100–2
Mass Air Flow (MAF) sensor (12B579), B22 – 4.6L	24–3	Power window motor, right front, M244 – coupe	100–5
Master window/door lock/unlock switch, N416 – Convertible	100–2	Power window motor, right rear (23394), M117	100–3
Master window/door lock/unlock switch, N416 – coupe	100–4	Radio (18806), A11 – Mach 1000	130–5
Master window/door lock/unlock switch, N416	110–1	Radio (18806), A11 – Mach 460	130–3
Master window/door lock/unlock switch, N416	111–2	Radio (18806), A11 – premium radio	130–2
Multifunction switch, N442	81–2	Rear window defrost grid (18C618), R19	56–1
Multifunction switch, N442	85–1	Rear window defrost relay, K1	56–1
Multifunction switch, N442	90–2	Rear window defrost switch (18578), N10	56–1
Oil pressure switch (9278), N17	60–2	Relay box, P98	113–1
Output Shaft Speed (OSS) sensor (7M101), B110 – 3.8L	23–9	Relay box, P98	44–2
Output Shaft Speed (OSS) sensor (7M101), B110 – 4.6L	24–7	Relay box, P98	81–1
Package tray assembly, rear, Y264 – Mach 460, Mach 1000	130–8	Relay box, P98	92–1
Park/stop/turn lamp 1, left rear, E273	90–4	Restraints control module (14B321), A208	46–1
Park/stop/turn lamp 1, left rear, E273	92–2	Reversing lamp, left (13411), E105	93–1
Park/stop/turn lamp 1, right rear, E275	90–4	Reversing lamp, right (13411), E109	93–1
Park/stop/turn lamp 1, right rear, E275	92–2	Reversing lamps switch, N19	93–1
Park/stop/turn lamp 2, left rear, E274	90–4	S100	10–3
Park/stop/turn lamp 2, left rear, E274	92–2	S101	10–7
Park/stop/turn lamp 2, right rear, E276	90–4	S102	13–1
Park/stop/turn lamp 2, right rear, E276	92–2	S103	10–1
Park/turn lamp, left front (13411), E164	90–3	S104	10–3
Park/turn lamp, left front (13411), E164	92–1	S105	13–3
Park/turn lamp, right front (13411), E166	90–3	S106	10–3
Park/turn lamp, right front (13411), E166	92–1	S107	13–3
Parking brake switch (15A851), N63	59–3	S108	13–2
Park lamp relay, K52	92–1	S109	13–2

## 2-5 Index

---

S110	10-1	S174	13-12
S111	13-4	S180	10-3
S112	31-2	S200 - 3.8L	23-7
S113	13-10	S200 - 4.6L	24-6
S115	10-2	S201	10-5
S117 - 3.8L	23-9	S202	13-4
S117 - 4.6L	24-7	S203	10-5
S120 - 3.8L	23-6	S204	10-4
S120 - 4.6L	24-9	S205	10-5
S121 - 3.8L	23-9	S206	10-5
S121 - 4.6L	24-7	S207	13-9
S122 - 3.8L	33-1	S208	10-5
S122 - 4.6L	33-2	S211	13-5
S123 - 3.8L	23-4	S213	54-2
S123 - 4.6L	24-4	S215	13-2
S126 - 3.8L	23-9	S217	13-2
S126 - 4.6L	24-7	S225	13-10
S127	13-1	S230	71-1
S128 - 3.8L	23-5	S231	13-14
S128 - 4.6L	24-5	S233	13-2
S129 - 3.8L	23-7	S234 - 3.8L	23-3
S129 - 4.6L	24-6	S234 - 4.6L	24-3
S130 - 3.8L	23-7	S239	13-15
S130 - 4.6L	24-6	S242	13-7
S133	85-1	S243	13-12
S134	14-2	S245	13-11
S135	14-2	S246	59-3
S140	33-2	S247	90-3
S143	10-4	S248	90-3
S158	24-4	S249	44-2
S164 - 3.8L	23-9	S250 - 3.8L	21-4
S164 - 4.6L	24-7	S252	14-2
S168	10-4	S253	14-2
S169	21-3	S255	14-1
S170 - 4.6L	21-5	S256	13-11
S171 - 4.6L	21-5	S257	13-11

S258	13-9	S419	13-14
S259	13-8	S420	13-14
S260	13-7	S425	93-1
S262	13-12	S429	89-2
S263	85-1	S431	13-9
S264	13-5	S432	13-9
S265	13-10	S433	130-8
S266	13-12	S434	130-8
S267	13-6	S436 - Mach 1000, Convertible	130-7
S268	13-7	S436 - Mach 1000, coupe	130-6
S269	13-7	S436 - Mach 460	130-4
S270	13-8	S437 - Mach 1000, Convertible	130-7
S272	31-3	S437 - Mach 1000, coupe	130-6
S274	93-1	S437 - Mach 460	130-4
S275	31-3	S440	89-5
S276	59-2	S450	10-6
S277	56-1	S451	10-6
S278	13-1	S470	130-10
S280	81-1	S471	130-11
S281	85-1	S472	130-10
S282	113-1	S473	10-9
S283	10-5	S474	130-11
S284	13-11	S475	10-9
S307	10-7	S504	13-7
S312	13-10	S505	13-6
S321	10-7	S506	124-1
S322	10-7	S507	10-8
S323	90-2	S510 - Convertible	100-2
S404	10-9	S510 - coupe	100-4
S405	10-9	S515	10-8
S407	10-6	S901	10-7
S409	13-3	S902 - Convertible	89-4
S414	10-6	S902 - coupe	89-3
S415	10-6	Safety belt buckle switch (10B924), N317	66-1
S417	13-14	Seat adjust switch, driver side front (14A701), N216	120-1
S418	13-14	Side lamp, left rear (13411), E210	92-2

- Side lamp, right rear (13411), E211 ..... 92-2
- Speaker, left front (18808), Y28 – Mach 1000 ..... 130-5
- Speaker, left front (18808), Y28 – Mach 460 ..... 130-3
- Speaker, left front (18808), Y28 – premium radio ..... 130-2
- Speaker, left rear (18808), Y17 – Mach 1000 ..... 130-5
- Speaker, left rear (18808), Y17 – Mach 460 ..... 130-3
- Speaker, left rear (18808), Y17 – premium radio ..... 130-2
- Speaker, right front (18808), Y18 – Mach 1000 ..... 130-5
- Speaker, right front (18808), Y18 – Mach 460 ..... 130-3
- Speaker, right front (18808), Y18 – premium radio ..... 130-2
- Speaker, right rear (18808), Y19 – Mach 1000 ..... 130-5
- Speaker, right rear (18808), Y19 – Mach 460 ..... 130-3
- Speaker, right rear (18808), Y19 – premium radio ..... 130-2
- Speed control servo (9C735), M87 ..... 31-2
- Starter motor (11002), M8 ..... 20-1
- Starter relay (11450), K22 ..... 20-1
- Steering wheel/speed control switch (9F924), N78 ..... 31-4
- Subwoofer, left front, Y258 – Mach 1000, Convertible ..... 130-7
- Subwoofer, left front, Y258 – Mach 1000, coupe ..... 130-6
- Subwoofer, left front, Y258 – Mach 460 ..... 130-4
- Subwoofer, left rear, Y260 – Mach 460, Mach 1000 ..... 130-8
- Subwoofer, luggage compartment left, Y290 – Mach 1000 .... 130-11
- Subwoofer, luggage compartment right, Y291 – Mach 1000 ... 130-10
- Subwoofer, right front, Y259 – Mach 1000, Convertible ..... 130-7
- Subwoofer, right front, Y259 – Mach 1000, coupe ..... 130-6
- Subwoofer, right front, Y259 – Mach 460 ..... 130-4
- Subwoofer, right rear, Y261 – Mach 460, Mach 1000 ..... 130-8
- Subwoofer amplifier, front, Y262 – Mach 1000, Convertible .... 130-7
- Subwoofer amplifier, front, Y262 – Mach 1000, coupe ..... 130-6
- Subwoofer amplifier, front, Y262 – Mach 460 ..... 130-4
- Subwoofer amplifier, luggage compartment left inboard, A442 – Mach 1000 ..... 130-11
- Subwoofer amplifier, luggage compartment left inboard, A442 – Mach 1000 ..... 130-9
- Subwoofer amplifier, luggage compartment left outboard, A441 – Mach 1000 ..... 130-11
- Subwoofer amplifier, luggage compartment left outboard, A441 – Mach 1000 ..... 130-9
- Subwoofer amplifier, luggage compartment right inboard, A443 – Mach 1000 ..... 130-10
- Subwoofer amplifier, luggage compartment right inboard, A443 – Mach 1000 ..... 130-9
- Subwoofer amplifier, luggage compartment right outboard, A444 – Mach 1000 ..... 130-10
- Subwoofer amplifier, luggage compartment right outboard, A444 – Mach 1000 ..... 130-9
- Subwoofer amplifier, rear, Y263 – Mach 1000, Convertible .... 130-7
- Subwoofer amplifier, rear, Y263 – Mach 1000, coupe ..... 130-6
- Subwoofer amplifier, rear, Y263 – Mach 460 ..... 130-4
- Throttle Position Sensor (TPS) (9B989), B8 – 3.8L ..... 23-7
- Throttle Position Sensor (TPS) (9B989), B8 – 4.6L ..... 24-6
- Traction control switch (2C418), N452 ..... 42-2
- Transmission control switch, N405 ..... 29-3
- Transmission hardware unit, A40 ..... 29-3
- Vanity mirror lamp, left (04100), E30 – Convertible ..... 89-4
- Vanity mirror lamp, left (04100), E30 – coupe ..... 89-3
- Vanity mirror lamp, right (04100), E31 – Convertible ..... 89-4
- Vanity mirror lamp, right (04100), E31 – coupe ..... 89-3
- Washer pump relay, front, K139 ..... 81-1
- Wheel speed sensor, left front (2C205), B15 ..... 42-3
- Wheel speed sensor, left rear, B17 ..... 42-3
- Wheel speed sensor, right front (2C204), B14 ..... 42-3
- Wheel speed sensor, right rear, B16 ..... 42-3
- Windshield washer pump motor (17618), M112 ..... 81-1
- Windshield wiper motor (17508), M111 ..... 81-1
- Wiper high/low relay, K316 ..... 81-1
- Wiper run/park relay, K140 ..... 81-1

### Note


All wiring connections between components are shown exactly as they exist in the vehicles. It is important to realize, however, that no attempt has been made on the schematic to represent components and wiring as they physically appear on the vehicle. For example, a 4-foot length of wire is treated no differently in a schematic from one which is only a few inches long. Furthermore, to aid in understanding electrical (electronic) operation, wiring inside complicated components has been simplified.

### Complete Circuit Operation

Each circuit is shown completely and independently in one cell. Other components which are connected to the circuit may not be shown unless they influence the circuit operation.

### System Overview

Each major vehicle system includes a complete system overview prior to each set of schematic pages. It is important to realize that this is only a high level overview of the complete system connectivity. It includes component operational information (1), component name and base part number (2), and basic component internals (3). It does not include specific circuit information, connector or pin numbers, splices or grounds. That information is found on the schematic pages.



**Current Flow (1)**

Each cell normally starts with the component that powers the circuit such as a fuse or the ignition switch. Current flow is shown from the power source at the top of the page to ground at the bottom of the page. In order to concentrate on the essential parts, power supply and ground connections are sometimes simplified by a dashed line in the schematics. A full representation of the power supply of a fuse or the power distribution from a fuse to various components is given in cell 13 "Power Distribution". Full representation of the ground connections are shown in cell 10 "Grounds".

**Switch Positions (2)**

Within the schematic, all switches, sensors and relays are shown "at rest" (as if the Ignition Switch were OFF).

**Splices (3)**

A dashed line indicates that the splice is not shown completely. A reference is given to the page where the splice appears in full. It is also listed in the Index.

**Component Referencing (4)**


Each component on a schematic has a reference to the component location view for that component. It is located to the right of each component.

**Component Names, Notes and Base Part Numbers (5)**

Component names are placed on the right hand side of each component. Any notes that describe switch positions or operating conditions follow the name. Descriptions of the internals of the component are also included here. The page where the component appears in full is listed in the Index. The base part number for a component is listed in parentheses next to or under a component. These part numbers will appear any place the component name appears in the publication.


**Component Identification Numbers (6)**

Each component on each schematic has a component identification number located to the upper right hand side of the component. By finding this number in the Component Location Chart, the Component Location View for that component can easily be found.




### Fuse and Relay Information

Cell 11 "Fuse and Relay Information" contains a view of the fuse-/relay box in which all fuses and relays are identified.




### Power Distribution

Cell 13 "Power Distribution" shows the current feed circuit. The current path is shown from the battery to the ignition switch and to all fuses. It also shows the circuits protected by each fuse. The circuit is traced from the fuse to the component. All details (wires, splices, connectors) between the fuse and the first component are shown.



**Ground Distribution**

Cell 10 “Grounds” contains the schematics that show the complete details for each ground connection or main ground splice. This is useful in diagnosing a problem affecting several components at once (poor ground connection or ground splice). All details (wires, splices, connectors) between the ground point and the components are shown. These ground connection details are shown here in order to keep the individual cell schematics as uncluttered as possible.



**Component and Connector Information**

Cell 152 “Component Location Charts” helps the user find where the various items depicted on the schematic can physically be found on the vehicle. A brief written description of the location is given, along with a reference to the component location views.

Cell 151 “Component Location Views” show the components and their connecting wires as they can be found on the vehicle.

Cell 150 “Connector Views” show the views of the pins and/or cavities of all connectors. The pin and cavity sides are shown separately as if the connector were disconnected. The color of the connector housing is indicated next to the connector number when available. The harness causal number is located above the connector view and below the connector number. The circuit function charts are located below each connector. The wiring harness designations are listed in cell 152 “Component Location Charts”.

**C150**  
**12A581**  
 B15  
 Wheel speed sensor, left front (2C205)


F02085

Pin	Circuit	Circuit Function
1	522 (TN/BK)	Wheel speed sensor, left front (2C205) –
2	521 (TN/OG)	Wheel speed sensor, left front (2C205) +


**WARNINGS**

- *Always wear safety glasses for eye protection.*
- *Use safety stands whenever a procedure requires being under a vehicle.*
- *Be sure that the **Ignition Switch** is always in the OFF position, unless otherwise required by the procedure.*
- *Set the parking brake when working on any vehicle. An automatic transmission should be in PARK. A manual transmission should be in NEUTRAL.*
- *Operate the engine only in a well-ventilated area to avoid danger of carbon monoxide.*
- *Keep away from moving parts, especially the fan and belts, when the engine is running.*
- *To prevent serious burns, avoid contact with hot metal parts such as the radiator, exhaust manifold, tail pipe, catalytic converter and muffler.*
- *Do not allow flame or sparks near the battery. Gases are always present in and around the battery cell. An explosion could occur.*
- *Do not smoke when working on a vehicle.*
- *To avoid injury, always remove rings, watches, loose hanging jewelry and avoid wearing loose clothing.*

# 4-1 Symbols



Distributed splice



Crossed wiring without connection



Splice



Removable connection



Ground



Connector



Female connector



Male connector



Entire component




Part of a component




Component case directly attached to metal part of vehicle (ground)



Component with screw terminals



Connector attached to component



Connector attached to component lead (pigtail)




Resistor or heating element



Potentiometer (pressure or temperature)



Potentiometer (outside influence)



Battery



Fuse



Circuit breaker



Heating element, Conductor loop



Ignition coil assembly



Buzzer



Antenna



Solenoid controlled valve  
or clutch solenoid



Air bag sliding contact  
(14A664)



Permanent magnet,  
one-speed-motor



Light emitting diode  
(LED)



Diode, current flows in  
direction of arrow



Permanent magnet,  
two-speed-motor



Capacitor



Transistor



Rotational sensor



Variable capacitor



Lamp



Shield



Piezoelectric sensor



Bifilament lamp




Signal horn or speaker



Coil




Gauges



Fusible link

## 4-3 Symbols



Wire colors	
<b>BK</b>	Black
<b>BN</b>	Brown
<b>BU</b>	Blue
<b>DB</b>	Dark blue
<b>DG</b>	Dark green
<b>GN</b>	Green
<b>GY</b>	Gray
<b>LB</b>	Light blue
<b>LG</b>	Light-green
<b>NA</b>	Natural
<b>OG</b>	Orange
<b>PK</b>	Pink
<b>RD</b>	Red
<b>SR</b>	Silver
<b>TN</b>	Tan
<b>VT</b>	Violet
<b>WH</b>	White
<b>YE</b>	Yellow



Power ground



signal



Signal return



Switched ground



Reference voltage



Left-hand-drive vehicles

VBATT Battery voltage

VPWR Switched or module voltage

SCP + Standard Corporate Protocol (SCP) data +

SCP - Standard Corporate Protocol (SCP) data -

ISO Data bus ISO 9141 (K-line)

PWR Switched power


Country code



Canada



A thick dashed line represents 2 or more wires

A thin dashed line represents a continuation




Two connections (pins) in the same connector






Dashed line indicates terminals for the same connector




Circuit references a wire which connects to another circuit








Circuit number



A choice bracket shows wiring differences between models, countries or options




# 4-5 Symbols



### Troubleshooting wiring harness and connector hidden concerns

The following illustrations are known examples of wiring harness, splices and connectors that will create intermittent electrical concerns. The concerns are hidden and can only be discovered by a physical evaluation as shown in each illustration.


NOTE: Several components, such as the PCM, utilize gold plated terminals in their connections to the wiring harness. If those terminals need to be replaced, they must be replaced with a gold plated terminal.



### Terminal not properly seated


- 1 = Locked terminal
- 2 = Male half
- 3 = Female half
- 4 = Seal
- 5 = Intermittent contact
- 6 = Unlocked terminal (Hidden by wire seal)
- 7 = Seal

Check for unlocked terminals by pulling each wire at the end of the connector.



**Defective insulation stripping**


- 1 = Proper crimp
- 2 = Insulation not removed
- 3 = Wire strands missing
- 4 = Intermittent signals through pierced insulation



**Partially mated connectors**

- 1 = Seal
- 2 = Displaced tab
- 3 = Female half
- 4 = Seal
- 5 = Intermittent contact
- 6 = Male half
- 7 = Intermittent contact


Lock may be displaced into an unlocked position; pull on the connector to verify the lock.



**Deformed (enlarged) female terminals**


- 1 = Enlarged
- 2 = Normal

Any probe entering the terminal may enlarge the contact spring opening creating an intermittent signal. Insert the correct mating terminal (Location A) from the service kit and feel for a loose fit.



**Electrical short inside the harness**


- 1 = Solder coated wire to ground
- 2 = Harness protective tape
- 3 = Intermittent short  
Solder coated wire pierced through the insulation of another circuit
- 4 = Grounding foil



**Electrical short within the harness**


Splice tape removed

- 1 = Intermittent short



Splice covered

- 1 = Wire strand
- 2 = Splice tape
- 3 = Harness tape




**Broken wire strands in harness**

- 1 = Wiring harness tape
- 2 = Wiring strand
- 3 = Broken strands intermittent signal
- 4 = Circuit insulation


Remove the tape and flex/feel each circuit for a reduction in diameter at break.

## 5-5 Connector Repair Procedures


### Recommended splicing method




1. Disconnect battery ground cable.
2. Strip wires to appropriate length.




3. Install heat shrink tubing.
4. Twist wires together.
5. Solder wires together.  
**NOTE:** Use rosin core mildly-activated (RMA) solder. Do not use acid core solder.



6. Bend Wire 1 back in a straight line.  
**NOTE:** Wait for solder to cool before moving wires.




7. Evenly position heat shrink tubing over wire repair.  
**NOTE:** Overlap tubing on both wires.




8. Use heat gun to heat the repaired area until adhesive flows out of both ends of heat shrink tubing.
9. Reconnect battery ground cable.

## 8-1 Systems Overview



# 9-1 Wiring Harness Overview

NOTES




## Two-door model

Item	Part Number	Description
1	A7	ABS control module (2C219)
2	P92	Auxiliary fuse box
3	P93	Battery Junction Box (BJB) (14A003)
4	P91	Central Junction Box (CJB) (14A068)
5	A426	Constant Control Relay Module (CCRM)
6	A253	Daytime Running Lamps (DRL) module
7	A17	Electronic flasher module
8	A195	Fuel pump driver module (9H307)
9	A112	Generic Electronic Module (GEM) (14B205)
10	A149	Inlet Manifold Runner Control (IMRC) module
11	A102	Passive anti-theft transceiver module (15607)
12	A147	Powertrain Control Module (PCM) (12A650)
13	P98	Relay box
14	A208	Restraints control module (14B321)
15	7C078	Wiring harness – Transmission control selector neutral switch (automatic transmission)
	15525	Wiring harness – Reversing lamps switch, to, Rear, lamp feed (manual transmission)
16	9D930	Wiring harness – Fuel charge (3.8L)
	12B637	Wiring harness – Engine control sensor and fuel charge (4.6L)
17	12638	Wiring harness – Starter relay circuit
18	12A581	Wiring harness – Engine control sensor
19	12B559	Engine, to knock sensor
20	12B566	Wiring harness – Engine electronic control air sensor
21	13407	Wiring harness – Rear lamp, Right
22	13410	Wiring harness – Rear lamp, Left
23	13A625	Wiring harness – High mounted stoplamp
24	13B319	Wiring harness – Turn signal switch
25	14290	Wiring harness – Dash panel to headlamp junction
26	14305	Wiring harness – Alternator rectifier system (3.8L)
	14B060	Wiring harness – Starter motor relay and battery ground (4.6L)
27	14334	Wiring harness – Interior lamps (coupe)
	14335	Wiring harness – Interior illumination (Convertible)


Item	Part Number	Description
28	14401	Main wiring harness
29	14630	Wiring harness – Window regulator, right front door
30	14631	Wiring harness – Window regulator, left front door
31	14A005	Wiring harness – Body Main
32	14A546	Wiring harness – Safety belt switch, Extension (without power seats)
	14C719	Wiring harness – Seat control feed jumper (with power seats)
33	14A699	Wiring harness – Power seats (without lumbar)
	14B084	Wiring harness – Lumbar adjust switch, driver side (with lumbar)
34	14B079	Wiring harness – Console Panel
35	14K095	Wiring harness – Fan motor
36	18C619	Wiring harness – Rear window heater
37	18C620	Wiring harness – Rear window heater ground
38	18C629	Wiring harness – Blower motor
39	19B113	Wiring harness – Radio amplifier
40	19B516	Wiring harness – Rear license plate lamp
41	–	Battery

# 10-1 Grounds

## G102




G104, G105




# 10-3 Grounds


## G101, G103



G201




G203, G204



See page  
G204 151-15

G400



**Buy Now**

