

Discover more ebooks! Visit our website: [fordshopmanual.com](http://fordshopmanual.com)

1986 MUSTANG/CAPRI

#### DEMO

This DEMO contains only a few pages of the entire manual/product.

Not all Bookmarks work on the Demo, but they do on the full version.


#### Features:

- Searchable text
- Printable pages
- Bookmarked for easy navigation
- High Resolution images
- Zoom to see exact details
- Money back Guarantee
- Transfer to USB flash drive support


# 1986 MUSTANG/ CAPRI




**Buy Now**



License #84356800



## Electrical & Vacuum Trouble- Shooting Manual



Copyright © 2023, Forel Publishing Company, LLC, Woodbridge, Virginia

All Rights Reserved. No part of this book may be used or reproduced in any manner whatsoever without written permission of Forel Publishing Company, LLC. For information write to Forel Publishing Company, LLC, Woodbridge, VA 22192

**1986 Mustang / Capri Electrical & Vacuum Trouble-  
Shooting Manual (EVTM)  
EAN: 978-1-60371-397-9  
ISBN: 1-60371-397-2**

Forel Publishing Company, LLC  
Woodbridge, VA 22192



This publication contains material that is reproduced and distributed under a license from Ford Motor Company. No further reproduction or distribution of the Ford Motor Company material is allowed without the express written permission of Ford Motor Company.

---

## **Note from the Publisher**

This product was created from the original Ford Motor Company's publication. Every effort has been made to use the original scanned images, however, due to the condition of the material; some pages have been modified to remove imperfections.

---

## **Disclaimer**

Although every effort was made to ensure the accuracy of this book, no representations or warranties of any kind are made concerning the accuracy, completeness or suitability of the information, either expressed or implied. As a result, the information contained within this book should be used as general information only. The author and Forel Publishing Company, LLC shall have neither liability nor responsibility to any person or entity with respect to any loss or damage caused, or alleged to be caused, directly or indirectly by the information contained in this book. Further, the publisher and author are not engaged in rendering legal or other professional services. If legal, mechanical, electrical, or other expert assistance is required, the services of a competent professional should be sought.

---



How to Use This Manual	1
How to Find the Electrical Problem	2
Symbols (Electrical)	4
(Vacuum)	70
How to Find the Vacuum Problem	71
Component Testing	
Introduction	79
Light Switch	79
Ignition Switch	80
Multi-Function Switch	81
Interval Wiper/Washer Switch	83
A/C-Heater Function Control	84
A/C-Heater Blower Switch	85
Instrument Panel (Back View)	89
.....	.....
A/C-Heater	74
Brake Warning Indicator	46
Charge	10, 142
Choke Heater	10
Cigar Lighter	52
Clock	52
Compressor Clutch Control	91, 95, 141
Convertible Top	125
Coolant Temperature Gage	48
Cooling Fan Control	91
Electronic Engine Control (EEC)	103
Electronic Radio (Premium Sound)	127
Fuel Filler Door Release	23
Fuel Gage	48
Fuse Block	9
Gages	48
Graphic Warning Module	50
Grounds	142, 138, 6, 26, 19
Heater	78
Horn	52
Ignition	98
Instrument Cluster Connectors	44, 48
Instrument Illumination	44
Key Warning	42
Liftgate Release	59
Light Out Warning	50, 58

Lights	
Backup	41
Brake Indicator	46
Clock	44
Courtesy	42
Dome/Map	43
Exterior	34
Fog	134, 139
Glove Box	42
Hazard	38
Headlights	32
Instrument Illumination	44
License	36
Map	43
Marker	34, 36
Park	34
Radio Illumination	44
Rear Park (Tail)	36
Stop	38, 40, 144
Turn	38, 40
Light Switch	12
Low Fuel Warning	48
Power Distribution	10, 138
Power Door Locks	60
Power Windows	62
Printed Circuit Board Connector (RH)	44
(LH)	48
Radio (Mono)	64
(Stereo/Tape)	65
(Premium Sound)	66
Rear Window Defrost	24
Seatbelt Warning	46
Speed Control	72
Start	98
Tachometer	14
Trunk Release	59
Turbo Indicators	118
Upshift Indicator	30
Vacuum Distribution	69, 120
Warning Indicators	46
Wiper/Washer (Interval)	56

### IMPORTANT SAFETY NOTICE

*Appropriate service methods and proper repair procedures are essential for the safe, reliable operation of all motor vehicles, as well as the personal safety of the individual doing the work. This Manual provides general directions for accomplishing service and repair work with tested, effective techniques. Following them will help assure reliability.*

*There are numerous variations in procedures, techniques, tools, and parts for servicing vehicles, as well as in the skill of the individual doing the work. This Manual cannot possibly anticipate all such variations and provide advice or cautions as to each. Accordingly, anyone who departs from the instructions provided in this Manual must first establish that he compromises neither his personal safety nor the vehicle integrity by his choice of methods, tools or parts.*

*The dotted and hashed secondary colors on wires are being phased out of production. References to dotted or hashed wires may or may not be on the actual wire. The dot or hash may be replaced by a stripe, but the colors will remain the same.*



The purpose of this manual is to show electrical and vacuum circuits of these vehicles in a clear and simple fashion to make troubleshooting easier. With each circuit is a description of *How the Circuit Works* and some *Troubleshooting Hints*. A *Component Location* chart lists components, connectors, and references to pictures in the manual.

**Wiring Diagrams** give a schematic picture of when and how the circuit is powered, what the current path is to circuit components, and how the circuit is grounded. Each circuit component is named (underlined titles). Wire and connector colors are listed (standard Ford color abbreviations are used):

#### COLOR ABBREVIATIONS

BL	Blue	N	Natural
BK	Black	O	Orange
BR	Brown	PK	Pink
DB	Dark Blue	P	Purple
DG	Dark Green	R	Red
GR	Green	T	Tan
GY	Gray	W	White
LB	Light Blue	Y	Yellow
LG	Light Green		

Where two colors are shown for a wire, the first color is the basic color of the wire. The second color is the dot, hash, or stripe marking. If D or H is given, the second color is dots or hash marks. If there is no letter after the second color, the wire has a stripe.

For example:

BR/O is a brown wire with an orange stripe.  
R/Y D is a red wire with yellow dots.  
BK/W H is a black wire with white hash marks.

**Connector end views** of switches and other components are shown to help with bench testing. The views show the harness wire colors that connect to the mating terminals. Connector colors and locations are shown in the *Component Location* chart. Two-color listings indicate separate colors for each connector half.

**Components** which work together are shown together. For example, all electrical components used in any circuit are shown on one diagram. The circuit breaker or fuse is shown at the top of the page. All wires, connectors, splices, switches, and motors are shown in the flow of current to ground at the bottom of the page. Notes are included which describe how switches and other components work. If a component is used in several different circuits, it is shown in several different schematics. For example, the **Light Switch** is an electrical part of many circuits and is repeated on many pages. In some cases, however, a component may seem by its name to belong on a page where it has no electrical connection. For example, **Radio Illumination** is electrically part of **Instrument Illumination**. Since it has no electrical connection at all with the actual **Radio** circuit, it is not shown on the **Radio** page.

*Troubleshooting Hints* point the technician in a general direction, but are not intended as a step-by-step procedure. Ignition troubleshooting is an exception to this. It includes a step-by-step procedure of basic quick checks to locate some of the more common **Ignition System** problems. Read the Shop Manual for more detailed repair procedures.

The **Grounds** pages show detailed views of multiple component ground points. This is useful for checking interconnections among the ground circuits of different diagrams.

**Notes, Cautions, and Warnings** appear in boxes on text pages and contain important car and mechanic safety information.

Notes give added information to help complete a particular procedure. Cautions are included to prevent making an error that could damage the vehicle. Warnings highlight areas where carelessness can cause personal injury. The following list contains some general **Warnings** that should be followed when working on a vehicle.

- Always wear safety glasses for eye protection.
- Use safety stands whenever a procedure requires being under a vehicle.
- Be sure that the **Ignition Switch** is always in the OFF position, unless otherwise required by the procedure.
- Set the parking brake when working on any vehicle. An automatic transmission should be in PARK. A manual transmission should be in NEUTRAL.
- Operate the engine only in a well-ventilated area to avoid the danger of carbon monoxide.
- Keep away from moving parts when the engine is running, especially the fan and belts.
- To prevent serious burns, avoid contact with hot metal parts such as the radiator, exhaust manifold, tail pipe, catalytic converter, and muffler.
- Do not allow flame or sparks near the battery. Gases are always present in and around the battery cell. An explosion could occur.
- Do not smoke.
- To avoid injury, always remove rings, watches, loose hanging jewelry, and loose clothing.



## 2 HOW TO FIND THE ELECTRICAL PROBLEM

### TROUBLESHOOTING STEPS

These six steps present an orderly method of troubleshooting:

#### Step 1. Verify the problem.

- Operate the complete system and see all symptoms for yourself in order to:
  - check the accuracy and completeness of the customer's complaint.
  - learn more that might give a clue to the nature and location of the problem.

#### Step 2. Narrow the problem.

- Using the EVTM, narrow down the possible causes and locations of the problem in order to more quickly find the exact cause.
- Read the description of *How the Circuit Works* and study the wiring diagram. You should then know enough about the circuit operation to figure out where to check for this trouble.

#### Step 3. Test the cause.

- Use electrical test procedures to find the specific cause of the symptoms.
- *Troubleshooting Hints* will give some helpful ideas.
- The *Component Location* charts and the pictures will help you find components, grounds, and connectors.

#### Step 4. Verify the cause.

- Confirm the fact that you have found the correct cause through operating the parts of the circuit you think are good.

#### Step 5. Make the repair.

- Repair or replace the faulty component.

#### Step 6. Verify the repair.

- Operate the system as in Step 1 and check that your repair has removed all symptoms, and also has not caused any new symptoms.

Some engine circuits may need special test equipment and special procedures. See the *Shop Manual* and other service books for

details. You will find the circuits in this manual to be helpful with these special tests.

### TROUBLESHOOTING TOOLS

#### JUMPER WIRE

This is a test lead used to connect two points of a circuit. A **Jumper Wire** can complete a circuit by bypassing an open.

**Uses:** Bypassing Switches or Open Circuits

#### WARNING

*Never use a jumper wire across high resistance loads (motors, etc.) connected between hot and ground. This direct battery short may cause injury or fire.*

#### VOLTMETER

A DC **Voltmeter** measures circuit voltage. Connect negative (- or black) lead to ground, and positive (+ or red) lead to voltage measuring point.

#### OHMMETER




Figure 1— Resistance Check

An **Ohmmeter** shows the resistance between two connected points (Figure 1).

#### TEST LIGHT




Figure 2 —Test Light

A **Test Light** is a 12-volt bulb with two test leads (Figure 2).

**Uses:** Voltage Check. Short Check

#### SELF-POWERED TEST LIGHT




Figure 3—Continuity Check

The **Self-Powered Test Light** is a bulb, battery and set of test leads wired in series (Figure 3). When connected to two points of a continuous circuit, the bulb glows.

**Uses:** Continuity Check. Ground Check

#### CAUTION

*When using a self-powered test light or ohmmeter, be sure power is off in circuit during testing. Hot circuits can cause equipment damage and false readings.*



## TROUBLESHOOTING CHECKS

### SWITCH CIRCUIT CHECK




Figure 4—Switch Circuit Check and Voltage Check

In a bad circuit with a switch in series with the load, jumper the terminals of the switch to power the load. If jumping the terminals powers the circuit, the switch is bad (Figure 4).

### CONTINUITY CHECK (Locating open circuits)

Connect one lead of **Self-Powered Test Light** or **Ohmmeter** to each end of circuit (Figure 3). Light will glow if circuit is closed. Switches and fuses can be checked in the same way.

### VOLTAGE CHECK

Connect one lead of **Test Light** to a known good ground, or the negative (-) battery terminal. Test for voltage by touching the other lead to the test point. Bulb goes on when the test point has voltage (Figure 4).

### SHORT CHECK (short to ground)




Figure 5—Short Check

A fuse that repeatedly blows is usually caused by a short to ground. It's important to be able to locate such a short quickly (Figure 5).

- 1) Turn off everything powered through the fuse.
- 2) Disconnect other loads powered through the fuse:
  - Motors: disconnect motor connector.
  - Lights: remove bulbs.
- 3) Turn **Ignition Switch** to RUN (if necessary) to power fuse.
- 4) Connect one **Test Light** lead to hot end of blown fuse. Connect other lead to ground. Bulb should glow showing power to fuse. *(This step is just a check to be sure you have power to the circuit.)*
- 5) Disconnect the **Test Light** lead from ground and reconnect it to the load side of the fuse.
  - If the **Test Light** is off, the short is in the disconnected equipment.
  - If the **Test Light** goes on, the short is in the wiring. You must find the short by disconnecting the circuit connectors one at a time until the **Test Light** goes out. For example: with a ground at X, the bulb goes out when C1 or C2 is disconnected, but stays on after disconnecting C3. This

means the ground is between C2 and C3.

### "GOOD GROUND" CHECK




Figure 6 — Grounds Checks

Turn on power to circuit. Perform Voltage Check between suspected bad ground and frame. Any voltage means ground is bad.

Turn off power to circuit. Connect one lead of **Self-Powered Test Light** or **Ohmmeter** to wire in question, and the other to known ground. If bulb glows, circuit ground is OK (Figure 6).


## TROUBLESHOOTING HINTS

The circuit schematics in this manual are designed to make it easy to identify common points in circuits. This knowledge can help narrow the problem to a specific area. For example, if several circuits fail at the same time, check for a common power or ground connection. (See *Power Distribution* or *Grounds*). If part of a circuit fails, check the connections between the part that works and the part that doesn't work.


For example, if low beam headlights work, but high beams and the indicator light don't work, then power and ground paths must be good. Since the dimmer switch is the component which switches this power to the high beam lights and indicator, it is most likely the cause of failure.




# 4 ELECTRICAL SYMBOLS




**DASHED COMPONENT BOX**  
ONLY PART OF THE COMPONENT IS SHOWN, OR COMPONENT IS SHOWN IN TWO PLACES



**COMPONENT WITH CONNECTORS**




**FUSE**  
POSITION NUMBER  
CURRENT RATING



**CIRCUIT BREAKER**  
POSITION NUMBER  
CURRENT RATING




**SCREW TERMINAL ON COMPONENT**



**SOLID STATE**  
**SEALED ELECTRONIC COMPONENT**  
ANY CIRCUITRY SHOWN INSIDE THE BOX IS A FUNCTIONAL EQUIVALENT ONLY AND IS NOT EXACT



**GAGE**



**WIRE COLORS ARE LABELED FOR MATING HARNESS CONNECTOR**


**COMPONENT CONNECTOR END VIEW**  
SHOWS PINS OR SOCKETS ON A COMPONENT TO AID IN BENCH TESTING



**PIN TERMINAL TYPES**  
**SOCKET TYPES**




**IN-LINE CONNECTOR**  
C100  
PIN




**SPLICE OR CRIMP TERMINAL**  
S100



**GROUND CONNECTION**




**JUNCTION BLOCK**




**SOLID WIRE**  
**STRIPED WIRE**  
**DOTTED WIRE**  
**HASHED WIRE**

*The dotted and hashed secondary colors on wires are being phased out of production. References to dotted or hashed wires may or may not be on the actual wire. The dot or hash may be replaced by a stripe, but the colors will remain the same.*



**ALTERNATE CIRCUIT PATHS**




**RELAY**  
CONTACTS CLOSE WITH CURRENT THROUGH COIL


**DASHED LINE SHOWS MECHANICAL CONNECTIONS**




**DIODES**  
CURRENT FLOWS IN DIRECTION OF ARROW ONLY



**OPTIONAL WIRING**  
BR WIRES (INCLUDING C101) ARE ON ALL VEHICLES, BUT W WIRES (INCLUDING C101A) ARE USED ONLY WITH TRAILER



**"CUT" WIRES REFERENCED BETWEEN PAGES**  
ARROWS SHOW CURRENT FLOW FROM POWER TO GROUND



**"REFERENCE" WIRES**  
COMPLETE WIRING SHOWN ON ANOTHER PAGE

**CANDELABRA CONNECTOR**  
ACCEPTS SINGLE-PIN CONNECTORS

**SEE GROUNDS PAGE 6, 7**



**DASHED WIRE**  
CIRCUITRY IS NOT SHOWN IN COMPLETE DETAIL, BUT IS COMPLETE ON ANOTHER PAGE






Figure 1 - LH Cowl Area




Figure 2 - LH Engine Cowl (5.0L Engine)




Figure 3 - Under LH Side of I/P




Figure 4 - Behind RH Side of I/P





Figure 5 - Under LH Side Of I/P



## INSTRUMENT PANEL GROUND WITHOUT CONSOLE





The ground circuits shown here are complete, and connect several components together to screw terminal ground points. On other pages only parts of these circuits may be shown. Partial ground circuits are shown dashed on those pages.

All simple or component ground circuits are shown on the individual circuit pages, and are complete on those pages.

All wires are 57 BK unless otherwise noted.

## NOTE

See LH FRONT LIGHTS GROUND on pages 19 and 21.


See REAR LIGHTS GROUND on pages 26 and 27.

See INSTRUMENT PANEL GROUND on pages 142 and 143.


## COMPONENT LOCATION

		Page-Figure	Color	Terminals
Connector C106.....	Near both RH and LH side markers.....	33-1	BR	2
Connector C152.....	LH fender apron .....		BL	1
Connector C168.....	Near starter relay .....		BR	2
Connector C204.....	Behind RH side of I/P above glove box.....	78-1	GY	4
Connector C206.....	Attached behind graphic warning module....	51-1	GY	4
Connector C213.....	Under LH side of I/P .....	53-1	BK	6
Connector C233.....	Near transmission support brace .....	47-1	GY	2
Connector C241.....	Behind center of I/P above radio .....	78-1	BR	2
Connector C243.....	Attached to graphic warning module.....	51-1	GY	8
Connector C246.....	Behind LH side of I/P on instrument cluster...	89-1	GY	14
Connector C262.....	Attached to light switch.....		BR	3
Connector C279.....	Beneath steering column .....		GY	3
Connector C312.....	LH side of transmission hump .....	47-1	GY	2
Connector C350.....	Behind center of I/P .....		BK	8
Connector C351.....	At LH shake brace .....		BR	6
Connector C352.....	Behind center of I/P .....		BR	2
Connector C359.....	Under LH side of I/P on shake brace.....		GY	4
Connector C370.....	Behind LH side of glove box .....		GY	1
Ground G102.....	Top RH side of radiator support .....	33-1		
Ground G103.....	Top LH side of radiator support .....	33-1		
Ground G201.....	Behind LH side of glove box .....	45-1		
Ground G301.....	LH side of trunk lid striker.....	35-2		
Splice S302.....	In 14401, near T/O to radio .....			
Splice S303.....	In 14401, near T/O to horn switch .....			
Splice S404.....	In 14290, near T/O to LH front side marker lamp .....			
Splice S408.....	In 14290, near T/O to RH front side marker lamp .....			
Splice S505.....	In 14405, near T/O to inertia switch .....			


## RH FRONT LIGHTS GROUNDS (4 CYL 50 STATES AND CANADA)





REPLACEMENT OF FUSES/  
CIRCUIT BREAKERS



GOOD FUSE



BLOWN FUSE

Fuses are mounted either in the **Fuse Block** or in-line. They are identified by the numbered value in amperes, and by a color code. Some positions may have either a fuse with adapter or a circuit breaker. Be sure to replace a fuse or circuit breaker with the same kind of unit and with the same ampere rating. Remove fuses in order to check them.

## CIRCUIT BREAKER OPERATION


EXTERNAL  
SIDE VIEWINTERNAL  
SIDE VIEW

Cycling Fuse Block Type

Some circuits are protected by circuit breakers. (Abbreviated "c.b." in fuse chart.) They can be **Fuse Block** mounted or in-line. Like fuses, they are rated in amperes.

Each circuit breaker conducts current through an arm made of two types of metal fastened together (bimetal arm). If the arm starts to carry too much current, it heats up. As one metal expands faster than the other the arm bends, opening the contacts. Current flow is broken. In the cycling type, the arm cools and straightens out. This closes the circuit again. This cycle repeats as long as the overcurrent exists, with power applied.

In the non-cycling type, there is also a coil wrapped around the bimetal arm. When an overcurrent exists and the contacts open, a small current passes through the coil. This current through the coil is not large enough to operate a load, but it does heat up both the coil and bimetal arm. This keeps the arm in the open position until power is removed.




Non-Cycling Fuse Block Type



Cycling In-Line Type

## FUSE LINKS



The fuse link is a short length of wire smaller in gage than the wire in the protected circuit. The wire is covered with a thick non-flammable insulation. An overload causes the link to heat and the insulation to blister. If the overload remains, the link will melt, causing an open circuit. The links are color coded for wire size as follows:

## COLOR CODE

BLUE	20 GA
BROWN	18 GA
BLACK	16 GA
GREEN	14 GA


When replacing, make tight crimp joints or hot solder joints for good connections.

## DIODES



Diodes are electrical devices that permit current to flow in one direction only. The current flows in the direction indicated by the arrow.





Fuse Value Amps	Color Code
4	Pink
5	Tan
10	Red
15	Light Blue
20	Yellow
25	Natural
30	Light Green

## Power Distribution

The **Alternator** and **Battery** are connected together at the **Starter Relay** hot terminal. Other circuits originate at the **Starter Relay** hot terminal and are protected by fuse links. Low power circuits are also protected by fuses.

Fuse Position	Amps	Circuits Protected
1	15	Stop/Hazard Lights; Speed Control
2	6 c.b.	Interval Wiper
4	10	Exterior Lights; Instrument Illumination
5	15	Turn Lights; Backup Lights
6	20	A/C Clutch; Speed Control; Rear Window Defrost; Trunk Release; Digital Clock, Light Out Warning.
7	—	(Not Used)
8	15	Courtesy Lights; Clock; Key Warning; Fuel Filler Door Release
9	15 or 30	Heater Blower (15 amps); A/C Blower (30 amps)
10	20	Passing Beam
11	15	Radio, Premium Sound
12	20 c.b.	Power Door Locks
13	5	Instrument Illumination
14	20 c.b.	Power Windows
15	—	(Not used)
16	20	Horn; Cigar Lighter; Digital Clock
17	—	(Not Used)
18	15	Seatbelt Buzzer; Warning Indicators; Carburetor Circuits; Tachometer; Low Fuel Warning; Idle Tracking Air Control; Cooling Fan/Compressor Clutch Control.


The **Ignition Switch** and **Light Switch** are powered at all times, as are **Fuses 1, 4, 8, 10 and 16**. The other fuses are powered through the **Ignition Switch** or the **Light Switch**

Position 3 is not used, and is covered by **Circuit Breaker 2**.


















**Figure 1 - RH Front Fender**



## 2.3L N.A./3.8L (ALL)/5.0L (ALL)

## CHARGE

## HOW THE CIRCUIT WORKS

The **Battery**, **Alternator**, and **Voltage Regulator** make up the **Charging System**.

With the **Ignition Switch** in **RUN**, **Battery** current flows through the solid-state **Electronic Control** of the **Voltage Regulator**. The **Electronic Control** operates the solid-state field switch which applies **Battery** voltage to the **Alternator** field.

With current in the field and the rotor turning, the **Alternator** produces a **DC voltage** at terminal **B (to Battery)**. If the **Alternator Output Voltage** is greater than the **Battery** voltage, current will flow from the **Alternator** to the **Battery** as well as to the **Vehicle Electrical Load**. The **Ammeter** needle points toward "**Charge**." If the **Battery** is fully charged the **Ammeter** will deflect very little. If the **Alternator** voltage is less than **Battery** voltage, current will flow from the **Battery** to help supply the vehicle load.




Figure 1 - RH Fender

## COMPONENT LOCATION

	Page-Figure	Color	Terminals
Alternator (4 cyl) .....			
(6 and 8 cyl) .....			
Ammeter .....			
Choke Heater .....			
Fuse Links A, B, C, D, H, K, Q, W, Z .....			
Fuse Link J .....			
Fuse Links L, N .....			
Starter Relay .....			
Voltage Regulator .....			
Connector C104 .....			
Connector C118 .....			
Connector C147 .....			
Connector C201 .....			
Connector C210 .....			
Connector C214 .....			
Connector C247 .....			
Connector C258 .....			
Connector C370 .....			
Ground G101 (Non-Turbo) .....			
Ground G101 (2.3L EFI Turbo) .....			
Ground G201 .....			
Splice S105 .....			
Splice S106 .....			
Splice S117 .....			
Splice S202 .....			
Splice S204 .....			
Splice S205 .....			
Splice S302 .....			
Splice S303 .....			
LH front of engine assembly			
RH front of engine assembly			
Part of instrument cluster			
Attached to carburetor	25-1		
Near starter relay assembly	12-1		
At starter relay	61-1		
Near LH shock tower	25-2		
RH fender apron in front of wheel well (except turbo)	12-1		
RH fender apron attached below starter relay			
Near starter relay		BR	2
LH fender apron below starter relay	12-1	GY	1
Lower LH frame near shock tower		BK	3
Under LH side of I/P on shake brace	22-2	GY	8
Under LH side of I/P on shake brace	22-2	GY	12
Clipped to LH I/P support brace	45-3	GY	4
Behind LH side of I/P on instrument cluster	89-1	GY	14
Behind LH side of I/P attached to light switch	45-2	GY	7
In 14401, near T/O to cigar lighter		GY	1
Lower LH front of engine assembly	13-1		
Lower RH front of engine assembly	124-1		
Behind LH side of glove box	45-1		
In 14401, near T/O to windshield wiper switch			
In 14290, near T/O to starter motor relay			
In 14401 near fuse panel			
In 14290, near T/O to alternator regulator			
In 14401, near T/O to LH I/P speaker			
In 14290, near T/O to windshield wiper motor			
In 14401, near T/O to radio			
In 14401, near T/O to horn switch			

## TROUBLESHOOTING HINTS


## IMPROPER CHARGING

The most common charge system complaints are dead **Battery**, and **Ammeter** discharging at normal speed.

- Check **Fuse Link A** at **Starter Relay**.
- Check **Alternator** belt tension.
- Check **Battery** terminals and cable clamps.
- Check for clean and tight connections on **Alternator**, **Regulator**, and **Starter Relay**.

Read "Charging System Diagnosis" in Section 31-01 of Shop Manual for detailed **Charging System** tests.







REFER TO PAGES 98-101 FOR SCHEMATICS

## START

### HOW THE CIRCUIT WORKS

The **Battery**, **Starter Motor**, **Starter Relay**, and **Ignition Switch** make up the **Starting System**. In vehicles with automatic transmission, the **Backup Neutral Safety Switch** must be closed (PARK or NEUTRAL) in order to operate the **Starter Motor**.

Turning the **Ignition Switch** to START sends current through the **Starter Relay** coil and operates the relay. Current from the **Battery** then flows directly through the **Starter Relay** to the **Starter Motor** to start the engine.

When the **Ignition Switch** is in START, Battery voltage is applied to the START (white) wire of the **Ignition Module** through circuit 32. Full voltage is applied to the BATT terminal of the **Ignition Coil**. After the engine has started, **Ignition Coil** voltage is reduced through the 1.1 Ohm Resistance Wire.

### TROUBLESHOOTING HINTS

#### CHECK BATTERY AND CABLES

- Check condition of **Battery**. Recharge or replace if necessary. Read part 31-02 of Shop Manual.
- Check **Battery** posts and cable lugs.
- Check cable terminals at **Starter Relay**, engine ground, and **Starter Motor** and clean if necessary. Make sure cable wire strands are securely attached in terminals. Cables are tight when eyelet can't be easily turned by hand.

#### IF STARTER CRANKS SLOWLY

- Check **Battery** and cables (see above).
- If still slow, repair or replace **Starter Motor**.

### COMPONENT LOCATION

		Page-Figure	Color	Terminals
Clutch Safety Switch .....	Above clutch pedal			
Distributor (8 cyl) .....	Top front of engine			
Fuse Link C .....	At starter relay assembly .....	12-1		
Ignition Coil (4 & 8 cyl) .....	LH fender apron .....	25-2		
(6 cyl) .....	Lower LH side of engine			
Ignition Module .....	LH fender apron .....	25-2		
Ignition Switch .....	Lower RH side of steering column .....	53-1		
Backup/Neutral Safety Switch...	Part of transmission assembly .....	22-4		
Starter Motor .....	Lower RH rear of engine .....	13-1		
Starter Relay .....	RH fender apron in front of wheel well .....	12-1		
Connector C107 .....	Attached to LH side of transmission support	22-4	BR	4
Connector C111 .....	LH fender apron .....	25-2	BK	4
Connector C112 .....	LH fender apron .....	25-2	BK	3
Connector C113 .....	Near distributor .....		BK	3
Connector C135 (8 cyl) .....	Center of dash panel .....		GY	8
(4 cyl) .....	LH fender apron .....	25-2	GY	8
Connector C163 .....	Rear face of RH shock tower .....		BK	4
Connector C201 .....	Under LH side of I/P on shake brace .....	22-2	GY	8
Connector C210 .....	Under LH side of I/P on shake brace .....	22-2	GY	12
Connector C246 .....	Behind LH side of I/P on instrument cluster ...	89-1	GY	14
Connector C350 .....	Behind center of I/P .....		BK	8
Ground G101 .....	Lower LH front of engine assembly .....	13-1		
Ground G116 .....	Inside RH fender behind battery .....	13-1		
Ground G201 .....	Behind LH side of glove box .....	45-1		
Splice S105 .....	In 14401, near T/O to windshield wiper switch			
Splice S203 .....	In 14401, near T/O to horn switch			
Splice S204 .....	In 14401, near T/O to LH I/P speaker			
Splice S205 .....	In 14290, near T/O to windshield wiper motor			
Splice S206 .....	In 14290, near T/O to A/C cycling pressure switch			
Splice S302 .....	In 14401, near T/O to radio			

#### IF STARTER RELAY CHATTERS OR DOESN'T CLICK (STARTER DOES NOT CRANK)

- Check **Battery** and cables (see above).
- Make sure **Starter Relay** bracket is grounded tightly.
- With R/LB wire removed from **Starter Relay**, and transmission in PARK or NEUTRAL, jumper this terminal on **Starter Relay** to main terminal (**Battery** connection). If **Starter Motor** works, check **Ignition Switch**. Check wiring to **Starter Relay** for open or dirty connections. If this jumper doesn't operate **Starter Relay**, replace it.

#### IF STARTER DOES NOT CRANK AND STARTER RELAY CLICKS

- Clean and tighten cable connection to **Starter Motor** terminal and relay terminals. Check cable to **Starter Motor** for damage and make sure wire strands are secure in eyelets.
- If still bad, repair or replace **Starter Motor**.

#### IF STARTER SPINS (HUMMING NOISE) BUT DOES NOT CRANK ENGINE

- Remove **Starter Motor**. Repair or replace starter drive.



- Read the Shop Manual for detailed Starting tests.

## TACHOMETER TROUBLESHOOTING HINTS

### TACHOMETER READS HIGH OR LOW

- Check that 3-position switch on front of tach (behind mask) is in proper position for number of cylinders in engine.

### NO TACHOMETER INDICATION

- Check that the 3 nuts on the tach terminal studs behind the cluster, and the printed circuit connector to the cluster, are secure.
- With the **Ignition Switch** in the RUN position, check for battery voltage between the 2 o'clock terminal and the 6 o'clock terminal (as viewed from rear of cluster).
- Check for continuity from 6 o'clock terminal to G201.
- Disconnect the 2-terminal **Ignition Coil Connector**. Check for continuity between the DG/Y D wire and the 10 o'clock terminal.

## IGNITION HOW THE CIRCUIT WORKS

The basic **Ignition System** contains the breakerless **Ignition Module**, the **Ignition Coil**, the **Distributor**, and the spark plugs and wires.

When the engine is cranking or running:

- The magnetic pickup in the **Distributor** sends pulses to the **Ignition Module** as each tooth of the rotor passes the pickup.
- The **Ignition Module** switches current on and off to the primary (TACH TEST) of the **Ignition Coil** according to the **Distributor** pulses;
- Each interruption of primary current makes the **Ignition Coil** secondary produce a high-voltage pulse of up to 40,000 volts;

- High voltage pulses are transmitted to the **Distributor**, which sends them to fire the spark plugs.

### CAUTION

*In the Dura Spark II system, a high-voltage pulse is produced when the Ignition Switch is turned OFF.*

## TROUBLESHOOTING HINTS

The following steps are intended only as quick checks to identify and locate some of the more frequent problems. If these checks do not solve the problem, refer to the **Ignition System** diagnosis procedure in the proper Ford Shop Manual for complete system tests.

If the **Ignition System** is OK, check the fuel system and the engine itself.

### PRELIMINARY CHECKS

- Check **Battery** for state of charge and for clean, tight battery terminal connections.
- Inspect all wires and connectors for breaks, cuts, abrasions or burned spots. Repair or replace as necessary. Make sure all wires are connected correctly.
- Unplug all connectors and inspect for corroded or burned contacts. Repair as necessary and plug connectors back together. Do NOT remove grease in connectors.
- Check for loose or damaged spark plug or coil wires. If boots or nipples are removed on 8mm ignition wires, reline inside of each with new silicone di-electric compound.

### SPECIAL TEST JUMPER

Make up a test jumper as shown in Figure 1 below. It is important to use only this test jumper when making these checks. Solid wire jumpers will not work for the quick checks.




Figure 1 - Ignition Test Jumper

## RUN MODE SPARK TEST

### Step 1

- Remove **Distributor** cap and rotor from **Distributor**.
- Crank engine to align one tooth of armature (Figure 2) with magnet in pick-up coil (ignition OFF). Use a bump switch, or briefly touch a jumper between the R and R/LB terminals of the **Starter Relay**.
- Remove coil (center) wire from **Distributor** cap. Install modified spark plug (side electrode removed) in coil wire terminal.
- Turn **Ignition Switch** to RUN.
- Hold side of spark plug against engine block using insulated pliers. Tap base of **Distributor** with screwdriver handle and watch for SPARK at the spark plug.




Figure 2 - Align Armature to Pickup



- If there is a good *SPARK*, primary circuit is OK. Skip to "START MODE SPARK TEST" below.
- If *NO GOOD SPARK*, perform **Step 2**.

### Step 2

- Unplug **C111** (4 wire connector) at **Ignition Module**.
- In the harness side of the connector, connect the special test jumper (Figure 1) between the **DG/Y D** lead and the **BK/LG D** or **BK** leads. Use paper clips on connector socket holes to make contact.
- With the **Ignition Switch** in **RUN**, close the test jumper switch. Leave closed for about one second, then open. Repeat this several times. There should be a *SPARK* each time this switch is opened.
  - If there is *NO SPARK*, the problem is in the primary circuit — the **Ignition Switch**, **Ignition Coil**, **DG/Y D** lead, **BK/LG D** or **BK** lead, **R/LG** lead, or ground connection in the **Distributor**. Perform **Step 3**.
  - If there is *SPARK*, the primary circuit wiring and Coil are OK. The problem is in the **Distributor** pick-up, the **Ignition Module** bias power feed (**R** wire), or the **Ignition Module**. Perform **Step 6**.

### Step 3

- Disconnect the test jumper lead from the **BK** or **BK/LG D** lead and connect to a good ground on the engine. Turn the test jumper switch ON and OFF several times as in **Step 2**.
  - If there is *NO SPARK*, the problem is in the **DG/Y D** lead, the **Coil**, or the coil feed circuit. Perform **Step 5**.
  - If there is *SPARK*, the problem is in the **BK** or **BK/LG D** lead or the ground connection in the **Distributor**. Perform **Step 4**.

### Step 4

- Connect an ohmmeter between the **BK** or **BK/LG D** lead and a good ground on the engine. With the meter on its lowest scale there should be no measurable resistance in the circuit.
  - If there is *RESISTANCE*, check ground connection in **Distributor** and **BK** or lead from module. Repair or replace as necessary. Remove meter plug in all connectors and repeat **Step 1**.
  - If there is *NO RESISTANCE*, the primary ground wiring is OK. Perform **Step 6**.
- Disconnect the test jumper from the **DG/Y D** lead and ground and connect it between the **Tach-Test** terminal of the coil and a good ground on the engine.
- With the **Ignition Switch** in **RUN**, turn the jumper switch ON. Hold it ON for approximately one second and turn it OFF as in **Step 2**. Repeat this several times. There should be a *SPARK* each time the switch is turned OFF.
  - If there is *NO SPARK*, the problem is in the coil or in the primary circuit through the **Ignition Switch** to the coil **BATT** terminal.
    - Check coil for internal shorts or opens and for primary resistance (1.13 to 1.23 ohms) and secondary resistance (**R/LG** wire) (7.7 to 9.3 K ohms). Replace coil if necessary.
    - Check coil feed circuit for opens, shorts, or high resistance. Repair as necessary. Remove test jumper, plug in connectors, and repeat **Step 1**.
  - If there is *SPARK*, the coil and its feed circuit are OK. The problem is in the **DG/Y D** lead between the coil and the module. Check for open or short and

repair as necessary. Remove test jumper plug in all connectors, and repeat **Step 1**.

### Step 6

- Connect a voltmeter between the **O/Y H** and **P/LB H** leads on the harness side of the module 4-wire connector.

#### CAUTION

*If the vehicle has a catalytic converter, disconnect the air supply line between the Bypass Valve and the Manifold before cranking the engine with the Ignition Switch in OFF. This will prevent damage to the catalytic converter. After testing, run the engine for at least 3 minutes before reconnecting the air supply line to clear excess fuel from the exhaust system.*

#### NOTE

Do not use a voltmeter which is combined with a dwell-meter. Slight needle oscillations ( $\frac{1}{2}$  volt) may not be detectable on this type of test unit.

- Set meter on its lowest scale and crank the engine. Meter needle should oscillate slightly (approximately  $\frac{1}{2}$  volt).
  - If meter needle does *NOT OSCILLATE*, check circuit through magnetic pick-up (in **Distributor**) for open, shorts, shorts to ground, and resistance. Resistance between **O/Y H** and **P/LB H** leads should be 400—1000 ohms and between each lead and ground should be more than 70K ohms. Repair as necessary, plug in all connectors, and repeat **Step 1**.



- If meter *OSCILLATES*, problem is in the power feed to the **Ignition Module** (R wire) or in the module itself. Perform **Step 7**.

## Step 7

- Remove all meters and jumpers. Plug in all connectors.
- Turn the **Ignition Switch** to RUN and measure voltage to engine ground at:
  - **Battery** positive terminal. This reading should be at least 12 volts.
  - The **R** lead of the **Ignition Module**. Use a straight pin to pierce the insulation of the lead and connect voltmeter to pin (Figure 3).
- These two readings should be within 1 volt of each other.
  - If readings are *NOT WITHIN ONE VOLT*, check circuit feeding power to R lead for shorts, open, or high resistance. Repair as necessary and repeat **Step 1**.
  - If readings are *WITHIN ONE VOLT*, the problem is probably in the module. Disconnect the module and connect a known-good module in its place and repeat **Step 1**. If this corrects the problem reconnect the original module and recheck. If problem returns, remove the old module and install the new one.

### NOTE

If the above steps do not solve the problem, see "Engine Diagnosis and Service" section of the Shop Manual.

**Buy Now**

