

Free Bonus!

30-Minute Video

Fora Training
Course 13001 Vol 68 S7

How to Read Wiring

How to Read "Diagrams"

Diagrams Included!

(with Electrical Illustrations)

Buy Now



A consolidated collection of original Ford electrical & vacuum diagrams with illustrations

Color diagrams for:

Convenience System; Exterior Lights; Interior Lights; Heater and Air Conditioner; Horns; Convertible Top; Ignition, Starting and Charging; Heated Backlite, Cigar Lighter, Clock, Power Windows; Radio AM, FM and Stereo Tape; Windshield Wiper and Washer; Intermittent Wipers; Key Warning Buzzer; Mustang Emission Control

...and much more!!

Licensed and approved
by the Ford Motor Company



5236

All Rights Reserved. Copyright 2008
Forel Publishing Company, LLC


DEMO

This DEMO contains only a few pages of the entire manual/product.

Not all Bookmarks work on the Demo,
but they do on the full version.

Features:

- Searchable text
- Printable pages
- Bookmarked for easy navigation
- High Resolution images
- Zoom to see exact details
- Money back Guarantee
- Transfer to USB flash drive support



MUSTANG CONVENIENCE SYSTEM (With Tach)

All Rights Reserved. Copyright 2008
Forel Publishing Company, LLC

Example of colorized diagrams

Copyright © 2008, Forel Publishing Company, LLC, Woodbridge, Virginia

All Rights Reserved. No part of this book may be used or reproduced in any manner whatsoever without written permission of Forel Publishing Company, LLC. For information write to Forel Publishing Company, LLC, 3999 Peregrine Ridge Ct., Woodbridge, VA 22192


1971 Colorized Mustang Wiring and Vacuum Diagrams

(Extracted from Form FD-7795P-71, Form 7098-71-3, FP-7635B, and FD-7943-G)

EAN: 978-1-60371-030-5

ISBN: 1-60371-030-2

*Forel Publishing Company, LLC
3999 Peregrine Ridge Ct.
Woodbridge, VA 22192*



This publication contains material that is reproduced and distributed under a license from Ford Motor Company. No further reproduction or distribution of the Ford Motor Company material is allowed without the express written permission of Ford Motor Company.

Note from the Editor

This product was compiled using several original Ford Motor Company publications. In some cases, there are slight differences between publications, so it is important to compare between diagrams, schematics, or illustrations. The contents of this product were extracted from: *1971 Wiring and Vacuum Diagrams* (Form FD-7795P-71), *1965/1972 Ford Car Master Parts and Accessory Catalog* (Form FP-7635B), *1971 Car Shop Manual (Volume III, FORM 7098-71-3)*, and *How to Read Wiring Diagrams* (FD-7943-G, January 1968).

Disclaimer

Although every effort was made to ensure the accuracy of this book, no representations or warranties of any kind are made concerning the accuracy, completeness or suitability of the information, either expressed or implied. As a result, the information contained within this book should be used as general information only. The author and Forel Publishing Company, LLC shall have neither liability nor responsibility to any person or entity with respect to any loss or damage caused, or alleged to be caused, directly or indirectly by the information contained in this book. Further, the publisher and author are not engaged in rendering legal or other professional services. If legal, mechanical, electrical, or other expert assistance is required, the services of a competent professional should be sought.

ATTENTION



Please Read This



It is important to note that there may be errors in the diagrams, even though they are original Ford publications. Below are two examples of possible errors because the color code on the page diagram does not match the master Car Standard Wire Code Chart. If your vehicle has a color coded wire that does not match a diagram you should consult the other diagrams contained in the manual for a possible match.

Example of possible errors

37	YELLOW
38	BLACK
54	LT. GREEN-YELLOW STRIPE
158	BLACK-PINK HASH STRIPE

In the wiring diagrams from the Ford publication Form 7795P-71, the Key Warning Buzzer Wiring Color Code shows:

38 Black

However, the Car Standard Wire Color Code Chart lists:

38 – Black-Orange Stripe

37	YELLOW
38	BLACK
54	LT. GREEN-YELLOW STRIPE
158	BLACK-PINK HASH STRIPE

In the wiring diagrams from the Ford publication Form 7795P-71, the Key Warning Buzzer Wiring Color Code shows:

158 Black-Pink HASH STRIPE

However, the Car Standard Wire Color Code Chart lists:

158 – Black- Pink HASH

The color coded wiring diagrams are provided for illustration purposes only. Only the wire number should be used for the identification of the wire itself. The color coding of the wires in the product may not match the actual colors of the wires in the vehicle. In some cases, the colors have been altered to provide a visual contrast (i.e. the color white has been shaded to make it more visible). As stated in the paragraph above, there are some variation and/or differences between the original Ford wiring diagrams. If your vehicle has a color coded wire that does not match a diagram you should consult the other diagrams contained in the manual for a possible match.

Disclaimer: Although every effort was made to ensure the accuracy of this book, no representations or warranties of any kind are made concerning the accuracy, completeness or suitability of the information, either expressed or implied. As a result, the information contained within this book should be used as general information only. The author and Forel Publishing Company, LLC shall have neither liability nor responsibility to any person or entity with respect to any loss or damage caused, or alleged to be caused, directly or indirectly by the information contained in this book. Further, the publisher and author are not engaged in rendering legal or other professional services. If legal, mechanical, electrical, or other expert assistance is required, the services of a competent professional should be sought.

Source Document
Ford Publication Form 7795P-71

1971

COURSE 13003 and 1703

WIRING and VACUUM DIAGRAMS



SERVICE
TRAINING

FORM 7795P-71

FOREWORD

This book contains wiring and vacuum diagrams for all Ford and Lincoln-Mercury car lines and all Ford trucks.

Both wiring and vacuum diagram replacement sheets will be released as required to keep the book current.

All vacuum systems are contained in a separate section.

This book is divided by vehicles. Refer to the applicable section as follows:

- Pinto
- Maverick and Comet
- Mustang and Cougar
- Torino
- Montego
- Ford and Meteor
- Mercury
- Thunderbird
- Mark III
- Lincoln
- Bronco, Econoline and P-Series
- B and F-100-750 Series
- C and CT-Series
- W-Series
- L-Series



The illustrations contained in this book were in effect at the time the book was approved for printing. Ford Motor Companies, whose policy is one of continuous improvement, reserves the right to discontinue models at any time, or to change specifications or design, without notice and without incurring obligation.

HOW TO USE THE WIRING DIAGRAMS

Two styles of wiring diagrams are contained in this book.

I — Cars (Except Mustang, Cougar and Lincoln) and L-Series Truck.

II — Mustang, Cougar, Lincoln and Truck (Except L-Series

I — CARS (Except Mustang, Cougar and Lincoln) AND L-SERIES TRUCKS

Each electrical circuit is illustrated in a clear and easy to follow style.

There are 7 steps that should be followed to use this diagram to diagnose electrical problems.

- Verify the complaint
- Refer to the Index
- Locate inoperative system
- Identify other systems on the circuit
- Isolate the problem area
- Correct the problem
- Operate the corrected system

VERIFY THE COMPLAINT

To diagnose a customer complaint "Back Up Lights Don't Work" the first thing we should do is verify the complaint.

If both lights do not work, refer to the INDEX on page 1 of the vehicle schematic.

REFER TO THE INDEX

An INDEX is provided on page 1 to locate the inoperative components.

See LAMPS — BACK-UP on the INDEX. The INDEX lists the location of the part on the drawing.

The drawing is set up like a road map. For example: the Pinto Back-up lights are located at B-27. To locate B-27 on the schematic, find the number 27 at the top of the illustration.

Now, find the letter B on the side of the illustration. Follow the number and the letter until they intersect. The part will be within an inch or two of the intersection.

LOCATE INOPERATIVE SYSTEM

Generally, the power supply for all components on this drawing comes from the top of the page and over to the battery at the left.

The ground for each component is always toward the bottom of the drawing.

There are symbols used on this drawing that are explained as follows:

- Ground symbols are shown in Figure 1. A ground wire connected away from the component is identified by a code G1 or G2, etc. The location of the remote ground is listed in the GROUND CODES chart and the bottom of the page.



Fig. 1 — Ground Symbols

- Wire color code is shown in Fig. 2. Wiring Color Codes are listed at the bottom of the drawing. New Standard Wiring Color Codes are listed behind these instructions.

140B

Fig. 2 — Wire Color Code

CORRECT THE PROBLEM

Use standard continuity tests for open circuits and short circuit tests to find the specific problem.

Repair or replace the electrical component that is malfunctioning.

OPERATE CORRECTED SYSTEM

It is a good practice to operate the system after a repair has been made to see if it now works.

BULB AND FUSE CHART

A bulb and fuse chart is included on the first page of this schematic for your convenience.

II - MUSTANG, COUGAR, LINCOLN AND TRUCKS (Except L-Series)

The index page is the first page in each section. Each electrical schematic will have a notation as to the source of power for that system. All wires will be shown as single lines to provide a clear understanding of the diagrams. To trace a circuit, it is recommended to start at the ground circuit of the inoperative component, trace it through all connectors to the source, and note the possible trouble areas and points of most convenient access. Wire connectors will be identified on the schematic and the pictorial drawings, this will show the technician the location of the connectors. Most wire connectors are shown in open book fashion. A wire on the top right of a connector (open side by side) will be on the top left side of the other half of the connector. See Figure 9 (Wire No. 140 to No. 140A, etc.)

Wire disconnects and connectors will all be black unless a color code is noted on the diagram. The colored disconnects and connectors are to aid the technician in finding the proper circuit to be tested or traced. Pictorial drawings of a component will include the specific location of some components in cases where it is difficult to determine if the component is under the instrument panel or in the engine compartment.

Relays and switches are shown in the "System Off" position. If a vehicle specific wire color in a connector does not match the diagram shown, it can usually be identified by comparing the other colors shown at the wire connectors. Specific wire color deviations in the manufacturing of a wire harness are usually for a short duration.




Fig. 9 - Connectors

CAR STANDARD WIRE COLOR CODE CHART

(1 OF 3)

CIRCUITS IN CURRENT USE

CIRCUIT	DESCRIPTION	COLOR NO.	BASE	STRIPE	HASH	DOT	CIRCUIT
1	HORN SWITCH CONTROL	69	DR. BLUE				1*
2	RH FRONT TURN SIGNAL LAMP	55	WHITE	LT. BLUE		2	
3	LH FRONT TURN SIGNAL LAMP	33	LT. GREEN	WHITE		3	
4	ALTERNATOR REG. "E" TERM. TO ALTERNATOR "S" TERM	51	WHITE	BLACK		4	
5	RH REAR TURN SIGNAL LAMP	25	ORANGE	LT. BLUE		5	
6	HORN RELAY TO HORN	130	YELLOW			6	
7	SEAT SWITCH ARM TERM TO RELAY FIELD TERM	232	LT. GREEN		LT. GREEN	7	
8	TURN SIGNAL FLASHER FEED	23	ORANGE	YELLOW		8	
9	LH REAR TURN SIGNAL LAMP	36	LT. GREEN	ORANGE		9	
10	STOP/BLINK SWITCH FEED	147	LT. GREEN		RED	10	
11	HEADLAMP DIMMER SWITCH TO HIGH BEAMS	34	LT. GREEN	BLACK		12	
12	HEADLAMP DIMMER SWITCH TO LOW BEAMS	14	RED	BLACK		13	
13	HEADLAMP SWITCH TO TAIL LAMPS AND SIDE MARKER LAMPS	7	BROWN			14*	
14	HEADLAMP SWITCH TO HEADLAMP DIMMER SWITCH	16	RED	YELLOW		15	
15	HEADLAMP SWITCH TO HEADLAMP DIMMER SWITCH	17	RED	LT. GREEN		16	
16	IGNITION SWITCH TO IGNITION COIL "BATT." TERMINAL	57	WHITE			17	
17	LOW OIL PRESSURE WARNING LAMP TO LOW OIL PRESS. SENDING UNIT	215	WHITE			18	
18	SEAT SWITCH TO RELAY FIELD TERM	42	ORANGE			19	
19	INSTRUMENT PANEL LAMPS FEED	41	LT. BLUE	BLACK		22	
22	BRAKE FEED	181	BLACK			28	
26	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	32	YELLOW	WHITE		29	
29	FUEL GAGE TO FUEL GAGE SENDER	4	BLACK	LT. GREEN		30	
30	CONSTANT VOLTAGE UNIT AND INDICATOR LAMPS FEED	52	WHITE	RED		31	
31	OIL PRESSURE INDICATOR TO OIL PRESSURE SENDING UNIT	18	RED	LT. BLUE		32	
32	CHARGER CONTROL	25	ORANGE	LT. BLUE		35	
35	ALTERNATOR REGULATOR "F" TERM. TO ALTERNATOR	223	YELLOW			36	
36	ALTERNATOR OUTPUT	27	YELLOW			37*	
37	BATTERY TO LOAD	2	BLACK	ORANGE		38	
38	POWER SUPPLY TO BATTERY	19	RED	WHITE		39	
39	TEMP. GAGE TO TEMP. SENDING UNIT	45	LT. BLUE	WHITE		40	
40	CIGAR LIGHTER FEED	102	BLACK			41	
41	WARNING LAMP FEED	206	RED			42	
42	SWITCH TO WARNING LAMP	40	LT. BLUE			43	
43	LOW AIR BUZZER FEED	134	ORANGE			44	
44	TURN SIGNAL FLASHER TO TURN SIGNAL SWITCH	40	LT. BLUE			45	
45	HOT WATER TEMP. RELAY TO HOT WATER TEMP. SENDING UNIT	29	YELLOW	RED		48*	
48	BLINK CIRCUIT TERM. IN HARNESS CANNOT BE CHECKED FOR CONT. (COLOR OPT.)	264	BLACK			51	
51	SEAT REG. CONTROL SWITCH FEED	184	BLACK	LT. BLUE		53	
53	COURTESY LAMP SWITCH TO COURTESY LAMP	37	LT. GREEN	YELLOW		54	
54	INTERIOR LAMP SWITCH FEED	51	BLACK	PINK		55	
55	CARGO LAMP SW. TO CARGO LAMP	70	DK. BLUE	ORANGE		56	
56	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	1	BLACK			57*	
57	GROUND CIRCUIT	50	WHITE			58	
58	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	184	BLACK	LT. BLUE		60	
60	CONSTANT VOLTAGE UNIT TO GAGE	29	YELLOW	RED		61	
61	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	13	RED			63	
63	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	64	DK. GREEN			65	
64	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	40	LT. BLUE			66	
66	AIR SHIFT SWITCH TO INDICATOR LAMP	118	RED			69	
69	COIN TERM. IGN. SW. TO FUEL SOLENOID	133	ORANGE	LT. GREEN		73	
73	LOW AIR BUZZER TO LOW AIR BUZZER SWITCH	33	LT. GREEN			74	
74	RELAY "B" TERMINAL TO LAMP (WATER)	150	LT. GREEN			75	
75	STARTING MOTOR RELAY TO SERIES PARALLEL SW. (#1 TERM.)	182	BLACK			80	
80	ENGINE COMPARTMENT LAMP FEED	163	PURPLE			84	
84	DECK LID SOLENOID FEED	6	BLACK	WHITE		88	
88	INSTRUMENT PANEL LAMP SWITCH FEED						

89	GLOW PLUG TO GLOW PLUG SWITCH	24	ORANGE	LT. GREEN		89	
102	OVERDRIVE KICKDOWN SWITCH TO OVERDRIVE GOVERNOR	50	WHITE		RED	102	
103	OVERDRIVE KICKDOWN SW. TO IGN. COIL	257	WHITE			103	
104	OVERDRIVE KICKDOWN SW. TO OVERDRIVE SOLENOID	43	LT. BLUE	ORANGE		104	
105	OVERDRIVE KICKDOWN SWITCH TO OVERDRIVE RELAY	203	RED			105	
106	OVERDRIVE SOLENOID TO OVERDRIVE RELAY	40	LT. BLUE	YELLOW		106	
111	WARNING LAMP TO LIGHTS ON RELAY	3	BLACK			111	
112	WARNING LAMP RELAY FEED	183	BLACK			112	
113	STARTING MOTOR TO STARTING MOTOR RELAY	222	YELLOW			113	
114	FEED TO VACUUM DOOR LOCK SWITCH	113	TAN			114	
115	VACUUM DOOR LOCK SWITCH TO SOLENOID (LOCK)	33	LT. GREEN			115	
116	VACUUM DOOR LOCK SWITCH TO SOLENOID (UNLOCK)	188	BROWN			116	
117	DOOR LATCH MOTOR (LOCK)	207	PINK			117	
118	DOOR LATCH MOTOR (UNLOCK)	208	PINK			118	
119	DOOR LATCH SWITCH (LOCK)	209	PINK			119	
120	DOOR LATCH SWITCH (UNLOCK)	210	PINK			120	
121	TOP CONTROL SWITCH TO TOP CONT. MOTOR OR RELAY	13	RED	YELLOW		122	
122	TOP CONTROL SWITCH TO TOP CONT. MOTOR OR RELAY	9	BROWN	YELLOW		123	
125	MAP LAMP SWITCH TO RM. MAP LAMP	182	BLACK			126	
126	COURTESY LAMP SW. TO INSTR. PANEL COURTESY LAMP	185	BLACK			127	
127	COURTESY LAMP SW. TO "C" PILLAR LAMPS	33	LT. GREEN			129	
129	GLOW PLUG SWITCH FEED	60	PURPLE	ORANGE		131	
131	CIGAR LIGHTER LAMP FEED	111	TAN		RED	131	
133	RELAY TO MAP LAMP SWITCH	136	YELLOW		BLACK	133	
137	RADIO # ANTENNA SWITCH FEED	11	BROWN	LT. BLUE		137	
139	DOOR JAMB SWITCH TO LIGHTS ON RELAY	61	BLACK	PINK		138	
140	BACK UP LAMP	61	BLACK	PINK		140	
141	TWO OR THREE SPEED AXLE SWITCH TO TWO OR THREE SPEED AXLE MOTOR	181	BLACK			141	
142	TWO OR THREE SPEED AXLE SWITCH FEED	142	DK. GREEN			142	
143	TWO OR THREE SPEED AXLE SWITCH TO TWO OR THREE SPEED AXLE MOTOR	13	RED			143	
151	SWEEP CONTROL ON-OFF SWITCH TO AMPLIFIER	156	LT. BLUE			151	
153	STARTING MOTOR RELAY TO FLASHER	19	RED	WHITE		193	
158	KEY WARNING SWITCH TO BUZZER	98	BLACK			158	
159	DOOR JAMB SWITCH TO BUZZER	63	RED	PINK		159	
160	BUZZER TO WARNING INDICATOR RELAY	64	WHITE	PINK		160	
162	EMERG. BRAKE WARNING LAMP TO EMERG. BRAKE SWITCH	230	LT. GREEN		RED	162	
170	INDOOR REGULATOR SWITCH FEED	205	RED			170	
171	DOOR LATCH BREAKER TO SEAT LATCH RELAY	21	BLACK	WHITE		171	
172	RELAY TO SEAT LATCH SOLENOID	85	ORANGE			172	
173	DOOR SWITCH TO SEAT LATCH RELAY (COPIL. TERM.)	71	PINK	WHITE		173	
175	TOP CONTROL SWITCH OR RELAY FEED	181	BLACK			175	
176	REAR WINDOW REGULATOR SWITCH FEED	50	WHITE			176	
179	HORIZONTAL SEAT REG. MOTOR TO RELAY	27	YELLOW			179	
180	HORIZONTAL SEAT REG. MOTOR TO RELAY	13	RED			180	
181	FLOWER MOTOR FEED	8	BROWN	ORANGE		181	
182	THERMOSTAT SWITCH FEED	12	BROWN	WHITE		182	
184	AIR COND SW. (LO) TO AIR COND BLOWER MOTOR	112	TAN			184	
186	DEFROGGER SW. TO DEFROGGER MOTOR	105	BROWN	LT. BLUE		186	
188	CIRCUIT HRKR. TO HEADLAMP SW. "BATT." TERM.	1	BLACK			188	
191	DEFROGGER SW. TO DEFROGGER MOTOR	71	DK. BLUE	YELLOW		191	
193	WINDOW REGULATOR RELAY FEED	159	YELLOW			193	
194	WINDOW REG. RELAY ACCY FEED	79	PINK			194	
196	COOLANT FAN CONTROL RELAY FEED	194	TAN			196	
197	COOLANT TEMPERATURE SWITCH TO CONTROL RELAY	195	TAN			197	
198	A/C PRESSURE SWITCH TO CONTROL RELAY	196	TAN			198	
199	CONTROL RELAY TO IGNITION RELAY	197	TAN			199	
200	IGNITION RELAY TO COOLANT FAN	198	TAN			200	
206	GROUND RETURN TO TOWING VEHICLE	50	WHITE			206*	
207	MARKER LAMP SWITCH TO MARKER LAMPS	1	BLACK			207*	
212	AUXILIARY CIRCUIT FEED TO TRACTOR TRAILER PLUG	69	DK. BLUE			212*	

CAR STANDARD WIRE COLOR CODE CHART

(2 OF 3)

CIRCUITS IN CURRENT USE

CIRCUIT

212 SIGNAL UNIT LAMP TO FUEL SIGNAL RELAY
 226 LF WINDOW REG SW TO LF WINDOW REG MOTOR
 237 LF WINDOW REG SW TO LF WINDOW REG MOTOR
 241 DE-ICE SOLENOID CONTROL
 243 POWER SERVO TO CLIMATE CONTROL UNIT (MODE)
 244 THERMAL SW TO CLIMATE CONTROL UNIT
 245 POWER SERVO TO CLIMATE CONTROL UNIT (AMP)
 246 POWER SERVO TO CLIMATE CONTROL UNIT (AMP)
 247 POWER SERVO TO CLIMATE CONTROL UNIT (AMP)
 248 HEATER & A/C CONTROL SW, (DE-ICE) TO CLIMATE CONTROL UNIT
 249 HEATER & A/C CONTROL SW, (LO-NORM) TO CLIMATE CONTROL UNIT
 250 HEATER & A/C CONTROL SW, (LO-NORM) TO POWER SERVO
 253 INTERMEDIATE TERM 3 SPEED AXLE SWITCH TO SOLENOID VALVE FORWARD TANDEM
 254 HIGH TERMINAL 3 SPEED AXLE SWITCH TO SOLENOID VALVE REAR TANDEM
 255 AXLE LOCKOUT DIFFERENTIAL SWITCH FEED
 260 FLOWER MOTOR TO SWITCH - LO
 261 FLOWER MOTOR TO SWITCH - HI
 262 STARTING MOTOR RELAY TO IGN. COIL "I" TERM.
 269 HEATER BLOWER MOTOR TO SWITCH (MEDIUM)
 282 TURN SIGNAL SW. TO RH REAR TURN SIGNAL LAMP
 283 TURN SIGNAL SW. TO LH REAR TURN SIGNAL LAMP
 284 BATTERY SW. TO STOP/ALARM SWITCH
 287 SPEAKER VOICE COIL RETURN
 296 FUSED ACCY FEED FEED
 297 ACCY. FEED FROM IGNITION SWITCH
 298 FUSED ACCY FEED #2
 306 SEAT REG. SW. TO HORIZ. SOLENOID BATT. TERM.
 307 SEAT REG. SW. TO VERT. SOLENOID BATT. TERM.
 313 LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT FRONT WINDOW REGULATOR MOTOR
 314 LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT FRONT WINDOW REGULATOR MOTOR
 316 LEFT FRONT WINDOW REGULATOR SWITCH TO LEFT REAR WINDOW REGULATOR MOTOR
 317 LEFT FRONT WINDOW REGULATOR SWITCH TO LEFT REAR WINDOW REGULATOR MOTOR
 319 LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT REAR WINDOW REGULATOR MOTOR
 320 LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT REAR WINDOW REGULATOR MOTOR
 328 WINDOW REG.MASTER CONT. SW. TO WIND. REG. SW. FEED
 335 WINDOW REG SW TO WINDOW REG MOTOR
 334 WINDOW REG SW TO WINDOW REG MOTOR
 347 COMPRESSOR CLUTCH FEED
 348 THERMOSTATIC SW. TO AIR COND. SW. SELECTOR TERM.
 364 FLOWER MOTOR RELAY FEED
 365 FUEL LEVEL WARNING RELAY FEED
 366 FUEL WARNING RELAY CONTROL
 367 FUEL LEVEL (DECEIVER) FUEL LEVEL WARNING RELAY (RFC. TERM)
 369 VACUUM SOLENOID TO TERM. SW.
 371 BLOWER MOTOR RELAY TO MOTION
 372 MOVABLE STEERING COLUMN SOLENOID FEED
 379 TURN SIGNAL SWITCH TO RH CORNERING LAMP
 380 TURN SIGNAL SWITCH TO LH CORNERING LAMP
 381 MOVABLE STEERING COLUMN SOLENOID TO COURTESY LAMP SWITC
 383 EMERGENCY WARNING FLASHER FEED
 385 FLASHER TO EMERGENCY WARNING SWITCH
 387 READING LAMP SWITCH TO READING LAMP (LH)
 394 HEATER BLOWER SWITCH FEED
 400 SAFETY RELAY LOAD TERM. TO WIND. REG. SW. FEED
 401 LIMIT SW. TO BACK WINDOW REG. MOTOR
 402 WINDOW REG SW TO BACK WINDOW REG MOTOR
 403 WINDOW REG. SW. TO WIND. REG. MOTOR
 404 WINDOW REG. SW. TO BACK WIND. SW.
 405 WINDOW REG. SW. TO BACK WIND. SW.
 406 WINDOW REG. SW. TO BACK WIND. AUX. SW.

CIRCUIT	COLOR NO.	BASE	STRIPE	HASH	DET	CIRCUIT
212 SIGNAL UNIT LAMP TO FUEL SIGNAL RELAY	219	YELLOW			BLACK	215
226 LF WINDOW REG SW TO LF WINDOW REG MOTOR	13	RED				226
237 LF WINDOW REG SW TO LF WINDOW REG MOTOR	27	YELLOW				227
241 DE-ICE SOLENOID CONTROL	44	LT BLUE	YELLOW			241
243 POWER SERVO TO CLIMATE CONTROL UNIT (MODE)	148	LT GREEN			ORANGE	243
244 THERMAL SW TO CLIMATE CONTROL UNIT	149	YELLOW			WHITE	244
245 POWER SERVO TO CLIMATE CONTROL UNIT (AMP)	150	BROWN	LT GREEN			245
246 POWER SERVO TO CLIMATE CONTROL UNIT (AMP)	46	PURPLE				246
247 POWER SERVO TO CLIMATE CONTROL UNIT (AMP)	89	WHITE	YELLOW			247
248 HEATER & A/C CONTROL SW, (DE-ICE) TO CLIMATE CONTROL UNIT	139	YELLOW			LT BLUE	248
249 HEATER & A/C CONTROL SW, (LO-NORM) TO CLIMATE CONTROL UNIT	57	DK BLUE	LT GREEN			249
250 HEATER & A/C CONTROL SW, (LO-NORM) TO POWER SERVO	20	ORANGE				250
253 INTERMEDIATE TERM 3 SPEED AXLE SWITCH TO SOLENOID VALVE FORWARD TANDEM	13	RED				253
254 HIGH TERMINAL 3 SPEED AXLE SWITCH TO SOLENOID VALVE REAR TANDEM	1	BLACK				254
255 AXLE LOCKOUT DIFFERENTIAL SWITCH FEED	157	LT BLUE			RED	255
260 FLOWER MOTOR TO SWITCH - LO	119	RED			RED	260
261 FLOWER MOTOR TO SWITCH - HI	21	ORANGE	BLACK		WHITE	261
262 STARTING MOTOR RELAY TO IGN. COIL "I" TERM.	62	BROWN	PINK			262
269 HEATER BLOWER MOTOR TO SWITCH (MEDIUM)	159	LT BLUE			WHITE	269
282 TURN SIGNAL SW. TO RH REAR TURN SIGNAL LAMP	64	DK GREEN	BLACK			282*
283 TURN SIGNAL SW. TO LH REAR TURN SIGNAL LAMP	28	YELLOW	BLACK			283*
284 BATTERY SW. TO STOP/ALARM SWITCH	13	RED				284*
287 SPEAKER VOICE COIL RETURN	103	BLACK			WHITE	287
296 FUSED ACCY FEED FEED	56	WHITE	PURPLE			296
297 FUSED ACCY FEED FROM IGNITION SWITCH	101	BLACK			LT GREEN	297
298 FUSED ACCY FEED #2	162	PURPLE			WHITE	298
306 SEAT REG. SW. TO HORIZ. SOLENOID BATT. TERM.	40	LT BLUE			WHITE	306
307 SEAT REG. SW. TO VERT. SOLENOID BATT. TERM.	50	WHITE				307
313 LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT FRONT WINDOW REGULATOR MOTOR	28	YELLOW	BLACK			313
314 LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT FRONT WINDOW REGULATOR MOTOR	14	DK GREEN	BLACK			314
316 LEFT FRONT WINDOW REGULATOR SWITCH TO LEFT REAR WINDOW REGULATOR MOTOR	31	YELLOW	LT BLUE			316
317 LEFT FRONT WINDOW REGULATOR SWITCH TO LEFT REAR WINDOW REGULATOR MOTOR	122	RED			LT BLUE	317
319 LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT REAR WINDOW REGULATOR MOTOR	136	YELLOW			BLACK	319
320 LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT REAR WINDOW REGULATOR MOTOR	117	RED			BLACK	320
328 WINDOW REG.MASTER CONT. SW. TO WIND. REG. SW. FEED	203	RED				328
335 WINDOW REG SW TO WINDOW REG MOTOR	29	YELLOW	RED			333
347 COMPRESSOR CLUTCH FEED	16	RFD	YELLOW			334
348 THERMOSTATIC SW. TO AIR COND. SW. SELECTOR TERM.	100	BLACK			YELLOW	347
364 FLOWER MOTOR RELAY FEED	150	LT GREEN			PURPLE	348
365 FUEL LEVEL WARNING RELAY FEED	4	BLACK			LT GREEN	364
366 FUEL WARNING RELAY CONTROL	157	LT BLUE			RED	365
367 FUEL LEVEL (DECEIVER) FUEL LEVEL WARNING RELAY (RFC. TERM)	117	RFD			BLACK	366
369 VACUUM SOLENOID TO TERM. SW.	224	DK GREEN				367
371 BLOWER MOTOR RELAY TO MOTION	105	BROWN			WHITE	369
372 MOVABLE STEERING COLUMN SOLENOID FEED	129	PINK				371
379 TURN SIGNAL SWITCH TO RH CORNERING LAMP	221	YELLOW				375
380 TURN SIGNAL SWITCH TO LH CORNERING LAMP	109	BROWN				379
381 MOVABLE STEERING COLUMN SOLENOID TO COURTESY LAMP SWITC	47	PURPLE	YELLOW			380
383 EMERGENCY WARNING FLASHER FEED	26	ORANGE	WHITE			381
385 FLASHER TO EMERGENCY WARNING SWITCH	123	RFD			WHITE	383
387 READING LAMP SWITCH TO READING LAMP (LH)	114	WHITE			RED	385
394 HEATER BLOWER SWITCH FEED	33	LT GREEN				387
400 SAFETY RELAY LOAD TERM. TO WIND. REG. SW. FEED	259	LT BLUE			BLACK	399
401 LIMIT SW. TO BACK WINDOW REG. MOTOR	73	GRAY	BLACK			400
402 WINDOW REG SW TO BACK WINDOW REG MOTOR	74	GRAY	RED			401
403 WINDOW REG. SW. TO WIND. REG. MOTOR	78	GRAY	WHITE			402
404 WINDOW REG. SW. TO BACK WIND. SW.	86	PURPLE	LT GREEN			403
405 WINDOW REG. SW. TO BACK WIND. SW.	87	PURPLE	LT BLUE			404
406 WINDOW REG. SW. TO BACK WIND. AUX. SW.	90	TAN				405

407 WINDOW REG. SW. REAR TO LIMIT SW.	91	TAN	BLACK			407
408 WINDOW REG. SW. FRONT TO LIMIT SW.	92	TAN	RED			408
409 PRESSURE SWITCH TO KEY SWITCH	193	TAN			BLACK	409
442 SEQUENTIAL LH REAR INBOARD TURN SIGNAL LAMP	36	LT GREEN	ORANGE			442
443 SEQUENTIAL LH REAR CENTER TURN SIGNAL LAMP	35	LT GREEN	RED			443
444 SEQUENTIAL LH REAR OUTBOARD TURN SIGNAL LAMP	34	LT GREEN	BLACK			444
445 SEQUENTIAL RH REAR INBOARD TURN SIGNAL LAMP	29	ORANGE	LT BLUE			445
446 SEQUENTIAL RH REAR CENTER TURN SIGNAL LAMP	28	ORANGE	WHITE			446
447 SEQUENTIAL RH REAR OUTBOARD TURN SIGNAL LAMP	22	ORANGE	RED			447
450 SEAT BELT WARNING INDICATOR LAMP FEED	67	DK GREEN	LT GREEN			450
454 IGN. SW. COIL TERM. TO CIRCUIT BREAKER	17	RED	LT GREEN			454
455 CIRCUIT BREAKER TO FUEL VALVE	149	LT GREEN			YELLOW	455
458 TURN SIGNAL SWITCH TO INDICATOR RELAY	130	ORANGE	LT GREEN		BLACK	458
459 INDICATOR RELAY TO FLASHER	24	ORANGE	LT GREEN			459
460 HORN SWITCH FEED	222	YELLOW			LT BLUE	460
464 SEAT BELT WARNING SWITCH FEED	33	LT GREEN				464
475 STOP/ALARM SW. TO STOP/ALARM RELAY (CCFL TERM)	80	PINK	BLACK			474
476 FLASHER SW. TO FLASHER LAMP	145	DK GREEN	WHITE			475
478 IGNITION SWITCH ACCY. TERM. TO DECK LID OPEN WARNING LAMP	93	TAN	ORANGE			478
486 DECK LID OPEN WARNING LAMP TO DECK LID OPEN SWITCH	104	BROWN			PINK	485
497 READING LAMP SWITCH TO READING LAMP	192	BROWN			WHITE	486
498 TURN SIGNAL RELAY TO TURN SIGNAL FLASHER	81	PINK	WHITE			487
500 HEADLAMP DIMMER SWITCH TO HEADLAMP DIMMER RELAY	114	TAN			LT GREEN	494
502 HEADLAMP DIMMER RELAY TO HEADLAMP DIMMER	46	PURPLE				500
503 HEADLAMP DIMMER RELAY TO FUSE HOLDER	49	GRAY				502
504 FUSE HOLDER TO HEADLAMP DIMMER AMPLIFIER	40	LT BLUE				503
507 HEADLAMP DIMMER SWITCH TO HEADLAMP DIMMER AMP. IFIFER	155	DK BLUE				504
508 AMPLIFIER TO RH/OSTAT	1	BLACK				505
509 AIR COND. CONDENSER THERMAL SWITCH FEED	50	WHITE				506
511 STOP/ALARM SW. TO TURN SIGNAL SW.	33	LT GREEN	YELLOW			509
512 RESISTOR TO BLOWER MOTOR (HT)	22	ORANGE	RED			512
517 CIRCUIT BREAKER (LOAD TERM) TO CONTROL SW. (BATT. TERM)	6	BLACK	WHITE			517
519 GLOW PLUG SW. TO LAMP (FEED)	50	WHITE				519
520 SEAT BELT WARNING LAMP TO WARNING LAMP SWITCH	166	PURPLE				520
522 CIRCUIT BREAKER TO MARKER LAMP SW. FEED	6	BLACK			WHITE	526
524 HEADLAMP DIMMER SWITCH OVERRIDE TO RH/OSTAT	13	RED				527
530 BLOWER MOTOR RELAY (LOAD TERM) TO BLOWER MOTOR	184	BLACK				536
562 ALTERNATOR RELAY TO ALTERNATOR REGULATOR	33	LT GREEN			LT GREEN	536
587 WINDSHIELD WIPER SWITCH TO INTERMITTENT GOVERNOR FED	103	BLACK				568
588 WINDSHIELD WIPER SWITCH TO INTERMITTENT GOVERNOR GROUND	20	ORANGE				589
591 INTERMITTENT GOVERNOR TO W/S WIPER SWITCH	72	DK BLUE	WHITE			590
592 SPEED CONTROL RELAY TO SPEED REGULATOR	2	BLACK	ORANGE			591
593 SPEED CONTROL ACTUATOR TO CUTOUT RELAY	161	LT BLUE				592
594 PRIMER SW. TO OIL PRESSURE SAFETY SWITCH	27	YELLOW				593
595 COIL TERM. OF TGN. SW. TO OIL PRESSURE SAFETY SWITCH	182	BLACK			WHITE	594
598 COIL TERM. OF TGN. SW. TO FUEL PUMP PRIMER SWITCH	13	RFD				596
601 BRAKE SKID CONTROL MODULE FEED	82	PINK	YELLOW			597
602 COIL TERM. OF TGN. SW. TO BRAKE SKID CONTROL MODULE	58	LT BLUE	PINK			598
604 SKID CONTROL MODULE TO RH WHEEL SENSOR HI	121	RFD			LT GREEN	601
625 OPEN DOOR WARNING LAMP FEED	131	ORANGE			RED	604
627 OPEN DOOR WARNING LAMP TO OPEN DOOR WARNING SWITCH	126	PINK	YELLOW			626
632 IGN. SW. COIL TERM. TO OIL TEMP. WARNING LAMP	99	BLACK			WHITE	627
633 TGN. SW. TO OIL TEMP. WARNING RELAY	1	BLACK				632
634 OIL TEMP. WARNING RELAY TO OIL TEMP. WARNING LAMP	13	RED				633
635 OIL TEMP. WARNING LAMP TO OIL TEMP. WARNING SWITCH	40	LT BLUE				634
640 WARNING LAMPS FEED	33	LT GREEN				635
642 WATER TEMP. WARNING LAMP TO WATER TEMP. SW. (COLD)	120	RED			WHITE	640
	54	WHITE	LT GREEN			642

CAR STANDARD WIRE COLOR CODE CHART


(3 OF 3)

CIRCUITS IN CURRENT USE


CIRCUIT	COLOR NO.	BASE	STRIPE	HASH	DOT	CIRCUIT
647 WATER TEMP. WARNING LAMP TO WATER TEMP. SWITCH (HOT)	200	RED			BLACK	647
648 TACHOMETER FEED	205	RED			LT BLUE	648
654 ALT. SHUNT TO AMMETER	30	YELLOW	LT GREEN			654
655 STARTING MOTOR RELAY SHUNT TO AMMETER	15	RED	ORANGE			655
656 AIR COND. CONTROL SW. TO FRESH-AIR RECIRC. DOOR SOLENOID	224	YELLOW			LT GREEN	660
611 SPEED REG. SW. "ON" POSITION TO ON & OFF RELAY	59	WHITE				671
672 SELECTOR SW. TO LEFT HAND PUMP MOTOR	109	BROWN		WHITE		672
673 SELECTOR SW. TO LEFT FUEL GAGE	33	LT GREEN				673
674 SELECTOR SW. TO RIGHT HAND PUMP MOTOR	12	BROWN	WHITE			674
675 SELECTOR SW. TO RIGHT FUEL GAGE	35	LT GREEN	RED			675
676 F/L SW. "H" TERM. TO TRACTOR-TRAILER RELAY "F" TERM.	187	BROWN			PINK	683
684 TRACTOR-TRAILER RELAY "F" TERM. TO MARKER LAMP SW.	6	BLACK	WHITE			684
685 HEAD LP TIME DELAY CONTROL RELAY TO CIR. BREAKER	75	GRAY	ORANGE			686
687 ACC FEED	76	GRAY	YELLOW			687
688 LIGHT BACKLITE SW TO TIME DELAY RELAY	21	GRAY	LT BLUE			688
689 SPEED REG. SW. "OFF" POSITION TO CM & OFF RELAY	21	ORANGE	BLACK			697
745 ANTENNA SWITCH TO POWER ANTENNA (LP)	113	RED			PINK	745
746 ANTENNA SWITCH TO POWER ANTENNA (DOWN)	66	DK GREEN	YELLOW			746
751 BLOWER MOTOR SPEED CONTROLLER TO RESISTOR #3 (MED.)	155	DK BLUE		WHITE		751
752 BLOWER MOTOR SPEED CONTROLLER TO RESISTOR #2 (MED.)	220	YELLOW			RED	752
753 HEATER & A/C CONTROL SW. TO BLOWER RELAY SW.	29	YELLOW	RED			753
754 BLOWER MOTOR SPEED CONTROLLER TO RESISTOR #1 (MED.)	151	LT GREEN	WHITE			754
755 BLOWER MOTOR SWITCH RELAY TO RESISTOR (LOW SPEED)	12	BROWN	WHITE			755
756 HEATER AND A/C CONTROL SW. (HI-NORM) TO RESISTOR (LOW RANGE)	201	RED			PINK	756
757 HEATER & A/C CONTROL SW. (HI-NORM) TO BLOWER MOTOR SW. RELAY	19	RED	WHITE			757
758 HEATER AND A/C CONTROL SW. (LO-NORM) TO RESISTOR (LOW RANGE)	249	PURPLE			WHITE	758
761 BLOWER MOTOR RELAY TO ENG. WATER TEMP. SWITCH (COLD)	54	WHITE	LT GREEN			761
765 HEATER AND A/C CONTROL SW. TO REHEAT & A/C FEED	149	LT GREEN	YELLOW			765
766 HEATER AND A/C CONTROL SW. (DE-FOG) TO INLET AIR CONTROL SOLENOID	204	RED			LT GREEN	766
767 AMBIENT SENSOR TO INST. PANEL THERMISTOR	43	LT BLUE	ORANGE			767
768 REFERENCE SENSOR TO HEAT DUCT THERMISTOR	149	LT GREEN	YELLOW			768
769 HEATER & A/C CONTROL SW. (HI & LO NORM) TO BLOWER MTR. SW. RELAY	160	LT BLUE	YELLOW			769
773 HEATER & A/C CONTROL SW. (TEMP. SELECTOR) TO REHEAT AMPL.	141	DK GREEN	WHITE			773
775 HEATER & A/C CONTROL SW. (DEFOG) TO DEFROST CONT. SOLENOID	84	WHITE	PINK			775
776 CLIMATE CONTROL BOX TO HIGH BLOWER RELAY	213	ORANGE			BLACK	776
780 ENGINE ALARM RELAY(OIL PRESS.) "F" TERM. TO "A" TERM. IGN. SW.	13	RED				780
784 FUEL PUMP SAFETY SWITCH TO FUEL PUMP MOTOR	124	PINK		BLACK		784
786 REHEAT AMPLIFIER TO HEAT DUCT THERMISTOR	202	RED		ORANGE		788
790 HEATER AND A/C CONTROL SW. TO INST. PANEL THERMISTOR	53	WHITE	ORANGE			790
797 BATTERY FEED TO STEREOF.	38	LT GREEN	PURPLE			797
804 SPEAKER VOICE COIL FEED-FRONT (LEFT CHANNEL)	133	ORANGE		LT GREEN		804
805 SPEAKER VOICE COIL FEED-FRONT (RIGHT CHANNEL)	178	WHITE		LT GREEN		805
806 SPEAKER VOICE COIL FEED-REAR (RIGHT CHANNEL)	84	PINK	LT BLUE			806
807 SPEAKER VOICE COIL FEED-REAR (LEFT CHANNEL)	83	PINK	LT GREEN			807
808 SELECTOR SWITCH TO FULL TANK SOLENOID VALVE	8	BROWN	ORANGE			808
810 STOPLAMP SW. TO STOPLAMP	121	RED		LT GREEN		810
817 INDICATOR RELAY TO RH TURN LAMP	115	TAN	LT BLUE			817
818 INDICATOR RELAY TO LH TURN LAMP	116	TAN	WHITE			818
822 SPEAKER VOICE COIL FEED	184	BLACK		LT GREEN		822
823 RADIO TO FADE CONTROL	33	LT GREEN		ORANGE		823
848 BALLAST RESISTOR "E" TERM. TO TRANSISTOR UNIT "E" TERM.	202	RED		WHITE		850
850 BALLAST RESISTOR COIL TERM. TO IGN. COIL BATT. TERM.	244	LT BLUE				851
851 TRANSISTOR UNIT "B" TERM. TO DISTRIBUTOR	33	LT GREEN				851
852 TRANSISTOR UNIT "C" TERM. TO BALLAST RESISTOR "E" TERM.	154	LT BLUE		PINK		852
853 COIL TERM. IGN. SW. TO BALLAST RESISTOR "E" TERM.	119	RED		ORANGE		853
854 C/S. RELAY TO STARTER SOLENOID "I" TERM.	106	BROWN		YELLOW		854
858 MAKE READY SWITCH TO BRAKE PEDAL PAD SWITCH	125	PINK		ORANGE		858
859 BRAKE PEDAL PAD SWITCH TO CONTROL RELAY TERM. #4	27	YELLOW				859
860 MAKE READY SWITCH TO SET SPEED SWITCH	48	PURPLE	WHITE			860
861 RETARD SWITCH TO CONTROL RELAY TERM. #7	45	LT BLUE	WHITE			861

863 BRAKE SWITCH TO HOLDING RELAY	3	BLACK	YELLOW			863
869 RETARD VALVE TO CONTROL RELAY TERM. #1	37	LT GREEN	YELLOW			869
*870 EMERGENCY STOP LAMP SWITCH TO TRACTOR-TRAILER PLUG	13	RED			870+	883
883 AIR COND. CONTROL RELAY FEED	123	PINK		LT BLUE		883
904 (COIL) ON (ACCY.) TERM. OF IGN. SW. TO ALT. REG. (IGN. TERM.)	35	LT GREEN	RED			904
914 SPEED REGULATOR SWITCH FEED	65	DK GREEN	ORANGE			934
917 VENT SWITCH TO BLOWER MOTOR LO	127	PINK		LT GREEN		937
920 BRAKE SW. TO SPEED CONTROL REG.	177	WHITE		YELLOW		980
923 SPEED CONTROL SW. TO SPEED REG. SCOLENOID	46	PURPLE				923
924 HOLDING RELAY TO SPEED CONTROL SW. FEED	13	RED				924
925 SPEED CONTROL SW. TO SPEED REG. COUPLING COIL	53	WHITE	ORANGE			925
934 FWTSSSTIN SPEED SENSOR TO MODULATOR CONTROL	97	TAN	WHITE			934
939 MODULATOR TO THERMO. SW.	110	TAN		BLACK		939
941 WASHER PUMP MOTOR FEED	6	BLACK	WHITE			941
943 TRACTOR TRAILER RELAY "B" FEED	144	DK GREEN		PURPLE		943
946 REAR WASHER PUMP FEED	164	PURPLE		LT GREEN		946
950 WASHER CONTROL SWITCH FEED	51	WHITE	BLACK			950
955 W/SHIELD WIPER MOTOR ARM RH TO W/S WIPER SWITCH	15	RED	ORANGE			955
956 W/SHIELD WIPER SW. TO W/SHIELD WIPER MOTOR FIELD RH	36	LT GREEN	ORANGE			956
960 AUX. HEATER SW. TO SWITCH	203	RED			YELLOW	960
962 DIFF. TEMP. SW. TO FRONT DIFFERENTIAL	204	RED		LT GREEN		962
966 DIFF. TEMP. TO REAR DIFFERENTIAL	143	DK GREEN		BLACK		963
972 TRANSLATION TEMPERATURE LAMP INDICATOR FEED	117	RED				975
976 FUSE PANEL TO FUEL GAUGE INDICATOR	184	BLACK	WHITE	LT GREEN		976
977 BRAKE WARNING SWITCH TO INDICATOR LAMP	43	PURPLE	WHITE			977
978 SEAT REGULATOR SWITCH TO FRONT MOTOR (LH)	31	YELLOW	LT BLUE			978
979 SEAT REGULATOR SWITCH TO FRONT MOTOR (RH)	18	RED	LT BLUE			979
980 SEAT REGULATOR SWITCH TO HORIZ. MOTOR (LH)	32	YELLOW	WHITE			980
981 SEAT REGULATOR SWITCH TO HORIZ. MOTOR (RH)	19	RED	WHITE			981
982 SEAT REGULATOR SWITCH TO REAR MOTOR (LH)	30	YELLOW	LT GREEN			982
983 SEAT REGULATOR SWITCH TO REAR MOTOR (RH)	17	RED	LT GREEN			983
984 SEAT REGULATOR SWITCH TO FRONT MOTOR (RH)	222	YELLOW		LT BLUE		984
985 SEAT REGULATOR SWITCH TO FRONT MOTOR (RH)	205	RED		LT BLUE		985
986 SEAT REGULATOR SWITCH TO HORIZ. MOTOR (RH)	223	YELLOW		WHITE		986
987 SEAT REGULATOR SWITCH TO HORIZ. MOTOR (RH)	206	RED		WHITE		987
988 SEAT REGULATOR SWITCH TO REAR MOTOR (RH)	221	YELLOW		LT GREEN		988
989 SEAT REGULATOR SWITCH TO REAR MOTOR (RH)	204	RED		LT GREEN		989
993 INTERMITTENT GOVERNOR TO WINDSHIELD WIPER SWITCH	12	BROWN	WHITE			993








CIRCUIT SYMBOLS




SWITCHES




RELAYS





N.O. - NORMALLY OPEN
 N.C. - NORMALLY CLOSED
 S.P.S.T. - SINGLE POLE, SINGLE THROW
 D.P.S.T. - DOUBLE POLE, SINGLE THROW
 S.P.D.T. - SINGLE POLE, DOUBLE THROW
 D.P.D.T. - DOUBLE POLE, DOUBLE THROW




LAMPS





CONNECTORS





FEMALE ← MALE






FEMALE



MOTORS




GAUGES




1971 MUSTANG AND COUGAR ELECTRICAL DRAWINGS

SECTION 2 INDEX


	PICTORIAL	SCHEMATIC		PICTORIAL	SCHEMATIC		PICTORIAL	SCHEMATIC
AIR CONDITIONER			GAUGES			POWER SEAT		
Mustang & Cougar	2-E5 2-E28	Mustang	2-E5 2-E11	Cougar		2-E25
CHARGING			Cougar	2-E5 2-E13	POWER WINDOWS		
Mustang	2-E2 2-E10 & 11	Cougar XR7	2-E5 2-E14	Mustang & Cougar	2-E4 2-E32
Cougar	2-E3 2-E10 & 11	HEADLAMP "ON" WARNING BUZZER	2-E29	RADIO AND STEREO TAPE	Mustang & Cougar	2-E4 & 5 2-E31
Cougar XR7	2-E3 2-E12 & 13	HEATED BACKLITE		SEAT BACK LATCH		 2-E7 & 8
CIGAR LIGHTER			Mustang	2-E6	SEAT BELT REMINDER LIGHTS	Mustang & Cougar	2-E2 & 3 E9 & E13
Mustang	2-E2 2-E22	Cougar	2-E33	STARTING	Mustang	2-E2 2-E11
Cougar	2-E3 2-E22	HEATER AND DEFROSTER		Cougar	2-E3 2-E12	
CLOCK			Mustang & Cougar	2-E2 & 3	Cougar XR-7	2-E3 2-E13	
Mustang	2-E5 2-E22	HORNS		TACHOMETER	Mustang & Cougar	2-E5 2-E11 & 13
Cougar	2-E4 2-E23	Mustang & Cougar	2-E2 & 3	TURN SIGNALS	Mustang	2-E2 2-E16 & 17
CONVENIENCE SYSTEMS			KEY WARNING BUZZER		Cougar	2-E3 2-E20 & 21	
Mustang	2-E8		IGNITION		WINDSHIELD WIPERS AND WASHERS	Mustang & Cougar	2-E2 & 3 2-E25
Cougar	2-E14		Mustang	2-E2	Mustang & Cougar (Intermittent)	Mustang & Cougar	2-E2	
CONVERTIBLE TOP			Cougar	2-E3				
Mustang & Cougar	2-E2 & 3 2-E19	Cougar XR7	2-E3				
EMISSION CONTROL			INTERIOR LIGHTS					
Mustang 6 Cyl. Auto. Trans.	2-E34		Mustang	2-E2				
EXTERIOR LIGHTS			Cougar	2-E3				
Mustang	2-E2 2-E16 & 17	Cougar	2-E3				
Cougar	2-E3 2-E18 & 20	Cougar XR7	2-E3				
Mach I	2-E15		PARKING BRAKE WARNING LIGHT	2-E9 & 13				




MUSTANG OVERALL VIEW PICTORIAL




MUSTANG-COUGAR AM RADIO & FRONT SPEAKER



COUGAR-ENGINE COMPARTMENT LAMP




MUSTANG AND COUGAR PICTORIALS




COUGAR LOW FUEL WARNING & DOOR AJAR WARNING


MUSTANG-COUgar
RADIO RECEIVER (AM) STEREO TAPE PLAYER




MUSTANG-COUgar AIR CONDITIONER CIRCUIT



MUSTANG-COUgar MAPLAMP CIRCUIT




MUSTANG AND COUGAR PICTORIALS



MUSTANG HEATED BACKLITE

2-E6
8-1-70



Source Document
Ford Publication Form 7795P-71

1971

COURSE 13003 and 1703

WIRING and VACUUM DIAGRAMS



SERVICE
TRAINING

FORM 7795P-71

1971 VACUUM SYSTEMS INDEX

FORD-MERCURY-METEOR VACUUM SYSTEM

INCLUDES FORCED VENT SYSTEM	V-2
INCLUDES MANUAL AIR CONDITIONER	V-3
INCLUDES AUTOMATIC TEMPERATURE CONTROL	V-4

LINCOLN CONTINENTAL VACUUM SYSTEM	V-5
---	-----

MAVERICK-COMET VACUUM SYSTEM	V-6
------------------------------------	-----

MUSTANG-COUGAR VACUUM SYSTEM	V-7
------------------------------------	-----

PINTO VACUUM SYSTEM	V-8
---------------------------	-----

THUNDERBIRD-MARK III VACUUM SYSTEM	V-9
--	-----

TORINO-MONTEGO VACUUM SYSTEM	V-10
------------------------------------	------


HOW TO USE THE VACUUM DIAGRAMS

IF IT IS A FORD CAR LINE VACUUM SYSTEM, THE TECHNICIAN WILL FIND A PAGE FOR THE TOTAL SCHEMATIC SYSTEM AS WELL AS A LISTING FOR A SCHEMATIC AND PICTORIAL OF EACH SUBSYSTEM ON EACH SECTION INDEX PAGE. IT IS RECOMMENDED THAT THE TECHNICIAN FIRST TURN TO THE TOTAL SYSTEMS SCHEMATIC TO DETERMINE IF THERE ARE ANY BRANCH SYSTEMS OPERATING FROM THE SAME SOURCE. THIS WILL ASSIST IN LOCATING SYSTEM TROUBLES. HE WILL THEN BE ABLE TO TURN TO A PAGE TO FIND DETAILED INFORMATION ON A PARTICULAR SYSTEM. IN TRACING VACUUM SYSTEMS, IT IS RECOMMENDED THAT A CIRCUIT BE TRACED FROM ITS CONTROL UNIT TO ITS SOURCE OF VACUUM, AND THEN FROM THE CONTROL UNIT TO THE OPERATING UNIT, NOTING POINTS OF POSSIBLE MALFUNCTION AND ACCESSIBILITY.

THE VACUUM SYMBOLS AND THEIR MEANINGS ARE NOTED ON EACH DIVIDER PAGE TO PROVIDE A CLEAR UNDERSTANDING OF THE DIAGRAMS.

VACUUM

CIRCUIT SYMBOLS



VACUUM MOTOR OR RESERVOIR



RESERVOIR AND
CHECK VALVE




INTAKE MANIFOLD FITTING




NIPPLE ON A MOTOR



VACUUM CONTROL



T OR CAP (NOT OPEN)



OR DUAL VACUUM
MOTOR



GROUP CONNECTOR




TEE CONNECTOR



HOSE CLAMP



VACUUM DISTRIBUTOR



DASH PANEL
GROMMET




OR VACUUM LINE
CROSSOVER



CONNECTOR



CHECK VALVE



MUSTANG-COUGAR VACUUM SYSTEMS

1971 CAR SHOP MANUAL

Source Document

Includes all Five Volumes:

Volume I - Chassis

Volume II - Engine

Volume III - Electric

Volume IV - Body

Volume V - Pre-Delivery



MAVERICK

TORINO

MUSTANG

FORD

THUNDERBIRD

MONTEGO

COUGAR

COMET

METEOR

MERCURY

LINCOLN

CONTINENTAL

CONTINENTAL MARK III

GROUP INDEX

IDENTIFICATION CODES	10
WHEELS and TIRES	11
BRAKES	12
STEERING	13
SUSPENSION	14
DRIVING STAFTS	15

VOLUME ONE

CLUTCH and MANUAL TRANSMISSION	16
AUTOMATIC TRANSMISSION	17

IDENTIFICATION CODES	20
----------------------------	----

GASOLINE ENGINES	21
------------------------	----

IGNITION SYSTEM	23
-----------------------	----

FUEL SYSTEM	24
-------------------	----

EXHAUST SYSTEM	26
----------------------	----

COOLING SYSTEM	27
----------------------	----

STARTING SYSTEM	28
-----------------------	----

VOLUME TWO

VOLUME THREE ELECTRICAL

IDENTIFICATION CODES	40
----------------------------	----

SEATS	41
-------------	----

WINDOW GLASS and MECHANISMS	42
-----------------------------------	----

STATIONARY WINDOW GLASS	43
-------------------------------	----

DOORS, HOOD, LUGGAGE COMPARTMENT and	
--------------------------------------	--

VOLUME FOUR

INTERIOR TRIM	44
---------------------	----

TOPS and EXTERIOR FINISHES	45
----------------------------------	----

BODY SHELL, EXTERIOR TRIM, FRAME AND UNDERBODY	46
--	----

MAINTENANCE and LUBRICATION	47
-----------------------------------	----

MAINTENANCE and LUBRICATION	50
-----------------------------------	----

VOLUME FIVE

IDENTIFICATION CODES **30**

CHARGING SYSTEM **31**

LIGHTING SYSTEM **32**

INSTRUMENTS, CLUSTERS and CONTROLS **33**

MAIN WIRING HARNESES and CIRCUIT PROTECTION **34**

AUXILIARY EQUIPMENT **35**

VENTILATING HEATING and AIR CONDITIONING **36**

SPEED CONTROL and ANTI-SKID CONTROL **37**



FOREWORD

This manual is divided into five volumes: 1 – Chassis, 2 – Engine, 3 – Electrical, 4 – Body, 5 – Maintenance and Lubrication. These volumes should provide Service Technicians with complete information covering normal service repairs on all 1971 model passenger cars (except Pinto) built by the Ford Companies in the U. S. and Canada. Service procedures for the Pinto are covered in the Pinto Car Shop Manual. As changes in the product occur, this information will be updated by Technical Service Bulletins. When issued, TSB information always supersedes that published herein.

Within each volume, information is grouped by system or component plus "General Service" parts which contain information which is common to several similar components.

The table of contents on the first page of each volume indicates the general content of the book and provides a handy tab locator to make it easy to find the first page of each "Group". That page will contain an index to "Parts" and the first page of each "Part" contains a detailed index which gives page location for each service operation covered. Page numbers are consecutive in each "Part".

To make reference easier, information has been broken down into smaller units so that essentially there is now one "Part" for each component or system. Group numbers indicate the volume in which the group may be found.

Indicates:

42 – 04 – 23
Volume 4 – Group 42 – Part 4 – Page 23

The descriptions and specifications in this manual were in effect at the time this manual was approved for printing. Ford Marketing Corporation reserves the right to discontinue models at any time, or change specifications or design, without notice and without incurring obligation.



SERVICE PUBLICATIONS

Identification Codes


GROUP
30

PART 30-01 Car Identification Codes

OFFICIAL VEHICLE IDENTIFICATION NUMBER

The official Vehicle Identification Number (VIN) for title and regis-

tion purposes is stamped on a metal tab that is riveted to the instrument panel close to the windshield on the driver's side of the car and is visible from outside (Fig. 1).



VEHICLE CERTIFICATION LABEL

The Vehicle Certification Label (V.C. Label) is attached to the rear face of the driver's door. The upper half of the label contains the name of the manufacturer, the month and year of manufacture and the certification statement. The V.C. label also contains the Vehicle Identification Number. This number is also used for Warranty identification of the vehicle. The first number indicates the model year. The letter following the model year number indicates the manufacturing assembly plant. The next two numbers designate the Body Serial Code followed by a letter expressing the Engine Code. The last six digits of the Vehicle Identification Number indicate the Consecutive Unit Number.

The remaining information on the V.C. Label consists of pertinent vehicle identification codes. The BODY code is two numerals and a letter identifying the body style. The COL (color) code is a number or letter (or both) indicating the exterior paint color code. The TRIM code consists of a number-letter combination designating the interior trim. The axle code is a number or letter indicating the rear axle ratio and standard or locking type axles. The TRNS. code is a number or letter indicating the type of transmission, numerals for manual and letters for automatic. The DSO code consisting of two numbers designates the district in which the car was ordered and may appear in conjunction with a Domestic Special Order or Foreign Special Order number when applicable. Ford of Canada DSO codes consist of a letter and a number.

MODEL YEAR CODE

The number 1 designates 1971.

Y 1298-A

FIG. 1 . Vehicle Certification Label and Identification Number

CONSECUTIVE UNIT NUMBER

Starting Serial Numbers—1971

Passenger Cars

100,001—Ford, Torino, Mustang,

Thunderbird, Maverick

500,001—Mercury, Meteor,
Montego, Cougar, Comet800,001—Lincoln Continental &
Continental Mark III**ASSEMBLY PLANT CODES**

Code Letter	
A	Atlanta
B	Oakville (Canada)
E	Mahwah
F	Dearborn
G	Chicago
H	Lorain
J	Los Angeles
K	Kansas City
N	Norfolk
P	Twin Cities
R	San Jose
S	Allen Park
T	Metuchen
U	Louisville
W	Wayne
X	St. Thomas
Y	Wixom

CY-1299-A

DATE CODES

A number signifying the date precedes the month code letter. A second-year code letter will be used if the model exceeds 12 months.

Month	Code First Year	Code Second Year
January	A.....	N
February.....	B.....	P
March.....	C.....	Q
April.....	D.....	R
May.....	E.....	S
June.....	F.....	T
July.....	G.....	U
August.....	H.....	V
September.....	J.....	W
October.....	K.....	X
November.....	L.....	Y
December.....	M.....	Z

DISTRICT CODES (DSO)

Units built on a Domestic Special Order, Foreign Special Order, or other Special orders will have the complete order number in this space. Also to appear in this space is the two-digit code number of the District which ordered the unit. If the unit is a regular production unit, only the District code number will appear.

FORD

Code	District
11	Boston
13	New York
15	Newark
16	Philadelphia
17	Washington
21	Atlanta
22	Charlotte
24	Jacksonville
25	Richmond
28	Louisville
32	Cleveland
33	Detroit
35	Lansing
37	Buffalo
38	Pittsburgh
41	Chicago
43	Milwaukee
44	Twin Cities
46	Indianapolis
47	Cincinnati
51	Denver
53	Kansas City
54	Omaha
55	St. Louis
56	Davenport
61	Dallas
62	Houston
63	Memphis
64	New Orleans
65	Oklahoma City
71	Los Angeles
72	San Jose
73	Salt Lake City
74	Seattle
75	Phoenix
83	Government
84	Home Office Reserve
85	American Red Cross
89	Transportation Services
90-99	Export

LINCOLN-MERCURY

Code	District
11	Boston
15	New York
16	Philadelphia
17	Washington
21	Atlanta
22	Dallas
23	Jacksonville
26	Memphis
31	Buffalo
32	Cincinnati
33	Cleveland
34	Detroit
41	Chicago
42	St. Louis
46	Twin Cities
51	Denver
52	Los Angeles
53	Oakland
54	Seattle
84	Home Office Reserve
90	Export

FORD OF CANADA

Code	District
B1.....	Central
B2.....	Eastern
B3.....	Atlantic
11 thru 17	Export
B4.....	Midwestern
B6.....	Western
B7.....	Pacific

Note: Canadian Lincoln-Mercury units use prefix "A" in place of "B".

CK2456-B

GROUP
31

Charging System

PART	PAGE	PART	PAGE
PART 31-01		PART 31-21	
Charging System General Service ..	31-01-01	Leece-Neville Alternators	31-21-01
PART 31-02		PART 31-40	
Batteries	31-02-01	Autolite Alternator Regulator	31-40-01
PART 31-10		PART 31-42	
Autolite Alternators	31-10-01	Leece-Neville Alternator Regulator	31-42-01

PART 31-01 Charging System General Service

COMPONENT INDEX	PAGE	COMPONENT INDEX	PAGE
DESCRIPTION AND OPERATION	31-01-01	TESTING	31-01-01
Fuse Link - Charging System	31-01-01	Charging System	31-01-01
REMOVAL AND INSTALLATION	31-01-02	Fuse Link Continuity Test	31-01-02
Fuse Link Replacement	31-01-02		

1 DESCRIPTION AND OPERATION

CHARGING SYSTEM FUSE LINK

The fuse link is a short length of insulated wire integral with the engine compartment wiring harness. It is several wire gages smaller than the circuit that it protects. Production fuse links are black. Service fuse links are green or black depending on usage. All

fuse links have the words FUSE LINK printed on the insulation. Fig. 1 shows fuse link installations.

The fuse link burns out, thus protecting the alternator or wiring, when heavy current flows, such as when a booster battery is connected incorrectly or a short to ground occurs

in the wiring harness.

A burned out link may have bare wire ends protruding from the insulation, or it may only have expanded or bubbled insulation with illegible identification. If it is hard to determine if the link is burned out, perform a continuity test.




FIG. 1 Fuse Link Installation

2 TESTING

CHARGING SYSTEM

The alternator and alternator regulator are precision built units, and the equipment to make tests in the charging system must be accurate. Voltmeters must be accurate within 0.1 (one tenth) volt within the range of 12 to 16 volts and ammeters within one ampere at 30 to 65 amperes to permit correct measurement of the alternator and regulator. The meters on Rotunda equipment should be calibrated once a year and the date of calibration stamped on the meter face. It is recommended that this practice be followed by technicians with other than approved equipment in order to maintain their meters at acceptable accuracy.

Certain tests outlined in this section are illustrated in schematic and in pictorial form. The schematic illustrates the internal connections of the Rotunda equipment so that these connections can be duplicated when this equipment is not available. The

Rotunda test units are a combination of accepted instruments incorporated into a single unit. The various circuits involved in the tests can be selected by means of switches without the necessity of changing connections. This reduces the time required to test units and circuits on the vehicle.

Where applicable, the tests are divided into On The Vehicle and On The Test Bench procedures. Either procedure can be followed depending on the equipment available for the tests.

Trouble shooting or diagnosis is required before actual repairs can be made in the electrical system. Even where an obvious fault makes the replacement of a unit necessary, you must still find out why the unit failed. The trouble shooting procedures given in the Electrical Systems Diagnosis Manual will aid in making a correct diagnosis. When a trouble is diagnosed correctly, unnecessary repairs are prevented, the time the vehicle is out of service will be decreased, and the

repairs that are made will be permanent.

FUSE LINK CONTINUITY TEST

1. On the Cougar, Mustang, Thunderbird, Lincoln Continental and Continental Mark III, make certain first that the battery is OK, then turn on the headlights or any accessory. If the headlights or accessory do not operate, the fuse link is probably burned out.

2. On the Ford, Mercury, Meteor, Torino, Montego, Maverick and Comet, there are two fuse links (Fig. 1). Use the same procedure as in step 1 to test the fuse link that protects the vehicle equipment.

To test the fuse link that protects the alternator, make certain that the battery is OK then check with a voltmeter for voltage at the BAT terminal of the alternator. No voltage indicates that the fuse link is probably turned out.

4 REMOVAL AND INSTALLATION

FUSE LINK REPLACEMENT

1. Procure the proper service fuse link for the vehicle being repaired (Fig. 1). The two fuse links shown have an eyelet terminal for a 5/16-inch

stud on one end. When the terminal is not required, cut off the fuse link as close to the terminal as possible and strip approximately 3/8-inch of insulation from the cut end.

2. Disconnect the battery ground cable.
3. Disconnect the fuse link and/or fuse link eyelet terminal from the battery terminal of the starter

relay. On the Thunderbird, Lincoln Continental and the Continental Mark III, the fuse link is looped outside of the wire harness behind the point at which the harness is clipped to the right rocker cover above the starter.

4. Cut the fuse link and the

splice(s) from the wire(s) to which it is attached.

5. Splice and solder the new fuse link to the wire(s) from which the old link was cut. Use rosin core solder. Wrap the splice(s) completely with vinyl electricians tape.

6. Securely connect the eyelet terminals (if any) to the battery stud on the starter relay.

7. Install the repaired wiring as before using existing clips if provided.

8. Connect the ground cable to the battery.

PART 31-02 Batteries

COMPONENT INDEX	PAGE	COMPONENT INDEX	PAGE
SPECIFICATIONS	31-02-03	TESTING..... With Rotunda Battery-Starter Tester (Are 16-31)..... With Rotunda Cell Analyzer (SRECA-200).....	31-02-01 31-02-02 31-02-01

1

2 TESTING

Tests are made on a battery to determine the state of charge and also the condition. The ultimate result of these tests is to show that the battery is good, needs recharging, or should be replaced.

If a battery has failed, is low in charge, or requires water frequently, good service demands that the reason for this condition be found. It may be necessary to follow trouble shooting procedures to locate the cause of the

trouble. Refer to the Ford Car and Truck Diagnosis Manual for battery diagnosis procedures.

Hydrogen and oxygen gases are produced during normal battery operation. This gas mixture can explode if flames or sparks are brought near the vent openings of the battery. The sulphuric acid in the battery electrolyte can cause a serious burn if spilled on the skin or spattered in the eyes. It should be flushed away

with large quantities of clear water.

Particular care should be used when connecting a booster battery in order to prevent sparks. Be certain to connect positive terminal to positive terminal and negative terminal to negative terminal.


Before attempting to test a battery, it is important that it be given a thorough visual examination to determine if it has been damaged. The presence of moisture on the outside of the case and/or low electrolyte level in one or more of the cells are indications of possible battery damage.

Autolite batteries have a single one-piece cover which completely seals the top of the battery and the individual cell connectors. This cover must not be pierced with test probes to perform individual cell tests.

TESTS USING THE ROTUNDA CELL ANALYZER (SRECA-200)

The Rotunda Cell Analyzer (SRECA-200) measures the individual cell voltages by inserting probes into the cell openings. Follow the instructions provided with the unit.

A battery can also be tested by determining its ability to deliver current. This may be determined by conducting a Battery Capacity Test. Fig. 1 shows the battery capacity test in outline form.



J 1039-F

FIG. 1 Battery Capacity Test Outline

**TESTS USING THE ROTUNDA
BATTERY—STARTER TESTER ARE
16-31**

Battery Capacity Test

A high rate discharge tester (Rotunda Battery-Starter Tester ARE 16-31) in conjunction with a voltmeter is used for this test.

1. Turn the control knob on the BatteryStarter Tester to the OFF position.

2. Turn the voltmeter selector switch to the 20-volt position.

3. Connect both positive test leads to the positive battery post and both negative test leads to the negative battery post. The voltmeter clips must contact the battery posts and not the high rate discharge tester clips. Unless this is done, the actual battery terminal voltage will not be indicated.

4. Turn the load control knob in a clockwise direction until the ammeter reads three times the ampere hour rating of the battery. (A 45 ampere-hour battery should be tested at 135 amperes load).

5. With the ammeter reading the required load for 15 seconds, note the voltmeter reading. Avoid leaving the high discharge load on the battery for periods longer than 15 seconds.

6. If the voltmeter reading is 9.6 volts or more, the battery has good output capacity and will readily accept a charge, if required. Check the specific gravity. If the specific gravity reading is 1.230 or below, add water if necessary and charge the battery until it is fully charged (Fig. 1). Always disconnect the battery ground cable

Specific Gravity Reading	Charge Rate Amperes	Battery Capacity – Ampere Hours				
		45	55	70	80	85
1.125–1.150 ①	35	65 min.	80 min.	100 min.	115 min.	125 min.
1.150–1.175	35	50 min.	65 min.	80 min.	95 min.	105 min.
1.175–1.200	35	40 min.	50 min.	60 min.	70 min.	75 min.
1.200–1.225	35	30 min.	35 min.	45 min.	50 min.	55 min.
Above 1.225	5	②	②	②	②	②

① If the specific gravity is below 1.125, use the indicated high rate of charge for the 1.125 specific gravity, then charge at 5 amperes until the specific gravity reaches 1.250 at 80° F.

② Charge at 5 ampere rate only until the specific gravity reaches 1.250 at 80° F. At no time during the charging operation should the electrolyte temperature exceed 130° F.

J 1355-C

FIG. 2 Allowable Battery High Rate Charge Time Schedule

when charging the battery.

The battery is fully charged when the cells are all gassing freely and the specific gravity ceases to rise for three successive readings taken at hourly intervals. Additional battery testing will not be necessary after the battery has been properly charged.

7. If the voltage reading obtained during the capacity test is below 9.6 volts, check the specific gravity of each cell.

8. If the difference between any two cells is more than 50 points (0.050), the battery is not satisfactory for service and should be replaced.

9. If the difference between cells is less than 50 points (0.050), the battery should be charged according to the charging schedule in Fig. 2. In some cases the electrolyte level may be

too low to obtain a specific gravity reading. In such cases water should be added until the electrolyte level just covers the ring in the filler well, then charge the battery at 35 amperes for the maximum charging time indicated in Fig. 2 for the capacity of the battery being tested.

10. After the battery has been charged, repeat the capacity test. If the capacity test battery voltage is still less than 9.6 volts, replace the battery. If the voltage is 9.6 volts or more, the battery is satisfactory for service.

11. If the battery is found to be discharged only, check for a loose fan belt, loose electrical connections and charging system performance.

9 SPECIFICATIONS

BATTERIES

Allowable Battery High Rate Charge Time Schedule						
Specific Gravity Reading	Charge Rate Amperes	Battery Capacity—Ampere Hours				
		45	55	70	80	85
1.125–1.150①	35	65 min.	80 min.	100 min.	115 min.	125 min.
1.150–1.175	35	50 min.	65 min.	80 min.	95 min.	105 min.
1.175–1.200	35	40 min.	50 min.	60 min.	70 min.	75 min.
1.200–1.225	35	30 min.	35 min.	45 min.	50 min.	55 min.
Above 1.225	5	②	②	②	②	②

①If the specific gravity is below 1.125, use the indicated high rate of charge for the 1.125 specific gravity, then charge at 5 amperes until the specific gravity reaches 1.250 at 80° F.
 ②Charge at 5 ampere rate only until the specific gravity reaches 1.250 at 80° F.
 At no time during the charging operation should the electrolyte temperature exceed 130° F.

Battery Freezing Temperatures			
Specific Gravity	Freezing Temp	Specific Gravity	Freezing Temp
1.280	–90°F	1.150	+5°F
1.250	–62°F	1.100	+19°F
1.200	–16°F	1.050	+27°F

Battery Ampere Hours	Number Of Plates
45	54
55	66
70	66
80	78

CJ1447-A


1965/72 FORD CAR

FINAL ISSUE

Master Parts and Accessories


Source Document
CATALOG
Ford Publication Form FP-7635-B
Form FP 7635-A & B

Supersends All Previous Issues, Changes and Revisions




May, 1975

FINAL ISSUE



ALTERNATOR (FORD 15 VOLT - 38,42,45,55,60,61 AMP.)
1965/72

- ◆ SERVICED ONLY IN ASSY. - GROUP 10304
- † ALSO SUPPLIED IN 10304 RECTIFIER ASSEMBLY
- % ALSO SUPPLIED IN 10334 REAR HOUSING ASSEMBLY



ALTERNATOR (FORD 15 VOLT - 65 AMP.)
1967/72

† ALSO SUPPLIED IN 10304 RECTIFIER ASSEMBLY
‡ ALSO SUPPLIED IN 10304 RECTIFIER ASSEMBLY
§ ALSO SUPPLIED IN 10347 BRUSH REPAIR KIT
|| ALSO SUPPLIED IN 10B363 COVER & BRUSH ASSEMBLY




READY REFERENCE

13001

HOW TO READ WIRING DIAGRAMS



VOL 68 S7 L2A



HOW TO READ WIRING DIAGRAMS

COURSE 13001 • VOL. 68 S7 L2A

TABLE OF CONTENTS

	Page
INTRODUCTION	
A LOGICAL APPROACH TO ELECTRICAL DIAGNOSIS	1
Like reading a road map	2
How wires are numbered and color-coded	2
CIRCUIT – A COMPLETE ELECTRICAL PATH BETWEEN TWO POINTS	5
2-wire circuit	6
Single wire circuit	6
Ground connections	7
OPEN CIRCUITS	8
Shorts	9
Grounded circuit	9
Series and parallel open circuits	10
BREAKS IN PARALLEL CIRCUITS	11
Common points	14
Splices	15
Fuses and circuit breakers	17
Quick disconnects	18
Male and female elements	20
Types of quick disconnects	22
HINTS FOR TRACING WIRES THROUGH A DRAWING	23
Curve directions	23
Common points	24
Switches	25
Relays	26
Assemblies	28
Locating the assembly	29
Finding the wire	30
SUMMARY	31

The descriptions, testing procedures, and specifications in this handbook were in effect at the time the handbook was approved for printing. Ford Motor Company reserves the right to discontinue models at any time, or change specifications, design, or testing procedures without notice and without incurring obligations.

NATIONAL SERVICE OFFICE
FORD DIVISION



FIRST PRINTING – JANUARY, 1968

© 1968 FORD MOTOR COMPANY
DEARBORN, MICHIGAN

INTRODUCTION

The Why and Wherefore of Wiring Diagrams

To the uninformed, a wiring diagram — or a wiring assembly — looks like it might take a genius to figure out.

Not so — as you'll find out when you get better acquainted with these subjects.

There're as understandable and logical as a road map and road markers, when you're finding your way on a cross-country drive.

The ability to read a wiring diagram and relate it to a vehicle's wiring system is, of course, an essential part of a modern service technician's skill. And it's growing in relative importance, too, due to owner's increasing demands for the comforts and conveniences supplied by electrically-operated options and accessories. This opens up greater opportunities, for the forward-looking technician.

The Purpose of this Booklet . . .

. . . is to acquaint you with the systems by which electrical circuits are traced on vehicles. Specifically, it is designed to help you acquire the ability to make your own power checks, quickly and accurately.

Scope of the Booklet

Basically, this is a printed version of the film, "How to Read a Wiring Diagram." It is in no sense a manual of the shop methods by which electrical repairs are made.

It *can* be a helpful guide that can introduce you to the principles of wiring diagrams and vehicle wiring. As you gain experience in reading wiring diagrams, you'll accumulate your own know-how in this important skill. When it becomes "second nature" to you, these pages will have served their purpose — and yours.




To show how to read wiring diagrams — and to explain how they can be used to help you troubleshoot problems in the electrical system — is what this booklet is all about. Obviously, these are important subjects.


A LOGICAL APPROACH TO ELECTRICAL DIAGNOSIS




If a customer comes in because his headlights aren't working, you can't just make a snap decision. That's not the *professional way*.



Putting in a new sealed-beam unit *may* be the answer . . . but then again, *it may not*. Snap decisions are *out*. They're *not professional*.



When you go to a doctor, for example, he tries to find out what's *really* wrong with you. He looks beyond the aches and pains you feel, to see what's causing the trouble. We call this, *diagnosis*.



Tre
diagn
doctor
trouble

Buy Now

