

Discover more ebooks! Visit our website: fordshopmanual.com

Motorcraft

1980 / 1989

DEMO

This DEMO contains only a few pages of the entire manual/product.

Not all Bookmarks work on the Demo, but they do on the full version.

Features:

- Searchable text
- Printable pages
- Bookmarked for easy navigation
- High Resolution images
- Zoom to see exact details
- Money back Guarantee
- Transfer to USB flash drive support

Buy Now



CAR PARTS MASTER CATALOG

Ford / Lincoln - Mercury

FORD MOTOR COMPANY

Dearborn, Michigan

**FPS 8470
November 1993**



License #84356800

Copyright © 2022, Forel Publishing Company, LLC, Woodbridge, Virginia

All Rights Reserved. No part of this book may be used or reproduced in any manner whatsoever without written permission of Forel Publishing Company, LLC. For information write to Forel Publishing Company, LLC, Woodbridge, VA 22192

**1980/89 Ford/Lincoln-Mercury
Car Master Parts and Accessories Catalog
EAN: 978-1-60371-107-4
ISBN: 1-60371-107-4**

Forel Publishing Company, LLC
Woodbridge, VA 22192



This publication contains material that is reproduced and distributed under a license from Ford Motor Company. No further reproduction or distribution of the Ford Motor Company material is allowed without the express written permission of Ford Motor Company.

Note from the Publisher

This product was created from the original Ford Motor Company's publication. Every effort has been made to use the original scanned images, however, due to the condition of the material; some pages have been modified to remove imperfections.

Disclaimer

Although every effort was made to ensure the accuracy of this book, no representations or warranties of any kind are made concerning the accuracy, completeness or suitability of the information, either expressed or implied. As a result, the information contained within this book should be used as general information only. The author and Forel Publishing Company, LLC shall have neither liability nor responsibility to any person or entity with respect to any loss or damage caused, or alleged to be caused, directly or indirectly by the information contained in this book. Further, the publisher and author are not engaged in rendering legal or other professional services. If legal, mechanical, electrical, or other expert assistance is required, the services of a competent professional should be sought.

MASTER PARTS AND ACCESSORIES CATALOG

FORM FPS 8470/1-A (Text Only)
 FORD PARTS and SERVICE DIVISION

INDEX

Abbreviations.....	29, 30
Accessory Weight Chart.....	13 thru 26
Attaching Parts (Nuts, Bolts, etc.).....	11
Body Type Codes.....	11
Build Date.....	30
Canadian and U.S. Built Vehicle.....	3
D.S.O.	12
Exhaust Systems Certification.....	4
Footnotes.....	4
Formats.....	4
F.S.O.	12
General Instructions.....	2
How to Order Parts.....	12
How to Use This Catalog.....	2, 3
Identification.....	3
Liquid Measure.....	11
L.P.O.	12
Locator Codes.....	11
Metric to Inches Conversion Chart.....	27, 28
Model Year Application.....	11
Owner Card.....	34
Right Hand & Left Hand Parts.....	3
Soft Trim.....	11
Symbols Used Regularly in Catalog.....	2
Vehicle Catalog Codes.....	2

FORD PART NUMBERING SYSTEM

Body Parts Group Numbering System.....	4
Explanation of the Ford Part Numbering System.....	4
Group Numbers and Related Catalog Sections.....	8, 9, 10
Motorcraft Sales Numbers.....	3
Part Name Index (Body Parts).....	7
Part Name Index (Chassis Parts).....	5, 6
Part Name Index (Soft Trim Parts).....	7

CERTIFICATION LABEL

Air Conditioning.....	49
Assembly Plant Codes.....	35

BODY TYPE CODES

Ford/Lincoln-Mercury.....	42
Calibration Parts List Label.....	51
Color Codes (Exterior Paint).....	48
Diagrams and Instructions.....	30, 31
District Codes.....	52
Engine Assembly Plant Codes.....	52
Engine Codes.....	35
Front-Rear Spring Codes.....	51
Manufacturer Identifier.....	33
Numerical Sequence of Assembly.....	36
Production Effective Dates.....	31
Radio Type Codes.....	49
Rear Axle and Transaxle Ratio Codes.....	50
Restraint System.....	33
Serial Number.....	31

SERIES CODES

Ford/Lincoln-Mercury.....	36
Sun Roof/Moon Roof Codes.....	49
Tape Stripe Color Code.....	49
Transmission Codes.....	50
Trim Codes.....	48
Vehicle Identification Number.....	51
Vinyl Bodyside Mouldings Codes.....	48
Vinyl Roof Top and Color Identification.....	48
Year Codes.....	35

FIESTA VEHICLE IDENTIFICATION PLATE

Diagrams and Instructions.....	53
Vehicle Identification Codes.....	54, 55

MERKUR, SCORPIO VEHICLE IDENTIFICATION PLATE

Diagrams and Instructions.....	56, 57
Vehicle Identification Codes.....	56, 57

SYMBOLS USED REGULARLY IN CATALOG

The following symbols appearing on revised pages are to be interpreted as follows:

- * Indicates Motorcraft Sales Part Number.
- # Indicates some form of identification such as part number, stamping, paint stripes and tags.
- ★ Symbol indicates part is not supplied for service for the following reasons:
 - a. Part is superseded and replaced as indicated in the description column of text.
 - b. Part can be improvised as indicated in the description column of text.
 - c. Due to its function there would be little or no demand.

NOTE 1 — ALWAYS REFER TO THE DESCRIPTION COLUMN OF THE TEXT FOR POSSIBLE SUBSTITUTION OR FOR MATERIAL SPECIFICATIONS AND DIMENSIONS WHICH MAY BE HELPFUL IN OBTAINING THE NON-SERVED PART LOCALLY.

NOTE 2 — * Body # Chassis (THESE SYMBOLS APPLY ONLY TO THE VEHICLE AND RELATED CATALOG CODES SHOWN BELOW)

<u>VEHICLES and RELATED CATALOG CODES</u>		<u>CATALOG CODES and RELATED VEHICLES</u>	
Bobcat	L*, ML#	A, MA	Ford, Mercury
Capri	J	BT	Festiva
Cougar (XR7)	F (XR7)*, MF(XR7)	B, MB	Tempo, Topaz
Cougar (exc. XR7)	F (Exc. XR7)*, MF (Exc. XR7)	C, MC	EXP, LN7
Escort, EXP (1986/)	W	D	Lincoln
EXP (1983/85)	C	DC	Lincoln Continental
Fairmont	P	DT	Lincoln Town Car
Festiva	BT	E, ME	Sable, Taurus
Fiesta	X	F	Mustang
Ford	A	F (Exc. XR7)	Cougar (exc. XR7)
Granada	G	G, MG	Granada, Monarch
Lincoln	D	G, MG	LTD, Marquis
Lincoln Continental	DC	J	Capri
Lincoln Town Car	DT	K	Mark VI, VII
LN7	C*, MC#	L, ML	Pinto, Bobcat
LTD	G	MM	Mercury Tracer (Canada only)
Lynx	W*, MW#	MM	Mercury Tracer (U.S. only)
Mark VI, VII	K	MX	Merkur (X4Ti)
Marquis	G*, MG#	MY	Scorpio
Mercury	A*, MA#	P, MP	Fairmont, Zephyr
Mercury Tracer (Canada only)	MM	S, MF (XR7)	Thunderbird, Cougar (XR7)
Mercury Tracer (U.S. only)	MM	ST	Probe
Merkur (XRTi)	MX	MV	Versailles
Monarch	G*, MG#	W, MW	Escort, Lynx
Mustang	F	X	Fiesta
Pinto	L		
Probe	ST		
Sable	E*, ME#		
Scorpio	MY		
Taurus	E		
Tempo	B		
Topaz	B*, MB#		
Versailles	V*, MV#		
Zephyr	P*, MP#		

GENERAL INSTRUCTIONS

This catalog contains replacement parts and accessories information for model year 1980/ U.S. and Canadian built vehicles noted above. Unique Canadian part numbers and applications have been identified by a symbol and noted below the group title. Unique U.S. part numbers and applications have been identified by a symbol and noted below the group title. Use this Text Catalog in conjunction with the Illustration Catalog Form FPS 8470/1-B.

Refer to the Index on page 1 for a listing of the items appearing in the General Information Section.

HOW TO USE THIS CATALOG

There are three ways of finding part numbers:

1. By Part Name
2. By Illustration
3. By Identification

Should an inquiry be received for a fuel pump for a 1982 Ford or Mercury with a 351 CID engine.

BY PART NAME

- A. Refer to the Chassis Parts Alphabetical Index.
- B. Refer to the alphabetical nomenclature and find the part name "Pump assy. (fuel)". The group number listed is 9350.
- C. Refer to group number 9350 and locate the year 1982 in the "YEAR" column. Find the vehicle catalog code "A" (for Ford or Mercury) in the "MODEL/RESTRICTIONS" column.
- D. The part number shown is EOAZ 9350-C.

HOW TO USE THIS CATALOG - Cont'd

BY ILLUSTRATION

- A. Refer to the Illustration Catalog (Form FPS 8470/1-B) to the divider marked "FUEL".
- B. Refer to the index immediately behind the divider and find the illustration titles for 1982 A (Ford or Mercury).
- C. Under the heading find the "Fuel pump and filter" illustration for the 1982 Ford or Mercury.
- D. Refer to the illustration designated (on page 1 of Illustration Section 90.1) and find the group number for the fuel pump assy. to be 9350.
- E. Refer to group number 9350 in this Text Catalog and locate 1982 in the "YEAR" column. Find the vehicle catalog code "A" (Ford & Mercury) in the "MODEL/RESTRICTIONS" column.
- F. The part number shown is E0AZ 9350-C.

BY IDENTIFICATION

Certain parts and most major assemblies are identified with a part number shown on an attached tag or plate or on the part itself. Reference to identification numbers is made throughout the catalog and cross reference charts are included in some sections to provide immediate knowledge of the service part number when the identification number is known. All identification information other than charts will be preceded by the symbol (#).

IMPORTANT — Identification tags and plates must be retained with the part or assembly with which they are originally supplied.

R.H. and L.H. PARTS

The driver's side is the left hand side of the vehicle and determines whether such parts as fenders, lamps, etc. are right or left hand.

Most Right Hand and Left Hand parts are listed in adjacent columns as shown in the following examples:

YEAR	MODEL/RESTRICTIONS	PART NUMBER		DESCRIPTION		QTY.
81/	A(54,74)	(RH)	E1AZ 5420124-A	(LH)	E1AZ 5420125-B	1

MOTORCRAFT SALES PART NUMBERS

To facilitate the stocking and handling of those service parts which are assigned both service part numbers and Motorcraft Sales Part Numbers, the Motorcraft Sales Part Numbers are preceded by an asterisk (*) and are usually located at the beginning of the description column.

For example, refer to Section 96, group 9D695. The service part number for a carburetor air cleaner crankcase filter assy. used on a 1980 Ford or Mercury with an 8 cyl. 302 engine is D8AZ 9D695-A and the Motorcraft Sales Part Number is *FA-675. In the catalog this item will be shown as D8AZ-9D695-A *FA-675.

YEAR	MODEL/RESTRICTIONS	ENGINE		PART NUMBER	DESCRIPTION	QTY.
		CYL.	C.I.D.			
80	A	8	All	D8AZ 9D695-A	*FA-675	1

CANADIAN/U.S. BUILT VEHICLES

For vehicles licensed and sold in **Canada** use the Part Number indicated for Canada. Example:

83	P -- Canada	6	200	E3BZ 9600-B	D4ZZ 9601-AR *FA-584-R	
----	-------------	---	-----	-------------	---------------------------	--

For vehicles licensed and sold in the **U.S.** use the Part Number indicated exc. Canada. Example:

83	P -- exc. Canada	6	200	E3BZ 9600-A	D4ZZ 9601-AR *FA-584-R	
----	------------------	---	-----	-------------	---------------------------	--

FORMATS

Various formats are used throughout this catalog to coincide with the normal procedure for selecting the affected part numbers. Most areas of the catalog use a format arranged in the order shown below:

Column —

1. Model year
2. Type of vehicle or equipment within a specific model year
3. Complete part number
4. Description, size, etc.
5. Quantity required per vehicle

Formats peculiar to a particular area of the catalog are generally self explanatory. When necessary, instructions are shown at the beginning of the affected group. For instance, the various charts and parts list method of cataloging in the Carburetor Section are explained on Page 1 of Section 95.

EXHAUST SYSTEMS CERTIFICATION

"For their intended application as specified in this catalog, the exhaust system parts and systems listed for sale have been certified to be in compliance with the requirements of the rules of the Florida Department of Environmental Regulation (Chapter 17—18, Part III of the Florida Administrative Code), and the regulations of the California Highway Patrol (Chapter 2, Part 1052) for exhaust system certification."

FOOTNOTES

Various explanations of symbols, codes, etc., which formerly appeared as footnotes at the bottom of the affected pages are now noted immediately below the group title or name of the affected item.

EXPLANATION OF THE FORD PART NUMBERING SYSTEM

For greater convenience this catalog is divided into specific sections; such as brakes, front suspension, engine, transmission, etc. For example, FRONT SUSPENSION appears in Section 30, Transmission in Section 70, REAR AXLE in Section 40, etc. The applicable exploded illustrations are contained in separate sections which are related to the Text Section numbers. For example, REAR AXLE Illustrations appear in Illustration Section 40 of the Illustration Catalog, Form FPS 8470/1—B.

The part number groups, part names and the section numbers under which each is listed are shown on pages 5 thru 10 of the General Information Section.

In numerical listings, expanded group numbers will be considered to follow the same sequence as the regular group numbers from which they are expanded and are arranged in Catalogs as follows:

3538
3C538
3634
3A634

Illustrations contain group numbers only, therefore, it is necessary to refer to the group within this "text" catalog for complete applicable part numbers.

BODY PARTS GROUP NUMBERING SYSTEM

FOLLOWING IS A DIAGRAM OF THE BODY PARTS GROUP NUMBERING SYSTEM

● BODY GROUP

BODY TYPE

CHANGE IN DESIGN OR COLOR

54 20124—A

54 — 4 DOOR SEDAN
66 — 2 DOOR SEDAN

DOOR ASSY. (FRONT) — R.H.

- These five digits comprise the Body Group Numbers used throughout each body parts section.

PART NAME INDEX

Below are various major groups appearing in the Chassis and Body Sections of this Catalog. An Alphabetical Index for all chassis parts follows the General Information Section. A complete index of body parts is included at the beginning of the Body Section and a complete group index of Soft Trim parts is included at the beginning of the Soft Trim Section.

CHASSIS PARTS INDEX

MAJOR GROUP	● TABBED DIVIDER TITLE	SECTION
Accelerator Linkage	Fuel—Carburetor—Accelerator	97
Accessories	Listed in their appropriate groups as identified in this Index	
Adhesives	Paint—Wheel—Brake	Paint
Air Cleaner	Fuel—Carburetor—Accelerator	96
Air Conditioner	Speedometer—Bumper	190, 197
Alternator	Generator—Alternator—Starter—Distributor	103
Automatic Transmission	Automatic Transmission	A70
Axle (Rear)	Front Suspension—Steering—Rear Axle	40
Battery	Generator—Alternator—Starter—Distributor	103
Belt (Drive)	Cooling—Grille	86
Brake System	Paint—Wheel—Brake	20
Bulbs	Lamps—Wiring	130
Bumpers	Speedometer—Bumper	178
Cap (Radiator)	Cooling—Grille	80
Carburetor	Fuel—Carburetor—Accelerator	95
Carrier (Wheel)	Paint—Wheel—Brake	10
Chemicals	Paint—Wheel—Brake	Paint
Clutch	Manual Transmission—Clutch	71
Clutch Assy. (Fan)	Cooling—Grille	86
Cooling System	Cooling—Grille	80
Distributor	Generator—Alternator—Starter—Distributor	120
Drive Belt	Cooling—Grille	86
Driveshaft	Front Suspension—Steering—Rear Axle	46
Engine	Engine	60
Exhaust System	Frame—Muffler—Spring	50
Fan	Cooling—Grille	86
Fenders	Fender—Hood	160
Frame	Frame—Muffler—Spring	53
Front Springs	Frame—Muffler—Spring	53
Front Suspension	Front Suspension—Steering—Rear Axle	30
Fuel Pump	Fuel—Carburetor—Accelerator	93
Fuel Tank	Fuel—Carburetor—Accelerator	90
Gearshift Lever	Manual Transmission—Clutch	71
Grille	Cooling—Grille	80
Heater	Speedometer—Bumper	180, 184
Hood	Fender—Hood	160
Horns	Lamps—Wiring	130
Hose (Radiator)	Cooling—Grille	80
Ignition Switch	Generator—Alternator—Starter—Distributor	110
Instrument Cluster	Generator—Alternator—Starter—Distributor	103

● Applicable to Loose Leaf Catalogs only

PART NAME INDEX**CHASSIS PARTS INDEX – Cont'd**

MAJOR GROUP	● TABBED DIVIDER TITLE	SECTION
Jack	Speedometer—Bumper	170
Lamps	Lamps—Wiring	130
Lever (Gearshift)	Manual Transmission—Clutch	71
Linkage (Accelerator)	Fuel—Carburetor—Accelerator	97
Linkage (Steering)	Front Suspension—Steering—Rear Axle	30
Main Wiring	Lamps—Wiring	140
Manifold	Fuel—Carburetor—Accelerator	93
Mirrors	Speedometer—Bumper	176
Paint	Paint—Wheel—Brake	Paint
Pulley (Water Pump)	Cooling—Grille	80
Pump (Fuel)	Fuel—Carburetor—Accelerator	93
Pump (Water)	Cooling—Grille	80
Radiator	Cooling—Grille	80
Radio	Speedometer—Bumper	188
Radio Chassis	Speedometer—Bumper	188
Rear Axle	Front Suspension—Steering—Rear Axle	40
Regulator (Voltage)	Generator—Alternator—Starter—Distributor	103
Shock Absorber	Speedometer—Bumper	180
Shroud (Fan)	Cooling—Grille	80
Spacer (Pulley to Fan)	Cooling—Grille	80
Speed Control	Fuel—Carburetor—Accelerator	97
Speedometer (Drive & Driven Gears)	Speedometer—Bumper	170, 172
Springs	Frame—Muffler—Spring	53
Stabilizer	Frame—Muffler—Spring	53
Steering Gear	Front Suspension—Steering—Rear Axle	30
Steering Linkage	Front Suspension—Steering—Rear Axle	30
Suspension (Front)	Front Suspension—Steering—Rear Axle	30
Switch (Ignition)	Generator—Alternator—Starter—Distributor	103
Switch (Turn Indicator)	Lamps—Wiring	130
Tachometer	Speedometer—Bumper	173
Tank (Fuel)	Fuel—Carburetor—Accelerator	90
Thermactor	Fuel—Carburetor—Accelerator	93
Thermostat (Water)	Cooling—Grille	80
Transfer Case	Manual Transmission—Clutch	70
Transmission (Automatic)	Automatic Transmission	A70
Transmission (Manual)	Manual Transmission—Clutch	70
Turn Indicator, Switch	Lamps—Wiring	130
Voltage Regulator	Generator—Alternator—Starter—Distributor	103
Water Pump	Cooling—Grille	80
Wheels	Paint—Wheel—Brake	10
Windshield Washer	Speedometer—Bumper	173, 176
Windshield Wiper	Speedometer—Bumper	173
Wiring (Main)	Lamps—Wiring	140

● Applicable to Loose Leaf Catalogs only

PART NAME INDEX

BODY and SOFT TRIM PARTS

MAJOR GROUP	● TABBED DIVIDER TITLE	SECTION
Air Foil	Body Front—Floor	000
Auxiliary Seat	Seat	600
Center Body Pillar	Side—Door—Pillar—Quarter	200
Console	Body Front—Floor	040
Cowl	Body Front—Floor	000
Dash Panel	Body Front—Floor	000
Door (Front)	Side—Door—Pillar—Quarter	200
Door (Rear)	Side—Door—Pillar—Quarter	200
Floor	Body Front—Floor	040
Front Door	Side—Door—Pillar—Quarter	200
Front Seat Track	Seat	600
Glove Compartment	Body Front—Floor	040
Instrument Panel	Body Front—Floor	040
Liftgate	Back—Luggage Compartment	400
Luggage Compartment	Back—Luggage Compartment	400
Package Tray	Back—Luggage Compartment	400
Pillar (Center Body)	Side—Door—Pillar—Quarter	200
Quarter	Side—Door—Pillar—Quarter	270
Rear Door	Side—Door—Pillar—Quarter	200
Rear Seat	Seat	600
Roof	Back—Luggage Compartment	500
Seat (Auxiliary)	Seat	600
Seat (Front)	Seat	600
Seat (Rear)	Seat	600
Stripe Kits	Exterior Mouldings	Exterior Mldg.
Tailgate	Back—Luggage Compartment	400
Top (Folding)	Soft Trim	Soft Trim
Track (Front Seat)	Seat	600
Windshield	Body Front—Floor	000

● Applicable to Loose Leaf Catalogs only

GROUP NUMBERS and RELATED PART NAMES and CATALOG SECTIONS

Following is an index of the group number ranges, part name and their related catalog section numbers.

CHASSIS PARTS

GROUP NUMBER RANGE	PART NAME	CATALOG SECTION NUMBER
Miscellaneous	Paints and chemicals	Paint
1000 - 1999	Wheels, hubs and drums	10
2000 - 2099	Brakes	20
2001 and 2200	Brake shoe and lining details	20
2100 - 2199	Brakes	20
2200 - 2299	Brakes	20
2300 - 2399	Brake booster	20
2400 - 2999	Brake pedals and linkage	20
3000 - 3499	Front axle and front suspension	30
3500 - 3599	Steering gear	30
3600 - 3999	Steering wheel and column	36
3A635	P/S kit details	36.1
4000 - 4599	Rear axle	40
4600 - 4999	Driveshaft	46
5000 - 5199	Frame	50
5200 - 5299	Muffler	52.80
5300 - 5399	Front springs	53
5310	Spring charts	53.80
5400 - 5999	Stabilizers	53
6000 - 6999	Engine identification tag and pulley identification chart	60
	Engine parts list - 4 cyl. 140 (2.3L)	60.1
	Engine parts list - 4 cyl. 98 (1.6L)	60.1A
	Engine parts list - 4 cyl. 98 (1.6L)	60.1B
	Engine parts list - 4 cyl. 140 (2.3L) HSC	60.1C
	Engine parts list - 6 cyl. 200 (3.3L), 250 (4.1L)	60.2
	Engine parts list - 6 cyl. 230 (3.8L)	60.2A
	Engine parts list - 8 cyl. 255 (4.2L), 302 (5.0L)	60.3
	Engine parts list - 8 cyl. 351W (5.8L)	60.4
6900 - 7999	Manual transmission - exc. linkage	70
	Identification chart	70
	Application chart	70
	Manual transmission parts list - 4 speed German	70.1
	Manual transmission parts list - 4 speed Ford (RAD type)	70.3
	Manual transmission parts list - 4 speed Ford (RUG type)	70.2
	Manual transmission parts list - trans. axle	70.4
7000 - 7299	Manual transmission linkage, etc.	71
7300 - 7499	Manual transmission linkage, etc.	71
7500 - 7999	Clutch	71
7000 - 7999	Automatic transmission - exc. linkage	A70
	Identification chart	A70
	Application chart	A70
	Automatic transmission parts list - C3	A70.1
	Automatic transmission parts list - C4	A70.2
	Automatic transmission parts list (AOT type)	A70.4
	Automatic transmission parts list (FMX type)	A70.5
	Automatic transmission parts list - C6	A70.3
	Automatic transmission parts list - Jatco (PLA)	A70.6
	Automatic transmission parts list - ATX	A70.7
7000 - 7199	Automatic transmission linkage, cooling, etc.	A71
7200 - 7399	Automatic transmission linkage, etc.	A71
7400 - 7999	Automatic transmission linkage, etc.	A71

GROUP NUMBERS and RELATED PART NAMES and CATALOG SECTIONS

CHASSIS PARTS — Cont'd

GROUP NUMBER RANGE	PART NAME	CATALOG SECTION NUMBER
8000 — 8499	Radiator, grille and cooling	80
8500 — 8599	Water pump	80
8600 — 8999	Fan	86
8620	Drive belt identification chart	86
	Drive belt application	86
9000 — 9299	Fuel tank and lines	90
9300 — 9399	Fuel pump and gauge	93
9400 — 9499	Manifolds, thermostats and emission parts	93
9000 — 12999	Calibration application chart	93A
9000 — 12999	Calibration identification chart	93A
9000 — 12999	Calibration parts list	93B
9500 — 9599	Carburetor	95
9510	Carburetor application chart	95
9510	Carburetor identification chart	95
9500 — 9999	Carburetor parts list	95.1, 95.2, etc.
9600	Air cleaner application chart	96
9600	Air cleaner identification chart	96
9600 — 9699	Air cleaner parts and related parts	96
9700 — 9999	Choke, accelerator and speed control	97
10346	Alternator application chart	103
10300 — 10599	Alternator, pulleys and mounting parts	103
10300	Alternator identification chart	103
10300 — 10599	Alternator parts lists	103.1, 103.2, etc.
10600 — 10999	Battery and instrument cluster parts	103
11000 — 11999	Starter and ignition and headlamp switches	110
11001	Starter identification chart	110
11001 — 11999	Starter parts lists	110.1, 110.2, etc.
12000 — 12999	Coil, distributor and spark plugs	120
12127	Distributor identification chart	120
12000 — 12999	Distributor parts lists	120.1, 120.2, etc.
13000 — 13399	Headlamps, parking lamps and turn indicators	130
13400 — 13699	License, tail and stop lamps	130
13466	Miniature bulbs	130
13700 — 13999	Courtesy and instrument panel lamps, switches and horns	130
14000 — 14399	Wiring — main and window regulator	140
14400 — 14499	Wiring — tail lamp and battery	140
14500 — 14999	Wiring, fuses and circuit breakers	145
15000 — 15999	Clock, cigar lighter, marker lamps and backup lamps	145
16000 — 16099	Front fenders and aprons	160
16100 — 16599	Splash shields and radiator supports	160
16600 — 16999	Hood, hinges and latches	160
16000 — 16251	Fender ornamentation	Exterior Moulding
16000 — 16999	Fender, hood ornamentation retainers	Exterior Moulding Section "R"
17000 — 17299	Jacks, speedometer and speedometer cables	170
17271 and 17285	Speedometer gear identification chart	170
17271 and 17285	Speedometer gear application chart	172.80
17300 — 17399	Speedometer, tachometer and license plate frame	173
17400 — 17599	Windshield wipers and washers	173
17600 — 17999	Windshield wipers and washers, bumpers and mirrors	173, 176
18000 — 18399	Shock absorbers and heaters	180
18400 — 18999	Heaters, radios, antennas and speakers	184, 188
19000 — 19999	Air conditioner parts	190
19C705-9	Refrigerant lines	197

GROUP NUMBERS and RELATED PART NAMES and CATALOG SECTIONS

BODY and SOFT TRIM PARTS

GROUP NUMBER RANGE	PART NAME	CATALOG SECTION NUMBER
00000 - 01999	Body assemblies, air foils, air vents and dash panel	000
02000 - 02999	Cowl panel and front body pillar	000
03000 - 03999	Windshield	000
04200 - 04699	Instrument panel, console panel and visor arms	040
04700 - 09999	Ash receptacle and glove compartment	040
10000 - 19999	Floor, rocker panels and underbody parts	040
20000 - 20999	Front door, weatherstrips and interior mouldings	200
21000 - 21999	Front door windows, latches and mechanisms	200
22000 - 22999	Front door hinges, latches and handles	220
22050	Lock sets	220
20000 - 20999	Stripe kits and exterior mouldings	Exterior Moulding
20000 - 20999	Exterior moulding retainers	Exterior Moulding Section "R"
23000 - 23999	Front door window handles and regulators	230
24000 - 25999	Center body pillar, rear door, rear door windows, interior mouldings and weatherstrips	230
26000 - 26999	Rear door window mechanism and latches	230
24000 - 25999	Exterior mouldings	Exterior Moulding
24000 - 25999	Exterior moulding retainers	Exterior Moulding Section "R"
27000 - 27999	Rear door window regulators and quarter panels	270
28000 - 28999	Quarter latch pillar	270
29000 - 29999	Quarter window, interior mouldings and weatherstrips	270
29000 - 29999	Exterior mouldings	Exterior Moulding
29000 - 29999	Exterior moulding retainers	Exterior Moulding Section "R"
30000 - 39999	Quarter windows, weatherstrips and handles	270
40000 - 41999	Liftgate, tailgate and luggage compartment	400
42000 - 42999	Back window	400
43000 - 43999	Tailgate, latches, hinges and mechanism	400
44000 - 49999	Tailgate window and regulator and package tray	400
40000 - 49999	Transfers and exterior mouldings	Exterior Moulding
40000 - 49999	Exterior moulding retainers	Exterior Moulding Section "R"
50000 - 50999	Roof panel and folding top mechanism	500
51000 - 51999	Roof rails, weatherstrips and console	500
52000 - 52999	Roof bows and supports	500
53000 - 59999	Folding top mechanism and luggage carrier parts	500
50000 - 59999	Exterior mouldings	Exterior Moulding
50000 - 59999	Exterior moulding retainer	Exterior Moulding Section "R"
60000 - 60999	Seats, hinges and supports	600
61000 - 61499	Seats, head rest parts and seat belts	600
61500 - 61699	Seat side shields	600
61700 - 61999	Seat tracks and mechanism	600
62000 - 69999	Seat side shields and ash receptacles	600
00000 - 69999 (as applicable)	Soft Trim	Soft Trim - by model year

MODEL YEAR APPLICATION

Model year application is indicated by showing the first year followed by a diagonal line to indicate continued usage in all subsequent years until the insertion of the last year of usage, which will then be shown after the diagonal line. If no diagonal line is shown, the part is applicable only to the year shown.

Example:

- 80 Indicates part used 1980 model year only.
- 80/ Indicates part used 1980 through subsequent model years.
- 80/81 Indicates part used 1980 through 1981 model years.

BODY TYPE CODES

Most body parts and some chassis parts are cataloged by Body Type Codes. A complete listing of body type codes is shown on pages 29,30 of this section. Similar body types are identified by the same code number. The body type suffix is used to identify a particular body type. For example, (Ford or Mercury) body type 54 is used as shown below:

- A (54H) LTD S or Marquis 4 Door Pillared Hardtop
- A (54K) LTD or Marquis Brougham 4 Door Pillared Hardtop
- A (54L) LTD Crown Victoria or Grand Marquis 4 Door Pillared Hardtop

Body type codes (less suffix) are shown in the model column of the catalog text or with illustration titles when all body types of a related group are affected. For example, when Body Type Code 54 is shown it includes 54H, 54K and 54L.

SOFT TRIM

Soft Trim parts are arranged in separate sections by car line catalog code within each model year, i.e. 1980 Soft Trim Section A (Ford or Mercury). To determine the complete part number of a trim part, it is necessary to know the "Trim Code" which is shown on the Certification Label of the vehicle (refer to pages 22 thru 35). Instructions for selecting soft trim parts are contained at the beginning of the Soft Trim area of this catalog.

ATTACHING PARTS (NUTS, BOLTS, ETC.) and LOCATOR CODES

Standard and utility hardware, such as bolts, screws, fittings, etc. are listed below the part with which they are used. To facilitate the stocking and handling of standard and utility parts by Ford or L-M Dealers, locator codes are preassigned by Ford Motor Company. The locator codes are shown in parentheses immediately following or below the standard and utility part numbers. For example, refer to Body Section 200 group 22800-1. The part number for a 5/16"-18 x 1 1/8" screw-hex. head is 382623-S2 with the locator code (UU-52-AL) appearing at the beginning of the description column. In some charts, such as the Carburetor Parts List Charts in Section 95.1, 95.2, etc. the locator code will be shown next to or below the part number in the part number column.

LIQUID MEASURE

Most liquid measures listed in this catalog are in U.S. sizes and certain other liquid measure (unique to Canada) listed in this catalog are in Canadian sizes. The follow chart provides an understanding and a translation of U.S. to Canadian and Canadian to U.S. sizes.

	<u>1/2 Pint</u>	<u>Pint</u>	<u>Quart</u>	<u>Gallon</u>
	(CAPACITY IN OUNCES)		(CAPACITY IN OUNCES)	
Canada	10	20	40	160
U.S.	8	16	32	128

Example. 5 U.S. quarts (160 ounces) equal 4 Canadian quarts (160 ounces) or 1 Canadian gallon.

D.S.O., F.S.O. or L.P.O. (SPECIAL ORDERS)

The District Code Number will appear in the D.S.O. space on the Certification Label for all units including regular production. Always furnish appropriate Certification Label information and D.S.O. Number, if applicable, when ordering parts not listed in the catalog. If the unit is D.S.O., F.S.O. or L.P.O. (Special Order), the complete Order Number will appear in the D.S.O. space in addition to the District Code Number.

IMPORTANT — Many parts and assemblies used on Domestic Special Order vehicles may be standard or optional on other models. When the assembly number is known check the applicable identification and cross reference charts for possible service parts. If not listed in this catalog order the part on a Special Order basis through the Order Processing Center.

HOW TO IDENTIFY 351 C.I.D. ENGINES

The following methods will help to identify the subject engines that are in use:

- Decal on Air Cleaner Cover
- Emission Control Systems Decal on Valve Cover
- 351C was last produced in 1974
- 351M introduced in 1975 and used thru 1979.
- 351W introduced in 1969 in use through 1981.

<u>ITEM</u>	<u>351W</u>	<u>351C & M</u>
Number of bolts attaching valve cover on exhaust manifold side	3	4
Type of Front Cover	Bolted to Cylinder Block	Cast as part of Cylinder Block
Thermostat Housing	Bolts horizontal and mounts to intake manifold	Bolts vertical and mounts to front cover
Fuel Pump	Attaching Bolts side by side (horizontal plane)	Attaching Bolts one above the other (vertical plane)

HOW TO ORDER PARTS

When ordering parts, always give the complete part number.

In the event the part number is not known, the following information should be included:

- A. Complete description of part.
- B. Model, year and body type.
- C. Dimension, number of teeth, size, etc., if possible, rough sketch of part.
- D. If applicable to engine, transmission, axle, steering, etc., specify type, such as 302 C.I.D. Automatic Transmission, Power Steering, etc.
- E. Advise how shipment is to be made — Freight, Express, Air, Parcel Post.

ACCESSORY WEIGHT CHARTS

When adding accessories to your vehicle, the total weight capacity of the vehicle or of the front or rear axle (GVWR, GAWR as shown on the Vehicle Certification Label) must not be exceeded. See the listing below for the weight effect of the various accessories shown.

1980 VEHICLES

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Air Horns	9 1/2	9 1/2	0
Air Springs #	2 1/2	0	2 1/2
Antenna - Front Electric	4	4	0
Antenna - Rear Electric	4	0	4
Bicycle Rack	14	7	7
Body Side Moulding - Vinyl (exc. Fiesta)	3	1 1/2	1 1/2
Body Side Moulding - Vinyl - Fiesta	2	1	1
Control - Air Spring	5	2 1/2	2 1/2
Deck Lid Release Control	2	0	2
Defogger - Rear Window (exc. Ford)	3	0	3
Defogger - Rear Window (Ford)	4	0	4
Door Storage Bins (Fiesta)	2	1 1/2	1/2
Electric Clock	1	1	0
Fire Extinguisher - 10BC (include Fiesta) (1)	4	3	1
Floor Mat - Universal (Vinyl or Rubber Economy)	10	6	4
Floor Mat - Full - Vinyl Universal	11 1/2	6 1/2	5
Floor Mat - Carpet	6	3 1/2	2 1/2
Floor Mat - Rubber - Deluxe	13	8	5
Floor Mat - Front Twin - Rubber (Fiesta)	16	12	4
Floor Mat - Front Vinyl Insert (Fiesta)	9	7	2
Glove Box Door (Fiesta)	2 1/2	2	1/2
Heater - Engine Block	1/2	1/2	0
Hood Ornament	1	1	0
License Plate Frames	1/4	1/8	1/8
Lockable Storage Compartment (Fiesta)	7	0	7
Luggage Rack (Fiesta)	15	3	12
Luggage Rack with Cover (Fiesta)	25	10	15
Luggage Rack - Cover	20	0	20
Luggage Rack - Deck	8	-1	9
Luggage Rack - Roof (Sedan & Station Wagon)	24	-2	26
Outside Mirror - R.H. Convex (2)	1	1	0
Outside Mirror - L.H. (2)	1	1	0
Outside Mirror - R.H. (2)	1	1	0
Outside Mirror - Racing (2)	3	3	0
Radio - AM (Fiesta)	7	6	1
Radio - CB	9	5	4
Rear Package Tray (Fiesta)	10	0	10
Rear Speaker - Station Wagon	3	0	3
Reflector Flare (Fiesta)	14	0	14
Rustproofing (Super Seal)	12	6	6
Shock Absorbers (Super Flex)-Rear	4	0	4
Shock Absorbers (Super Flex)-Front	4	4	0
Speed Control	8	8	0
Splash Guard	3	1 1/2	1 1/2
Splash Guard (Fiesta)	1	1/2	1/2
Tool Kit - Large (Fiesta)	4 1/2	0	4 1/2
Tool Kit - Small (Fiesta)	1 1/2	0	1 1/2
Transmission Oil Cooler (Economy)	4	5	-1
Transmission Oil Cooler (High Capacity)	6 1/4	7	-3/4
Transmission Oil Cooler (Extra High Capacity)	5	6	-1

(1) Located in Passenger Compartment - Front

(2) Weight Per Mirror

Bumper Height Not Affected

ACCESSORY WEIGHT CHARTS — Cont'd

1980 VEHICLES — Cont'd

ACCESSORY	WEIGHT EFFECT (lbs.)		
	TOTAL	FRONT AXLE	REAR AXLE
Undercoating	10	5	5
Undercoating and Rustproofing (Super Seal)	19	9 1/2	9 1/2
Wheel Covers #	20	10	10
Wheel Trim Rings # (exc. Fiesta)	4	2	2
Wheel Trim Rings # (Fiesta)	3	1 1/2	1 1/2

1981 VEHICLES

Air Conditioning			
1.3/1.6L Engine	61 1/2	65	-3 1/2
2.3L Engine	74 1/2	78	-3 1/2
3.3L Engine	64 1/2	69 1/2	-5
4.2/5.0L All Except Thunderbird and Ford	73	78 1/2	-5 1/2
4.2/5.0/5.8L Thunderbird and Ford	67	73	-6
Air Deflector	5	0	5
Air Horns	9 1/2	9 1/2	0
Air Springs #	2 1/2	0	2 1/2
Body Side Moulding — Vinyl	3	1 1/2	1 1/2
Control — Air Spring	5	2 1/2	2 1/2
Deck Lid Lock	2	0	2
Electric Clock	1	1	0
Fire Extinguisher (1)	4	3	1
Floor Mat — Full Vinyl — Universal	11 1/2	6 1/2	5
Floor Mat — Twin — Corporate	6	3 1/2	2 1/2
Floor Mat — Twin — Rubber	13	8	5
Heater — Engine Block	1/2	1/2	0
Hood Ornament	1	1	0
License Plate Frame	1/4	1/8	1/8
Luggage Rack — Deck	8	-1	9
Luggage Rack — Roof Sedan and Station Wagon	24	-2	26
Luggage Rack — Cover	20	0	20
Outside Mirror — L.H. (2)	1	1	0
Outside Mirror — R.H. (2)	1	1	0
Outside Mirror — Racing (2)	3	3	0
Outside Mirror — Convex — R.H. (2)	1	1	0
Radio — AM and AM/FM Monaural (3)	5	4	1
Radio — AM/FM Stereo (4)	5	3	2
Radio — AM/FM w/Cassette (4)	6	5	1
Radio — AM/FM w/8 Track Tape (4)	8	5	3
Radio — Electronic (5)	3	3	0
Premium Sound System	4	2	2
Shades — Rear Window	10	1	9
Shock Absorbers (Spring Assist) — Rear #	4	0	4
Shock Absorbers (Spring Assist) — Front #	4	4	0
Speed Control	8	8	0
Splash Guard	3	1 1/2	1 1/2
Transmission Oil Cooler — Hi-Capacity	6 1/4	7	-3/4
Transmission Oil Cooler — Extra Hi-Capacity	5	6	-1
Rustproofing — Super Seal	12	6	6
Undercoating	10	5	5
Undercoating and Rustproofing — Super Seal	19	9 1/2	9 1/2
Wheel Covers #	10	10	10
Wheel Trim Rings #	4	2	2

Bumper Height Not Affected

(1) Located in Passenger Compartment — Front

(2) Weight Per Mirror

(3) Add if Not Factory Installed

(4) Use (3) plus (4) when (3) is not factory installed

(5) Add to either (3) or (4)

ACCESSORY WEIGHT CHARTS

When adding accessories to your vehicle, the total weight capacity of the vehicle or of the front or rear axle (GVWR, GAWR as shown on the vehicle Certification Label) must not be exceeded. See the listing below for the weight effect of the various accessories shown.

1982 VEHICLES

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Air Conditioning			
1.6L Engine	61 1/2	65	-3 1/2
2.3L Engine	74 1/2	78	-3 1/2
3.3L Engine	64 1/2	69 1/2	-5
4.2/5.0L All Exc. T'Bird/XR7 & Ford/Mercury	73	78 1/2	-5 1/2
4.2/5.0/5.8L T'Bird/XR7 & Ford/Mercury	67	73	-6
Air Deflector	5	0	5
Air Horns	9 1/2	9 1/2	0
Air Springs *	2 1/2	0	2 1/2
Body Side Moulding - Vinyl	3	1 1/2	1 1/2
Control - Air Spring	5	2 1/2	2 1/2
Electric Clock	1	1	0
Fire Extinguisher (1)	4	3	1
Floor Mat - Full Vinyl - Universal	11 1/2	6 1/2	5
Floor Mat - Twin - Corporate	6	3 1/2	2 1/2
Floor Mat - Twin - Rubber	13	8	5
Floor Mat - Universal - Twin Vinyl	10	6	4
Heater - Engine Block	1/2	1/2	0
Hood Ornament	1	1	0
License Plate Frame	1/4	1/8	1/8
Louvers - Rear Window	16	0	16
Luggage Rack - Deck	8	-1	9
Luggage Rack - Roof - Sedan and Station Wagon	24	-2	26
Luggage Rack - Cover	20	0	20
Luggage Carrier - Plastic (42" lg.)	25	12	13
Luggage Carrier - Plastic (47" lg.)	30	15	15
Outside Mirror - L.H. (2)	1	1	0
Outside Mirror - R.H. (2)	1	1	0
Outside Mirror - Racing (2)	3	3	0
Outside Mirror - Convex R.H. (2)	1	1	0
Radio - AM & AM/FM Monaural (3)	5	4	1
Radio - AM/FM Stereo (4)	5	3	2
Radio - AM/FM w/Cassette (4)	6	5	1
Radio - AM/FM w/8 Track Tape (4)	8	5	3
Radio - Electronic (5)	3	3	0
Premium Sound System	4	2	2

(1) Located in Passenger Compartment - Front

(2) Weight Per Mirror

(3) Add if not factory installed

(4) Use (3) plus (4) when (3) is not factory installed

(5) Add to either (3) or (4)

* Bumper Height Not Affected

ACCESSORY WEIGHT CHARTS — Cont'd

1982 VEHICLES — Cont'd

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Shades — Rear Window	10	1	9
Shock Absorbers — (Spring Assist) — Rear*	4	0	4
Shock Absorbers — (Spring Assist) — Front*	4	4	0
Speed Control	8	8	0
Splash Guard	3	1 1/2	1 1/2
Transmission Oil Cooler — Economy	4	5	-1
Transmission Oil Cooler — Hi-Capacity	6 1/4	7	-3/4
Transmission Oil Cooler — Extra Hi-Capacity	5	6	-1
Rustproofing — Super Seal	12	6	6
Undercoating	10	5	5
Undercoating and Rustproofing — Super Seal	19	9 1/2	9 1/2
Wheel Covers*	10	10	10
Wheel Trim Rings*	4	2	2

1983 VEHICLES

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Air Conditioning			
1.6L, 1.6L H.O. and 1.6L EFI Engine	61 1/2	65	-3 1/2
2.3L Engine	74 1/2	78	-3 1/2
3.3L Engine	64 1/2	69 1/2	-5
3.8L Mustang/Capri, T-Bird/XR-7 & LTD Marquis	73	78 1/2	-5 1/2
5.0L Mustang/Capri, Ford/Mercury — 5.0L CFI	67	73	-6
Air Deflector	5	0	5
Air Horns	9 1/2	9 1/2	0
Air Springs*	2 1/2	0	2 1/2
Body Side Moulding — Vinyl	3	1 1/2	1 1/2
Control — Air Spring	5	2 1/2	2 1/2
Electric Clock	1	1	0
Fire Extinguisher (1)	4	3	1
Floor Mat — Full Vinyl — Universal	11 1/2	6 1/2	5
Floor Mat — Twin — Corporate	6	3 1/2	2 1/2
Floor Mat — Twin — Rubber	13	8	5
Floor Mat — Universal — Twin Vinyl	10	6	4
Heater — Engine Block	1/2	1/2	0
Hood Ornament	1	1	0

(1) Located in Passenger Compartment — Front

(2) Weight Per Mirror

(3) Add if not factory installed

(4) Use (3) plus (4) when (3) is not factory installed

(5) Add to either (3) or (4)

* Bumper Height Not Affected

ACCESSORY WEIGHT CHARTS — Cont'd

1983 VEHICLES — Cont'd

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
License Plate Frame	1/4	1/8	1/8
Louvers — Rear Window	16	0	16
Luggage Rack — Deck	8	-1	9
Luggage Rack — Roof — Sedan and Station Wagon	24	-2	26
Luggage Rack — Cover	20	0	20
Luggage Carrier — Plastic (42" lg.)	25	12	13
Luggage Carrier — Plastic (47" lg.)	30	15	15
Outside Mirror — L.H. (2)	1	1	0
Outside Mirror — R.H. (2)	1	1	0
Outside Mirror — Racing (2)	3	3	0
Outside Mirror — Convex R.H. (2)	1	1	0
Radio — AM & AM/FM Monaural (3)	5	4	1
Radio — AM/FM Stereo (4)	5	3	2
Radio — AM/FM w/Cassette (4)	6	5	1
Radio — AM/FM w/8 Track Tape (4)	8	5	3
Radio — Electronic (5)	3	3	0
Premium Sound System	4	2	2
Shades — Rear Window	10	1	9
Shock Absorbers — (Spring Assist) — Rear*	4	0	4
Shock Absorbers — (Spring Assist) — Front*	4	4	0
Speed Control	8	8	0
Splash Guard	3	1 1/2	1 1/2
Transmission Oil Cooler — Economy	4	5	-1
Transmission Oil Cooler — Hi-Capacity	6 1/4	7	-3/4
Transmission Oil Cooler — Extra Hi-Capacity	5	6	-1
Rustproofing — Super Seal	12	6	6
Undercoating	10	5	5
Undercoating and Rustproofing — Super Seal	19	9 1/2	9 1/2
Wheel Covers*	10	10	10
Wheel Trim Rings*	4	2	2

(1) Located in Passenger Compartment — Front

(2) Weight Per Mirror

(3) Add if not factory installed

(4) Use (3) plus (4) when (3) is not factory installed

(5) Add to either (3) or (4)

* Bumper Height Not Affected

ACCESSORY WEIGHT CHARTS — Cont'd

1984 VEHICLES

ACCESSORY	WEIGHT EFFECT (lbs.)		
	TOTAL	FRONT AXLE	REAR AXLE
Air Conditioning			
1.6L, 1.6L H.O. and 1.6L EFI, 1.6L T.C. Engine	61 1/2	65	-3 1/2
2.3L Engine	74 1/2	78	-3 1/2
2.3L HSC	57	59	-2
3.8L Mustang/Capri, T-Bird & LTD Marquis	73	78 1/2	-5 1/2
5.0L Mustang/Capri, Ford/Mercury — 5.0L CFI	67	73	-6
Air Deflector	5	0	5
Air Horns	9 1/2	9 1/2	0
Air Springs*	2 1/2	0	2 1/2
Body Side Moulding — Vinyl	3	1 1/2	1 1/2
Control — Air Spring	5	2 1/2	2 1/2
Electric Clock	1	1	0
Fire Extinguisher (1)	4	3	1
Floor Mat — Full Vinyl — Universal	11 1/2	6 1/2	5
Floor Mat — Twin — Corporate	6	3 1/2	2 1/2
Floor Mat — Twin — Rubber	13	8	5
Floor Mat — Universal — Twin Vinyl	10	6	4
Heater — Engine Block	1/2	1/2	0
Hood Ornament	1	1	0
License Plate Frame	1/4	1/8	1/8
Louvers — Rear Window	16	0	16
Luggage Rack — Deck	8	-1	9
Luggage Rack — Roof — Sedan and Station Wagon	24	-2	26
Luggage Carrier — Plastic (42" lg.) (Clamshell)	25	12	13
Luggage Carrier — Plastic (47" lg.) (Clamshell)	30	15	15
Outside Mirror — L.H. (2)	1	1	0
Outside Mirror — R.H. (2)	1	1	0
Outside Mirror — Racing (2)	3	3	0
Radio — AM & AM/FM Monaural (3)	5	4	1
Radio — AM/FM Stereo (4)	5	3	2
Radio — AM/FM w/Cassette (4)	6	5	1
Radio — AM/FM w/8 Track Tape (4)	8	5	3
Radio — Electronic (5)	3	3	0
Shades — Rear Window	10	1	9
Shock Absorbers — (Spring Assist) — Rear*	4	0	4
Shock Absorbers — (Spring Assist) — Front*	4	4	0
Speed Control	5	5	0
Splash Guard	3	1 1/2	1 1/2
Transmission Oil Cooler — 2 Tube	3	3	0
Transmission Oil Cooler — 4 Tube	4 1/2	4 1/2	0
Rustproofing — Super Seal	12	6	6
Wheel Covers*	10	10	10
Wheel Trim Rings*	4	2	2

(1) Located in Passenger Compartment — Front

(2) Weight Per Mirror

(3) Add if not factory installed

(4) Use (3) plus (4) when (3) is not factory installed

(5) Add to either (3) or (4)

* Bumper Height Not Affected

ACCESSORY WEIGHT CHARTS — Cont'd

1985 VEHICLES

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Air Conditioning			
1.6L, 1.6L H.O. and 1.6L EFI, 1.6L EFI T.C. Engine	61 1/2	65	-3 1/2
2.3L Engine	74 1/2	78	-3 1/2
2.3L HSC Tempo	57	59	-2
3.8L Mustang/Capri, T-Bird/Cougar & LTD/Marquis	73	78 1/2	-5 1/2
5.0L Mustang/Capri, Ford/Mercury — 5.0L CFI	67	73	-6
Air Deflector	5	0	5
Air Horns	9 1/2	9 1/2	0
Air Springs*	2 1/2	0	2 1/2
Body Side Moulding — Vinyl	3	1 1/2	1 1/2
Control — Air Spring	5	2 1/2	2 1/2
Electric Clock	1	1	0
Fire Extinguisher (1)	4	3	1
Floor Mat — Full Vinyl — Universal	11 1/2	6 1/2	5
Floor Mat — Twin — Corporate	6	3 1/2	2 1/2
Floor Mat — Twin — Rubber	13	8	5
Floor Mat — Universal — Twin Vinyl	10	6	4
Heater — Engine Block	1/2	1/2	0
Hood Ornament	1	1	0
License Plate Frame	1/4	1/8	1/8
Louvers — Rear Window	16	0	16
Luggage Rack — Deck	8	-1	9
Luggage Rack — Roof — Sedan and Station Wagon	24	-2	26
Outside Mirror — L.H. (2)	1	1	0
Outside Mirror — R.H. (2)	1	1	0
Outside Mirror — Racing (2)	3	3	0
Radio — AM & AM/FM Monaural (3)	5	4	1
Radio — AM/FM Stereo (4)	5	3	2
Radio — AM/FM w/Cassette (4)	6	5	1
Radio — AM/FM w/8 Track Tape (4)	8	5	3
Radio — Electronic (5)	3	3	0
Shades — Rear Window	10	1	9
Shock Absorbers — (Spring Assist) — Rear*	4	0	4
Shock Absorbers — (Spring Assist) — Front*	4	4	0
Speed Control	5	5	0
Splash Guard	3	1 1/2	1 1/2
Super Seal — Anti-Corrosion Treatment	12	6	6
Transmission Oil Cooler — 2 Tube	3	3	0
Transmission Oil Cooler — 4 Tube	4 1/2	4 1/2	0
Wheel Covers*	10	10	10
Wheel Trim Rings*	4	2	2

- (1) Located in Passenger Compartment — Front
 (2) Weight Per Mirror
 (3) Add if not factory installed
 (4) Use (3) plus (4) when (3) is not factory installed
 (5) Add to either (3) or (4)
 * Bumper Height Not Affected

ACCESSORY WEIGHT CHARTS — Cont'd

1986 VEHICLES

ACCESSORY	TOTAL	WEIGHT EFFECT (lbs.)	
		FRONT AXLE	REAR AXLE
Air Conditioning			
1.9L-2V, 1.9L EFI and 2.0L Diesel Escort/Lynx	61 1/4	61	1/4
2.3L Engine	74 1/2	78	-3 1/2
2.3L HSC, 2.0L Diesel Tempo/Topaz	67 1/2	71 1/2	-4
2.5L Taurus/Sable	43	**	**
3.0L Taurus/Sable	43 1/2	**	**
3.8L Mustang/Capri, T-Bird/Cougar & LTD/Marquis	73	78 1/2	-5 1/2
5.0L Mustang/Capri, Ford/Mercury — 5.0L CFI	67	73	-6
Air Deflector	5	0	5
Air Horns	9 1/2	9 1/2	0
Air Springs*	2 1/2	0	2 1/2
Body Side Moulding — Vinyl	3	1 1/2	1 1/2
Control — Air Spring	5	2 1/2	2 1/2
Electric Clock	1	1	0
Fire Extinguisher (1)	4	3	1
Floor Mat — Full Vinyl — Universal	11 1/2	6 1/2	5
Floor Mat — Twin — Corporate	6	3 1/2	2 1/2
Floor Mat — Twin — Rubber	13	8	5
Floor Mat — Universal — Twin Vinyl	10	6	4
Heater — Engine Block	1/2	1/2	0
Hood Ornament	1	1	0
Koolatron Cold Box	17	7	10
110 — Volt Power Pack	4	—	4
Jack — Hydraulic Electro	14 1/4	—	14 1/4
License Plate Frame	1/4	1/8	1/8
Louvers — Rear Window	16	0	16
Luggage Rack — Deck	8	-1	9
Luggage Rack — Roof — Sedan and Station Wagon	24	-2	26
Outside Mirror — L.H. (2)	1	1	0
Outside Mirror — R.H. (2)	1	1	0
Outside Mirror — Racing (2)	3	3	0
Radio — AM & AM/FM Monaural (3)	5	4	1
Radio — AM/FM Stereo (4)	5	3	2
Radio — AM/FM w/Cassette (4)	6	5	1
Radio — AM/FM w/8 Track Tape (4)	8	5	3
Radio — Electronic (5)	3	3	0
Shades — Rear Window	10	1	9
Shock Absorbers — (Spring Assist) — Rear*	4	0	4
Shock Absorbers — (Spring Assist) — Front*	4	4	0
Speed Control	5	5	0
Splash Guard	3	1 1/2	1 1/2
Super Seal — Anti-Corrosion Treatment	12	6	6
Telephone	2 1/2	4	17 1/2
Anti Theft	1	1	0
Transmission Oil Cooler — 2 Tube	3	3	0
Transmission Oil Cooler — 4 Tube	4 1/2	4 1/2	0
Wheel Covers*	10	10	10
Wheel Trim Rings*	4	2	2
Window Shade — rear	3	—	3

(1) Located in Passenger Compartment — Front

(2) Weight Per Mirror

(3) Add if not factory installed

(4) Use (3) plus (4) when (3) is not factory installed

(5) Add to either (3) or (4)

* Bumper Height Not Affected

** To Be Added at Later Date

ACCESSORY WEIGHT CHARTS — Cont'd

1987 VEHICLES

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Air Conditioning			
1.9L EFI/CFI Escort/Lynx/EXP	53 1/2	53 1/4	+1/4
2.0L Diesel Escort/Lynx w/o P/S	56 1/2	57	-1/2
2.0L Diesel Escort/Lynx w/P/S	66 1/2	68	-1 1/2
2.3L Engine Mustang	48 1/4	52 1/2	-4 1/4
2.3L HSC, Tempo/Topaz	53 1/2	53	+1/2
2.5L Taurus/Sable	43	47 3/4	-4 3/4
3.0L Taurus/Sable	40 1/2	45 3/4	-5 1/4
3.8L Mustang, T-Bird/Cougar	73	78 1/2	-5 1/2
5.0L Ford/Mercury — 5.0L CFI	67	73	-6
5.0L Mustang	46 3/4	52	-5 1/4
Air Deflector	5	0	5
Air Springs*	2 1/2	0	2 1/2
Bike Carrier — Roof — Clamp On	8	4	4
Body Side Moulding — Vinyl	3	1 1/2	1 1/2
Cargo Liner	5	0	5
Control — Air Spring	5	2 1/2	2 1/2
Defroster — Rear Window	1	1	0
Electric Clock	1	1	0
Cassette	2 1/2	2	1/2
Fire Extinguisher (1)	4	3	1
Floor Mat — Full Vinyl — Universal	11 1/2	6 1/2	5
Floor Mat — Twin — Corporate	6	3 1/2	2 1/2
Floor Mat — Twin — Rubber	13	8	5
Floor Mat — Universal — Twin Vinyl	10	6	4
Fog Lights	9	10	-1
Heater — Engine Block	1/2	1/2	0
Hood Ornament	1	1	0
Koolatron Cold Box	17	7	10
110 — Volt Power Pack	4	—	4
Jack — Hydraulic Electro	14 1/4	—	14 1/4
License Plate Frame	1/4	1/8	1/8
Louvers — Rear Window	17	0	17
Luggage Rack — Deck	8	-1	9
Luggage Rack — Roof — Sedan and Station Wagon	24	-2	26
Outside Mirror — L.H. (2)	1	1	0
Outside Mirror — R.H. (2)	1	1	0
Outside Mirror — Racing (2)	3	3	0
Radio — AM & AM/FM Monaural (3)	5	4	1
Radio — AM/FM Stereo (4)	5	3	2
Radio — AM/FM w/Cassette (4)	6	5	1
Radio — AM/FM w/8 Track Tape (4)	8	5	3
Radio — Electronic (5)	3	3	0
Shades — Rear Window	10	1	9
Shock Absorbers — (Spring Assist) — Rear*	4	0	4
Shock Absorbers — (Spring Assist) — Front*	4	4	0
Ski Rack — Roof — Clamp On	10	5	5

- (1) Located in Passenger Compartment — Front
 (2) Weight Per Mirror
 (3) Add if not factory installed
 (4) Use (3) plus (4) when (3) is not factory installed
 (5) Add to either (3) or (4)
 * Bumper Height Not Affected
 ** To Be Added at Later Date

ACCESSORY WEIGHT CHARTS — Cont'd

1987 VEHICLES

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Ski Rack — Adapts to 4-Seasons Rack	4 1/2	2	2 1/2
Speed Control	5	5	0
Splash Guard	3	1 1/2	1 1/2
Super Seal — Anti-Corrosion Treatment	12	6	6
Telephone	1 1/2	4	8 1/2
Anti Theft	1	1	0
Transmission Oil Cooler — 2 Tube	3	3	0
Transmission Oil Cooler — 4 Tube	4 1/2	4 1/2	0
Wheel Covers*	10	10	10
Wheel Nut—Locking	1	1/2	1/2
Wheel Trim Rings*	4	2	2
Window Shade — rear	3	—	3

(1) Located in Passenger Compartment — Front

(2) Weight Per Mirror

(3) Add if not factory installed

(4) Use (3) plus (4) when (3) is not factory installed

(5) Add to either (3) or (4)

* Bumper Height Not Affected

** To Be Added at Later Date

ACCESSORY WEIGHT CHARTS — Cont'd

1988 VEHICLES

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Air Conditioning			
1.6 EFI Tracer	36	40	-4
1.3 Festiva	35.1	38.8	-3.7
1.9L EFI/CFI Escort/Lynx/EXP	53 1/2	53 1/4	+1/4
2.3L Engine Mustang	48 1/4	52 1/2	-4 1/4
2.3L HSC, Tempo/Topaz	37.8	43.1	-5.3
2.5L Taurus/Sable	43	47 3/4	-4 3/4
3.0L Taurus/Sable	40 1/2	45 3/4	-5 1/4
5.0L Mustang	46 3/4	52	-5 1/4
Air Deflector	5	0	5
Air Springs*	2 1/2	0	2 1/2
Bike Carrier — Roof — Clamp On	8	4	4
Body Side Moulding — Vinyl	3	1 1/2	1 1/2
Cargo Liner	5	0	5
Cassette	2 1/2	2	1/2
Control — Air Spring	5	2 1/2	2 1/2
Defroster — Rear Window	1	1	0
Door Edge Guard—Universal	1/2	1/4	1/4
Electric Clock	1	1	0
Electric I/S Rear View Mirror	1	1	0
Fire Extinguisher (1)	4	3	1
Floor Mat — Full Vinyl — Universal	11 1/2	6 1/2	5
Floor Mat — Twin — Corporate	6	3 1/2	2 1/2
Floor Mat — Twin — Rubber	13	8	5
Floor Mat — Universal — Twin Vinyl	10	6	4
Fog Lights	9	10	-1
Front End Cover	5	5	0
Heater — Engine Block	1/2	1/2	0
Hood Ornament	1	1	0
Jack — Hydraulic Electro	14 1/4	—	14 1/4
Koolatron Cold Box	17	7	10
110 — Volt Power Pack	4	—	4
License Plate Frame	1/4	1/8	1/8
Louvers — Rear Window	17	0	17
Luggage Rack — Deck	8	-1	9
Luggage Rack — Roof — Sedan and Station Wagon	24	-2	26
Outside Mirror — L.H. (2)	1	1	0
Outside Mirror — R.H. (2)	1	1	0
Outside Mirror — Racing (2)	3	3	0
Shades — Rear Window	10	1	9
Shock Absorbers — (Spring Assist) — Rear*	4	0	4
Shock Absorbers — (Spring Assist) — Front*	4	4	0
Ski Rack — Roof — Clamp On	10	5	5

- (1) Located in Passenger Compartment — Front
 (2) Weight Per Mirror
 (3) Add if not factory installed
 (4) Use (3) plus (4) when (3) is not factory installed
 (5) Add to either (3) or (4)
 * Bumper Height Not Affected
 ** To Be Added at Later Date

ACCESSORY WEIGHT CHARTS — Cont'd

1988 VEHICLES

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Ski Rack — Adapts to 4-Seasons Rack	4 1/2	2	2 1/2
Speed Control	5	5	0
Splash Guard	3	1 1/2	1 1/2
Super Seal — Anti-Corrosion Treatment	12	6	6
Super Seal — Undercoating	8	3	5
Telephone	12 1/2	4	8 1/2
Anti Theft	1	1	0
Transmission Oil Cooler — 2 Tube	3	3	0
Transmission Oil Cooler — 4 Tube	4 1/2	4 1/2	0
Wheel Covers*	10	10	10
Wheel Nut—Locking	1	1/2	1/2
Wheel Trim Rings*	4	2	2
Window Shade — rear	3	—	3

(1) Located in Passenger Compartment — Front

(2) Weight Per Mirror

(3) Add if not factory installed

(4) Use (3) plus (4) when (3) is not factory installed

(5) Add to either (3) or (4)

* Bumper Height Not Affected

** To Be Added at Later Date

ACCESSORY WEIGHT CHARTS — Cont'd

1989 VEHICLES

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Air Conditioning			
1.6 EFI Tracer	36	40	-4
1.3 Festiva	35.1	38.8	-3.7
1.9L EFI/CFI Escort/Lynx/EXP	53 1/2	53 1/4	+1/4
2.2L Probe	42.33	47.97	-5.64
2.3L Engine Mustang	48 1/4	52 1/2	-4 1/4
2.3L HSC, Tempo/Topaz	37.8	43.1	-5.3
2.5L Taurus/Sable	43	47 3/4	-4 3/4
3.0L Taurus/Sable	40 1/2	45 3/4	-5 1/4
5.0L Mustang	46 3/4	52	-5 1/4
Air Deflector	5	0	5
Air Springs*	2 1/2	0	2 1/2
Bike Carrier — Roof — Clamp On	8	4	4
Body Side Moulding — Vinyl	3	1 1/2	1 1/2
Cargo Liner	5	0	5
Cassette	2 1/2	2	1/2
Control — Air Spring	5	2 1/2	2 1/2
Defroster — Rear Window	1	1	0
Door Edge Guard—Universal	1/2	1/4	1/4
Electric Clock	1	1	0
Electric I/S Rear View Mirror	1	1	0
Fire Extinguisher (1)	4	3	1
Floor Mat — Twin — Corporate	6	3 1/2	2 1/2
Floor Mat — Twin — Rubber	13	8	5
Floor Mat — Universal — Twin Carpet	10	6	4
Fog Lights	9	10	-1
Front End Cover	5	5	0
Heater — Engine Block	1/2	1/2	0
Hood Ornament	1	1	0
Koolatron Cold Box	17	7	10
110 — Volt Power Pack	4	—	4
License Plate Frame	1/4	1/8	1/8
Louvers — Rear Window	17	0	17
Luggage Rack — Deck	8	-1	9
Luggage Rack — Roof — Sedan and Station Wagon	24	-2	26
Outside Mirror — L.H. (2)	1	1	0
Outside Mirror — R.H. (2)	1	1	0
Outside Mirror — Racing (2)	3	3	0
Shades — Rear Window	10	1	9
Shock Absorbers — (Spring Assist) — Rear*	4	0	4
Shock Absorbers — (Spring Assist) — Front*	4	4	0
Ski Rack — Roof — Clamp On	10	5	5

- (1) Located in Passenger Compartment — Front
 (2) Weight Per Mirror
 (3) Add if not factory installed
 (4) Use (3) plus (4) when (3) is not factory installed
 (5) Add to either (3) or (4)
 * Bumper Height Not Affected
 ** To Be Added at Later Date

ACCESSORY WEIGHT CHARTS — Cont'd

1989 VEHICLES

<u>ACCESSORY</u>	<u>WEIGHT EFFECT (lbs.)</u>		
	<u>TOTAL</u>	<u>FRONT AXLE</u>	<u>REAR AXLE</u>
Ski Rack — Adapts to 4-Seasons Rack	4 1/2	2	2 1/2
Speed Control	5	5	0
Splash Guard	3	1 1/2	1 1/2
Super Seal — Anti-Corrosion Treatment	12	6	6
Super Seal — Undercoating	8	3	5
Telephone	12 1/2	4	8 1/2
Anti Theft	1	1	0
Transmission Oil Cooler — 2 Tube	3	3	0
Transmission Oil Cooler — 4 Tube	4 1/2	4 1/2	0
Wheel Covers*	10	10	10
Wheel Nut—Locking	1	1/2	1/2
Wheel Trim Rings*	4	2	2
Window Shade — rear	3	—	3

- (1) Located in Passenger Compartment — Front
 (2) Weight Per Mirror
 (3) Add if not factory installed
 (4) Use (3) plus (4) when (3) is not factory installed
 (5) Add to either (3) or (4)
 * Bumper Height Not Affected
 ** To Be Added at Later Date

INCHES and MILLIMETERS CONVERSION CHART

MILLIMETERS TO DECIMAL (inches) EQUIVALENT

MM = DECIMAL (Inches)	MM = DECIMAL (Inches)	MM = DECIMAL (Inches)	MM = DECIMAL (Inches)	MM = DECIMAL (Inches)	MM = DECIMAL (Inches)
1 .039	21 .827	41 1.614	61 2.402	81 3.189	125 4.921
2 .079	22 .866	42 1.654	62 2.441	82 3.228	150 5.906
3 .118	23 .906	43 1.693	63 2.480	83 3.268	175 6.890
4 .157	24 .945	44 1.732	64 2.520	84 3.307	
5 .197	25 .984	45 1.772	65 2.559	85 3.346	
6 .236	26 1.024	46 1.811	66 2.598	86 3.386	200 7.874
7 .276	27 1.063	47 1.850	67 2.638	87 3.425	225 8.858
8 .315	28 1.102	48 1.890	68 2.677	88 3.465	250 9.843
9 .354	29 1.142	49 1.929	69 2.717	89 3.504	275 10.827
10 .394	30 1.181	50 1.969	70 2.756	90 3.543	
11 .433	31 1.220	51 2.008	71 2.795	91 3.583	300 11.811
12 .472	32 1.260	52 2.047	72 2.835	92 3.622	325 12.795
13 .512	33 1.299	53 2.087	73 2.874	93 3.661	350 13.780
14 .551	34 1.339	54 2.126	74 2.913	94 3.701	375 14.764
15 .591	35 1.378	55 2.165	75 2.953	95 3.740	
16 .630	36 1.417	56 2.205	76 2.992	96 3.780	400 15.748
17 .669	37 1.457	57 2.244	77 3.031	97 3.819	
18 .709	38 1.496	58 2.283	78 3.071	98 3.858	
19 .748	39 1.535	59 2.323	79 3.110	99 3.898	
20 .787	40 1.575	60 2.362	80 3.150	100 3.937	

DECIMAL (inches) TO METRIC EQUIVALENT

DECIMAL = MM (Inches)	DECIMAL = MM (Inches)	DECIMAL = MM (Inches)	DECIMAL = MM (Inches)	DECIMAL = MM (Inches)	DECIMAL = MM (Inches)
.001 .025	.120 3.048	.320 8.128	.520 13.208	.720 18.288	.920 23.368
.002 .051	.130 3.302	.330 8.382	.530 13.462	.730 18.542	.930 23.622
.003 .076	.140 3.556	.340 8.636	.540 13.716	.740 18.796	.940 23.876
.004 .102	.150 3.810	.350 8.890	.550 13.970	.750 19.050	.950 24.130
.005 .127	.160 4.064	.360 9.144	.560 14.224	.760 19.304	.960 24.384
.006 .152	.170 4.318	.370 9.398	.570 14.478	.770 19.558	.970 24.638
.007 .178	.180 4.572	.380 9.652	.580 14.732	.780 19.812	.980 24.892
.008 .203	.190 4.826	.390 9.906	.590 14.986	.790 20.066	.990 25.146
.009 .229	.200 5.080	.400 10.160	.600 15.240	.800 20.320	
.010 .254	.210 5.334	.410 10.414	.610 15.494	.810 20.574	1.000 25.400
.020 .508	.220 5.588	.420 10.668	.620 15.748	.820 20.828	2.000 50.800
.030 .762	.230 5.842	.430 10.922	.630 16.002	.830 21.082	3.000 76.200
.040 1.016	.240 6.096	.440 11.176	.640 16.256	.840 21.336	4.000 101.600
.050 1.270	.250 6.350	.450 11.430	.650 16.510	.850 21.590	5.000 127.000
.060 1.524	.260 6.604	.460 11.684	.660 16.764	.860 21.844	10.000 254.000
.070 1.778	.270 6.858	.470 11.938	.670 17.018	.870 22.098	15.000 381.000
.080 2.032	.280 7.112	.480 12.192	.680 17.272	.880 22.352	20.000 508.000
.090 2.286	.290 7.366	.490 12.446	.690 17.526	.890 22.606	25.000 635.000
.100 2.540	.300 7.620	.500 12.700	.700 17.780	.900 22.860	50.000 1270.000
.110 2.794	.310 7.874	.510 12.954	.710 18.034	.910 23.114	100.000 2540.000

INCHES and MILLIMETERS CONVERSION CHART — Cont'd

FRACTIONS (inches) TO DECIMALS (inches) and METRIC EQUIVALENTS					
FRACTION (Inches)	= DECIMAL = (Inches)	MM	FRACTION (Inches)	= DECIMAL = (Inches)	MM
1/64	.016	.397	5/8	.625	15.875
1/32	.031	.794	41/64	.641	16.272
3/64	.047	1.191	21/32	.656	16.669
1/16	.063	1.588	43/64	.672	17.066
5/64	.078	1.984	11/16	.687	17.463
3/32	.094	2.381	45/64	.703	17.859
7/64	.109	2.778	23/32	.719	18.256
			47/64	.734	18.653
1/8	.125	3.175	3/4	.750	19.050
9/64	.141	3.572	49/64	.766	19.447
5/32	.156	3.969	25/32	.781	19.844
11/64	.172	4.366	51/64	.797	20.241
3/16	.188	4.763	13/16	.813	20.638
13/64	.203	5.159	53/64	.828	21.034
7/32	.219	5.556	27/32	.844	21.431
15/64	.234	5.953	55/64	.859	21.828
1/4	.250	6.350	7/8	.875	22.225
17/64	.266	6.747	57/64	.891	22.622
9/32	.281	7.144	29/32	.906	23.019
19/64	.297	7.541	59/64	.922	23.416
5/16	.313	7.938	15/16	.938	23.813
21/64	.328	8.334	61/64	.953	24.209
11/32	.344	8.731	21/32	.969	24.606
23/64	.359	9.128	63/64	.984	25.003
3/8	.375	9.525	1	1.000	25.400
25/64	.391	9.922	2	2.000	50.800
13/32	.406	10.319	3	3.000	76.200
27/64	.422	10.716	4	4.000	101.600
7/16	.438	11.113	5	5.000	127.000
29/64	.453	11.509	10	10.000	254.000
15/32	.469	11.906	15	15.000	381.000
31/64	.484	12.303	20	20.000	508.000
1/2	.500	12.700	25	25.000	635.000
33/64	.516	13.097	50	50.000	1270.000
17/32	.531	13.494	100	100.000	2540.000
35/64	.547	13.891			
9/16	.563	14.288			
37/64	.578	14.684			
19/32	.594	15.081			
39/64	.609	15.478			

ABBREVIATIONS

A/C	air conditioner (ing)	E.E.C.	engine electronic control
accel.	accelerator	E.F.I.	electronic fuel injection
adj.	adjuster (ing)	ea.	each
alt.	altitude	E/H/D	extra heavy duty
alum.	aluminum	emer.	emergency
amp.	ampere	em/re	emission reduction
AOT	automatic overdrive transmission	eng.	engine
approx.	approximate (ly)	equip.	equipment
AR	as required	ESCO	ESCORT
assy.	assembly	ev/em	evaporative emission
A/T	automatic transmission	exc.	except
A.T.C.	automatic temperature control	exh.	exhaust
ATX	automatic transaxle	E.G.R.	exhaust gas recirculation
attach.	attaches (ing) (ed)		
auto.	automatic	FAIR	FAIRMONT
aux.	auxiliary	FIES	FIESTA
		fill.	fillister
BOBC	BOBCAT	flex.	flexible
B/T	body type	FMX	automatic transmission
B/W	Borg-Warner	F.S.O.	foreign special order
		F2	Ford 2 barrel
CALIF.	CALIFORNIA	F/4/S	Ford 4 speed transmission
CAN.	CANADA	gal.	gallon
cap.	capacity	g/compt.	glove compartment
CAPRI	CAPRI	GRAN	GRANADA
carb.	carburetor	G.V.W.	gross vehicle weight
cc	cubic centimeter		
c.c.d.	cubic centimeter displacement	hd.	head
c/cw	counter clockwise	H/D	heavy duty
Chg./L	change level	hel.	helical
C.I.D.	cubic inch displacement	hex.	hexagon (al)
cm	centimeter	Hi-Perf.	High Performance
C/M	automatic transmission (MX type)	H/O	High Output
c/member	cross member	HP	horse power
col.	column	hsg.	housing
compt.	compartment	HSC	high swirl combustion
conn.	connection or connector	htr.	heater
cont'd.	continued	hyd.	hydraulic
C.P.	candle power		
CONT	CONTINENTAL	I.D.	inside diameter
COUG	COUGAR	ident.	identification
COUG (XR7)	COUGAR (XR7)	ign.	ignition
COUG (EXC. XR7)	COUGAR (EXC. XR7)	incl.	includes
cw	clockwise	INJ.	injector
cyl.	cylinder	instal.	installation
C1	Carter 1 barrel	I.S.	Instruction Sheet
C3	automatic transmission	I.W.	inertia weight
C4	automatic transmission	I.W.W.G.	Intermittent windshield wiper governor
C5	automatic transmission		
C6	automatic transmission	K.D.	shipped in disassembled form
		KM.P.H.	kilometers per hour
D.C.	double contact	L	litre
D/D	direct drive	lb.	pound
defl.	deflector	l/compt.	luggage compartment
dia.	diameter	L/D	light duty
diff.	differential	L.H.	left hand
disp.	displacement	lic.	license
dist.	distributor	LINC	LINCOLN
D.S.O.	domestic special order	L/N	Leece Neville
		LPG	propane fueled
		L.P.O.	Limited Production Option

ABBREVIATIONS — Cont'd

M	1000 (pounds)	S/E	single exhaust or special economy
max.	maximum	sec.	secondary
MCU	microprocessor control unit	Ser.	serial
med.	medium	s/member	side member
MERC	MERCURY	spec.	special
mldg.	moulding	speedo.	speedometer
mm	millimeter	spg.	spring
m.p.h.	miles per hour	sq.	square
MONA	MONARCH	sq. hd.	square head
M/S	manual steering	S/R	side rail
M/T	manual transmission	SROD	single rail overdrive trans.
mtd.	mounted	std.	standard
mtg.	mounting	strg.	steering
mtr.	motor	suppt.	support
MTX	manual transaxle	SVO	Special Vehicle Operations
MUST	MUSTANG	susp.	suspension
		S/X/C	super extra cooling
		sys.	system
Nags. No.	National Automotive Glass Society number	tach.	tachometer
No.	number	TC	turbocharger
N.P.T.F.	nationa. pipe thread fine	T/E	thermactor emission control system
N.R.	not replaced	temp.	temperature
N.S.	not serviced	TEMP	TEMPO
		t/gate	tailgate
O.D.	outside diameter	thd.	thread
O/D	overdrive	THUN	THUNDERBIRD
O/S	oversize	TOPA	TOPAZ
oz.	ounce	trans.	transmission
		Trans/ign.	transistorized ignition
pass.	passenger	Trans/reg.	transistorized regulator
P/B	power brake	TT	trailer tow
P/C	Police Car	T/T	trailer tow
pcs.	pieces	T5	WARNER 5 speed overdrive trans.
PINT	PINTO		
pri.	primary	UBS	uniform bearing stress
P/S	power steering	u/joint	universal joint
		univ.	universal
qt.	quart	U/S	undersize
qty.	quantity		
		vac.	vacuum
rad.	radiator	VERS	VERSAILLES
r/b	replaced by	VV	variable venturi
R/D	regular duty		
rd.	round	w/	with
recirc.	recirculating	W/4/S	Warner 4 speed transmission
reinf.	reinforcement	W/B	wheelbase
Repl.	replaced	w/o	without
req'd.	required	W/S	windshield
resvr.	reservoir	w/strip	weatherstrip
R.F.	regular fuel		
R/G	ring gear	X/C	extra cooling
R.H.	right hand	ZEPH	ZEPHYR
R.P.M.	revolutions per minute	2/B	2 barrel
rr.	rear	4/B	4 barrel
r/wheels	rear wheels	4/M/T	4 speed manual transmission
		5/M/OD/T	5 speed manual overdrive transmission
S/C	standard cooling	&	and
S.C.	single contact		
s/compt.	storage compartment		

CERTIFICATION LABEL — TYPICAL

(Refer to Pages 27 thru 53 for CERTIFICATION LABEL)

Located on the latch face of the left Front Door.


The Certification Label includes:

1. Built date (e.g. 10/80) in upper left hand corner which indicates the month and year in which the unit was built.
2. Vehicle Identification Number (left half of first line) consisting of Codes which identify Model Year, Assembly Plant, Series, Engine and Numerical Sequence of Assembly (also shown in upper right hand corner).
3. Vehicle Identification Number consisting of Codes which identify Model Year Code, Assembly Plant Code, Series Code, Engine Code and Numerical Sequence of Assembly.
4. Certification Label consisting of Codes which identify Body Color Code, District Codes (D.S.O. Number where applicable), Body Type Code, Vinyl Roof Code, Bodyside Moulding Code, Trim Code, Air Conditioning Code, Radio Code, Sun/Moon Roof Code, Rear Axle Ratio Code, Transmission Code and Front-Rear Spring Code.

The codes shown below are listed on pages 23 thru 26.

1980


FIRST LINE (0G63G100001) VEHICLE IDENTIFICATION NUMBER



- "0" — 1980 Model Year
- "G" — Assembled at Chicago Assembly Plant
- "63" — LTD 4 Door Pillared Hardtop or Marquis Brougham 2 Door Sedan
- "G" — 8 Cyl. 351-2/B engine
- "100001" — First Ford Series Vehicle assembled during Model Year.
- "10/79" — Built during October, 1979

1981/

FIRST LINE (1FDBP05F@BA 100,001) VEHICLE IDENTIFICATION NUMBER



- "1FD" — Manufactured by Ford Motor Co., U.S.A., as an incomplete vehicle
- "B" — Active Belts
- "P" — "P" (Passenger Car only)
- "05" — Escort or Lynx—3 Door Sedan Hatchback
- "F" — 8 cyl. 302 (5.0 litre) 2/B Engine
- "@" — Check Digit (internal usage)
- "B" — Model Year 1981
- "A" — Assembly Plant — Atlanta
- "100,001" — First Unit Built (Escort)
- "600,001" — First Unit Built (Lynx)

- "1C" — Black
- "54H" — LTD 4 Door Pillared Hardtop, or Marquis 4 Door Sedan
- "HD" — Grande Full — Red
- "G6D" — Medium Red Metallic
- "DD" — Ford or Mercury—B/cloth & vinyl—L/B Split Bench—Dark Red
- "A" — A/C Installed (Before 1/83)
- "4" — Tape stripe color (From 1/83)
- "2" — Am Radio
- "B" — Sunroof Glass
- "6" — Rear Axle Ratio of 3.00 to 1 (non—locking)
- "X" — Cruise—O—Matic (FMX)
- "MMMM" — Springs — left front, right front, left rear, right rear
- "41" — Chicago District

CERTIFICATION LABEL — TYPICAL — Cont'd

1981/ VEHICLE IDENTIFICATION NUMBER 1FD BP05F@BA100,001
THE FIRST 3 DIGITS OF THE VEHICLE IDENTIFICATION
NUMBER INDICATES THE WORLD MANUFACTURER IDENTIFIER.

FORD MOTOR COMPANY WORLD MANUFACTURER IDENTIFIER

CODE	MANUFACTURER	MAKE	TYPE
1 F A	Ford Motor Company, USA	Ford	Passenger Car
1 F B	Ford Motor Company, USA	Ford	Bus
1 F C	Ford Motor Company, USA	Ford	Truck Stripped Chassis
1 F D	Ford Motor Company, USA	Ford	Incomplete vehicles
1 F F	Ford Motor Company, USA	Ford	Motor Vehicle Equipment w/o Engine Powertrain (Glider)
1 F M	Ford Motor Company, USA	Ford	MPV
1 F T	Ford Motor Company, USA	Ford	Truck (Complete Vehicle)
1 L J	Ford Motor Company, USA	Lincoln	Incomplete vehicle
1 L N	Ford Motor Company, USA	Lincoln	Passenger Car
1 M E	Ford Motor Company, USA	Mercury	Passenger Car
1 M H	Ford Motor Company, USA	Mercury	Incomplete Vehicle
1 M B	Ford Motor Company, USA	Continental	Passenger Car
1 N J	Ford Motor Company, USA	Continental	Passenger Car
1 Z V	Mazda Mtr. Manufacturing (USA)	Ford	Passenger Car
2 F A	Ford Motor Company of Canada, Ltd.	Ford	Passenger Car
2 F B	Ford Motor Company of Canada, Ltd.	Ford	Bus
2 F C	Ford Motor Company of Canada, Ltd.	Ford	Truck Stripped Chassis
2 F D	Ford Motor Company of Canada, Ltd.	Ford	Incomplete Vehicle
2 F F	Ford Motor Company of Canada, Ltd.	Ford	Ford Vehicle Equipment w/o Engine/Powertrain (Glider)
2 F M	Ford Motor Company of Canada, Ltd.	Ford	MPV
2 F T	Ford Motor Company of Canada, Ltd.	Ford	Truck (Complete Vehicle)
2 M E	Ford Motor Company of Canada, Ltd.	Mercury	Passenger Car
2 M H	Ford Motor Company of Canada, Ltd.	Mercury	Incomplete Vehicle
3 M A	Ford Motor Company, S.A. (Mexico)	Mercury	Passenger Car
3 F A	Ford Motor Company, S.A.	Ford	Passenger Car
3 F C	Ford Motor Company, S.A. (Mexico)	Ford	Basic Stripped Chassis
6 M P	Ford Motor Company of Australia, Ltd.	Mercury	Passenger Car (Imported Capri)
9 B F	Ford Brazil, S.A.	Ford	Incomplete vehicle (Truck) Imported Cargo
J C 1	Toyo Kogyo Company, Ltd., Japan	Ford	Passenger Car (Imported Laser)
J C 2	Toyo Kogyo Company, Ltd., Japan	Ford	Truck (Complete Vehicle) (Imported Courier)
J C 4	Toyo Kogyo Company, Ltd., Japan	Ford	Incomplete Vehicle (Imported Courier)
K N J	KIA Motors Inc., Korea	Ford	Passenger Car
L F A	Ford Lio Ho Motor Company (Taiwan), Ltd.	Mercury	Passenger Car (Imported Mercury Tracer)
W F O (Zero)	Ford Werke A.G., Germany	Ford	Passenger Car (Imported Fiesta)
W F 1	Ford Werke A.G., Germany	Merkur	Passenger Car (Imported XR4Ti)

1981/ VEHICLE IDENTIFICATION NUMBER 1FD B P05F@BA100,001
THE FOURTH DIGIT OF THE VEHICLE IDENTIFICATION
NUMBER INDICATES THE RESTRAINT SYSTEM.

RESTRAINT SYSTEM

VIN CODE	DESCRIPTION
B	Active Belts
C	Air Bags and Active Belts (Front)
P	Passive Belts (Front)

1981/ VEHICLE IDENTIFICATION NUMBER 1FDB P 05F@BA100,001
THE FIFTH DIGIT OF THE VEHICLE IDENTIFICATION
NUMBER INDICATES PASSENGER CAR.

PRODUCTION EFFECTIVE DATES**Catalog Reference**

The preferred method for identifying replacement parts for identical application is to utilize physical differences between the parts, which are oftentimes denoted in the catalog under the description column. Occasionally it is necessary to reference the vehicle build date to determine which replacement part to order. The dates are shown in the text as "BEFORE" and "FROM" a specific date. The date shown in the catalog is the earliest tentative production incorporation date and therefore is subject to change. It is also possible that a production change which is effective at more than one assembly plant may be incorporated on different dates. For these reasons the productions effective date shown in the catalog should be considered as an approximate date.

Vehicle Reference

There are three principal methods for determining the vehicle build date: 1. the yellow date stamp on the radiator support. 2. the date on the Vehicle Certification Label and 3. the date code on the Owners Card. It is preferable to reference the yellow ink stamp date, as the other two dates are tentative scheduled off-line dates. The locations and codes for these dates are shown below:

1. Location of Vehicle Build Date Stamp

Top of radiator support assembly plants use a 4 digit number to indicate the month and day of build.

Example —

<u>Actual Calendar Date of Build</u>	<u>Date Stamp On Unit</u>
January 24	0124
October 21	1021

2. Certification Label

The month code is shown on the Certification Label in the upper left hand corner (e.g. 10/79 indicates October, 1979).

OWNER CARD
WARRANTY IDENTIFICATION CARD
NAME _____
ADDRESS _____
CITY & STATE _____
NO SERVICE DATE _____
DEALER SALES CODE _____

MFG. BY FORD MOTO
DATE: 10-79 GTWR: 5347
FRONT GAWR: 2714.LB REAR
1231.KG

3. Owner Card

The month and day of manufacture is shown on the owner card. The numerical portion identifies the day and the alphabetical portion identifies the month. The month codes are listed in the following chart together with the month which they represent.

0063G100001 R 3HYO 84
66H PB 221 KXA7
P.14003

CODE	MONTH — FIRST YEAR	CODE	MONTH — FIRST YEAR	CODE	MONTH — SECOND YEAR	CODE	MONTH — SECOND YEAR
A	January	G	July	N	January	U	July
B	February	H	August	P	February	V	August
C	March	J	September	Q	March	W	September
D	April	K	October	R	April	X	October
E	May	L	November	S	May	Y	November
F	June	M	December	T	June	Z	December

CERTIFICATION LABEL

YEAR CODES

1980

VEHICLE IDENTIFICATION NUMBER 0 G63G100,001

THE FIRST DIGIT OF THE VEHICLE IDENTIFICATION NUMBER IDENTIFIES THE MODEL YEAR OF THE VEHICLE.

1981/

VEHICLE IDENTIFICATION NUMBER 1FDBP05F@ B A100,001

THE TENTH DIGIT OF THE VEHICLE IDENTIFICATION NUMBER IDENTIFIES THE MODEL YEAR OF THE VEHICLE.

THE FOLLOWING CHART LISTS THESE CODES AND THE CORRESPONDING MODEL YEAR.

Code — 0 or A	Year — 1980	Code — F	Year — 1985
Code — B	Year — 1981	Code — G	Year — 1986
Code — C	Year — 1982	Code — H	Year — 1987
Code — D	Year — 1983	Code — J	Year — 1988
Code — E	Year — 1984	Code — K	Year — 1989

ASSEMBLY PLANT CODES — PASSENGER CAR

1980

VEHICLE IDENTIFICATION NUMBER 0 G 63G100,001

THE SECOND DIGIT OF THE VEHICLE IDENTIFICATION NUMBER INDICATES THE PLANT AT WHICH THE VEHICLE WAS ASSEMBLED.

1981/

VEHICLE IDENTIFICATION NUMBER 1FDBP05F@B A 100,001

THE ELEVENTH DIGIT OF THE VEHICLE IDENTIFICATION NUMBER INDICATES THE PLANT AT WHICH THE VEHICLE WAS ASSEMBLED.

CODE	ASSEMBLY PLANT	CODE	ASSEMBLY PLANT	CODE	ASSEMBLY PLANT	CODE	ASSEMBLY PLANT
A	Atlanta	H	Lorain	R	San Jose	X	St. Thomas
B	Oakville	J	Los Angeles		Hermosillo, Mexico	Y	Wixom
E	Mahwah	K	Kansas City	S	Pilot	5	Mazda-Flat Rock, MI
	Niehl, Cologne, W. Germany	M	Karmann, Rheine, W. Germany	T	(Allen Park)	6	Mazda-Kia, Korea
F	Dearborn	N	Norfolk	W	Metuchen (Edison)		
G	Chicago	P	Twin Cities		Wayne		

ENGINE CODES

1980

VEHICLE IDENTIFICATION NUMBER 0G63 G 100,001

THE FIFTH DIGIT OF THE VEHICLE IDENTIFICATION NUMBER INDICATES BASIC ENGINE IDENTIFICATION.

1981/

VEHICLE IDENTIFICATION NUMBER 1FDBP05 F @BA100,001

THE EIGHTH DIGIT OF THE VEHICLE IDENTIFICATION NUMBER INDICATES ENGINE IDENTIFICATION.

CODE	YEAR	ENGINE CYL. C.I.D.	CARB.	REMARKS	CODE	YEAR	ENGINE CYL. C.I.D.	CARB.	REMARKS
A	80/	4 140		2.3 litres — OHC — EFI	R	83/85	4 140		2.3 litres — HSC
B	80/82	6 200	1/B	3.3 litres		89	4 134		2.2 litres — EFI — Turbo — Probe
C	80	6 250	1/B	4.1 litres	R	86/87	4 140	1/B	2.3 litres — Canada only
	84/85	6 232	2/B	3.8 litres — U.S. only		89	6 232		3.8 litres — EFI — SC
	89	6 232		3.8 litres — EFI SC	S	85/	4 140		2.3 litres — HSC — HO — CFI EFI
	89	4 133		2.2 litres — E.F.I. (Probe only)	T	81/	4 140		2.3 litres (Turbo/IC) — EFI
D	80/82	8 255	2/B	4.2 litres	U	86/	6 183		3.0 litres — EFI
D	83	4 140		2.3 litres (Turbo) — EFI	V	88/	6 177		2.9 litres — Germany
D	86/	4 153		2.5 litres — CFI	W	83/	4 140		2.3 litres (Turbo) — EFI
E	87/	8 302		5.0 litres — EFI/HO — Mustang, Mark VII	X	83	6 200		3.3 litres
					X	85/	4 140		2.3 HSC — CFI — EFI
F	80/	8 302		5.0 litres — CFI — EFI	Y	89	6 182		3.0 litres SHO (Yamaha) — EFI
G	80/	8 351	2/B	5.8 litres — HO	1	81	4 79		1.3 litres
H	84/87	4 122		2.0 litres — Diesel — Toyo Kogyo	2	81/85	4 98		1.6 litres
	89	4 79		1.3 litres — EFI (Mazda)	3	82/87	6 232		3.8 litres — CFI
J	85/	4 116		1.9 litres — EFI		84/86	6 232	2/B	3.8 litres — Canada only
K	88/	4 79	2-V	1.3 litres — Mazda	4	83/85	4 98		1.6 litres — HO
L	84/85	6 146		2.4 litres — Diesel — Turbo	4	87/	6 232		3.8 litres — EFI — SEFI
	89	4 133		2.2 litres — E.F.I./TC	5	83/85	4 98		1.6 litres — EFI
M	84/86	8 302	4/B	5.0 litres — CFI/HO	5	87/	4 98		1.6 litres — Mazda
M	87	8 302		5.0 litres — EFI/HO Mark VII LCS Only	6	82/85	4 140		2.3 litres LP Gas
					7	83/85	4 98		1.6 litres Methanol — HO
O	80			D.S.O. Gas Engines	8	84/85	4 98		1.6 litres (Turbo) — EFI
					9	85/	4 116		1.9 litres — 2V or CFI

CERTIFICATION LABEL — Cont'd

NUMERICAL SEQUENCE OF ASSEMBLY

1980

VEHICLE IDENTIFICATION NUMBER 0G63G 100,001

1981/

VEHICLE IDENTIFICATION NUMBER
1FDBP05F@BA 100,001 FORD OR 600,001 MERCURY

SERIES CODES—FORD/LINCOLN-MERCURY

1980

VEHICLE IDENTIFICATION NUMBER 0G 63 G100,001

THE THIRD AND FOURTH DIGITS OF THE VEHICLE
IDENTIFICATION NUMBER INDICATES THE BODY SERIES.

1981/

VEHICLE IDENTIFICATION NUMBER 1FDBP 05 F@BA100,001

THE SIXTH AND SEVENTH DIGIT OF THE VEHICLE
IDENTIFICATION NUMBER INDICATES THE BODY SERIES.

CODE		YEAR	DESCRIPTION	CODE		YEAR	DESCRIPTION
SERIES	TYPE			SERIES	TYPE		
1980							
(A) FORD							
60	66D	80	LTD S 2 Door Sedan	64	66K	80	LTD Crown Victoria 2 Door Sedan
61	54D	80	LTD S 4 Door Sedan	65	54K	80	LTD Crown Victoria 4 Door Sedan
62	66H	80	Custom 500 2 Door Sedan	72	74D	80	LTD S 4 Door Station Wagon
62	66H	80	LTD 2 Door Sedan	74	74H	80	Custom 500 4 Door Station Wagon (Canada)
62	54H	80	Custom 500 4 Door Sedan	74	74H	80	LTD Station Wagon
63	54H	80	LTD 4 Door Sedan	76	74K	80	Country Squire Station Wagon
(MA) MERCURY							
61	66H	80	Marquis 2 Door Sedan	65	66L	80	Gran Marquis 2 Door Sedan
62	54H	80	Marquis Brougham 4 Door Sedan	66	54L	80	Gran Marquis 4 Door Sedan
63	66K	80	Marquis Brougham 2 Door Sedan	74	74H	80	Marquis Station Wagon
64	54K	80	Marquis Brougham 4 Door Sedan	76	74K	80	Colony Park Station Wagon
(D) LINCOLN							
81	66D	80	2 Door Pillar Hardtop	82	54D	80	4 Door Pillar Hardtop
(F) MUSTANG							
02	66B	80	2 Door Sedan	04	66H	80	Ghia 2 Door Sedan
03	61R	80	3 Door Sedan	05	61H	80	Ghia 3 Door Sedan
(J) CAPRI							
14	61D	80	3 Door Fastback	16	61H	80	Ghia 3 Door Fastback
(K) MARK VI							
89	66D	80	2 Door Sedan	90	54D	80	4 Door Pillar Hardtop
(G) GRANADA							
81	66H	80	2 Door Sedan	82	54H	80	4 Door Sedan
(MG) MONARCH							
33	66H	80	2 Door Sedan	34	54H	80	4 Door Sedan
(L) PINTO							
10	62B	80	2 Door Sedan	12	73B	80	2 Door Station Wagon
11	64B	80	3 Door Sedan (Runabout)				
(ML) BOBCAT							
20	64H	80	3 Door Sedan (Runabout)	24	64B	80	3 Door Sedan—Runabout (Canada Only)
22	73H	80	2 Door Station Wagon	25	73B	80	2 Door Station Wagon (Canada Only)
23	62B	80	2 Door Sedan (Canada Only)				
(P) FAIRMONT							
91	66B	80	2 Door Sedan	93	36R	80	2 Door Sedan (Sporty Coupe)
92	54B	80	4 Door Sedan	94	74B	80	Station Wagon
(MP) ZEPHYR							
31	66D	80	2 Door Sedan	35	36R	80	Sporty Coupe 2 Door Sedan
32	54D	80	4 Door Sedan	36	74D	80	4 Door Station Wagon
(S) THUNDERBIRD							
87	66D	80	2 Door Sedan				

CERTIFICATION LABEL — Cont'd

BODY TYPE CODE — FORD/LINCOLN MERCURY

THIS CODE APPEARS ABOVE OR BELOW "BODY" AND IDENTIFIES THE BODY TYPE OF THE UNIT.

THE FOLLOWING CHART LISTS THESE CODES (IN CONJUNCTION WITH THE SERIES CODES)

AND THE BODY TYPE WHICH THEY REPRESENT.

THIS VEHICLE CONFORMS ALL APPLICABLE FET
BUMPER STANDARDS IN EFFECT ON THE DATE

VEH. IDENT. NO. 0G63G100001

TYPE PASSENGER

1C

EXTERIOR PAINT COLORS
54H HD G6D DD A

CERTIFICATION LABEL SHOWN

CODE		YEAR	DESCRIPTION	CODE		YEAR	DESCRIPTION
TYPE	SERIES			TYPE	SERIES		
1980							
(A) FORD							
54D	61	80	LTD S 4 Door Sedan	66K	64	80	LTD Crown Victoria 2 Door Sedan
54H	63	80	Custom 500 4 Door Sedan	74D	72	80	LTD S 4 Door Station Wagon
	63	80	LTD 4 Door Sedan	74H	74	80	Custom 500 Station Wagon (Canada)
54K	65	80	LTD Crown Victoria 4 Door Sedan		74	80	LTD Station Wagon
66D	60	80	LTD S 2 Door Sedan	74K	76	80	Country Squire Station Wagon
66H	62	80	Custom 500 2 Door Sedan				
	62	80	LTD 2 Door Sedan				
(MA) MERCURY							
54H	62	80	Marquis 4 Door Sedan	66K	63	80	Marquis Brougham 2 Door Sedan
54K	64	80	Marquis Brougham 4 Door Sedan	66L	65	80	Gran Marquis 2 Door Sedan
54L	66	80	Gran Marquis 4 Door Sedan	74H	74	80	Marquis Station Wagon
66H	61	80	Marquis 2 Door Sedan	74K	76	80	Colony Park Station Wagon
(D) LINCOLN							
54D	82	80	4 Door Pillar Hardtop	66D	81	80	2 Door Pillar Hardtop
(F) MUSTANG							
61H	05	80	Ghia 3 Door Sedan	66B	02	80	2 Door Sedan
61R	03	80	3 Door Sedan	66H	04	80	Ghia 2 Door Sedan
(J) CAPRI							
61D	14	80	3 Door Fastback	61H	16	80	Ghia 3 Door Fastback
(G) GRANADA							
54H	82	80	4 Door Sedan	66H	81	80	2 Door Sedan
(MG) MONARCH							
54H	34	80	4 Door Sedan	66H	33	80	2 Door Sedan
(K) MARK VI							
54D	90	80	2 Door Pillar Hardtop	66D	89	80	2 Door Sedan
(L) PINTO							
62B	10	80	2 Door Sedan	64B	11	80	3 Door Sedan (Runabout)
				73B	12	80	2 Door Station Wagon
(ML) BOBCAT							
62B	23	80	2 Door Sedan (Canada Only)	73B	25	80	2 Door Station Wagon (Canada Only)
64B	24	80	3 Door Sedan — Runabout (Canada Only)	73H	22	80	2 Door Station Wagon
64H	20	80	3 Door Sedan (Runabout)				
(P) FAIRMONT							
36R	93	80	2 Door Sedan (Sporty Coupe)	66B	91	80	2 Door Sedan
54B	92	80	4 Door Sedan	74B	94	80	Station
(MP) ZEPHYR							
36R	35	80	Sporty Coupe 2 Door Sedan	66D	31	80	2 Door Sedan
54D	32	80	4 Door Sedan	74D	36	80	Station Wagon
(S) THUNDERBIRD							
66D	87	80	2 Door Sedan				
(MF) COUGAR							
66D	93	80	XR7 2 Door Hardtop				
(MV) VERSAILLES							
54M	84	80	4 Door Sedan				

1980/89
FORD/LINCOLN-MERCURY CARS

GENERAL
INFORMATION 43

CERTIFICATION LABEL — Cont'd

BODY TYPE CODE—FORD/LINCOLN MERCURY—Cont'd

CODE		YEAR	DESCRIPTION	CODE		YEAR	DESCRIPTION
TYPE	SERIES			TYPE	SERIES		
1981/82							
(A) FORD							
54D	31	81/82	LTD S 4 Door Sedan	74D	37	81/82	LTD S 4 Door Station Wagon
54H	33	81/82	LTD 4 Door Sedan	74H	38	81/82	LTD 4 Door Station Wagon
54K	35	81/82	LTD Crown Victoria 4 Door Sedan	74K	39	81/82	LTD Country Squire
66H	32	81/82	LTD 2 Door Sedan				4 Door Station Wagon
66K	34	81/82	LTD Crown Victoria 2 Door Sedan				
(MA) MERCURY							
54H	81	81/82	Marquis 4 Door Sedan	66L	84	81/82	Gran Marquis 2 Door Sedan
54K	83	81/82	Marquis Brougham 4 Door Sedan	74H	87	81/82	Marquis 4 Door Station Wagon
54L	85	81/82	Gran Marquis 4 Door Sedan	74K	88	81/82	Colony Park 4 Door Station Wagon
66K	82	81/82	Marquis Brougham 2 Door Sedan				
(C) EXP							
67D	01	82	3 Door Hatchback Coupe				
(MC) LN7							
67D	61	82	3 Door Hatchback Coupe				
(D) LINCOLN							
54D	94	81	4 Door Sedan	66D	93	81	2 Door Sedan
(DC) LINCOLN CONTINENTAL							
54D	98	82	4 Door Sedan				
(DT) LINCOLN TOWN CAR							
54D	94	82	4 Door Sedan				
(F) MUSTANG							
61B	16	82	3 Door Sedan Hatchback	66B	10	81/82	2 Door Sedan
61H	13	81/82	Ghia 3 Door Sedan Hatchback	66H	12	81/82	Ghia 2 Door Sedan
61R	15	81	Cobra 3 Door Sedan Hatchback				
(J) CAPRI							
61D	67	81/82	3 Door Sedan Hatchback	61H	68	81/82	Ghia 3 Door Sedan Hatchback
(G) GRANADA							
54D	27	81/82	4 Door Sedan	66D	26	81/82	2 Door Sedan
				74D	28	82	4 Door Station Wagon
(K) MARK VI							
54D	96	81/82	4 Door Sedan	66D	95	81/82	2 Door Coupe
(P) FAIRMONT							
36R	22	81/82	Futura 2 Door Sport Coupe	66B	20	81/82	2 Door Sedan
54B	21	81/82	Futura 4 Door Sedan	74B	23	81	Futura 4 Door Station Wagon
(MP) ZEPHYR							
36R	72	81/82	Z7 2 Door Sedan	66D	70	81	2 Door Sedan
54D	71	81/82	4 Door Sedan	74D	73	81	4 Door Station Wagon
(S) THUNDERBIRD							
66D	42	81/82	Town Landau Heritage				
(MF) COUGAR EXC. XR7							
54D	77	81/82	4 Door Sedan	74D	78	82	4 Door Station Wagon
66D	76	81/82	2 Door Sedan				

CERTIFICATION LABEL — Cont'd

BODY TYPE CODE—FORD/LINCOLN MERCURY—Cont'd

CODE		YEAR	DESCRIPTION	CODE		YEAR	DESCRIPTION
TYPE	SERIES			TYPE	SERIES		
1981/82 — Cont'd							
(MF) COUGAR							
66D	90	81/82	2 Door Sedan				
(W) ESCORT							
58D	06	82	5 Door Sedan Hatchback	74D	08	81/82	4 Door Liftgate
61D	05	81/82	3 Door Sedan Hatchback				
(MW) LYNX							
58D	64	82	5 Door Sedan Hatchback	74D	65	81/82	4 Door Liftgate
61D	63	81/82	3 Door Sedan Hatchback				
1983/86							
(A) FORD							
54K	43	83/86	LTD Crown Victoria 4 Door Sedan	74K	44	83/86	LTD Country Squire 4 Door Station Wagon
66K	42	83/86	LTD Crown Victoria 2 Door Sedan				
(MA) MERCURY							
54K	95	83/86	Grand Marquis 4 Door Sedan	74K	94	83/86	Grand Marquis Colony Park 4 Door Station Wagon
66K	93	83/86	Grand Marquis 2 Door Sedan				
(B) TEMPO							
54D	21	84/86	4 Door Sedan—Base Series	66D	18	84/86	2 Door Sedan—Base Series
54D	22	84/86	4 Door Sedan—GL Series	66D	19	84/86	2 Door Sedan—GL Series
54D	23	84/86	4 Door Sedan—GLX, LX Series	66D	20	84/86	2 Door Sedan—GLX, LX Series
(MB) TOPAZ							
54D	74	84/86	4 Door Sedan — Base Series	66D	71	84/86	2 Door Sedan — Base Series
54D	75	84/86	4 Door Sedan — GS Series	66D	72	84/86	2 Door Sedan — GS Series
54D	76	84/86	4 Door Sedan — LS Series	66D	73	84/86	2 Door Sedan — LS Series
(C) EXP							
67D	01	83/85	3 Door Hatchback Coupe				
(MC) LN7							
67D	51	83	3 Door Hatchback Coupe				
(DC) LINCOLN CONTINENTAL							
54D	97	83/86	4 Door Sedan				
(DT) LINCOLN TOWN CAR							
54D	96	83/86	4 Door Sedan				
(E) TAURUS							
54D	29	86	4 Door Sedan	74D	30	86	4 Door Wagon
(ME) SABLE							
54D	87	86	4 Door Sedan	74D	88	86	4 Door Wagon
(F) MUSTANG							
61B	28	83/86	3 Door Sedan Hatchback	66B	27	83/86	2 Door Sedan Convertible
66B	26	83/86	2 Door Sedan				
(J) CAPRI							
61D	79	83/86	3 Door Sedan — Hatchback				
(G) LTD							
54D	39	83/86	4 Door Sedan	74D	40	83/86	4 Door Station Wagon

CERTIFICATION LABEL — Cont'd

BODY TYPE CODE—FORD/LINCOLN MERCURY—Cont'd

CODE		YEAR	DESCRIPTION	CODE		YEAR	DESCRIPTION
TYPE	SERIES			TYPE	SERIES		
1983/86 — Cont'd							
(MG) MARQUIS							
54D	89	83/86	Brougham 4 Door Sedan	74D	90	83/86	4 Door Station Wagon
(K) MARK VI-VII							
54D	99	83	4 Door Sedan	66D	98	83	2 Door Coupe — Mark VI
63D	98	84/86	2 Door Coupe — Mark VII				
(MX) MERKUR XR4Ti							
61D	80	85/86	3 Door Sedan (4 Pillar)				
(P) FAIRMONT							
36R	37	83	2 Door Sport Coupe	66B	35	83	2 Door Sedan
54B	36	83	4 Door Sedan				
(MP) ZEPHYR							
36R	87	83	2 Door Sedan — Z7	54D	86	83	4 Door Sedan — Base
(S) THUNDERBIRD							
63D	46	83/86	Base, Sport, LX, Turbo 2 Door Sedan				
(MF) COUGAR							
66D	92	83/86	2 Door Sedan				
(W) ESCORT							
58D	13	83/85	4 Door Sedan Hatchback—Base Series	61D	31	85/86	2 Door Sedan Hatchback—L
58D	14	83/85	4 Door Sedan Hatchback—GL Series	61D	32	85/86	2 Door Sedan Hatchback—GL
58D	36	85/86	4 Door Sedan Hatchback—L	61D	33	85/86	2 Door Sedan Hatchback—GT
58D	37	85/86	4 Door Sedan Hatchback—GL	67D	01	86	2 Door Hatchback—EXP
58D	15	83/84	4 Door Sedan Hatchback—LX Series	74D	09	83/85	4 Door Station Wagon—Base Series
61D	04	83/85	2 Door Sedan Hatchback—Base Series	74D	10	83/85	4 Door Station Wagon—GL Series
61D	05	83/85	2 Door Sedan Hatchback—GL Series	74D	11	83/84	4 Door Station Wagon—LX Series
61D	06	83	2 Door Sedan Hatchback—GLX Series	74D	34	85/86	4 Door Station Wagon—L
61D	07	83/85	2 Door Sedan Hatchback—GT, Turbo Series	74D	35	85/86	4 Door Station Wagon—GL
(MW) LYNX							
58D	63	85/86	5 Door Sedan Hatchback — L	61D	55	83/85	3 Door Sedan Hatchback — GS Series
58D	64	85/86	5 Door Sedan Hatchback — GS	61D	57	83/84	3 Door Sedan Hatchback — RS Series
58D	65	83/85	5 Door Sedan Hatchback — Base Series	61D	58	83	3 Door Sedan Hatchback — LS Series
58D	66	83/85	5 Door Sedan Hatchback — GS Series	74D	58	85/86	4 Door Station Wagon — L
58D	68	83/84	5 Door Sedan Hatchback — LS Series	74D	59	85/86	4 Door Station Wagon — GS
61D	51	85/86	3 Door Sedan Hatchback — L	74D	60	83/85	4 Door Station Wagon — Base Series
61D	52	85/86	3 Door Sedan Hatchback — GS	74D	61	83/85	4 Door Station Wagon — GS Series
61D	53	85/86	3 Door Sedan Hatchback — XR3	74D	63	83	4 Door Station Wagon — LS Series
61D	54	83/85	3 Door Sedan Hatchback — Base Series				
1987/							
(A) FORD							
54K	72	87/	LTD Crown Victoria — 4 Dr. Sedan — S Series	74K	75	87/88	LTD Crown Victoria — 4 Dr. Wagon — S Series
54K	73	87/	LTD Crown Victoria — 4 Dr. Sedan — Base	74K	76	87/	LTD Crown Victoria — 4 Dr. Wagon — Base
54K	74	87/	LTD Crown Victoria — 4 Dr. Sedan — LX Series	74K	77	87/	LTD Crown Victoria — 4 Dr. Wagon — LX Series
66K	70	87	LTD Crown Victoria — 2 Dr. Coupe — Base				
66K	71	87	LTD Crown Victoria — 2 Dr. Coupe — LX Series	74K	78	87/	LTD Country Squire — Base
				74K	79	87/	LTD Country Squire — LX
(MA) GRAND MARQUIS							
54K	74	87/	GS — 4 Dr. Sedan	66K	72	87	LS — 2 Dr. Sedan
54K	75	87/	LS — 4 Dr. Sedan	74K	78	87/	Colony Park GS — 4 Dr. Station Wagon
66K	71	87	GS — 2 Dr. Sedan	74K	79	87/	Colony Park LS — 4 Dr. Station Wagon

CERTIFICATION LABEL — Cont'd

BODY TYPE CODE—FORD/LINCOLN MERCURY—Cont'd

CODE		YEAR	DESCRIPTION	CODE		YEAR	DESCRIPTION
TYPE	SERIES			TYPE	SERIES		
1987/ — Cont'd							
(B) TEMPO							
54D	35	87/	4 Dr. Sedan — L (Canada Only) AWD	66D	30	87/	2 Dr. Sedan — L (Canada Only) AWD
54D	36	87/	4 Dr. Sedan — GL	66D	31	87/	2 Dr. Sedan — GL
54D	36	89	4 Dr. Sedan — GL (Canada Only) AWD	66D	31	89	2 Dr. Sedan — GL (Canada Only) AWD
54D	37	87/	4 Dr. Sedan — LX	66D	32	87	2 Dr. Sedan — LX
54D	38	87/	4 Dr. Sedan — Sport—GLS	66D	33	87/	2 Dr. Sedan — Sport—GLS
54D	39	87/	4 Dr. Sedan — All Wheel Drive	66D	34	87/	2 Dr. Sedan — All Wheel Drive—(Canada)
(MB) TOPAZ							
54D	35	87/	4 Dr. Sedan L — (Canada Only)	66D	30	87/	2 Dr. Sedan L — (Canada Only)
54D	35	89	4 Dr. Sedan L — (Canada Only) AWD	66D	30	89	2 Dr. Sedan L — (Canada Only) AWD
54D	36	87/	4 Dr. Sedan GS — All Wheel Drive	66D	31	87/	2 Dr. Sedan GS — All Wheel Drive
54D	37	87/	4 Dr. Sedan LS — All Wheel Drive	66D	32	87	2 Dr. Sedan LS
54D	38	87/	4 Dr. Sedan Sport — LS — All Wheel Drive	66D	33	87/	2 Dr. Sedan Sport — XR5 — All Wheel Drive
(BT) FESTIVA							
61	06	88/	2 Dr. Sedan Hatchback — L Series	61	07	88/	2 Dr. Sedan Hatchback — LX Series
(DC) LINCOLN CONTINENTAL							
54D	97	87/	(Base) — 4 Dr. Sedan	54D	98	88/	Signature — 4 Dr. Sedan
54D	98	87	Givenchy — 4 Dr. Sedan				
(DT) LINCOLN TOWN CAR							
54D	81	87/	(Base) — 4 Dr. Sedan	54D	83	87/	Cartier — 4 Dr. Sedan
54D	82	87/	Signature — 4 Dr. Sedan	54D	84	89	Signature Special Edition — 4 Dr. Sedan
(E) TAURUS							
54D	50	87/	4 Dr. Sedan — L	74D	55	87/	4 Dr. Station Wagon — L
54D	51	87/88	4 Dr. Sedan — MT5	74D	56	87	4 Dr. Station Wagon — MT5
54D	52	87/	4 Dr. Sedan — GL	74D	57	87/	4 Dr. Station Wagon — GL
54D	53	87/	4 Dr. Sedan — LX	74D	58	87/	4 Dr. Station Wagon — LX
54D	54	89	4 Dr. Sedan — SHO				
(ME) SABLE							
54D	50	87/	GS — 4 Dr. Sedan	74D	55	87/	GS — 4 Dr. Station Wagon
54D	53	87/	LS — 4 Dr. Sedan	74D	58	87/	LS — 4 Dr. Station Wagon
(F) MUSTANG							
61B	41	87/	2 Dr. Hatchback — LX	66B	44	87/	2 Dr. Sedan Convertible — LX
61B	42	87/	2 Dr. Hatchback — GT	66B	45	87/	2 Dr. Sedan Convertible — GT
66B	40	87/	2 Dr. Sedan — LX				
(K) MARK VIII							
63D	91	87	(Base) — 2 Dr. Coupe	63D	93	87/	LSC — 2 Dr. Coupe
63D	92	87/	Blass — 2 Dr. Coupe				
(MM) MERCURY TRACER							
58D	12	87/	LS — 4 Dr. Hatchback — Canada Only	61D	15	87/	GS — 2 Dr. Hatchback — Canada Only
58D	16	87/	GS — 4 Dr. Hatchback — Canada Only	61D	11	88/	Non—Designated 2 Dr. Hatchback — U.S. Only
58D	12	88/	Non—Designated 4 Dr. Hatchback — U.S. Only	74D	13	87/	LS — 4 Dr. Hatchback — Canada Only
61D	10	87/	L — 2 Dr. Hatchback — Canada Only	74D	13	88/	Non—Designated 4 Dr. Station Wagon — U.S. Only
61D	11	87/	LS — 2 Dr. Hatchback — Canada Only				
(MX) MERKUR XR4Ti							
61D	80	87/89	XR4Ti — 3 Dr. Hatchback				
(MY) SCORPIO							
58	81	87/	5 Dr. Sedan Hatchback				

**1980/89
FORD/LINCOLN-MERCURY CARS**

**GENERAL
INFORMATION 47**

CERTIFICATION LABEL — Cont'd

BODY TYPE CODE—FORD/LINCOLN MERCURY—Cont'd

CODE		YEAR	DESCRIPTION	CODE		YEAR	DESCRIPTION
TYPE	SERIES			TYPE	SERIES		
1987/ — Cont'd							
(S) THUNDERBIRD							
63D	60	87/	2 Dr. Sedan — Standard	63D	62	87/	2 Dr. Sedan—LX
63D	61	87/88	2 Dr. Sedan — Sport	63D	64	87/	2 Dr. Sedan—Turbo Coupe—Super Coupe
(ST) PROBE							
61	20	89	2 Dr. Sedan Hatchback — GL	61	21	89	2 Dr. Sedan Hatchback — LX
61	22	89	2 Dr. Sedan Hatchback — GT				
(MF) COUGAR							
66D	60	87/	LS — 2 Dr. Sedan	66D	62	87/	XR7 — 2 Dr. Sedan
(W) ESCORT							
58D	25	87/88	4 Dr. Sedan Hatchback — GL	58D	95	88/	4 Dr. Hatchback — LX
61D	20	87/88	2 Dr. Sedan Hatchback — Pony	61D	90	88/	2 Dr. Hatchback — Pony
61D	21	87/88	2 Dr. Sedan Hatchback — GL	61D	91	88/	2 Dr. Hatchback — LX
61D	23	87/88	2 Dr. Sedan Hatchback — GT	61D	93	88/	2 Dr. Hatchback — GT
67D	17	87/88	2 Dr. Coupe — EXP Luxury Coupe	67D	88	88/	2 Dr. Coupe — EXP Base
67D	18	87/88	2 Dr. Coupe — EXP Sport Coupe	67D	89	88	2 Dr. Coupe — EXP Sport
74D	28	87/88	4 Dr. Wagon — GL	74D	98	88/	4 Dr. Wagon — LX
(MW) LYNX							
58D	25	87	GS — 4 Dr. Sedan Hatchback	61D	23	87	XR3 — 2 Dr. Sedan
61D	20	87	L — 2 Dr. Sedan	74D	28	87	GS — 4 Dr. Station Wagon
61D	21	87	GS — 2 Dr. Sedan				

CERTIFICATION LABEL — Cont'd**VINYL ROOF TYPE and COLOR IDENTIFICATION**

CERTIFICATION LABEL SHOWN

A CODE (TWO DIGITS) IDENTIFYING THE ROOF STYLE AND TYPE OF GRAIN (FIRST POSITION) AND THE COLOR (SECOND POSITION). REFER TO THE APPROPRIATE SOFT TRIM SECTION FOR A LISTING AND DESCRIPTION OF THE VINYL ROOF COVER CODES.

THIS VEHICLE CONFORMS ALL APPLICABLE FEI
BUMPER STANDARDS IN EFFECT ON THE DATE

VEN. IDENT. NO. 0G63G100001
TYPE PASSENGER

1C
EXTENSION PAINT COLORS
BODY | VR | MLOC | INT TRIM | A/C
54H (HD) G6D DD A

VINYL BODYSIDE MOULDING CODES

CERTIFICATION LABEL SHOWN

A CODE (THREE DIGITS) WHICH IDENTIFIES THE VINYL BODYSIDE MOULDING COLOR. REFER TO THE EXTERIOR MOULDING SECTION WHERE THE APPROPRIATE CODE IS LISTED WITH THE PART NUMBER OF THE BODYSIDE MOULDING IT REPRESENTS.

THIS VEHICLE CONFORMS ALL APPLICABLE FEI
BUMPER STANDARDS IN EFFECT ON THE DATE

VEN. IDENT. NO. 0G63G100001
TYPE PASSENGER

1C
EXTENSION PAINT COLORS
BODY | VR | MLOC | INT TRIM | A/C
54H HD (G6D) DD A

COLOR CODES — EXTERIOR PAINT

CERTIFICATION LABEL SHOWN

THE CODE ABOVE OR BELOW "COLOR" INDICATES THE EXTERIOR PAINT COLOR OF THE VEHICLE REFER TO THE PAINT SECTION FOR A LISTING OF THESE CODES AND THE PART NUMBER OF THE REQUIRED PAINT.

THIS VEHICLE CONFORMS ALL APPLICABLE FEI
BUMPER STANDARDS IN EFFECT ON THE DATE

VEN. IDENT. NO. 0G63G100001
TYPE PASSENGER

1C
EXTENSION PAINT COLORS
BODY | VR | MLOC | INT TRIM | A/C
54H HD G6D DD A

TRIM CODES

CERTIFICATION LABEL SHOWN

TWO CODE COMBINATION REPRESENTING THE SEAT TYPE AND COLOR OF INTERIOR TRIM SCHEME.

REFER TO THE APPROPRIATE SOFT TRIM SECTION FOR A LISTING OF THESE CODES AND THE COLOR AND TYPE OF MATERIALS USED IN THE INTERIOR UPHOLSTERY. REFER TO THE PAINT SECTION FOR A LISTING OF THESE CODES AND THE PART NUMBER FOR THE REQUIRED PAINT.

THIS VEHICLE CONFORMS ALL APPLICABLE FEI
BUMPER STANDARDS IN EFFECT ON THE DATE

VEN. IDENT. NO. 0G63G100001
TYPE PASSENGER

1C
EXTENSION PAINT COLORS
BODY | VR | MLOC | INT TRIM | A/C
54H HD G6D (DD) A

CERTIFICATION LABEL — Cont'd

AIR CONDITIONER CODE (BEFORE 1/83)


TAPE STRIPE COLOR CODE (FROM 1/83)

A — FORD FACTORY INSTALLED (INTEGRAL) AIR CONDITIONING
BLANK — UNIT BUILT AND DELIVERED LESS FACTORY INSTALLED (INTEGRAL) AIR CONDITIONING.

4 — REFER TO EXTERIOR MOULDING SECTION WHERE THE APPROPRIATE CODE IS LISTED WITH THE PART NUMBER OF THE TAPE STRIPE IT REPRESENTS.

CONFORMS ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY AND
IDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE

1. 0G63G100001
ENGER




CERTIFICATION LABEL SHOWN

RADIO TYPE CODES

THE CODE SHOWN BELOW IDENTIFIES THE TYPE OF RADIO AND WHETHER OR NOT THE VEHICLE IS ALSO EQUIPPED WITH C.B. RADIO OPTION.

CONFORMS ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY AND
IDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE

0G63G100001
ENGER



CERTIFICATION LABEL SHOWN


CODE	DESCRIPTION	CODE	DESCRIPTION
B	Radio — Luxury Sound System/Compact Disc Player	W	AM/FM MPX Quad 8 Electronic — w/o CB Radio
C	Compact Disc Player	X	Radio Flexibility Option and Rear Speakers — w/o CB Radio
F	AM/FM Stereo — Electric Tune Seek	Y	Radio Flexibility Option and Rear Speakers — w/CB Radio
G	AM/FM MPX, Cassette — w/CB Radio		Radio Delete (1988/)
H	AM/FM Electric Tuned Stereo w/Cassette	Z	Delete
J	AM/FM MPX, Quadrasonic Tape — w/CB Radio (1980)	1	AM/FM MPX Quadrasonic Tape — w/o CB Radio (1980)
	AM/FM MPX, Electronic Search — w/CB Radio (1981/)		AM/FM MPX, Electronic Search — w/o CB Radio (1981/)
	Japan/Arab Delete	2	AM — w/o CB Radio
K	AM — w/CB Radio	3	AM/FM Monaural — w/o CB Radio
L	AM/FM Monaural — w/CB Radio	4	AM/FM Multiplex — w/o CB Radio
	Radio — Luxury Sound System	5	AM/FM Multiplex Stereo Tape — w/o CB Radio
M	AM/FM Multiplex — w/CB Radio	6	AM/FM Multiplex Search — w/o CB Radio (1980)
N	AM/FM Multiplex Stereo Tape — w/CB Radio		AM/FM MPX, Electronic Search Cassette — w/o CB Radio (1981/)
O	AM/FM Multiplex Search — w/CB Radio	7	AM/FM MPX, Cassette — w/o CB Radio
	AM/FM MPX, Electronic Search Cassette — w/CB Radio (1981/)		AM/FM Stereo/Clock/Elec. Tune (1988)
P	AM and Dual Rear Speakers — w/CB Radio	8	AM Digital Clock — w/o CB Radio (1980/81)
Q	AM/FM Mono & Dual Rear Speakers — w/CB Radio		AM/FM Stereo/Cassette Tape w/Auto Reverse (1984)
R	Radio Flexibility Option — w/CB Radio		AM/FM Stereo/Clock — electric tune seek
S	AM and Dual Rear Speakers — w/o CB Radio	9	AM/FM Stereo/Clock/Cassette — elect. tune seek
	AM/FM/MPX Electronic Search Radio		
T	AM/FM Mono & Dual Rear Speakers — w/o CB Radio		
U	AM/FM MPX Quad 8 Electronic — w/CB Radio		
V	Flexibility Option — w/o CB Radio		
	AM/FM/MPX Electronic Search Cassette		

SUNROOF/MOONROOF CODES

- B — SUNROOF GLASS — SLIDING ROOF
- C — SUNROOF REMOVABLE GLASS
- D — T/ROOF

CONFORMS ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY AND
IDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE

1. 0G63G100001
ENGER



CERTIFICATION LABEL SHOWN


FIESTA VEHICLE IDENTIFICATION PLATE

Located on the right hand fender apron/or firewall

The Vehicle Identification Plate includes —

1. The (First Line) consists of codes which identify Product Source Company, Body Type Code, Year of Model Introduction, Version, Country of Origin Code, Assembly Plant Code, Body Type Code, Calendar Year Code, Month Code and Numerical Sequence of Assembly.
2. The (Second Line) consists of Codes which identify Drive Code, Engine Code, Transmission Code, Axle Ratio Code, Color Code (Exterior Paint) and Trim Code.


Refer to Pages 36 and 37 for complete listing of Codes.



FB — 3 Door Hatchback
 G — Germany
 C — Assembled at Saarlouis
 W — W-1979 (Calendar Year)
 P — Month Code
 10001 — Numerical Sequence of Assembly

Typ/Type		Version	Fahrgestell/Vehicle No.	
FB	D		GCFBTP	10001
Zul. Gesamtgew. Gross Vehicle Wgt.		Zul. Achslast vorn Perm. Axle Ld. Front	Zul. Achslast hinten Perm. Axle Ld. Rear	
Kg		Kg	Kg	
Lenk. Drive	Motor Engine	Getr. Trans.	Achse Axle	Farbe Colour
A	L4	T	P	9A
Polst. Trim		K.D. Bremsen Ref. Brakes		
A1				

P.139C4



A — Left Hand Drive
 L4 — 1.6 Litre
 T — 4 Speed Manual
 P — Axle Ratio of 3.58 to 1
 9A — Yellow (9) with Black Vinyl Roof (A)
 A1 — Black (A) with Cloth/Vinyl (1)

FIESTA VEHICLE IDENTIFICATION PLATE — Cont'd**DRIVE CODES**

A — Left Hand Drive

YEAR of MODEL INTRODUCTION

W — 1979: For Model Year 1980

CATALOG MODEL YEAR CODES

The vehicle model year as shown in this catalog is to be determined from the Build Date indicated below:

MODEL YEAR	*BUILD DATE	
	FROM	TO
1980	10/79	

*Build Date is identified on Warranty Plate as Calendar Year Code and Month Code. These codes are explained on the next page.

ENGINE CODES

L4 — (1.6 Litre)

TRANSMISSION CODES

T — 4 Speed Manual Transmission

AXLE RATIO CODES

P — 3.58 to 1

COLOR CODES (EXTERIOR PAINT)

Single digit code indicates solid color. Two digit code indicates solid color with vinyl roof cover. For a listing of these codes and the part number of the required paint refer to Paint Section.

TRIM CODES

First digit indicates color . . . Second digit indicates type of fabric
Refer to the appropriate Soft Trim Section for a listing of these codes and the color and type of materials used in the Interior Upholstery.

COUNTRY of ORIGIN CODES

G — Germany

ASSEMBLY PLANT CODES

C — Saarlouis

FIESTA VEHICLE IDENTIFICATION PLATE — Cont'd

VERSION

D — 64D (Decor 3 Door Sedan)
P — 64P (Ghia 3 Door Sedan)
R — 64R (Sport 3 Door Sedan)
S — 64S (3 Door Sedan)

BODY TYPE CODES

FB — 3 Door Hatchback

CALENDAR YEAR CODES

(First Digit of Date Code)

W — 1979
A — 1980

MONTH CODES

(Second Digit of Date Code)


MONTH CODE	1979 CALENDAR YEAR CODE W	1980 CALENDAR YEAR CODE A	MONTH CODE	1979 CALENDAR YEAR CODE W	1980 CALENDAR YEAR CODE A	MONTH CODE	1979 CALENDAR YEAR CODE W	1980 CALENDAR YEAR CODE A
A		March	J	September		S	July	November
B		January	K	February	June	T	August	December
C	January	May	L	May	September	U	October	
D	March	July	M	November		Y	June	October
E	April	August	P	December				
G		April	R		February			

CERTIFICATION LABEL — MERKUR (XR4Ti), SCORPIO

The Certification Label includes:

1. Build date (e.g. 10/80) in upper left hand corner which indicates the month and year in which the unit was built.
2. Vehicle Identification Number (left half of first line) consisting of Codes which identify Model Year, Assembly Plant, Series, Engine and Numerical Sequence of Assembly (also shown in upper right hand corner).
3. Vehicle Identification Number consisting of Codes which identify Model Year Code, Assembly Plant Code, Series Code, Engine Code and Numerical Sequence of Assembly.
4. Certification Label consisting of Codes which identify Body Color Code, District Codes (D.S.O. Number where applicable), Body Type Code, Vinyl Roof Code, Bodyside Moulding Code, Trim Code, Air Conditioning Code, Radio Code, Sun/Moon Roof Code, Rear Axle Ratio Code, Transmission Code and Front-Rear Spring Code.

1981/

FIRST LINE VEHICLE IDENTIFICATION NUMBER

- "WF1" — Manufactured by Ford — Werke, A. G., West Germany
- "B" — Active Belts
- "P" — "P" (Passenger Car Only)
- "80" — Merkur XR4Ti — 3 Door Hatchback
- "W" — 2.3 EFI TC, (140 CID), I-4 cyl., gas
- "@" — Check Digit (internal usage)
- "F" — Model Year 1985
- "M" — Karmann Assembly Plant — Rheine, West Germany
- "600,001" — First Unit Built

CERTIFICATION LABEL — MERKUR

First line

Second line

MFD. BY FORD—WERKE AG

DATE: GYWR:

FRONT GAWR: REAR GAWR:

THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY AND BUMPER
STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE

VIN
TYPE

EXTERIOR PAINT COLORS										DSO	
BODY	VR	MLDG.	INT. TRIM	A/C	R	S	AX	TR		TR	

MADE IN WEST GERMANY

VE5RD-B20472-AB

SECOND LINE MISCELLANEOUS VEHICLE DATA

BODY COLOR CODE _____ BODY TYPE CODE _____ VINYL ROOF CODE _____ BODYSIDE MOULDING CODE _____ TRIM CODE _____ AIR CONDITIONING CODE (BEFORE 1/83) _____ TAPE STRIPE COLOR CODE (FROM 1/83) _____	OR	DISTRICT CODE _____ D.S.O. NUMBER _____ FRONT-REAR SPRING CODE _____ TRANSMISSION CODE _____ REAR AXLE RATIO CODE _____ SUN/MOON ROOF CODE _____ RADIO CODE _____
---	----	--

**1980/89
FORD/LINCOLN MERCURY CARS**

1

SERVICE PART NUMBER PREFIX

CAR LINES (Cat. Code)	ENG PROD LINE SYM	1970 1980	1971 1981	1972 1982	1973 1983	1974 1984	1975 1985	1976 1986	1977 1987	1978 1988	1979 1989
Ford (A) 1970/	A	D0AZ E0AZ	D1AZ E1AZ	D2AZ E2AZ	D3AZ E3AZ	D4AZ E4AZ	D5AZ E5AZ	D6AZ E6AZ	D7AZ E7AZ	D8AZ E8AZ	D9AZ E9AZ
Mercury (MA) 1970/	M	D0MY E0MY	D1MY E1MY	D2MY E2MY	D3MY E3MY	D4MY E4MY	D5MY E5MY	D6MY E6MY	D7MY E7MY	D8MY E8MY	D9MY E9MY
Meteor (Y) 1970/76	Y,M	D0YY D00Z	D1YY D10Z	D2YY D20Z	D3YY D30Z	D4MY D40Z	D5MY D50Z	D6MY D60Z	—	—	—
Torino (B) 1970/76	O	—	—	—	—	—	—	—	—	—	—
LTD II (B) 1977/79	O	—	—	—	—	—	—	—	D70Z	D80Z	D90Z
Festiva (BT) 1988/	B	—	—	—	—	—	—	—	—	E8BZ	E9BZ
Montego (C) 1970/76	G	D0GY —	D1GY —	D2GY —	D3GY —	D4GY —	D5GY —	D6GY —	—	—	—
Cougar (exc. XR7) 77/79	W	—	—	—	—	—	—	—	D7WY	D8WY	D9WY
Cougar (exc. XR7) 81/82	4	—	E14Y	E24Y	—	—	—	—	—	—	—
Cougar XR7 (F) 1970/	W	D0WY E0WY	D1WY E1WY	D2WY E2WY	D3WY E3WY	D4WY E4WY	D5WY E5WY	D6WY E6WY	D7WY E7WY	D8WY E8WY	D9WY E9WY
Cougar (1983/)	—	—	—	—	—	—	—	—	—	—	—
Thunderbird (S) 1970/	S	D0SZ E0SZ	D1SZ E1SZ	D2SZ E2SZ	D3SZ E3SZ	D4SZ E4SZ	D5SZ E5SZ	D6SZ E6SZ	D7SZ E7SZ	D8SZ E8SZ	D9SZ E9SZ
Lincoln (D) 1970/82 (Town Car 1982/(DT))	V	D0VY E0VY	D1VY E1VY	D2VY E2VY	D3VY E3VY	D4VY E4VY	D5VY E5VY	D6VY E6VY	D7VY E7VY	D8VY E8VY	D9VY E9VY
Mark III & IV (K) 70/76	L	D0LY —	D1LY —	D2LY —	D3LY —	D4LY —	D5LY —	D6LY —	—	—	—
Mark V (K) 77/79	L	—	—	—	—	—	—	—	D7LY	D8LY	D9LY
Mark VI 1980/83	L	E0LY —	E1LY —	E2LY —	E3LY —	—	—	—	—	—	—
Mark VII (K) 1984/	—	—	—	—	—	E4LY	E5LY	E6LY	E7LY	E8LY	E9LY
Mustang 1970/72	Z	D0ZZ —	D1ZZ —	D2ZZ —	—	—	—	—	—	—	—
Mustang II (F) 1973/	Z	E0ZZ —	E1ZZ —	E2ZZ —	D3ZZ E3ZZ	D4ZZ E4ZZ	D5ZZ E5ZZ	D6ZZ E6ZZ	D7ZZ E7ZZ	D8ZZ E8ZZ	D9ZZ E9ZZ
Capri (Import) 1970/77	8,R	D0RY —	D1RY —	D2RY —	D3RY —	D4RY —	D5RY —	D6RY —	D7RY —	—	—
Capri (USA) (J) 1979/86	C	E0CY —	E1CY —	E2CY —	E3CY —	E4CY —	E5CY —	E6CY —	—	—	D9CY
Tracer (Canada) (MM) 1987/	—	—	—	—	—	—	—	—	E7GZ	E8GZ	E9GZ
Tracer (USA) (MM) 1988/	G	—	—	—	—	—	—	—	—	E8GZ	E9GY
Pinto (L) 1970/80	2,E	— E0FZ	D1FZ —	D2FZ —	D3FZ —	D4FZ —	D5FZ —	D6FZ —	D7FZ —	D8FZ —	D9FZ —
Bobcat (ML) 1975/1980	Y	— E0YY	—	—	—	—	D5YY	D6YY	D7YY	D8YY	D9YY
Maverick (P) 1970/77	D,B	D0DZ —	D1DZ —	D2DZ —	D3DZ —	D4DZ —	D5DZ —	D6DZ —	D7DZ —	—	—
Fairmont (P) 1978/83	B	— E0BZ	— E1BZ	— E2BZ	— E3BZ	—	—	—	—	D8BZ	D9BZ
Granada (G) 1975/82	D	—	—	—	—	—	D5DZ	D6DZ	D7DZ	D8DZ	D9DZ
LTD — 1983/86 (G)	—	E0DZ —	E1DZ —	E2DZ —	E3DZ —	E4DZ —	E5DZ —	E6KZ —	—	—	—
Taurus (E) 1986/	4	—	—	—	—	—	—	E6DZ	E7DZ	E8DZ	E9DZ
Comet (C) 1971/77	4,K	—	D14Y	D24Y	D34Y	D44Y	D54Y	D64Y	D74Y	—	—
Zephyr (MP) 1978/83	K	— E0KY	— E1KY	— E2KY	— E3KY	—	—	—	—	D8KY	D9KY
Monarch—1975/80 (MG) 1981/82 See Cougar Marquis—1983/86 (G)	4	— E04Y	—	—	— E34Y	— E44Y	D54Y E54Y	D64Y —	D74Y —	D84Y —	D94Y —
Sable (E) 1986/	4	—	—	—	—	—	—	E61Y	—	—	—
Versailles (MV) 1977/80	4	—	—	—	—	—	—	E64Y	E74Y	E84Y	E94Y
Linc. Cont. 1982/ (DC)	5	E04Y —	—	E25Y	E35Y	E45Y	E55Y	E65Y	E75Y	E80Y	E90Y
Merkur (MX) 1965/89	—	—	—	—	—	—	E5RY	E6RY	E7RY	E8RY	E9RY
Scorpio DE—1(MY) 1987/89	—	—	—	—	—	—	—	—	E7RY	E8RY	E9RY
Fiesta (X) 1978/80	R	— E0RZ	—	—	—	—	—	—	—	D8RZ	D9RZ
Elite 1975/76	C	—	—	—	—	—	D50Z	D60Z	—	—	—

1980/89
FORD/LINCOLN MERCURY CARS

SERVICE PART NUMBER PREFIX

CAR LINES (Cat. Code)	ENG PROD LINE SYM	1970 1980	1971 1981	1972 1982	1973 1983	1974 1984	1975 1985	1976 1986	1977 1987	1978 1988	1979 1989
Escort (W) 1981/		—	—	—	—	—	—	—	—	—	—
	E	—	E1FZ	E2FZ	E3F	E4FZ	E5FZ	E6FZ	E7FZ	E8FZ	E9FZ
Lynx (W) 1981/86		—	—	—	—	—	—	—	—	—	—
	Y	—	E1YY	E2YY	E3YY	E4YY	E5YY	E6YY	E7YY	—	—
EXP (C) 1981/85		—	—	—	—	—	—	—	—	—	—
	G	—	E2GZ	E2GZ	E3GZ	E4GZ	E5GZ	—	—	—	—
LN7 (MC) 1981/84		—	—	—	—	—	—	—	—	—	—
	O	—	E20Y	E20Y	E30Y	E40Y	—	—	—	—	—
Tempo (B) 1984/		—	—	—	—	—	—	—	—	—	—
	3	—	—	—	—	E43Z	E53Z	E63Z	E73Z	E83Z	E93Z
Topaz (MB) 1984/		—	—	—	—	—	—	—	—	—	—
	6	—	—	—	—	E46Y	E56Y	E66Y	E76Y	E86Y	E96Y
Probe		—	—	—	—	—	—	—	—	—	—
	Q	—	—	—	—	—	—	—	—	—	E92Z
TRUCK LINES (Cat. Code)	ENG PROD LINE SYM	1970 1980	1971 1981	1972 1982	1973 1983	1974 1984	1975 1985	1976 1986	1977 1987	1978 1988	1979 1989
Bronco 1970/	B,T	D0BZ	D1BZ	D2BZ	D3BZ	D4TZ	D5TZ	D6TZ	D7TZ	D8TZ	D9TZ
		E0TZ	E1TZ	E2TZ	E3TZ	E4TZ	E5TZ	E6TZ	E7TZ	E8TZ	E9TZ
Bronco II 1984/		—	—	—	—	—	—	—	—	—	—
	T,7	—	—	—	—	E4TZ	E5TZ	E6TZ	E7TZ	E8TZ	E9TZ
Light-Medium 1970/		—	—	—	—	—	—	—	—	—	—
	T	D0TZ	D1TZ	D2TZ	D3TZ	D4TZ	D5TZ	D6TZ	D7TZ	D8TZ	D9TZ
		E0TZ	E1TZ	E2TZ	E3TZ	E4TZ	E5TZ	E6TZ	E7TZ	E8TZ	E9TZ
Ranger (Yuma) 1983/		—	—	—	—	—	—	—	—	—	—
	T,7	—	—	—	E3TZ	E4TZ	E5TZ	E6TZ	E7TZ	E8TZ	E9TZ
Econoline 1970/		—	—	—	—	—	—	—	—	—	—
	U	D0UZ	D1UZ	D2UZ	D3UZ	D4UZ	D5UZ	D6UZ	D7UZ	D8UZ	D9UZ
		E0UZ	E1UZ	E2UZ	E3UZ	E4UZ	E5UZ	E6UZ	E7UZ	E8UZ	E9UZ
Courier 1972/83		—	—	—	—	—	—	—	—	—	—
	7	E07Z	E17Z	E27Z	E37Z	—	—	—	—	—	—
Heavy 1970/		—	—	—	—	—	—	—	—	—	—
	H	D0HZ	D1HZ	D2HZ	D3HZ	D4HZ	D5HZ	D6HZ	D7HZ	D8HZ	D9HZ
		E0HZ	E1HZ	E2HZ	E3HZ	E4HZ	E5HZ	E6HZ	E7HZ	E8HZ	E9HZ
Tilt Cab 1970/73		—	—	—	—	—	—	—	—	—	—
	K	D0KZ	D1KZ	D2KZ	D3KZ	—	—	—	—	—	—
Cab-over-Engine 1970/73		—	—	—	—	—	—	—	—	—	—
	E	D0EZ	D1EZ	D2EZ	D3EZ	—	—	—	—	—	—
Short Highway 1970/73		—	—	—	—	—	—	—	—	—	—
	X	D0XZ	D1XZ	D2XZ	D3XZ	—	—	—	—	—	—
Post Office G-100 1971		—	—	—	—	—	—	—	—	—	—
	B	—	D1BZ	—	—	—	—	—	—	—	—
Aerostar 1985/		—	—	—	—	—	—	—	—	—	—
	9	—	—	—	—	—	E59Z	E69Z	E79Z	E89Z	E99Z
Cargo (HL3) 1986/		—	—	—	—	—	—	—	—	—	—
	H	—	—	—	—	—	—	E6HZ	E7HZ	E8HZ	E9HZ

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
● This is a Body group. Body group numbers are listed numerically following group 19B969.			
Air conditioner kits	19B968	Leveler kit (air)	5A589
Air Spring Union	5B322	Light kit (snow plow)	15312
Angling kit (snow plow hydraulic)	19F502	Lock kit (rear door safety)	● 21850
Antenna kit (radio)	18813	Lock release kit (luggage compartment door remote control)	● 432A00
Ball kit (trailer hitch)	19F503	Mat (front floor)	● 13086
Bezel kit (A/C)	19C872	Mat (rear floor)	● 13106
Carrier kit (luggage)	● 55100	Mirror (vanity)	17A679
Chassis assy. (radio receiver)	18806	Mirror kit (inside rear view)	17700
Cigar lighter kit	15A044	Mirror kit (outside)	17696
Clock kit	15A000	Moulding kit (body side)	● 21048
Compressor kit (A/C)	19703	Moulding kit (door outside rear edge)	● 20910
Condenser kit (A/C)	19708	Moulding kit (body rocker panel)	● 10146
Coolant recover kit	8522	Oil cooler kit (transmission aux.)	7K177
Cover kit (luggage carrier)	19B507	Ornament kit (hood top)	16850
Cover kit (steering wheel)	3L600	Panel (roof air deflector)	50860
Decal kit (safety standard certification)	● 20472	Radio kit	18805
Deflector kit (air)	19E524	Reflector flare kit	19E500
Defogger kit (back window)	18397	Reservoir vacuum kit (speed control)	9E799
Drive kit (A/C)	19B969	Seat (child's safety)	19E535
Electronic anti-theft kit	19A361	Snow plow kit	19E537
Extension assy. (seat belt)	● 611C22	Speaker and hardware kit (radio)	18819
Fire extinguisher kit	19B540	Speaker kit (rear seat)	18875
Fog lamp kit	15200	Speaker kit (stereo)	18808
Framer kit (license plate)	17A387	Speed control kit	9A818
Free running hub kit	1104	Speedometer cable kit (speed control)	9A820
Game and table kit	● 279B76	Spotlight kit	15312
Guard kit (front bumper)	17996	Stripe kit (body side)	20000
Guard kit (rear bumper)	17984	Tachometer kit	17A326
Guard kit (splash shield)	16A550	Tonneau cover kit	● 501A42
Hitch kit (trailer)	19D520	Tool and safety kit (highway)	19F515
Horn kit	13800		
KIT – refer to appropriate noun name			
For example			
Guard kit (splash shield)	16A550		

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
A		A — Cont'd	
Absorber (Front Fender To Cowl Side Sound)	16071	Adapter (Speed Control Vacuum Valve Actuator)	9C962
Absorber Assy (Steering Column Impact)	3E664	Adapter (Stabilizer Bar Mounting Bracket)	5B482
Absorber Assy. (Steering Column)	3E644	Adapter (Steering Column Release Lever)	3F696
Abutment (Park Pawl Actuating)	7G101	Adapter (Thermostatic Choke Control Inlet Tube)	9C786
Accumulator (Pressure-Anti-Lock)	2L583	Adapter (Trans. Control Sel. Lever)	7E266
Accumulator Kit	2C231	Adapter (Windshield Washer Hose)	17A612
Actuator (Backup Lamp Switch)	15540	Adapter Air Charge (Temperature Sensor)	12B555
Actuator (Courtesy Lamp Switch)	13A786	Adapter Assy (Charge Air Cooler To Intake Manifold)	6C643
Actuator (Manual Lever)	7E333	Adapter Assy-Power Steering Tube	3N668
Actuator (Shift Lock)	3Z719	Adapter Assy. (Air Cleaner)	9C638
Actuator (Steering Column Lock Lever)	3E715	Adapter Assy. (Air Conditioner Evaporator To Plenum Chamber)	19D740
Actuator Assy (Engine Supercharger By-Pass Valve)	6F089	Adapter Assy. (Brake Pressure Switch)	2C320
Actuator Assy. (Door Lock Switch)	14A626	Adapter Assy. (Distributor Base)	12A217
Actuator Assy. (Garage Door)	19A332	Adapter Assy. (Engine Charge To Charge Air Cooler)	6K853
Actuator Assy. (Illuminating Entry)	13C718	Adapter Assy. (Heat Outlet Duct)	18C387
Actuator Assy. (Parking Brake Release Switch)	2B624	Adapter Assy. (Oil Cooler)	6881
Actuator Assy. (Power Steering Auxiliary)	3N803	Adapter Assy. (Oil Filter)	6881
Actuator Assy. (Shock Absorber Electronic)	18B012	Adapter Assy. (Rear Seat Heater Outlet Duct)	18C505
Actuator Assy. (Speed Control)	9A825	Adapter Assy. (Rear Wheel Disc Brake)	2C220
Actuator Assy. (Steering Column Lock)	3E723	Adapter Kit	2C265
Actuator Kit (Power Steering Control Valve)	3783	Adapter Kit (Speed Control)	9A819
Actuator Kit (Turbocharger)	9G488	Adapter Rear Disc Brake L.H.	2C101
Adapter (Air Conditioner Air Inlet Duct)	19816	Adapter Rear Disc Brake R.H.	2C100
Adapter (Air Conditioner Plenum Demister)	19E662	Adjuster (Parking Brake Cable - Rear)	2K390
Adapter (Automatic Temperature Control Evaporator Air)	19C800	Adjuster (Rear Axle Differential Bearing)	4067
Adapter (Brake Master Cylinder Mounting)	2B286	Adjuster (Speed Control Connector)	9C876
Adapter (Carburetor Air Cleaner Duct Tube)	9B676	Adjuster Assy. (Parking Brake Cable)	2B599
Adapter (Carburetor Air Cleaner Inlet Hose)	9E606	Adjuster Assy. (Steering Gear Worm Thrust Bearing)	3A670
Adapter (Carburetor Air Cleaner To Intake Tube)	9D608	Adjuster Assy. (Valve Hydraulic Lash)	6C501
Adapter (Crankcase Ventilation Tube)	6758	Air Conditioner Kits	19B968
Adapter (Crankshaft To Converter)	6381	Air Conditioner Upgrade Kit	19K603
Adapter (Eng. Mounting Rear)	6068	Air Duct (Battery Cover)	10B668
Adapter (Engine Spark Knock Intensity Sensor)	12B517	Air Seal	8R146
Adapter (Exhaust Air Supply Check Valve)	9A491	Alternator Assy.	10346
Adapter (Exhaust Air Supply Pump)	9G470	Alternator Assy.	10300
Adapter (Exhaust Gas Recirculating Valve)	9P753	Alternator Mounting Parts	10A313
Adapter (Flywheel Front)	6A369	Ammeter (Instrument Cluster)	10850
Adapter (Fuel Filter)	9B249	Amplifier Assy. (Air Conditioner)	19E719
Adapter (Fuel Vapor Purge Tube To Air Cleaner)	9D692	Amplifier Assy. (Inst/Cluster Gauge)	10E849
Adapter (Heater Windshield Defroster Outlet)	18A527	Amplifier Assy. (Light Sensor)	13A018
Adapter (Intake Manifold To Deceleration Valve)	9K495	Amplifier Assy. (Radio Power Booster And Equalizer)	18B849
Adapter (O/Drv. Clutch)	7660	Amplifier Assy. (Speed Control)	9D843
Adapter (Rear Axle Shaft)	4A404	Anchor (Wheel Ornament Screw)	1A100
Adapter (Rear Stabilizer Bar Mounting Bracket)	5D495	Anchor Push Rod Assy. Kit	2K100
Adapter (Seat Regulator Control Switch)	14C700	Antenna (Alarm And Lock System - Remote Control)	15603

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
A — Cont'd		A — Cont'd	
Antenna (Garage Door Actuator)	19A337	Assembly(Cable Parking Brake Intermediate)	2A620
Antenna Assy. (Mobile Telephone)	19A390	Attachment Pad (Rear)	2L200
Antenna Kit	18813	Automatic Transmission-Transaxle Assy.	7000,7A195
Antenna Repair Kit (Electric)	18A850	Auxiliary Oil Cooler Kit (Transmission)	7K177
Anti-Squeak (Rear Spring)	5586	Axle Assy. (Rear Axle Less Half Shafts)	4200
Applique (Wheel Cover)	1137	Axle Assy. (Rear Integral - Less Brakes, Hubs, Drums, And Shafts)	4006
Apron (Front Fender)	16054	Axle Shaft Assy. (Inner)	3A426
Arm & Support Assy. (Selector Lever)	7302	Actuator Assy. (Throttle Control)	9N825
Arm (Exhaust Air Supply Pump Belt Adjustment)	9B452	Air Horn Assy.	9520
Arm (Front Bumper)	17770	And 14301 - Cable Assy. (Battery Universal Type)	14300
Arm (Gearshift Selector)	7346	Arm (Throttle Shaft)	9D591
Arm (Heater Defroster Door)	18A357	Arm Assy. (Metering Rod)	9D819
Arm (Reverse Gear Actuating)	7L187	B	
Arm (Steering Gear Sector Shaft)	3590	Baffle (Air Conditioner Evaporator Case)	19A999
Arm (Timing Chain Tensioner)	6L253	Baffle (Air Distribution Flange)	9F553
Arm (Valve Rocker)	6564	Baffle (Brake Whl)	2240
Arm (Windshield Wiper Motor Output)	17A436	Baffle (Heater Plenum Chamber Air)	18C343
Arm (Windshield Wiper Mounting)	17540	Baffle (Intake Manifold Air)	9E463
Arm (Windshield Wiper Pivot)	17526,17527	Baffle (Oil Pan Upper)	6687
Arm Assy. (Air Conditioner Electronic Motor Door Actuator)	19E618	Baffle (Oil Pan)	6687
Arm Assy. (Control Selector)	7302	Baffle (Oil)	7040
Arm Assy. (Front Suspension Lower)	3078,3079	Baffle (P/S Pump Reservoir Filler Tube)	3E550
Arm Assy. (Front Suspension Upper)	3082	Baffle (Valve Push Rod Valley)	6522,6524
Arm Assy. (Gear Shift Selector)	7302	Baffle Assy. (Crankshaft Windage Oil)	6L680
Arm Assy. (Input Shift Shaft Selector Plate)	7F477	Baffle Assy. (Cyl. Block Ventilation)	6A630
Arm Assy. (Rear Suspension Lower)	5A649	Baffle Assy. (Radiator Air Intake)	8B029
Arm Assy. (Timing Chain Tensioner)	6285	Baffle Assy. (Trans. Air)	7L497
Arm Assy. (Valve Rocker)	6564	Baffle Kit (Warning Lamp Indicator)	10A990
Arm Bushing Joint Assy. (Front Suspension)	3084	Balance Shaft Assy. (Engine Dynamic)	6A311
Arm Kit (Valve Rocker)	6564	Ball (Clutch Release Equalizer Shaft)	7543
Arm And Blade Assy. (Rear Window Wiper)	17C403	Ball (Coasting Booster Valve Shuttle)	7E195
Arm And Bracket Assy. (Steering Idler)	3355	Ball (Fog Lamp Adjusting)	13135
Arm And Bushing Assy. (Rear Suspension Upper Front)	5A923	Ball Kit (Steering Gear Worm)	3647
Arm And Bushing Assy. (Rear Suspension Upper Rear)	5A927	Ball Ramp Kit (Rear Wheel Disc Brake)	2A870
Arm And Bushing Assy. (Rear Suspension)	5500	Ball Stud Kit (Power Steering Drag Link)	3A533
Arm And Pivot Shaft Assy. (Windshield Wiper Mounting)	17566,17567	Band (Air Conditioner Blower Motor Mounting)	19A991
Arm And Support Assy. (Transmission Selector Lever)	7302	Band Assy. (Front Servo)	7A162
Armature	11005	Band Assy. (Intermediate)	7D034
Armature (Distributor)	12A099	Band Assy. (Overdrive)	7F196
Armature (Windshield Wiper Motor)	17A485	Band Assy. (Rear)	7A176
Armature Kit (Hardware)	11K126	Band Assy. (Reverse Clutch)	7D095
Armature Thrust Ball	11A172	Bar & Support Assy. (Gearshift Lever)	7L257
Armour (Fuel Line)	9269	Bar & Support Assy. (Trans. Gearshift Lever-Stabilizer)	7L257
Aspirator Assy. (Speed Control Vacuum)	9F739	Bar (Radiator Grille)	8390
Aspirator Brake (Vacuum Booster)	2C318	Bar Assy. (Clutch Release Equalizer)	7528

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
B — Cont'd		B — Cont'd	
Bar Assy. (Front Stabilizer)	5482	Bearing (Planet Gear Thrust)	7F241
Bar Assy. (Radiator Grille)	8153	Bearing (Power Steering Gear Control Valve)	3K771
Bar Assy. (Rear Stabilizer)	5A772	Bearing (Power Steering Gear Input Shaft)	3D525
Base And Cable Assy. (Radio Antenna)	18A984	Bearing (Power Steering Gear Pinion Shaft-Lower)	3K769
Base Assy. (Jack)	17088	Bearing (Preload)	7L172
Battery Assy. (Rechargeable Telephone Power Pack)	10655	Bearing (Rear Axle Driving Pinion Pilot)	4625
Battery Chart	10653	Bearing (Rear Wheel)	1225
Battery Mounting Parts	10732	Bearing (Rear)	10A304
Beam (Crankshaft Main Bearing Cap Support)	6K321	Bearing (Seal Assy. - Power Steering Gear Rack)	3L576
Bearing	11135,1216, 7025	Bearing (Speedometer Driven Gear)	17K288
Bearing	7025	Bearing (Spindle Connecting Rod Ball)	3326
Bearing (Air Conditioner Compressor Pulley)	2990	Bearing (Steering Column Lock Housing)	3E700
Bearing (Auxiliary Drive Shaft Front)	6A753	Bearing (Steering Gear Worm Thrust)	3571
Bearing (Auxiliary Drive Shaft Rear)	6A738	Bearing (Steering Shaft Support)	3K618
Bearing (Balance Shaft Front & Rear)	6A333	Bearing (Transmission Control Selector Tube)	7347
Bearing (Camshaft Center)	6262	Bearing (Transmission Gear Shift Lever Socket)	7225
Bearing (Camshaft Front Intermediate)	6267	Bearing (Transmission Shift Bellcrank)	7C327
Bearing (Camshaft Front)	6261	Bearing (Windshield Wiper Arm)	17573
Bearing (Camshaft Intermediate)	6267	Bearing And Seal Assy. (Front Suspension)	3B455
Bearing (Camshaft Rear Intermediate)	6270	Bearing Assembly	7F368
Bearing (Camshaft Rear)	6263	Bearing Assy.	7F374,7F404
Bearing (Camshaft Slide Ring Vacuum Pump)	6A286	Bearing Assy. (1St Speed Gear)	7127
Bearing (Camshaft)	6261	Bearing Assy. (2Nd & 3Rd Speed Gear)	7B369
Bearing (Connecting Rod)	6211	Bearing Assy. (3Rd Speed Gear)	7127
Bearing (Countershaft - Center)	7121	Bearing Assy. (5Th Speed Gear)	7R130
Bearing (Countershaft Gear)	7121	Bearing Assy. (Case-Rear)	7F242
Bearing (Crankshaft Main)	6333	Bearing Assy. (Clutch Release Shaft)	7L569
Bearing (Drive End)	11135	Bearing Assy. (Countershaft - Rear)	7D283
Bearing (Drive Housing)	11135	Bearing Assy. (Countershaft - Tapered Roller)	7F431
Bearing (End Plate)	11052	Bearing Assy. (Countershaft Gear - Front)	7065
Bearing (Engine Throttle Shaft)	9992	Bearing Assy. (Countershaft Gear)	1225
Bearing (Front Axle)	3K093	Bearing Assy. (Countershaft Reverse Gear)	7N270
Bearing (Front Suspension Mounting)	3K099	Bearing Assy. (Countershaft Thrust)	7D234
Bearing (Front Wheel)	1215	Bearing Assy. (Countershaft Thrust-Rear)	3571
Bearing (Front)	10094, 10A303	Bearing Assy. (Direct & Interm. Clutch Thrust)	7F373
Bearing (Headlamp Adjusting Ring)	13B160	Bearing Assy. (Direct Clutch Inner)	7F243
Bearing (Heater Air Control)	18K532	Bearing Assy. (Drive Sprocket)	7G233
Bearing (Idle Gear)	7F458	Bearing Assy. (Driven Sprocket)	7G247
Bearing (Input Shaft Pilot)	7120	Bearing Assy. (Driveshaft)	4812
Bearing (Interm. Clutch Drum Thrust)	7F374	Bearing Assy. (Final Drive Gear - Front)	7F405
Bearing (Low & Interm. Gear Thrust)	7A045	Bearing Assy. (Final Drive Gear - Thrust Rear)	7F404
Bearing (One Way Over Running Clutch)	7A623	Bearing Assy. (Final Drive Gear Thrust - Rear)	7F405
Bearing (Output Shaft)	7G220	Bearing Assy. (Final Drive Gear Thrust)	7F405
Bearing (Output Shell Thrust)	7F404	Bearing Assy. (Final Drive Gear Thrust-Frt.)	7F404
		Bearing Assy. (Final Drive Input Gear)	7F403

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
B — Cont'd		B — Cont'd	
Bearing Assy. (First & Second Speed Gear)	7133	Bezel (Front Or Rear Side Lamp)	15A440
Bearing Assy. (Forward Clutch Hub Front)	7F231	Bezel (Headlamp)	13048
Bearing Assy. (Idler & Output Gear)	7G023	Bezel (Hood Latch Release Cable)	16B999
Bearing Assy. (Input Shaft Rear)	7120	Bezel (Instrument Cluster Control)	10852
Bearing Assy. (Input Shaft Thrust)	7C096	Bezel (Instrument Cluster)	10876
Bearing Assy. (Main Drive Gear)	7025	Bezel (Instrument Control Panel)	10B906
Bearing Assy. (O/Drv. Inner Race)	7L495	Bezel (Interior Lamp Switch)	13B739
Bearing Assy. (Oil Pump Drive Shaft)	6N755	Bezel (Radio Control)	18842
Bearing Assy. (Output Shaft - Center)	7118	Bezel (Radio Speaker Fader Control - Monaural)	18A842
Bearing Assy. (Output Shaft - Rear)	7R205	Bezel (Rear View Outside Mirror)	17530
Bearing Assy. (Output Shaft)	7065	Bezel (Roof Sliding Panel Switch)	15B686
Bearing Assy. (Planet Carrier - Thrust)	7F374	Bezel (Seat Regulator Control Switch)	14A706
Bearing Assy. (Rear)	10A304	Bezel (Selector Switch)	9A389
Bearing Assy. (Reverse Idler Gear)	7120,7E139	Bezel (Transmission Console Shift Selector Dial)	7D443
Bearing Assy. (Steering Column Tube)	3517	Bezel (Transmission Gearshift Lever Boot)	7E391
Bearing Assy. (Thrust)	7D234	Bezel Assy. (Clock)	15010
Bearing Assy. (Transfer Housing)	7F380	Bezel Assy. (Exterior Pillar Lamp Or Coach)	15B438
Bearing Assy. (Transmission 1St Speed Gear)	7K274	Bezel Assy. (Heater Control)	18K391
Bearing Assy. (Transmission 2Nd Speed Gear)	7K169	Bezel Assy. (Message Center Indicator)	10K931
Bearing Assy. (Transmission 4Th Speed Gear)	7K171	Bezel Assy. (Rear Hi-Mount Lamp)	13B479
Bearing Assy. (Transmission 5Th Speed Gear)	7K275	Bezel Assy. (Seat Back Control Switch)	14C713
Bearing Assy. (Transmission Reverse Idler Gear)	7K322	Bezel Assy. (Seat Belt Warning Indicator)	10C907
Bearing Assy. (Without Race)	3C123	Blade Assy. (Windshield Wiper)	17528
Bearing Assy.-Kit (Rear)	10A304	Block (Fuel Tube Support)	9K327
Bearing Hub (Outer Stub Shaft)	4K017	Block (Head Lamp Junction)	11A648
Bearing Kit (Camshaft)	6A251	Block (Headlamp Switch Junction)	11A647
Bearing Kit (Rear Axle)	4K621	Block (Mainshaft Control Shaft)	7F105
Bearing Set (Connecting Rod Complete)	6211	Block Assy. (Cylinder)	6010
Bearing Set (Connecting Rod)	6211	Block Assy. (Junction)	14448
Bearing Set (Crankshaft Complete)	6333	Board Assy. (Alternator Circuit)	10B301
Bearing And Retainer Kit (Rear Disc Brake)	2B598	Board Assy. (Courtesy Lamp Circuit)	13C771
Bearing Or Bushing (Drive Housing)	11135	Board Assy. (Electronic Instrument Indicator)	14B064
Bellcrank Assy.	7A185	Board Assy. (Printed Wiring Lightbar)	14B115
Bellcrank Assy. (Clutch Control)	7N628	Board Assy. (Speed Control Circuit)	9E743
Bellcrank Assy. (Column Shift Selector)	7A185	Board Assy. (Vanity Mirror Lamp Circuit)	17D687
Bellcrank Assy. (Throttle Control)	7F480,9A774	Board Kit (Printed Circuit)	10B301
Bellcrank Assy. (Trans. Column Shift Selector)	7A185	Body (Air Conditioner Charging Valve)	19D878
Bellcrank Assy. (Trans. Control To Accelerator Shaft)	7A185	Body (Backup Lamp)	15511
Bellcrank Assy. (Trans. Shift)	7A185	Body (Front Band Servo)	7A094
Belt (Drive)	8620	Body (Front Fender)	16015
Belt (Timing)	6268	Body (Front Seat Courtesy Lamp)	13C748
Bender (Heater Hose - 90 Degrees)	18573	Body (Governor Oil Collector)	7D220
Bezel (Air Conditioner Register)	19C784	Body (Interior Lamp)	13786
Bezel (Console Glove Compartment Lamp)	13C770	Body (Rear Band Servo)	7B172
Bezel (Door Lock Switch Actuator)	14A668	Body (Rear View Outside Mirror)	17A703

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
B — Cont'd		B — Cont'd	
Body Assy. (Air Intake Charge Throttle)	9E926	Bolt (Fuel Injection Pump Connector-Return Line)	9N517
Body Assy. (Fog Lamp)	15202	Bolt (Fuel Tank Strap)	9A010
Body Assy. (Governor)	7C063	Bolt (Fuse Junction Panel)	14A187
Body Assy. (Oil Pump And Oil Filter)	6603	Bolt (Gearshift Lever To Support)	7K104
Body Assy. (Rear Lamp)	13434	Bolt (Headlamp Mounting)	13N057
Bolt	11091,3055, 3Z098,3Z511, 3Z592,3Z593, 3Z594,3Z596, 3Z999,5Z486, 5Z995,5Z996, 5Z997,5Z998, 7A291,7E310, 7N539	Bolt (Hollow Pump To Booster)	2C235
		Bolt (Ignition Switch Cylinder Lock)	11Z582
		Bolt (Input Shaft Gear Brg. Cap)	7Z026
		Bolt (Jack Set)	17085
		Bolt (Main Control Mounting)	7Z311
		Bolt (Main Control)	7N450,7Z310
		Bolt (Oil Cooler Line)	7Z152
Bolt & Washer (Oil Pump Attaching)	6638	Bolt (Oil Filter Adapter Mounting)	6894
Bolt (5Th & Reverse Shift Rod)	7214	Bolt (Oil Pan To Cylinder Block)	6662
Bolt (Air Cleaner Cover To Body)	9K668	Bolt (Oil Supply Tube Connector)	6K757
Bolt (Air Conditioner Compressor Idler Pulley Mounting)	2A934	Bolt (Overrun Clutch To Case)	7D167
Bolt (Air Conditioner)	19B939	Bolt (P/S Control Valve)	3R659
Bolt (Axle Cover To Housing)	4346	Bolt (P/S Pump To Bracket)	3N533
Bolt (Battery Tray Hold Down)	10N768	Bolt (Park Support)	7L295
Bolt (Brace To Engine)	7Z450	Bolt (Piston Cooling Oil Jet Valve)	6K757
Bolt (Brace To Trans.)	7C059	Bolt (Planetary Gears Support)	7A291
Bolt (Camshaft Bearing Cap)	6L293	Bolt (Power Steering Control Valve Spool)	3698
Bolt (Camshaft Sprocket Retaining)	6K252	Bolt (Rear Axle Diff. To Ring Gear)	4558
Bolt (Camshaft Sprocket)	6279	Bolt (Rear Axle Differential Gear To Case)	4216
Bolt (Camshaft Tensioner)	6K289	Bolt (Rear Brake Backing Plate)	2248
Bolt (Charge Air Mounting Bracket)	6N865	Bolt (Rear Stab. Bar End Retaining)	5W495
Bolt (Clutch Housing)	7A771	Bolt (Rear Support Rebound Insulator)	6B091
Bolt (Clutch Lever)	7N539	Bolt (Selector Plate)	7A443,7F484
Bolt (Compressor)	19C582	Bolt (Servo Body To Case)	77420
Bolt (Connecting Rod)	6214	Bolt (Shaft Selector Plate)	7A443
Bolt (Connector)	6K679	Bolt (Spare Wheel Mounting)	1448
Bolt (Converter Drain Back)	7R449	Bolt (Steering Column Tube Flange)	3641
Bolt (Countershaft Brg. Retainer)	7C210	Bolt (Strap)	15863
Bolt (Crankshaft Pulley Retaining)	6A345	Bolt (Thru)	10A396, 10A596, 11091,18832
Bolt (Crankshaft Pulley)	6A340		
Bolt (Crankshaft Rear Seal Retainer)	6350	Bolt (Thru) - Hex Head	11091
Bolt (Cyl. Block Frt. Cover)	6N070	Bolt (Thru) - Hex. Head	11091
Bolt (Differential Carrier To Rear Axle Housing)	4347	Bolt (Thru)-Hex. Hd.-1/4"-20 X 2"	10A396
Bolt (Driveshaft Universal Joint)	4529	Bolt (Timing Belt Or Chain Tensioner)	6K282
Bolt (Engine Insulator Mounting)	6047	Bolt (Torsion Beam Axle)	5Y596
Bolt (Exhaust Air Supply Tube)	9C481	Bolt (Transmission Brace)	7Z450
Bolt (Flywheel Attaching)	6379	Bolt (Transmission To Case Or Clutch Housing)	7L605
Bolt (Front Suspension Lower Arm Strut)	3B267	Bolt (Transmission To Engine Attaching)	7A771
Bolt (Front Suspension Lower Arm)	3Z493	Bolt (Turbo Charger Oil Line Connector)	9G486
Bolt (Front Suspension)	3057	Bolt (Valve Rocker Arm Adjusting)	6549
Bolt (Fuel Flow Sensor-Connector)	10D957		

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
B — Cont'd		B — Cont'd	
Bolt (Valve Rocker Arm Shaft Support)	6A527	Boot Kit (Axle Shaft)	4A429
Bolt (Valve Rocker Arm)	6A527	Boot Kit Inner(Rear Axle Shaft)-Also Refer To Group 4A331	4L537
Bolt (Wheel Hub)	1107	Boot Kit Outer (Rear Axle Shaft)	4A331
Bolt (Hex Shoulder Hd.)	11091	Boot Rear Brake Caliper Cylinder	2M001
Bolt - Spare Wheel	1408	Boot Rubber Anti Lock	2A477
Bolt Assy. (Tensioner)	6E008	Boot And Insulator Kit (Power Steering Cylinder)	3C651
Bolt Caliper Brake	2W303	Boss (Radiator Drain Cock Repair)	8120
Bolt Connector	2L122	Box (Tool)	17009
Bolt Limiting	2A795	Brace (Accelerator Cable Bracket)	9F668
Bolt Or Stud (Crankshaft Main Bearing Cap)	6345	Brace (Alternator)	10B315
Bolt Or Stud (Valve Rocker Arm Cover)	6A548	Brace (Belt Idler)	8A680
Bolt Or Stud Assy.(Vlv Rkr Arm Cover)	6C520	Brace (Carburetor Air Cleaner Duct And Valve Housing)	9A619
Bolt Rear Shock Absorber	18Z125	Brace (Case To Cyl Block)	7E235
Bolt Special Reservoir Fixing	2M050	Brace (Engine Air Cleaner)	9663
Bolt Union	9J446	Brace (Front Bumper End)	17A820
Bolt Or Stud (Cylinder Head)	6065	Brace (Front Bumper)	17980
Bolt(Fan Belt Idler Pulley)	8688	Brace (Front Fender Apron To Dash)	16A052
Bond (Radio Frequency Interference Suppression)	19A095	Brace (Front Fender To Apron And Radiator Support)	16A023
Booster Assy. (Power Brake)	2005	Brace (Front Fender To Frame)	16B134
Booster Installation Kit (Power Brake)	2A091	Brace (Front Fender To Radiator Support Upper)	16B132
Boot (Brake Booster Relay Link Push Rod)	2L069	Brace (Front Fender To Radiator Upper)	16B132
Boot (Brake Master Cylinder)	2180	Brace (Front Support)	6D027
Boot (Engine Cooling Fan Motor Relay)	8C626	Brace (Headlamp Cover Reservoir)	13C096
Boot (Front Wheel Drive Flange)	1A015	Brace (Headlamp Housing)	13B123
Boot (Front Wheel Drive Shaft Joint)	3A331	Brace (Hood Latch Support)	16747
Boot (Gear Shift Control Shaft)	7F110	Brace (Radiator Grille Opening Panel Lower)	8C238
Boot (Gearshift Lever Lower)	7C301	Brace (Radiator Grille Opening Panel Upper)	8C236
Boot (Gearshift Lever)	7277,7C301, 7E138	Brace (Radiator Grille Opening Panel)	8B057
Boot (Parking Brake Cable)	2K650	Brace (Radiator Support To Side Member)	8A364
Boot (Parking Brake Lever)	2404,2A713	Brace (Rear Bumper End)	17789
Boot (Pin)	2L548	Brace (Rear Support Decking)	6C061
Boot (Rear Axle C.V. Joint)	4697	Brace (Trans. Case To Cyl Block-Rear)	7E235
Boot (Rear Shock Absorber Dust)	18159	Brace (Trans. Case To Cyl. Block - L.H.)	7E235
Boot (Relay Water Proof)	14530	Brace (Trans. Case To Cyl. Block - R.H.)	7E234
Boot (Speed Control Servo)	9F774	Brace (Transmission Case To Engine Block)	7E234
Boot (Steering Column Tube)	3C611	Brace Assy. (Air Conditioner Evaporator)	19C761
Boot (Transmission Gearshift Lever)	7277	Brace Assy. Steering Column Support Bracket	3F667
Boot (Transmission Gearshift Lever-Inner)	7E109	Brace Rear Suspension Support	5A881
Boot (U/Jt Slip Yoke)	4421	Brace(Radiator Grille Opening Reinforcement)	8C332
Boot (Vent)	7E424	Bracket & Cable Assy. (Steering Column Tilt Release)	3F700
Boot (Wiring Connector Sleeve)	14490	Bracket & Plate Assy. (Gearshift)	7B233
Boot Assy. (Courtesy Lamp Switch)	13C775	Bracket & Resistor Assy.(Fuel Pump)	9D360
Boot Assy. (Distributor)	12252	Bracket & Switch Assy. (Anti-Theft Control)	19A434
Boot Assy. Parking Brake Cable Front	2A863	Bracket (Accelerator Cable)	9723
Boot Clamp (Front Wheel Drive Shaft Joint)	3B478	Bracket (Accelerator Return Spring)	9741

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
B — Cont'd		B — Cont'd	
Bracket (Accelerator Shaft To Dash)	9A762	Bracket (Backup Lamp Mounting)	15A507
Bracket (Accelerator Shaft)	9728	Bracket (Battery Cable Mounting)	10A779
Bracket (Accelerator Shift Support)	9K756	Bracket (Battery Cable Support)	14551
Bracket (Accessory Drive Belt Tensioner)	6B212	Bracket (Belt Idler)	8680
Bracket (Air Bag Monitor Auxiliary Power Supply)	14B174	Bracket (Brake Anti-Lock Control Module)	2C214
Bracket (Air Bag Monitor)	14B058	Bracket (Brake Anti-Lock Hydraulic Control)	2C304
Bracket (Air By-Pass Valve)	9C486	Bracket (Brake Anti-Lock Pedal Sensor - Adapter)	2C312
Bracket (Air By-Pass Valve-Thermactor)	9B290	Bracket (Brake Cylinder Push Rod Fork End)	2A143
Bracket (Air Cleaner Intake Tube)	9C685	Bracket (Brake Hose Support)	2082
Bracket (Air Cleaner)	9B609	Bracket (Brake Line Support)	2A051
Bracket (Air Conditioner Accumulator)	19D607	Bracket (Brake Pressure Differential Valve)	2B260
Bracket (Air Conditioner Air Damper Door Motor Mounting)	18C607	Bracket (Breather Mounting)	7F445
Bracket (Air Conditioner Automatic Temperature Control Sensor)	19D668	Bracket (C.B. Speaker Relay Mounting)	18B824
Bracket (Air Conditioner Blower Housing Support)	19A623	Bracket (Carburetor Air Cleaner Support)	9A627,9C610
Bracket (Air Conditioner Condenser Inlet Tube)	19D720	Bracket (Carburetor Air Cleaner Vacuum Control)	9F660
Bracket (Air Conditioner Condenser Mounting)	19702, 19B594	Bracket (Carburetor Air Control)	9B971
Bracket (Air Conditioner Condenser Outlet Tube)	19D721	Bracket (Carburetor Throttle Position Actuator Switch)	9F712
Bracket (Air Conditioner Condenser Tube Support)	19C917	Bracket (Case)	7B229
Bracket (Air Conditioner Dehydrator Mounting)	19A959	Bracket (Center)	11126
Bracket (Air Conditioner Dehydrator Tank Mounting)	19B937	Bracket (Charge Air Cooler Front)	6K784
Bracket (Air Conditioner Evaporator Case Mounting)	19A865	Bracket (Charge Air Cooler Rear)	6K785
Bracket (Air Conditioner Evaporator Case Support)	19A639	Bracket (Clock Mounting)	15017
Bracket (Air Conditioner Evaporator Core Mounting)	19B993	Bracket (Clutch Cable)	7A554
Bracket (Air Conditioner Evaporator Expansion Valve Mounting)	19866	Bracket (Clutch Cyl. Hose Upper)	7T503
Bracket (Air Conditioner Evaporator Support)	19B992	Bracket (Clutch Cylinder Hose)	7B582
Bracket (Air Conditioner Evaporator Tube Support)	19A579, 19B589	Bracket (Clutch Pedal Bumper)	7A530
Bracket (Air Conditioner Hose Support)	19812	Bracket (Clutch Pedal Push Rod)	7A644
Bracket (Air Conditioner Inlet Manifold)	19D933	Bracket (Clutch Push Rod)	7A554
Bracket (Air Conditioner Register Temperature Switch Mounting)	19A949	Bracket (Compact Disc Mounting)	18C835
Bracket (Air Conditioner Register)	19B942	Bracket (Control Cable)	7F136
Bracket (Air Conditioner Relay)	19B609	Bracket (Control Sel. Dial Mounting)	7Z132
Bracket (Air Conditioner Servo Mounting Automatic Temperature Control)	19D873	Bracket (Control Selector Cable)	7989,7E364
Bracket (Air Conditioner Suction Throttling Valve To Dash)	19D851	Bracket (Control Shaft)	7K476
Bracket (Air Conditioner Temperature Control Switch Mounting)	19B864	Bracket (Control Unit)	9B364
Bracket (Air Conditioner Tube Support)	19C574	Bracket (Courtesy Lamp Switch)	13B756
Bracket (Air Conditioner Tube)	19B990	Bracket (Courtesy Lamp Or Map Lamp)	13763
Bracket (Air Conditioner)	19734	Bracket (Crankcase Vent Adapter)	6A745
Bracket (Air Supply Pump Thermactor Filter)	9G495	Bracket (Crankcase Vent Tube)	6N787
Bracket (Alternator Regulator Mounting)	10337	Bracket (Dampener Mounting)	6M047
Bracket (Anti-Theft Alarm Control Mounting)	19A435	Bracket (Dashpot)	9P530
Bracket (Ash Receptacle Lamp)	13C731	Bracket (Deceleration Valve Mounting)	9P654
Bracket (Auto Charge)	19810	Bracket (Distributor Vacuum Control Valve)	12A195
Bracket (Automatic Temperature Control Vacuum Solenoid Valve)	19D732	Bracket (Duct - Center)	19A260
		Bracket (Ego Sensor Coupler)	9E490
		Bracket (Egr Control Switch)	9E490

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
B — Cont'd		B — Cont'd	
Bracket (Egr Recirculating Cooler Mounting)	9F465	Bracket (Front Support Mounting)	6030
Bracket (Egr Vacuum Amplifier)	9E452	Bracket (Front Support)	6028
Bracket (Egr Vacuum Regulator)	9S430	Bracket (Front Suspension Bumper)	3382
Bracket (Egr Vacuum Reservoir)	9F430	Bracket (Front Valance Panel)	17C787
Bracket (Egr Vacuum Solenoid Valve)	9F461	Bracket (Front Wheel Splash Shield Rear)	16264
Bracket (Electric Antenna Mounting)	18939	Bracket (Frt. Support Brkt. To Body)	6B021
Bracket (Eng. Charge Air Cooler Adapter)	6K864	Bracket (Fuel Altitude Compensator Switch)	9F757
Bracket (Eng. Charge Air Cooler Tube)	6F086	Bracket (Fuel Filter)	9180
Bracket (Eng. Mounting)	6061	Bracket (Fuel Flow Sensor)	10D925
Bracket (Engine Air Cleaner Mounting)	9626	Bracket (Fuel Injection Pulse Dampener)	9F776
Bracket (Engine Air Cleaner Outlet Tube)	9B625	Bracket (Fuel Injection Pump Stop Screw)	9K513
Bracket (Engine Air Fuel Ratio Control)	12A689	Bracket (Fuel Injection Pump Support)	9P764
Bracket (Engine Charge Air Inlet Pipe)	9K641	Bracket (Fuel Injection Pump)	9B552
Bracket (Engine Control Junction Box Component Mounting)	12A640	Bracket (Fuel Line Support)	9D319
Bracket (Engine Control Mounting Plate)	12A508	Bracket (Fuel Pump Mounting)	9346
Bracket (Engine Cooling Fan Motor Relay)	8C625	Bracket (Fuel Pump Regulator)	9C376
Bracket (Engine Idle Speed-Up Control)	9D548	Bracket (Fuel Pump Switch)	9B364
Bracket (Engine Spark Knock Detection Control)	12B589	Bracket (Fuel Shut-Off Control)	9A760
Bracket (Exhaust Air Supply Control Valve)	9G426	Bracket (Fuel Tank Support)	9A004
Bracket (Exhaust Air Supply Pump Mounting)	9B450	Bracket (Fuel Tube Support-Supply & Return)	9B303
Bracket (Exhaust Air Supply Tube)	9B481	Bracket (Fuel Vapor Canister Anti-Rot)	9F875
Bracket (Exhaust Pipe - L.H.)	5G216	Bracket (Fuel Vapor Return Tube)	9H309
Bracket (Fan Motor Mounting)	8K655	Bracket (Fuel Vapor Storage Canister)	9D665
Bracket (Fender Support)	16B023	Bracket (Fuel Water Detector Sensor)	9J317
Bracket (Fog Lamp Mounting)	15266	Bracket (Fuse Junction Panel Mounting)	14A254
Bracket (Frame No. 3 Cross Member Support)	5A000	Bracket (Gear Shift Cable)	7K403
Bracket (Front Axle Bearing)	3K090	Bracket (Gearshift Cable Mounting)	7E381
Bracket (Front Brake Anti-Lock Sensor Wiring)	2C183	Bracket (Gearshift Mounting)	7A147
Bracket (Front Brake Anti-Lock Sensor)	2C180	Bracket (Gearshift Position Switch)	7L239
Bracket (Front Bumper Guide)	17C972	Bracket (Gearshift Support)	7K738
Bracket (Front Bumper Isolator)	17C886, 17D828	Bracket (Glove Compartment Lamp Switch)	14410
Bracket (Front Bumper Stone Deflector Mounting)	17A986	Bracket (Headlamp Cover Reservoir)	13B059
Bracket (Front Bumper To Fender)	17A869	Bracket (Headlamp Cover Solenoid)	13C022
Bracket (Front Fender Apron To Frame)	16A200	Bracket (Headlamp Dimmer Control)	13655,13732
Bracket (Front Fender Apron Upper Reinforcement)	16D156	Bracket (Headlamp Dimmer Sensor Mounting)	13A021
Bracket (Front Fender Extension To Radiator Support)	16C048	Bracket (Headlamp Housing Mounting)	13A114
Bracket (Front Fender Mounting Front)	16C076	Bracket (Headlamp Mounting)	13A015
Bracket (Front Fender Mounting Rear)	16C078	Bracket (Headlamp Switch)	11A668
Bracket (Front Fender To Apron)	16A204	Bracket (Heater Air Damper Door Control)	18A272
Bracket (Front Fender To Pillar)	16A005	Bracket (Heater Control Mounting)	18531
Bracket (Front Jack Retainer)	17A006	Bracket (Heater Control Vacuum Motor Mounting)	18B258
Bracket (Front License Plate Mounting)	17A385	Bracket (Heater Defroster Door Control)	18A343
Bracket (Front Mounting Lower)	6C016	Bracket (Heater Hose Support)	18481
Bracket (Front Shock Mounting)	18183	Bracket (Heater Mounting)	18A456
Bracket (Front Side Lamp)	15A455	Bracket (Heater Temperature Control Cable)	18A677

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
B — Cont'd		B — Cont'd	
Bracket (Hood Latch Cable Mounting)	16930	Bracket (Radiator Grille Locator)	8C327
Bracket (Hood Top Stay On Hood)	16K610	Bracket (Radiator Grille Mounting Center)	8174
Bracket (Horn Mounting)	13828	Bracket (Radiator Grille Mounting)	8A278
Bracket (Ignition Timing And Warning Indicator Switch)	12A277	Bracket (Radiator Grille Opening Panel Brace)	8C232
Bracket (Illuminated Entry Actuator)	13C721	Bracket (Radiator Grille Opening Panel)	8B455
Bracket (Inertia Fuel Shutoff Switch)	9D310	Bracket (Radiator Grille Outer)	8A153
Bracket (Instrument Panel Control)	10C935	Bracket (Radiator Mounting Upper)	8A194
Bracket (Instrument/Cluster Support - Cca-Switch)	10A919	Bracket (Radiator Support Upper)	8A193
Bracket (Interlock Cable Retaining)	7H178	Bracket (Radiator Support)	16D024,8052
Bracket (Jack Handle Retainer)	17A140	Bracket (Radio Foot Control Switch)	18B857
Bracket (Jack Handle And Wheel Nut Wrench Retainer)	17A139	Bracket (Radio Power Booster & Equalizer Amplifier)	18B860
Bracket (Jack Hold Down)	17A056	Bracket (Radio Receiver Suppression Choke)	19B136
Bracket (Jack Stowage)	17A040	Bracket (Rear Axle Bumper)	4731
Bracket (Jacking Lift Rear)	17K074	Bracket (Rear Axle Differential Carrier Bumper)	4905
Bracket (Lamp Set)	13N082	Bracket (Rear Axle Differential To Crossmember)	4K204
Bracket (Light Switch)	11A678	Bracket (Rear Axle Driving Pinion Bearing Retainer)	4298
Bracket (Low Fuel Level Warning Switch)	9H302	Bracket (Rear Brake Anti-Skid Sensor)	2C188
Bracket (Luggage Compartment Lamp)	13C706	Bracket (Rear Bumper Guide)	17B930
Bracket (Main Control)	7E081	Bracket (Rear Bumper Isolator)	17C897
Bracket (Manifold Absolute Pressure Sensor)	9G476	Bracket (Rear Bumper Jack Plate)	17236
Bracket (Master Cylinder)	2280	Bracket (Rear Bumper Reinforcement)	17C858
Bracket (Motor)	7F168	Bracket (Rear Hi-Mount Lamp Body)	13A624
Bracket (Mounting Rear Axle)	4K096	Bracket (Rear Jack Retainer)	17A007
Bracket (O/Drv Control)	7A653	Bracket (Rear Lamp Body Mounting)	13A418
Bracket (Oil Cooler Hose)	6K759	Bracket (Rear Lamp)	13432
Bracket (Oil Cooler Mounting)	7B142,7B242	Bracket (Rear License Lamp)	13423
Bracket (Oil Cooler Upper)	6K761	Bracket (Rear License Plate)	13406, 17N398
Bracket (Oil Cooler)	6K758,6K762	Bracket (Rear Shock Absorber)	18192
Bracket (Oil Level Indicator Tube)	6786	Bracket (Rear Shock Mounting Lower)	18164
Bracket (Parking Brake Cable Guide)	2B622	Bracket (Rear Stabilizer Bar)	5C482
Bracket (Parking Brake Cable Support)	2649	Bracket (Rear Stabilizer To Arm)	5L490
Bracket (Parking Brake Cable)	2530,2A669, 2A785	Bracket (Rear Support Insulator)	6069
Bracket (Parking Brake Equalizer)	2631	Bracket (Rear Support)	6096
Bracket (Parking Brake Lever)	2A686	Bracket (Rear View Inside Mirror)	17698
Bracket (Parking Lamp Mounting)	13256	Bracket (Rear View Outside Mirror Mounting)	17B715
Bracket (Passive Restraint Module)	14A680	Bracket (Rear View Outside Mirror)	17B714
Bracket (Pedestal Rear)	2C313	Bracket (Rear Window Defogger)	18D336
Bracket (Potentiometer And Switch Control)	19B945	Bracket (Relay Mounting)	14A301
Bracket (Power Steering Cooler)	3D744	Bracket (Roof Sliding Panel Switch)	15B692
Bracket (Power Steering Cylinder Mounting)	3A652	Bracket (Running Light)	13B214
Bracket (Power Steering Hose)	3C510	Bracket (Seat Belt Warning Chime)	10D876
Bracket (Power Steering Pump Adjusting)	3A732	Bracket (Seat Regulator Control Mounting)	14A705, 14B691
Bracket (Power Steering Pump Pressure And Return Tube)	3E596	Bracket (Seat Regulator Control Processor)	14C709
Bracket (Power Steering Reservoir)	3490	Bracket (Separator)	9A188
Bracket (Radiator Coolant Recovery Reservoir)	8A082		

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
C — Cont'd		C — Cont'd	
Connector & Bolt Assy. (Battery Ground)	14349	Connector Assy. (Air Conditioner Register)	19C627
Connector & Hose Assy. (Crankcase Vent)	6C324	Connector Assy. (Alternator Regulator)	10A568
Connector (3-Way)	2K572	Connector Assy. (Exhaust Gas Recirculation Vacuum Control)	9E455
Connector (Accelerator Shaft To Speed Control Shaft)	9B705	Connector Assy. (Fuel Evap. Hose)	9J313
Connector (Air Cleaner Temperature Control Sensor Vacuum Hose)	9E688	Connector Assy. (Main Emission Vacuum Control)	9E498
Connector (Air Conditioner Demister Hose)	19E680	Connector Assy. (Radiator Inlet)	8064
Connector (Air Conditioner Evaporator)	19B916	Connector Assy. (Rear Wheel Brake)	2074
Connector (Air Conditioner Register)	19C692	Connector Assy. (Wiring)	14487
Connector (Automatic Air Leveler Tube)	5A689	Connector Assy. (Fuel Injector Manifold)	9F754
Connector (Battery Clamp)	10658	Connector Kit (P/S Pressure, Return, & Pump Outlet Line)	3R608
Connector (Brake Hose)	2C230	Connector Kit (Power Steering Gear & Housing)	3A766
Connector (Converter Clutch Override)	7E449	Connector Window Defogger Duct	18C579
Connector (Crankcase Vent Hose)	6K722	Connector And Hose Assy. (Air Conditioner Side Window Demister)	19E705
Connector (Crankcase Ventilation Hose)	6767,6A614	Connectors (Wiring)	14488
Connector (Distributor Vacuum Pipe)	12224	Contact Assy. (Air Bag Sliding)	14A664
Connector (Drain Tube)	19A858	Container (Litter)	19D504
Connector (E.G.R. Valve Tube To Manifold)	9F485	Container Assy. (Stereo Tape Cartridge)	19A089
Connector (Egr Exhaust Manifold)	9J470	Container And Retainer Assy. (Stereo Tape Cartridge)	19A090
Connector (Emission Vacuum Control)	9E499	Control & Bracket Assy. (Variable Assist P/S)	3F721
Connector (Eng. Charge Air Cooler Tube)	6F077	Control (Garage Door Actuator)	19A374
Connector (Engine Air Inlet)	9C674	Control (Headlamp)	11654
Connector (Engine To Transmission Vacuum Tube)	7B087	Control (Radio Rear Seat Speaker Volume)	18972
Connector (Exhaust Manifold-Tube)	9D439	Control Assy.	7A782
Connector (Fuel Flow Sensor)	10D958	Control Assy. (Air Conditioner Blower Motor Speed)	19E624
Connector (Fuel Injection Pump Inlet)	9B375	Control Assy. (Air Conditioner)	19980
Connector (Fuel Tube)	9B376,9L276	Control Assy. (Anti-Theft Alarm)	19A366
Connector (Fuel Vapor Hose)	9K319	Control Assy. (Clutch Master Cyl.)	7A542
Connector (Fuel)	9274	Control Assy. (Daytime Running Lights)	15A272
Connector (Headlamp Cover Control)	13A169	Control Assy. (Deceleration Fuel Shutoff)	12B528
Connector (Heater Air Hose)	18A449	Control Assy. (Egr Vacuum Regulator)	9J459
Connector (Instrument Panel Wiring Link - Flex Circuit Retainer)	13K760	Control Assy. (Engine Accessory Drive)	12B567
Connector (Oil Cooler Tube)	7D273	Control Assy. (Engine Air Fuel Ratio)	12A651
Connector (Oil Drain Back Tube)	6A863	Control Assy. (Engine Idle)	9L513
Connector (Parking Brake Cable)	2A790	Control Assy. (Engine Knock Detection)	12B501
Connector (Pipe)	9G482	Control Assy. (Fuel Flow Sensor)	9J307
Connector (Power Steering Tube)	3R608	Control Assy. (Fuel Injection Pump)	9J464
Connector (Quick Connect Fuel Injection)	9F681	Control Assy. (Gear Shift)	7400
Connector (Radiator Overflow Hose)	8N030	Control Assy. (Headlamp Dimmer Sensor)	13C105
Connector (Thermo Switch)	7N138	Control Assy. (Heated Windshield Module)	18C531
Connector (Vacuum)	9C704,9D433	Control Assy. (Heater)	18549
Connector (Water Inlet Hose)	8A527	Control Assy. (Indicator Warning System)	10E850, 10K910
Connector (Water Inlet Water Pump)	8K528	Control Assy. (Inst./Panel Light Dimmer)	10E846
Connector (Windshield Defroster Nozzle)	18A435	Control Assy. (Message Center)	10D893
Connector (Wiper Wiring Harness)	17598	Control Assy. (Odometer Memory)	17C269
Connector And Wire Assy. (Repair)	12A209	Control Assy. (Parking Brake)	2780

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
G — Cont'd		G — Cont'd	
Gasket (E.G.R. Housing To Throttle Body)	9E933	Gasket (Intake Manifold)	9461
Gasket (Egr Cooler Tube-Inlet)	9F470	Gasket (Interm. Band Servo Cover)	7D026
Gasket (Engine Air Inlet Connector)	9D634	Gasket (Main Control Cover)	7F396
Gasket (Engine Plenum)	9F627	Gasket (Oil Cooler Housing)	6N782
Gasket (Exhaust Air Supply Pump Elbow-Outlet)	9F429	Gasket (Oil Cooler Return Tube)	6N789
Gasket (Exhaust Air Supply Tube)	9C435	Gasket (Oil Cooler)	6L621
Gasket (Exhaust Gas Recirculation Valve Adapter)	9E464	Gasket (Oil Filler Cap)	6789
Gasket (Exhaust Gas Recirculation Valve)	9D476	Gasket (Oil Filter Adapter Bolt)	6A636
Gasket (Exhaust Manifold To Muffler Inlet Pipe)	9450	Gasket (Oil Filter Adapter)	6840
Gasket (Exhaust Manifold)	9448	Gasket (Oil Level Indicator Boss)	6753
Gasket (Extension Housing)	7086	Gasket (Oil Pan Drain Plug)	6734,7L101
Gasket (Fog Lamp Housing)	15K243	Gasket (Oil Pan Screen)	7E062
Gasket (Front Brake Splash Shield)	2B160	Gasket (Oil Pan To Case)	7A191
Gasket (Front Turn Signal Lamp)	13211	Gasket (Oil Pan)	6710
Gasket (Fuel Gauge Tank Unit)	9276	Gasket (Oil Pump Body To Inlet Tube)	6626
Gasket (Fuel Injection Leakoff Fitting)	9G546	Gasket (Oil Pump Inlet Tube)	6626
Gasket (Fuel Injection Nozzle)	9C991	Gasket (Oil Pump To Cylinder Block)	6659
Gasket (Fuel Injection Pump Distribution Block)	9E904	Gasket (Oil Pump)	7A136
Gasket (Fuel Injection Pump Sump Cover)	9D962	Gasket (Piston Cooling Oil Jet)	6C349
Gasket (Fuel Leak Pipe)	9K540	Gasket (Plenum Chamber Outlet)	19C901
Gasket (Fuel Pressure Regulator)	9C977	Gasket (Plunger Cover)	11065
Gasket (Fuel Pump Filter Mounting)	9C395	Gasket (Potentiometer)	9F782
Gasket (Fuel Pump Mounting)	9417	Gasket (Power Steering Control Valve Body)	3A740
Gasket (Fuel Tank Cap)	9035	Gasket (Pump Body Sep. Plate)	7G331
Gasket (Fuel Tank Filler To Quarter Panel)	9076	Gasket (Radiator Drain Cock)	8B286
Gasket (Fuel Tank Isolator)	9C031	Gasket (Radiator Tank)	8B379
Gasket (Governor)	7B391	Gasket (Radio Antenna Base)	18946
Gasket (Heater Blower Motor Mounting)	18583	Gasket (Radio Antenna Control Lens)	18B870
Gasket (Heater Core Tube)	18596	Gasket (Radio Receiver Speaker)	18889
Gasket (Heater Inlet)	18A569	Gasket (Rear Axle Cover To Housing)	4036
Gasket (Heater Mounting Plate)	18695	Gasket (Rear Axle Differential Carrier)	4035
Gasket (Heater Plenum Chamber To Dash)	18B623	Gasket (Rear Hi-Mount Lamp Mounting)	13A669
Gasket (Heater To Dash)	18570	Gasket (Rear Housing)	6D083
Gasket (Hi-Mount Lamp)	13W615	Gasket (Rear Lamp Lens)	13461
Gasket (Input Shaft Bearing Retainer)	7051	Gasket (Rear License Plate Lamp)	13568
Gasket (Instrument Cluster Regulator Case)	10802	Gasket (Rear Oil Pump To Case)	7A222
Gasket (Instrument Cluster Warning Lamp)	10A995	Gasket (Rear View Outside Mirror)	17724
Gasket (Instrument Cluster)	10A949	Gasket (Rear Wheel)	1001
Gasket (Instrument Panel Radio Speaker Grille)	18A978	Gasket (Reverse Servo Separator Plate Cover)	7L173
Gasket (Intake Manifold Cover)	9E436	Gasket (Shift Fork Lever)	7N351
Gasket (Intake Manifold Internal Cooler)	9L438	Gasket (Side Lamp Lens)	15A209
Gasket (Intake Manifold Opening Cover)	9C484	Gasket (Speedometer Case)	17303
Gasket (Intake Manifold To Cylinder Head)	9439,9441	Gasket (Steering Gear Sector Shaft Housing Cover)	3581
Gasket (Intake Manifold Upper)	9H486	Gasket (Supply Line To Fuel Rail)	9229
Gasket (Intake Manifold Water Connection)	9L437	Gasket (Tachometer Sensor)	17C251

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
G — Cont'd		G — Cont'd	
Gasket (Throttle Valve Diaphragm)	7B426	Gauge (Oil Pressure Instrument Panel)	9273
Gasket (Transmission Case Deflector)	7166	Gauge (Radiator Fluid Level)	8C043
Gasket (Turbo Charger To Throttle Body Tube)	9F703	Gauge (Temperature And Oil)	10E872
Gasket (Turbocharger Oil Return Line)	9440	Gauge (Tire Pressure)	17B013
Gasket (Valve Body Sep. Plate)	7D100	Gauge (Voltage Indicator)	10A835
Gasket (Valve Rocker Arm Cover)	6584	Gauge Assy. (Fuel Instrument Panel Unit)	9280,9305
Gasket (Warning Indicator Lamp Lens)	10A867	Gauge Assy. (Oil Pressure Engine Unit)	9278
Gasket (Water Inlet Connector)	8K530	Gauge Assy. (Oil Pressure Instrument Panel Unit)	9B308
Gasket (Water Outlet Connection Plug)	8C309	Gear	7B456
Gasket (Water Outlet Connection)	8255	Gear & Shaft Assy. (Speedo Drive)	7G176
Gasket (Water Pump Cover)	8513	Gear & Shell Assy. (Reverse Clutch)	7A019
Gasket (Water Pump Housing)	8507	Gear (3Rd Speed Secondary)	7N315
Gasket (Water Pump Inlet)	8A531	Gear (4Th Speed Secondary)	7L199
Gasket (Wheel Cylinder)	2B194	Gear (5Th Speed Clutch)	7B218
Gasket (Windshield Defroster Nozzle)	18A638	Gear (5Th Speed Drive)	7144
Gasket (Windshield Wiper Motor Cover)	17471	Gear (Armature/Drive)	11A067
Gasket (Windshield Wiper Motor Seal)	17C430	Gear (Camshaft)	6256
Gasket (Wiring Connector)	14A297	Gear (Countershaft Cluster)	7113
Gasket (Yoke-Drive End) (Includes Steel Ball)	11065	Gear (Countershaft Reverse)	7N040
Gasket)Oil Separator To Cyl. Block)	6B752	Gear (Crankshaft)	6306
Gasket - Exhaust	5C266	Gear (Distributor Drive)	6255
Gasket And Oil Seal Kit	7153	Gear (Drive)	11A067
Gasket Booster Mounting Bracket Brake	2B022	Gear (Engine Balance Shaft Drive)	6A303
Gasket Kit (Air Conditioner Compressor)	19B684, 19D970	Gear (Engine Balance Shaft Driven)	6A304
Gasket Kit (Fuel Charging)	9F760	Gear (Fifth Speed Driven)	7K316
Gasket Kit (Fuel Flow Sensor)	10D959	Gear (Final Drive Idler)	7F475
Gasket Set (Cylinder Head)	6079	Gear (Final Drive Output)	7F343
Gasket Set (Lower)	6E078	Gear (First Speed)	7100,7A029
Gasket Set (Manifold)	9433	Gear (Flywheel Ring)	6384
Gasket Set (Oil Pan)	6781	Gear (Fourth Speed)	7112
Gasket Set (Overhaul Partial)	6008	Gear (Governor Drive)	7G237
Gasket Set (Radiator Tank Repair)	8B378	Gear (Governor Driven)	7F419
Gasket Set (Timing Cover)	6D000	Gear (Heater Control)	18K526
Gasket Set (Valve Grind)	6079	Gear (Input)	7Z115
Gasket And Shim Kit (Steering Gear Housing Cover)	3593	Gear (Oil Pump Drive)	6652
Gasket And Shim Kit (Steering Gear Sector Shaft Housing Cover)	3F518	Gear (Output Shaft - Reverse)	7142
Gasket(Air By-Pass Valve)	9F429	Gear (Output Shaft Parking)	7A233
Gasket(Cap)	9035	Gear (Output Shaft Ring)	7A153
Gasket(Timing Belt Cover)	6020	Gear (Rear Axle Differential Side)	4236
Gasket(Water Supply Tube)	8563	Gear (Rear Ring)	7A153
Gate (3Rd & 4Th Shift)	7232	Gear (Reverse Idler Sliding)	7D223
Gate (Reverse)	7K129	Gear (Reverse Sliding)	7C382
Gate (Transmission Gear Shift)	7279	Gear (Reverse)	7K013
Gauge (Fuel And Amp)	10E871	Gear (Ring Forward)	7D392
Gauge (Instrument Cluster Temperature)	10883	Gear (Second Speed)	7102

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
G — Cont'd		G — Cont'd	
Gear (Steering Column Lock)	3E717	Grommet (Cylinder Front Cover)	6C019
Gear (Third Speed Or Overdrive)	7B340	Grommet (Fuel Elbow Drain Pipe)	9324
Gear (Third Speed)	7B340	Grommet (Fuel Injector)	9229
Gear (Transaxle Differential Side)	4236	Grommet (Fuel Line To Side Apron)	9K288
Gear (Transmission Reverse Synchronizer 1St Speed)	7N100	Grommet (Heater And Air Conditioning Housing)	18460
Gear (Transmission Reverse Synchronizer 2Nd Speed)	7N105	Grommet (Heater Hose)	18K293
Gear Assy. (1St.-3Rd. & Reverse)	7N107	Grommet (Main Control Cover)	7G005
Gear Assy. (Final Drive Sun)	7F342	Grommet (Non Return Valve)	2L181
Gear Assy. (Oil Pump Drive)	6W846	Grommet (Oil Filler Tube)	7N243
Gear Assy. (Power Steering - Short Rack)	3L547	Grommet (Parking Brake Release Rod)	2K606
Gear Assy. (Primary Sun)	7A399	Grommet (Radiator Grille Panel)	8K013
Gear Assy. (Reverse Idler)	7141	Grommet (Speedometer Case)	17304
Gear Assy. (Stationary)	11A165	Grommet (Valve Rocker Arm Cover Isolator)	6C518
Gear Assy. (Steering)	3504	Grommet (Windshield Washer Hose)	17673
Gear Assy. (Sun)	7D063	Grommet (Windshield Wiper Motor Mounting)	17C431
Gear Kit (Rear Axle Differential Side)	4236	Grommet (Windshield Wiper Mounting Bracket)	17C432
Gear Kit (Transaxle Differential Side)	4236	Grommet Assy (Valve Rocker Arm Cover Isolator)	6C519
Gear And Bushing Assy. (Reverse Idler)	7141	Guard (Fan)	8A611
Gear And Pinion Input Kit (Windshield Wiper Motor)	17A479	Guard (Front Bumper)	17996
Gear And Shaft Assy. (Windshield Wiper Motor Output)	17A434	Guard (Fuel Tank)	9099
Glass (Rear View Outside Mirror)	17K707	Guard (Rear Bumper)	17984
Glow Plug (Intake Manifold)	12A342	Guide (Brake Shoe Adjusting Lever Cable)	2A179
Governor (Windshield Wipers)	17C476	Guide (Front Band Servo Piston)	7A269
Governor Assy.	7C053	Guide (Gearshift Lever)	7C449
Graphic Equalizer Assy. (Radio Receiver)	18T803	Guide (Idler Belt Bracket)	6A241
Grease Retainer Kit (Front Wheel)	2C135	Guide (Parking Brake Cable)	2A700
Grille (Courtesy Lamp Console)	13C746	Guide (Parking Brake Cable-Rear)	2A697
Grille (Defroster Nozzle)	18A565	Guide (Rear Bumper Isolator)	17C900
Grille (Front Bumper)	17B968	Guide (Rear View Outside Mirror Cable)	17D678
Grille (Hood Air Scoop)	16A624	Guide (Speed Control Connector)	9E856
Grille (Radiator Inner)	8150	Guide (Steering Gear Ball Return)	3523
Grille (Radiator)	8200	Guide (Timing Belt Camshaft)	6B260
Grille (Vent Air Inlet)	18A499	Guide (Timing Belt Crankshaft)	6K297
Grille (Windshield Defroster Nozzle)	18C490	Guide (Timing Chain)	6K297
Grille Assy. (Headlamp Dimmer Sensor)	13C108	Guide (Valve Rocker Arm Fulcrum)	6A588
Grille Assy. (Radio Speaker)	18978	Guide Assy. (Valve)	6510
Grommet	11A120	Guide Plate & Retainer Assy(Valve Tappet)	6K564
Grommet	14603	Gusset Assy. (Front Fender Apron To Radiator Support)	16B198
Grommet (Air Conditioner Hose)	19D743	Gasket (Accel. Pump Valve)	9W902
Grommet (Air/Fuel Filter)	9229	Gasket (Adjusting Nut)	9A522
Grommet (Brake Tube)	2K409	Gasket (Altitude Compensator Housing)	9A953
Grommet (Cable Abutment Tube)	7L602	Gasket (Altitude Compensator)	9S521
Grommet (Carburetor Air Cleaner)	9697	Gasket (Booster Venturi Support)	9A536
Grommet (Coil Strap)	11A120	Gasket (Choke Plate)	9S545
Grommet (Crankcase Ventilation)	6A892	Gasket (Discharge Pump Nozzle)	9580

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
G — Cont'd		H — Cont'd	
Gasket (Economizer Cover)	9563	Harness Assy. (Air Conditioner Temperature Control Box Wiring)	19C757
Gasket (Economizer Valve)	9A588	Harness Assy. (Heater Motor)	18C629
Gasket (Feedback Actuator)	9A953	Harness Assy. (Vacuum Hose)	19C827
Gasket (Flange Body)	9516	Head (Air Conditioner Compressor Cylinder)	2995
Gasket (Float Bowl Cover)	9561	Head (Air Conditioner Compressor)	19D646
Gasket (Float Bowl)	9561	Head (Cylinder)	6049
Gasket (Fuel Bowl Screw)	9592	Head (Rear View Outside Mirror)	17723
Gasket (Fuel Bowl)	9561	Head Assy. Cylinder	5345
Gasket (Fuel Bowl)-Primary	9561	Head Front Kit (Air Conditioner Compressor)	19E580
Gasket (Fuel Charging Body)	9C983	Head Rear Kit (Air Conditioner Compressor)	19E581
Gasket (Fuel Inlet Needle Seat)	9569	Headlamp Assy. (Auxiliary)	13C142
Gasket (Fuel Inlet Seat)	9569	Headlamp Kit	13008
Gasket (Fuel Inlet)	9229	Heat Shield (Starter Motor)	11006
Gasket (Fuel Level Check Plug)	9569	Heater Assembly	18478
Gasket (Fuel Press. Regulator)	9C977	Heater Assy. (Block)	6A051
Gasket (Hot Idle Compensator)	9B567	Heater Assy. (Fuel)	9J294
Gasket (Pump Discharge Nozzle)	9580	Heatsink (Ignition Multiple Control)	12B586
Gasket (Pump Relief)	9580	Hinge (Headlamp Cover)	13A154, 13A155
Gasket (Secondary Diaphragm Housing)	9853	Hinge (Hood)	16796
Gasket (Secondary Metering Body)	9A518	Hinge Assy. (Fuse Junction Panel)	14B100
Gasket (Solenoid Feed Back)	9S521	Hinge Assy. (Radiator Grille)	8C039
Gasket (Thermostat Choke Housing)	9871	Hoist (Spare Wheel)	1A432
Gasket (Thermostatic Choke Control)	9853	Holder (Brush)	10351, 11061
Gasket (Thermostatic Choke Housing)	9871	Holder (Fuel Injector Nozzle)	9F536
Gasket (Throttle Body To Main Body)	9516	Holder (Fuse)	14417
Gasket (Throttle Body)	9516	Holder (Pencil)	19A377
Gasket (Vent Valve Cover)	9592	Holder (Spare Wheel Carrier)	1443
Gasket (Venturi Valve Cover)	9A933	Holder Assy. (Brush & Terminal)	10320, 10347
Gasket Set (Carburetor)	9502	Holder Assy. (C.B. Radio Microphone)	18B834
Gauge (Fuel Level)	9J538	Holder Assy. (Fuse)	14411
Grommet (Seal Bowl Vent)	9562	Hood	16612
Guide (Venturi Valve Diaphragm)	9A906	Hook (Hood Auxiliary Catch)	16892
H		Hook (Spare Tire Clamp)	1474
Handle & Shank Assy. (Tilt Wheel)	3F609	Hook (Tie Down)	17A084
Handle (Hood Lock Release)	16B626	Hook (Towing)	17A954
Handle (Jack Assy.)	17081	Horn Assy.	13832, 13833
Handle And Cable Assy. (Hood Latch Control)	16916	Horn Assy. (Carburetor Air Cleaner)	9B695
Handle Assy. (Parking Brake Release)	2760, 2B658	Horn Kit (Vacuum Air)	13800
Handset (Mobile Telephone Assy.)	19A383	Hose	17543
Hanger (Rear Spring)	5775	Hose & Clamp Assy. (Cooler To Throttle Body)	9F699
Hardware Kit (Brake Shoe & Lining)	2C077	Hose & Clamp Assy. (Turbo To Cooler)	9F698
Hardware Kit (Brake Shoe And Lining)	2C077	Hose & Connector Assy. (Rear L.H.)	2C023
Harness (Short)	18B310	Hose & Filter Assy (P/S Return Line)	3F731
Harness Assy. (A/C Vacuum Hose)	9D438	Hose & Tube Assy. (Air By-Pass Valve Inlet)	9H300
Harness Assy. (Air Conditioner Plenum Vacuum)	18C581	Hose (Air By-Pass Valve Inlet-Thermactor)	9F287

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
H — Cont'd		H — Cont'd	
Hose (Air Cleaner Temperature Control Sensor Vacuum)	9P760	Hose (Oil By-Pass)	6K834
Hose (Air Conditioner Evaporator Drain)	19858	Hose (Oil Cooler)	6B852,8N021
Hose (Air Tube To Throttle Body)	9F722	Hose (Oil Pump Feed)	7N261
Hose (Anti-Backfire Valve Vacuum)	9C433	Hose (Oil Separator)	6A664
Hose (Anti-Backfire Valve)	9F287	Hose (Parking Brake)	2A596
Hose (Breather)	9048,9049	Hose (Power Steering Return Line)	3A005
Hose (By-Pass Valve To Check Valve)	9K446	Hose (Radiator Bulk)	8333
Hose (Charge Air Cooler)	6W650	Hose (Radiator Drain)	8B081
Hose (Crankcase Emission Connection)	6K869	Hose (Radiator Overflow)	8075
Hose (Crankcase Oil Separator To A/Cleaner)	6L615	Hose (Radiator Supply Tank O/Flow)	8B102
Hose (Crankcase Vent. Extension)	6N664	Hose (Radiator Supply Tank)	8063
Hose (Crankcase Ventilation Oil Return)	6A804	Hose (Radiator)	8260
Hose (Crankcase Ventilation)	6853,6A664	Hose (Rear Axle Housing Vent)	4A001
Hose (E.G.R. Cooler Inlet)	9F476	Hose (Rear Axle)	4090
Hose (E.G.R. Cooler Outlet)	9F475	Hose (Speed Control Regulator To Vacuum Supply)	9D770
Hose (Exhaust Air Supply Air Valve Inlet)	9J436	Hose (Trans Oil Cooler)	7B093
Hose (Exhaust Air Supply Air Valve Outlet)	9J437	Hose (Turbo Charger Heat Exchanger)	6N802
Hose (Exhaust Air Supply By-Pass Valve)	9K466	Hose (Vacuum Outlet Manifold)	9C493
Hose (Exhaust Air Supply Bypass Valve To Air Cleaner)	9K445	Hose (Vent)	9050
Hose (Exhaust Air Supply Check Valve Inlet Moulded)	9B466	Hose (Water By-Pass)	8597
Hose (Exhaust Air Supply Control Valve To Check)	9G459	Hose (Water Inlet Connector)	8A506
Hose (Exhaust Air Supply Control Valve)	9G424	Hose (Water Outlet)	8A507
Hose (Exhaust Air Supply Pump Inlet)	9B458	Hose (Water Pump Inlet)	8A567
Hose (Exhaust Air Supply Pump Outlet)	9B459	Hose (Windshield Washer)	17A605
Hose (Exhaust Air Supply Pump Silencer)	9H458	Hose And Connector Assy. (Carburetor Altitude Compensator)	9F701
Hose (Exhaust Air Supply Pump To By-Pass Valve)	9K451	Hose And Grommet Assy. (Turbo Boost)	12A161
Hose (Exhaust Air Supply Silencer Inlet)	9J435	Hose And Solenoid Assy. (Carburetor Float Bowl Vent)	9C917
Hose (Exhaust Gas Recirculating Vacuum Control Valve)	9P761	Hose Assy.(Water Outlet Connection)	8A577
Hose (Front Brake)	2078	Hose Assy. (Air Conditioner Vacuum Tank)	19C828
Hose (Fuel (Tube)	9324	Hose Assy. (Air Leveler)	5A667
Hose (Fuel Injection Hot Idle Speed-Up Control)	9H566	Hose Assy. (Alternator Air Intake)	10C353
Hose (Fuel Pump To Discharge Fitting)	9A383	Hose Assy. (Battery Vent)	10K650
Hose (Fuel Return)	9C327	Hose Assy. (Breather)	9A088
Hose (Fuel Tank Sensing)	9K164	Hose Assy. (Exhaust Air Supply Pump Outlet)	9B460
Hose (Fuel Tank To Filler Pipe)	9047	Hose Assy. (Fuel Filter Inlet)	9J290
Hose (Fuel Tube)	9324	Hose Assy. (Fuel Filter Outlet)	9J291
Hose (Fuel Vapor Return)	9G297	Hose Assy. (Fuel Pressure Gauge)	9D272
Hose (Fuel Vapor Separator To Fuel Pump)	9G296	Hose Assy. (Fuel Pump To Fuel Line)	9288
Hose (Fuel Vapor Separator To Fuel Tank Rear)	9C287	Hose Assy. (Fuel Pump To Injector Assy.)	9288
Hose (Fuel Vapor)	9E325	Hose Assy. (Fuel Pump Tube To Fuel Tank Tube)	9C339
Hose (Heater Air Outlet)	18556	Hose Assy. (Fuel Return To Tank)	9F306
Hose (Heater Core Inlet Or Outlet)	18D334	Hose Assy. (Fuel Return)	9D308
Hose (Heater Water)	18472, 18D359	Hose Assy. (Fuel Tank Overflow)	9C005
Hose (Heater And Air Conditioner Control Motor Vacuum Supply)	18A358	Hose Assy. (Fuel Tank To Fuel Tube)	9B286
Hose (Hi-Altitude Compensator)	9F677	Hose Assy. (Fuel Vapor Front)	9K313

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
H — Cont'd		H — Cont'd	
Hose Assy. (Fuel Vapor Return Connector)	9B999	Housing (Parking Lamp)	13206
Hose Assy. (Hyd. Clutch)	7T504	Housing (Radio Speaker)	19248
Hose Assy. (Lpg)	9J280	Housing (Rear)	10334
Hose Assy. (Oil By-Pass Inlet)	6B850	Housing (Trans. Control Selector)	7A306,7A307
Hose Assy. (Oil Cooler)	6A715,6B850	Housing (Warning Indicator)	10D970
Hose Assy. (Parking Brake Release Valve)	2A632	Housing (Window Regulator Switch)	14523,14527, 14528
Hose Assy. (Parking Brake Release-Vacuum)	2B653	Housing And Switch Assy. (Seat Back Control)	14B722
Hose Assy. (Power Steering Pressure)	3A719	Housing Assy. (Air Conditioner Blower)	19930
Hose Assy. (Rear Wheel Brake)	2A442,2A478	Housing Assy. (Air Conditioner Evaporator Core)	19A559
Hose Assy. (Speed Control Harness)	9D735	Housing Assy. (Air Conditioner Evaporator)	19850
Hose Assy. (Speed Control Regulator To Vacuum Supply)	9E723	Housing Assy. (Drive End)	11130
Hose Assy. (Window Washer)	17408	Housing Assy. (Drive End) - Incl. Bushing	11130
Hose Assy. Vacuum Reservoir	2B947	Housing Assy. (Drive End)-Incl. Bushing	11130
Hose Brake Booster	2A046	Housing Assy. (Extension)	7A039
Hose Brake Reservoir Outlet Assy.	2B319	Housing Assy. (Flywheel)	6392
Hose Coolant Return	8C289	Housing Assy. (Front)	10333
Hose Guard Kit (Air Conditioner)	19B970	Housing Assy. (Fuel Filler Pipe Rest)	9K165
Hose Kit (High Pressure)	2C234	Housing Assy. (Gear)	11A149
Hose Kit (Low Pressure)	2C252	Housing Assy. (Power Steering Gear Actuator)	3E564
Hose Vacuum Booster	2A047	Housing Assy. (Power Steering Pump)	3A643
Hose And Clamp Assy. (Air Bypass Valve Inlet)	9J272	Housing Assy. (Radio Receiver)	18K884
Hose And Connector Assy. (Fuel Pump)	9C394	Housing Assy. (Rear Axle)	4010
Hose And Elbow Assy. (Automatic Temperature Control Sensor)	19D888	Housing Assy. (Rear Brake Inner)	2N110
Housing & Bracket (Rear License Plate)	17B390	Housing Assy. (Roof Sliding Panel Switch)	15873
Housing & Shaft Assy.(Oil Pump Drive)	6C642	Housing Assy. (Shift Control)	7203
Housing (Air Conditioner Blower Outer)	18755	Housing Assy. (Steering Gear)	3548
Housing (Air Conditioner Instrument Panel Register)	19623	Housing Assy. (Trans. Control Sel. Dial)	7D394
Housing (Backup Lamp)	15502	Housing Assy. (Warning Indicator)	10C876
Housing (Control Sel. Dial W/Prndl)	7A213	Housing Assy. (Windshield Wiper Pivot Shaft)	17N431
Housing (Converter)	7976	Housing Garage Door Actuator (Hand Control)	19A373
Housing (Courtesy Lamp)	13B722	Housing Kit (Drive End)	11130
Housing (Drive End)	11130	Housing Kit (Power Steering Control Valve)	3F669
Housing (Eng. Charge Air)	6K863	Housing Window Regulator Switch	14527
Housing (Engine Rear)	6D050	Housing And Bearing (Rear)	10334
Housing (Extension)	7A039	Hub & Bearing Cup Assy.	1K002
Housing (Fog And Turn Signal Indicator Lamp)	13A360	Hub & Bearing, Cup	1A034
Housing (Front Bumper Isolator)	17E796	Hub & Bushing Assy. (Forward Clutch)	7B067
Housing (Front Suspension)	3438	Hub & Drum Assy. (Rear Wheel Brake)	1113
Housing (Front)	10333	Hub & Indicator Assy. Front Brake Anti Lock	2C202
Housing (Headlamp)	13100	Hub (Clutch)	7B067
Housing (Hood Hinge)	16C764	Hub (Direct Clutch)	7F236
Housing (Instrument Cluster)	10838	Hub (Front & Rear Wheels)	1104
Housing (Instrument Panel Lamp)	10C876	Hub (Instrument Cluster Dial)	10B899
Housing (Light Switch)	11K647	Hub (Output Shaft)	7D164
Housing (Message Center Control-Tripminder)	10D894	Hub (Power Steering Pump Pulley)	3D674

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
H — Cont'd		I — Cont'd	
Hub (Synchronizer)	7105	Insert (Eng. Charge Air Cooler Tube)	6F082
Hub And Indicator Assy.(Rear Brake Anti Lock)	2C271	Insert (Engine Air Cleaner Cover Sensor)	9F850
Hub And Spindle Assy. (Front Wheel)	3K206	Insert (Fan Shroud)	8A644
Hub Assy. (Crankshaft Damper)	6359	Insert (Fuel Tank)	9C048
Hub Assy. (Rear)	1109	Insert (Gear Shift Fork)	7L082
Hub Assy.(Crankshaft Pulley)	6C337	Insert (Kickdown Cable)	7L109
Hub And Bearing (Clutch Release)	7548	Insert (Oil Cooler Mtg. Bolt)	6L626
Hub And Rotor (Front Wheel Disc Brake)	1102	Insert (Oil Filler Cap)	6C614
Hub(Water Pump Pulley)	8553	Insert (Oil Filter Adapter)	6A719
Hinge Pin (Vent Valve)	9H584	Insert (Oil Filter Mounting)	6890
Holder (Idling Jet)	9575	Insert (Oil Level Indicator Tube Ext.)	6K816
Holder (Spare Wheel Carrier)	1443	Insert (Oil Pump Drive Gear)	7F402
Hook (Towing)	17A954	Insert (Radiator Temperature Sensor)	8C319
Housing (Choke Thermostat & Cap)	9848	Insert (Radio Antenna Base)	18934
Housing (Choke Thermostat)	9848	Insert (Steering Column Lock)	3E716
Housing (Electric Choke Heater)	9848	Insert (Synchronizer Hub)	7A044
Housing (Secondary Diaphragm)	9501	Insert (Thermostatic Choke Control Air Intake)	9A714
Housing (Thermostatic Choke)	9848	Insert (Transmission Shift Selector Position)	7A216
Housing And Diaphragm Assy. (Choke)	9849	Insert (Valve Rocker Arm Cvr. Vent Tube)	6C601
Housing And Plug Assy. (Choke)	9849	Insert (Valve Seat)	6057
Housing And Plugs Assy. (Choke)	9849	Insert Assy (Combustion Chamber)	6057
Housing Assy. (Choke Thermostat)	9848	Insert(Radiator Mounting Insulator)	8C298
Housing Assy. (Choke Thermostat)-	9848	Insulation (Air Conditioner Tube)	19A893
Housing Assy. (Choke)	9A575	Insulation (Air Conditioning Evaporator Core Rear)	19A830
Housing Assy. (Throttle Shaft)	9518	Insulator	17B947
Hub & Bearing Cup Assy.	1K002	Insulator & Bushing Assy. (Trans. Gear Shift Arm)	7F089
I		Insulator & Shield Assy. Rear Susp. Mtng.	5A910
Idler Assy (Timing Belt)	6M250	Insulator (A/C Condenser Bolt)	19E893
Impingement Screen (Air Conditioner Air Register)	19D627	Insulator (Air Cleaner Support)	9P686
Indicator (Front Brake Sensor Anti Lock)	2C182	Insulator (Air Conditioner Condenser Lower)	19C566
Indicator (Oil Level)	6750,7A020	Insulator (Air Conditioner Evaporator Case Cover)	19B666
Indicator (Power Steering Pump Reservoir Oil Level)	3E551	Insulator (Alternator Terminal)	10329
Indicator (Rear Brake Sensor Anti Lock)	2C189	Insulator (Bellcrank Or Shift Control Selector Arm)	7341
Indicator (Trans. Control Selector)	7A110	Insulator (Body Side Lamp Rear)	15C416
Indicator Assy. (Amp Gauge)	10670	Insulator (Brake Pedal Hub Spring)	2481
Indicator Assy. (Electronic Speedometer)	17C253	Insulator (Brush Holder)	11062
Indicator Assy. (Heated Windshield)	18D444	Insulator (Carburetor Transmission Vacuum Tube)	9S547
Indicator Assy. (Low Coolant)	10B977	Insulator (Charge Air Mounting Bracket)	6N865
Indicator Assy. (Message Center)	10D898	Insulator (Clutch Release Cable)	7C511
Indicator Assy. (Turbo-Instr/Cistr)	10A979	Insulator (Control Bellcrank Or Shift Control Selector Arm)	7341
Injector Assy. (Fuel)	9F593	Insulator (Dampener)	6F017
Inner Yoke Shaft (Rear Axle)	4365	Insulator (Diode Plate)	10A383
Input Shaft (Rear Axle)	4858	Insulator (Door Lock Solenoid)	14K133
Insert (Control Selector Rod)	7B233	Insulator (Egr Regulator Control)	9S469
Insert (Cylinder Head)	6E086	Insulator (Engine To Frame Mounting Bracket)	6F003

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
L — Cont'd		M — Cont'd	
Lever Assy. (Diaphragm)	9583	Mirror (Rear View Outside)	17682
Lever Assy. (Fast Idle Adjusting Intermediate)	9B912	Mirror (Vanity)	17A679
Lever Assy. (Throttle Shaft & Stop)	9581	Mirror Assy. (Rear View Inside)	17700
Lever Assy. (Wot A/C Cut-Out)	9A537	Mirror Kit (Rear View Outside)	17696
Limiter (Idle Adjusting Needle)	9J500	Mobile Telephone Kit (Cellular)	19A393
Limiter (Idle Adjusting)	9J500	Modulator Assy. - Ignition (Control Module)	12A199
Limiter (Idler Adjusting Needle)	9J500	Module (Glow Plug Control)	12B533
Link & Swivel Assy. (Accel. Pump)	9529	Module Assy. (Air Bag Reserve Power Supply)	14B165
Link (Accel. Pump)	9529	Module Assy. (Brake Anti Lock)	2C219
Link (Accelerator Pump)	9529	Module Assy. (Engine Control Relay)	12A510
Link (Choke Thermostat)	9834	Module Assy. (Exhaust Turbo Controller)	5E260
Lockwasher (Throttle Shaft)	9568	Module Assy. (Ignition Control Module) - Icm	12K072
M		Module Assy. (Instrument Cluster Display)	10N911
Magnet (Case)	7L027	Module Brake (Anti Lock Control)	2B373
Manifold (Exhaust Air Supply)	9B445	Module Control Relay (Anti Lock)	2C222
Manifold (Exhaust Gas Recirculation Cooler)	9G443	Monitor Assy. (Air Bag Diagnostic)	14B056
Manifold (Exhaust)	9430,9431	Motor Assy.	7G360
Manifold (Intake)	9424	Motor Assy. (Air Conditioner Blower)	19805
Manifold (Vacuum & Water Distribution)	9S431	Motor Assy. (Air Conditioner Door Actuator Electronic)	19E616
Manifold Assy. (Fuel Injection Supply)	9D280	Motor Assy. (Fuel Cold Start Vacuum)	9F785
Manifold Assy. (Vacuum Outlet)	9C490	Motor Assy. (Headlamp Cover Control)	13A167
Manifold Assy. Discharge Kit (Air Conditioner Compressor)	19E582	Motor Assy. (Heater Blower)	18527
Manifold Suction Kit (Air Conditioner Compressor)	19E583	Motor Assy. (Parking Brake Release Control)	2A843
Manifold And Crossover Tube Assy. (Fuel Injection Supply)	9F792	Motor Assy. (Radiator Electric)	8K621
Manifold And Tube Assy. (Air Conditioner Compressor Suction)	19E636	Motor Assy. (Seat Belt Retractor)	14B150
Manifold And Tube Assy. (Air Conditioner)	19D734	Motor Assy. (Seat Regulator)	14547
Manifold And Valve Assy. (Air Conditioner Compressor)	19E574	Motor Assy. (Sliding Roof Panel)	15790
Mask (Instrument Cluster)	10890	Motor Assy. (Vacuum Control)	18A318
Mask (Transmission Console Shift Selector Indicator Dial)	7B052	Motor Assy. (Windshield Wiper)	17508
Mask Assy. (Console Panel Lamp)	13C726	Motor Kit (Rear View Outside Mirror)	17D696
Mast (Radio Antenna Replacement)	18A886	Motor Oils And Lubricants	P0005,P0006
Medallion (Gear Shift Handle)	7G359	Motor And Tube Assy. (Elec. Antenna C.B.)	18B850
Medallion Assy. (Air Conditioner Register)	19A551	Motor And Tube Assy. (Radio Antenna - Electric)	18850
Member & Insulator Assy. Rr. Susp. Frnt. Mtg.	5K825	Moulding (Front Bumper)	17B970
Member (Front Fender Apron To Cowl Side Upper)	16A178	Moulding (Front Fender Upper Front)	16160
Member (Sub Frame Center Support)	5K065	Moulding (Front Fender Upper Rear)	16C132
Member (Sub Frame Cross)	5K068	Moulding (Hood Rear)	16B918
Member (Transmission Support)	7K065	Moulding (Hood)	16856
Member Assy. (Eng. Mounting Rear)	6A088	Moulding (Rear Lamp)	13476
Member Assy. (Engine Mounting Rear)	6A092	Moulding Assy. (Front Bumper Grille)	17C754
Member Assy. (Rear Shock Absorber Mounting)	18A000	Moulding Assy. (Front Fender Front Extension)	16B124
Message Assy. (Voice Information-Alert)	10D974	Moulding Assy. (Headlamp Cover)	13B088
Microphone Assy. (C.B. Radio)	18B804	Moulding Assy. (Headlamp Opening)	13B166
Microphone Assy. (Mobile Telephone)	19A391	Moulding Assy. (Radiator Grille Opening Panel)	8A19,8A156
Microphone Kit Hands Free (Mobile Telephone)	19B391	Moulding Assy.(Radiator Grille Opening Panel Side)	8B475

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
M — Cont'd		N — Cont'd	
Mounting (Clutch Release Equalizer Bar)	7507	Nut (Heater Regulator Control)	18A508
Mounting (Front Suspension Unit Upper)	3K132	Nut (Idle Pulley Adj.)	8A663
Mounting Kit (Rectifier)	10K346	Nut (Idler Gear Shaft)	7045
Mounting Kit (Regulator)	10A596	Nut (Output Shaft Gear Retaining)	7N170
Mounting Parts Kit	10B304	Nut (Output Shaft Rear Bearing - Lock)	7B364
Mounting Parts Kit (Pulley)	10B304	Nut (Power Steering Gear Race)	3D627
Muffler	5230	Nut (Radio Antenna)	18865
Muffler And Hose Assy. (A/C Evaporator)	19E732	Nut (Radio Control Shaft)	18818
Module (Glow Plug Control)	12B533	Nut (Rear Axle Differential)	4A142
Module Assy. (Engine Control Relay)	12A510	Nut (Rear Counter Shaft Bearing - Retaining)	7N170
Module Assy. (Exhaust Turbo Controller)	5E260	Nut (Rear View Outside Mirror Remote Control)	17B732
Motor Assy. (Feedback Actuator)	9C908	Nut (Reverse Shift Lever Pin)	7N428
Motor Assy. (Feedback Actuator)-	9C908	Nut (Servo Rod)	7N526
Motor Assy. (Carburetor Air Cleaner Vacuum)	9D612	Nut (Shaft Gear Retaining)	7N170
Motor Assy. (Fuel Cold Start Vacuum)	9F785	Nut (Shock Abs. Strut Mounting Bolt)	18A036
N		Nut (Spare Wheel Mounting Bolt)	1462
Nameplate Assy. (Rear Lamp)	13B467	Nut (Steering Gear Rack & Spindle Connecting Rod Lock)	3F514
Nameplate Assy. (Rear Reflector)	13B492	Nut (Steering Gear Worm Thrust Bearing Lock)	3707
Network Assy. (C.B. Radio)	18B812	Nut (Tire Low Pressure Indicator Valve)	1708
Nozzle (Windshield Defroster Hose)	18490	Nut (Transmission Gearshift Lever Ball Lock)	7C404
Nozzle Assy. (Window Defogger)	18C515	Nut (Transmission Input Shaft)	7N170
Nozzle Holder Assy. (Fuel Injector)	9E527	Nut (Valve Rocker Arm Adjusting)	6552
Nozzle And Duct Assy. (Heater & A/C Demister)	18D453	Nut (Valve Rocker Arm)	6A529
Nut	3Z595,5Z999	Nut (Wheel Hub Bolt)	1012
Nut (Adapter Heater Temperature Control Valve)	18K307	Nut (Windshield Wiper Control)	17512
Nut (Air Cleaner Clamp)	9B680	Nut (Windshield Wiper Pivot Shaft To Cowl)	17481
Nut (Air Cleaner Retention Wing)	9B686	Nut (Yoke Locking)	3F606
Nut (Band Adjusting Stop)	7Z114	Nut Kit (Air Conditioner Compressor Shaft)	19D667
Nut (Brake Shoe Adjusting Screw)	2047	Nut (Fuel Pump Retaining)	9351
Nut (Brake Tube)	2133	Needle (Idle Adjusting)	9541
Nut (Camshaft Bearing Cap)	6B272	Needle Assy. (Fuel Inlet)	9564
Nut (Cap)	13N401	Nozzle Assy. (Pump Discharge)	9577
Nut (Clutch Cable Adjusting)	7593	Nozzle Set (Pump)	9577
Nut (Clutch Release Lever)	7A525	Nozzle Holder Assy. (Fuel Injector)	9E527
Nut (Connecting Rod)	6212	Nut	9D564
Nut (Courtesy And Fog Lamp Switch)	13753	Nut (Throttle Lever And Choke)	9B527
Nut (Cover Lower Pinion)	3Z598	O	
Nut (Driveshaft Assy.)	4L817	O Ring	3Z728
Nut (Flywheel To Converter Retaining)	6441	O Ring (Fuel Injector - Fuel Rail)	9229
Nut (Fog Lamp)	15205	O Ring (Oil Filler Tube)	7B498
Nut (Front Stabilizer Bar Link)	5C491	O Ring (Power Steering Control Valve Spool Centering Spring)	3C706
Nut (Fuel Injector Nozzle)	9F540	O Ring (Power Steering Gear Control Valve To Housing)	3756
Nut (Gearshift Control Attaching)	7E093	O Ring (Rear Axle Shaft)	4A332
Nut (Headlamp Adjusting)	13181	O Ring (Tachometer Driven Gear Oil Seal)	17383
Nut (Headlamp Switch)	11650	O Ring Brake Anti Lock Control System	2M060

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
O — Cont'd		O — Cont'd	
O Ring Kit (Air Conditioner Compressor)	19D660	Outer Shaft (Rear Axle Yoke-Wheel End)	4L387
O Ring Kit (Air Conditioner)	19B596	Overhaul Kit	7C391
O Ring Kit (Turbocharger)	9G487	Orifice (Egr Valve Pressure Control)	9D481
O Ring Kit Reservoir	2M057	P	
O Ring Seal Kit (Air Conditioner Spring Lock Coupling)	19D690	Packing (Crankshaft Rear)	6701
O Ring Solenoid	5312	Pad (Air Conditioner Register Louver)	19C896
O Ring Suspension Air Spring Dryer Connection	5L346	Pad (Brake Pedal)	2454
O Rings	7N289	Pad (Clutch Pedal Plate)	7A624
O Ring (Float Bowl Tube Connector)	9229	Pad (Front Fender Upper Rear Moulding)	16A272
O Ring (Inlet Tube)	9229	Pad (Hood Front Moulding)	16C744
O Ring Seal	9229	Pad (Hood)	16740
O-Ring (Accumulator To Pump Body)	2C233	Pad (Instrument Cluster Bezel)	10A884
O-Ring (Anti Lock)	2C255	Pad (Parking Lamp To Body)	13217
O-Ring (Brake Pressure Control Valve)	2B467	Pad (Rear Bumper Jack Bracket)	17C874
O-Ring (Exhaust Gas Recirculation Valve)	9E457	Pad (Rear Lamp Door)	13478
O-Ring (High Pressure Hose)	2C237	Pad (Rear Lamp Mounting)	13420
O-Ring (Intercooler Tube To Insert)	6F088	Pad (Rear View Inside Mirror To Windshield)	17A720
O-Ring (Oil Control Plug)	6C004	Pad Assy. (Bumper Guard)	17A812
O-Ring (Oil Filter Adapter To Filter)	6838	Pad Assy. (Child Seat Impact Shield)	19F532
O-Ring (Oil Filter Cover To Housing)	6838	Pad Assy. (Front Bumper Horizontal)	17C829
O-Ring (Oil Pan Screen)	7A469	Pad Assy. (Rear Bumper Horizontal)	17C830
O-Ring (Oil Pump To Cylinder Block)	6643	Pad Compressor Mounting	5B349
O-Ring (Pressure Warning Switch)	2C245	Paints And Refinishing Materials	P0005,P0006
O-Ring (Rear Axle Bearing Retaining Cap)	4370	Pan (Oil)	7A194
O-Ring (Rear Axle Oil Seal)	4K101	Pan Assy. (Oil)	6675
O-Ring (Speedometer Gear)	17443	Panel (Air Conditioner Control)	19809
O-Ring (Water Temp Switch)	10X844	Panel (Air Conditioner Evaporator Case)	19801
O-Ring (Water Temp. Switch)	10X884	Panel (Front Valance)	17626
O-Ring - (Detent Plunger)	7B216	Panel (Headlamp Mounting)	13K002
Odometer Assy.	17A265	Panel (Radiator Grille Opening)	8190
Oil Jet Assy. (Piston Cooling)	6C327	Panel (Rear Lamp Finish)	13B452
Oil Pump Rotor Kit (Air Conditioner Compressor)	19D663	Panel (Relay)	14B120
Oil Seal (Front Band Servo Piston Guide)	7C050	Panel Assembly (Fuse Junction)	14A068
Orifice (Air Conditioner Evaporator Core)	19D990	Panel Assy. (Air Conditioner Control)	19808
Orifice (Egr Valve Pressure Control)	9D481	Panel Assy. (Air Conditioner Register Trim)	19C866
Orifice Tube Kit (Air Conditioner)	19D695	Panel Assy. (Auxiliary Instrument)	10B944
Ornament (Hood Top)	16850	Panel Assy. (Fuse Junction)	14A067
Ornament (Outside Rear View Mirror)	17B724	Panel Assy. (Headlamp Mounting)	13W017
Ornament (Radiator Grille)	8213	Panel Assy. (Heater Control)	18A651
Ornament (Wheel Cover)	1141	Panel Assy. (Instrument Cluster Switch)	10K961
Ornament Assy. (Headlamp Cover)	13A186	Panel Assy. (Relay Mounting)	14B144
Ornament Plate (Rocker Arm Cover)	6404	Panel Assy. (Warning Indicator)	10B987
Outer Shaft (Rear Axle Sleeve Yoke-Axle End)	4N387	Panel And Lens Assy. (Integrated Control)	19C925
		Parking Brake (Button Release)	2L760
		Parts Set (Wiper Motor)	17B585

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
P — Cont'd		P — Cont'd	
Pawl (Brake Adjuster)	2L380	Pin (Piston)	6135
Pawl (Clutch Pedal Quadrant Adjuster)	7L584	Pin (Rear Axle Differential And Pinion Shaft Lock)	4241
Pawl (Overdrive Shift)	7F304	Pin (Rear Band Actuating Lever Shaft)	77356
Pawl (Parking)	7A441	Pin (Reverse Clutch Hub)	7A618
Pawl (Shift Gate Plate)	7E159	Pin (Reverse Gear Selector Pivot)	7K024
Pawl (Steering Column Lock)	3E691	Pin (Reverse Gearshift Relay Lever)	7K024
Pawl (Trans. Control Selector Lever)	7L034	Pin (Reverse Lockout Pawl-Pivot)	7E484
Pedal Assy. (Brake)	2455	Pin (Reverse Relay Lever Pivot)	7F111
Pedal Assy. (Clutch)	7519	Pin (Shift Lever Connecting)	7F301
Pedestal (Wheel Cover - Locking)	1A113	Pin (Steering Column Lock)	3E718
Pilot Bearing	7600	Pin (Steering Column Pivot)	3D739
Pilot Bearing (Housing - Inboard Cv Joint Stub Shaft)	4B413	Pin (Steering Column Release)	3D545
Pilot Bearing Seal (Housing - Inboard Joint Stub Shaft)	4B416	Pin (Throttle Pressure Booster Retainer)	7D375
Pin (1St & 2Nd Speed Syn. Hub)	7K218	Pin (Timing Belt Tensioner)	6286
Pin (5Th & Reverse Shift Lever - Pivot)	7K179	Pin (Timing Chain Tensioner Arm)	6286
Pin (Accelerator Pedal Lever Link)	9B847	Pin (Timing Chain Tensioner Spring)	6K265
Pin (Air Conditioner Compressor Head Locator)	19D662	Pin (Top Gear Switch Actuating)	7C031
Pin (Brake Pedal Asst.)	2A190	Pin (Transaxle Differential And Pinion Shaft Lock)	4241
Pin (Brake Shoe Hold Down Spring)	2069,2L265	Pin (Transmission Shift Rod Clevis)	7C141
Pin (Clutch Pedal Pawl)	7L586	Pin (Valve Rocker Arm Fulcrum)	6A527
Pin (Clutch Pedal Rod Bracket)	7R531	Pin (Valve Rocker Arm Shaft Retaining)	6A533
Pin (Clutch Push Rod Bracket)	7N592	Pin (Vanity Mirror Cover)	17D682
Pin (Clutch Release Lever)	7N559	Pin (Windshield Wiper Motor)	17B563
Pin (Crankshaft Rear Oil Seal)	6A302	Pin Assy. (Front Air Suspension Sensor)	5C561
Pin (Drive Lever)	11139	Pin Assy. (Gear Shift Lever)	7G357
Pin (Engine Balance)	6A328	Pin Brake Low Pressure Hose	2M052
Pin (Front Disc Brake Caliper Locating)	2B296	Pin Kit (Brake Locating-Front)	2L527
Pin (Fuel Tank Strap Retaining)	9K139	Pin Spare Wheel Holder Assy.	1487
Pin (Gear Shift Selector Shaft)	7C316	Pinion (Transaxle Differential)	4215
Pin (Gearshift Lever)	7W441	Pinion Kit (Rear Axle Differential)	4215
Pin (Heater Control Locator)	18C408	Pipe (Brake Anti-Lock)	2L269
Pin (Hub Cap Retention)	1A103	Pipe (Cylinder Block Oil To Turbo Charger)	6K679
Pin (Interlock Sleeve Retaining)	7F488	Pipe (Engine Charge Air Inlet)	9K640
Pin (Manual Lever Shaft Retaining)	7B210	Pipe (Exhaust Manifold Outlet)	9G437
Pin (Manual Shaft Retaining)	7G100	Pipe (Fuel Evaporation)	9038
Pin (Manual Valve Detent Lever-Inner)	7E333	Pipe (Muffler Inlet)	5246
Pin (Overdrive Band Anchor)	7F295	Pipe Assy (Oil Fill)	6763
Pin (Park Brake Anchor)	2639	Pipe Assy. (Fuel Tank Filler)	9034
Pin (Parking Brake Handle Locking)	2819	Pipe Assy. (Main Brake)	2A335
Pin (Parking Brake Lever)	2107	Piston	7E005
Pin (Parking Brake Rear Cable Guide)	2B627	Piston & Pin Assy. (Front Band Servo)	7A164
Pin (Parking Pawl Toggle Lever)	7A244,7A295	Piston & Rod Assy. (Reverse Band Servo)	7D183
Pin (Parking Pawl Toggle Link To Pawl)	7E415	Piston & Seal Assy. (O/Drv. Servo)	7F200
Pin (Parking Pawl Toggle)	7A119	Piston & Seal Assy. (Reverse Band Servo)	7D189
Pin (Parking Pawl)	77312	Piston & Seal Assy. (Reverse Band Servo) - Select Fit	7D189

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
P — Cont'd		P — Cont'd	
Piston (1-2 Shift-Accumulator)	7G133	Plate (Clutch Pressure Low And Reverse Clutch)	7B066
Piston (2-3 Accumulator)	7F251	Plate (Clutch Pressure Overdrive Clutch)	7B066
Piston (3-4 Accumulator)	7F287	Plate (Clutch Pressure Reverse And High Clutch)	7B066
Piston (Accumulator)	7F251	Plate (Clutch Pressure Reverse Clutch)	7B066
Piston (Brake Cylinder)	2196,2197	Plate (Clutch Pressure)	7B066
Piston (Clutch)	7A262	Plate (Clutch Release Equalizer Bracket Mounting)	7B588
Piston (Direct Clutch)	7A262	Plate (Control Selector)	7F476
Piston (Drive Shift Accumulator)	7G274	Plate (Control Valve Lower Body End)	77014
Piston (Interm. Band Servo)	7D022	Plate (Door Lock Electric Control)	14B092
Piston (Interm. Clutch)	7E005	Plate (Drive Shaft)	4693
Piston (Rear Clutch)	7A262	Plate (Egr Valve Hole)	9G496
Piston (Reverse Clutch)	7D402	Plate (Engine Air Cleaner Mounting Tab Lock)	9F740
Piston And Pin Assy	6108	Plate (Exterior Pillar Lamp Opening Cover)	15B445, 15B455
Piston And Rod Assy. (Interm. & O/Drv. Servo Band)	7D021	Plate (Flywheel Reinforcing)	6A366
Piston Assy. (Interm. Band Servo)	7D021	Plate (Front Axle Locking)	3C133
Piston Assy. (Rear Clutch)	7D157	Plate (Front Bumper Arm)	17D767
Piston Assy. Red And Blue Size Are Optional For Select Fit.	6108	Plate (Front Bumper)	17859
Piston And Adjuster Assy. (Rear Disc Brake)	2B588	Plate (Front Coil Spring Top Mounting)	3A197
Piston, Pin And Ring Assy.	6102	Plate (Front Disc Brake Caliper Anchor)	2B292,2B293
Pivot (Clutch Release Fork)	7522	Plate (Front Fender Apron Access Hole Cover)	16D200
Planet & Carrier Assy. (Final Drive)	7F465	Plate (Front Fender Apron Lower)	16A298
Planet Assy.	7A398	Plate (Front Name)	16604
Planet Assy. (Forward)	7A398	Plate (Front Suspension Camber Adjusting)	3B391
Planet Assy. (Front)	7A398	Plate (Front Suspension Housing Reinforcement)	3B154
Planet Assy. (Rear)	7D006	Plate (Front Suspension Thrust Bearing Mounting)	3K048
Planet Assy. (Reverse)	7D006	Plate (Fuel Injection Pump Automatic Advance Adjustment)	9P939
Planet Gear Assy.	11K190	Plate (Gear Shift Selector Arm)	7N232
Plate & Bushing (Brush End)	11049	Plate (Gearshift Assist)	7E116
Plate (Air Bypass Valve Bracket)	9G303	Plate (Gearshift Lever Spring)	7454
Plate (Air Conditioner Blower Motor Cover)	19A802	Plate (Gearshift Lever)	7D462
Plate (Air Conditioner Blower Motor Mounting)	19833	Plate (Gearshift Selector Interlock)	7K201
Plate (Air Conditioner Compressor Valve)	19656	Plate (Heater Deflector)	18C296
Plate (Air Conditioner Condenser Tube)	19D926	Plate (Heater Housing Core)	18A488
Plate (Air Conditioner Evaporator Case Mounting)	19804	Plate (Heater Motor Mounting)	18581
Plate (Air Conditioner Evaporator Core)	19D736	Plate (Heater Mounting)	18679
Plate (Auxiliary Shaft Retaining)	6613	Plate (Heater Plenum Chamber)	18A485
Plate (Balance Shaft Thrust)	6C341	Plate (Hood Auxiliary Catch Striker)	16918
Plate (Battery Hold Down Anchor)	10B678	Plate (Hood Latch Cable Retainer)	16B968
Plate (Brake Shoe Anchor Pin Guide)	2028	Plate (Hood Latch Cover)	16N782
Plate (Brush End)	11049	Plate (Horn Contact)	13A808
Plate (C.B. Microphone Bracket Mounting)	18B825	Plate (Horn Switch Brush)	13A823
Plate (Camshaft Thrust)	6269	Plate (Instrument Cluster Back)	10848
Plate (Clutch Internal And External Spline)	7B164	Plate (Instrument Cluster Control Mounting)	10A860
Plate (Clutch Pressure 3Rd Gear Clutch)	7B066	Plate (Instrument Panel Control Identification Nomenclature)	11646
Plate (Clutch Pressure Forward Clutch)	7B066	Plate (Lock)	7C277

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
P — Cont'd		P — Cont'd	
Plate (Locking)	4A235	Plate Assy. (Fuel Injection Pump Bracket Locating)	9C388
Plate (Main Control Cover And Lower Valve Body Separating)	7734	Plate Assy. (Hood Front Name)	16B856
Plate (Main Control Lower Valve)	7729	Plate Assy. (Insulator Support Front)	6A068
Plate (Main Control Upper Valve Body Front)	7A396	Plate Assy. (Light Switch)	11673
Plate (Main Control Upper Valve Body Rear)	7A393	Plate Assy. (Parking Rod Support)	7D414
Plate (Main Control Valve Assy.)	77739	Plate Assy. (Rear Axle Differential)	4797
Plate (No 2 Crossmember To Body)	5B030	Plate Assy. (Speed Control Bracket)	9C809
Plate (Oil Level Thermostat Valve)	7G190	Plate Assy. (Transmission Shift Control Mounting)	7E393
Plate (Oil Pressure Regulator Body Separating)	7A142	Plate Assy. Bar (Rear)	5K845
Plate (Oil Pump Adapter)	7A472,7B472	Plate Assy. Transceiver Mounting (Mobile Telephone)	19A389
Plate (Oil Pump Body)	6616	Plate Kit (Rear Axle Differential Gear Clutch)	4947
Plate (Park Brake Support)	2B636	Plate Rear Suspension Steady	5K822
Plate (Power Steering Pump Pressure)	3D590	Plate And Bolt Assy. (Air Conditioner Evaporator Case Mounting)	19A586
Plate (Radiator Grille Opening Panel Name)	8C270	Plate And Bushing (Brush End)	11049
Plate (Radio Speaker Grille Name)	18B978	Plate And Bushing (Power Steering Pump)	3D643
Plate (Radio Speaker Mounting)	18963	Plate And Switch Assy. (Windshield Wiper Motor)	17B583
Plate (Rear Brake Backing)	2211	Player Assy. (Digital Audio Compact Disc)	18D806
Plate (Rear Disc Brake Caliper Anchor)	2B582	Plenum Assy. (Engine Inlet)	9E648
Plate (Rear Spring)	5796	Pliers (Fuse And Relay)	17025
Plate (Rear View Outside Mirror Remote Control)	17B733	Plug	7A010
Plate (Rear View Outside Mirror)	17B693	Plug (Air Cleaner Fuel Vapor Purge Tube Inlet)	9D693
Plate (Relay Panel Tapping)	14B145	Plug (Case Oil Pressure)	7D419
Plate (Spare Wheel Mounting)	1424	Plug (Case)	7A107
Plate (Steering Column Lock Barrel)	3B658	Plug (Control Housing)	7C147
Plate (Steering Column Shroud Clip Retainer)	3L525	Plug (Conv. Housing Access)	7N171
Plate (Tachometer Mounting)	17B261	Plug (Detent Spring)	7L013
Plate (Throttle Cam)	7D419	Plug (Engine)	6026
Plate (Throttle Pressure Booster Stop)	7E336	Plug (Engine)-Also Ref. Group 6266	6026
Plate (Timing Belt Inspection Cover)	6N089	Plug (Exhaust Manifold)	9G458
Plate (Timing Gear Marker)	6K298	Plug (Extension Housing)	7K381
Plate (Trans. Engine Rear Cover)	7007	Plug (Extension)	7K381
Plate (Transmission 5Th And Reverse Fork Interlock)	7421	Plug (Fuel Injection Pump Distribution Block)	9F644
Plate (Transmission Gearshift Tube Bracket)	7E417	Plug (Fuel Tank Drain)	9181
Plate (Valve Body Sep.)	7G348	Plug (Heater Case)	18C636
Plate (Valve Body Separating)	7A008	Plug (Ignition Multiple Heatsink Hole)	12B588
Plate (Valve Rocker Arm Cover Flange)	6A523	Plug (Input Gear)	7F127
Plate (Valve Tappet Guide)	6K512	Plug (Low Oil Level Sensor)	6A828
Plate (Window Regulator Switch)	14524	Plug (Oil Control)	6024
Plate And Spring Assembly	3C088	Plug (Oil Filter Drain)	6N855
Plate Assy. (Air Conditioner Compressor Valve)	19D656	Plug (Oil Pan Drain)	6730
Plate Assy. (Brush End)	11049	Plug (Oil Pan To Transmission Inspection)	6B709
Plate Assy. (Clutch Release)	7B517	Plug (Oil Pressure Relief)	7M050
Plate Assy. (Door Lock Switch Cover)	14B088	Plug (Oil Pressure)	7N279
Plate Assy. (Engine Rear)	7007	Plug (Oil Pump Relief Valve)	6666,6A616
Plate Assy. (Front Fender)	16228	Plug (Parking Plate Shaft)	6572

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
P — Cont'd		P — Cont'd	
Plug (Power Steering Control Valve Reaction Control Spring)	3A512	Pulley (Alternator)	10344
Plug (Radiator Drain)	8B192	Pulley (Belt Idler)	8679
Plug (Rear Axle Oil Level Indicator Hole)	4N202	Pulley (Fuel Injection Pump Drive)	9M564
Plug (Screw)	2Z700	Pulley (Parking Brake Cable)	2804
Plug (Spare Wheel Well)	15A408	Pulley (Power Steering Pump)	3A733
Plug (Steering Column Shroud)	3L529	Pulley (Water Pump)	8509
Plug (Steering Gear Housing Oil Filler)	3538	Pulley Assy. (Crankshaft)	6312
Plug (Throttle Plate)	9F927	Pulley Assy. (Accessory Drive Belt Routing)-Also Ref. 6B209,6B217 & 8678	6C348
Plug (Trans Case)	7A010	Pulley Assy. (Belt Idler)	8678
Plug (Transmission Shift Control Adjusting Hole)	7C147	Pulley Assy. (Crankshaft Outer)	6A312
Plug (Valve Rocker Arm Shaft)	6572	Pulley Assy. (Drive Belt Tensioner)-Also Ref. 6B209,6C348 & 8678	6B217
Plug (Water Outlet Connection Metering)	8A574	Pulley Assy. (Exhaust Air Supply Pump)	9B447
Plug (Wiring Connector)	14A666	Pulley And Bearing Assy. (Air Conditioner Compressor)	19D653
Plug Assembly (Power Steering Gear Housing)	3F704	Pump & Bracket Assy. (Fuel - In Tank Mounted)	9A407
Plug(Rear Axle Differential Seal)	4C130	Pump & Tube Assy. (Fuel Auxiliary)	9D349
Plunger (5Th Speed Inhibitor)	7K457	Pump (Windshield Washer)	17664
Plunger (Control Selector Lever)	7361	Pump And Regulator Assy. (Speed Control)	9P963
Plunger (Manual Control Valve Detent Lever)	77607	Pump Assy. (Exhaust Air Supply-Thermactor)	9A486
Plunger (Meshlock)	7233	Pump Assy. (Front Oil)	7A103
Plunger (Oil Pump Relief Valve)	6674	Pump Assy. (Fuel Injection - Remanufactured)	9A543
Plunger (Reverse Inhibitor)	7K187	Pump Assy. (Fuel)	9350
Point Kit (Contact)	11134	Pump Assy. (Oil)	6600
Pointer (Timing)	6023	Pump Assy. (Power Steering)	3A674
Potentiometer Assy. (A/C Temperature Control)	19C733	Pump Assy. (Vacuum)	6F049
Potentiometer Assy. (Throttle)	9B989	Pump Assy. (Water)	8501
Potentiometer And Bracket Assy.	19A945	Pump Assy. Vacuum	2A451
Power Adapter (Electronic Cooler And Warmer)	19A051	Pump Kit (Vacuum, Brake Booster)	2K179
Pressure Plate (Clutch)	7563	Pump And Bracket Assy. (Vacuum)	2B925
Pressure Warning Switch Assy.	2C244	Push Rod (Fuel Injector Nozzle)	9G508
Printed Circuit (Message Center-Keybaord)	10D891	Push Rod Assy. Clutch Master Cyl.	7641
Processor And Calibrator Assy. (Powertrain Control Module)	12A650	Pin (Choke Pulldown)	9B527
Processor Assy. (Electronic Door Lock Control)	14B001	Pin (Metering Rod Lever)	9B918
Processor Assy. (Powertrain Control Mocule) - Pcm	12A650	Pin (Metering Rod Pivot)	9A915
Processor Assy. (Powertrain Control Moduel)	12A650	Pin (Sensor)	9B918
Processor Assy. (Seat Regulator Control)	14C708	Pin (Switch Vent Solenoid Lever)	9H584
Processor Assy. (Transmission Control Module) - Tcm	12B565	Pin (Throttle Retaining Spring)	9B503
Protector	2L680	Pin (Venturi Valve)	9A918
Protector (Brake Hose-Coil)	2254	Pin Spare Wheel Holder Assy.	1487
Protector (Fuel Tube)	9J289	Piston (Accel Pump)	9B544
Protector (Handle And Cable Hood Latch Control)	16915	Piston (Accelerator Pump Assy.)	9B544
Protector (Hose)	9A288	Piston (Accelerator Pump)	9B544
Protector Air Tube	5361	Pivot (Venturi Valve)	9A928
Protector Brake Tube	2B452	Plate (Accelerator Pump Spring)	9528
Protector(Hose Water Inlet Tube)	8T506	Plate (Air By-Pass Valve)	9A972
Pulley	10344	Plate (Choke)	9545

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
P — Cont'd		R — Cont'd	
Plate (Choke)-Serviced In Assy. Only	9545	Radio Assortment Kit	18814
Plate (Fuel Bowl Baffle)	9A517	Radio Chassis	18806
Plate (Metering Body)	9514	Radio, Antenna And Speaker Kits	18805
Plate (Throttle)	9585	Rail (1St & 2Nd Speed Shift)	7240
Plate (Throttle)-Serviced In Assy. Only	9585	Rail (3Rd & 4Th Speed Shifter)	7241
Plug (Choke Pull Down)	9E515	Rail (5Th & Reverse Shift)	7242
Plug (Choke Pull Down) Brass	9E515	Rail (Guide)	19A884
Plug (Choke Pulldown Adjusting)	9E515	Rail (Reverse Gear Shifter)	7242
Plug (Drain)	9562	Rail (Shift Control)	7241
Plug (Fuel Level Check)	9562	Rear Axle Assy.	4000,4001
Plug (Fuel Level Check)-Slotted Head-	9562	Rear Axle Damper (Rear Axle Drive Line Vibration)	4A263
Plug (Fuel Press. Regulator)	9E938	Rear Head Gasket Kit (Air Conditioner Compressor)	19E578
Plug (Jet Channel)	9E515	Rear Suspension Repair Kit	5K500
Plug (Jet Channel) 7/16" Cup	9E515	Receiver (Alarm And Lock System - Remote Control)	15K602
Plug (Venturi Valve Pivot)	9A929	Rectifier Assy.	10304
Plug-Choke Diaphragm Adj. Screw-Plastic	9E515	Reed (Air Conditioner Compressor Valve Inlet)	19D659
Positioner (Fast Idle Control Rod)	9D993	Reflector (Courtesy Lamp)	13B755
Positioner Assy. (Throttle)	9S553	Reflector (Instrument Cluster Indicator Display)	10D982
Positioner Assy. (Throttle)-Also	9S553	Reflector (Rear Lamp)	13380
Positioner Assy. (Throttle)-Also Refer To 9D856	9S553	Reflector (Rear)	13A568
Potentiometer Assy. (Throttle)	9B989	Reflector Assy. (Flare)	19F524
Potentiometer Assy. (Throttle Position Sensor)	9B989	Reflector Assy. (Front Side)	15A448
Processor And Calibrator Assy.	12A650	Reflector Assy. (Rear Panel)	13A565, 13A566
Processor And Calibrator Assy. (Powertrain Control Module)	12A650	Reflector Flare Kit	19E500
Pump Assy. (Fuel Injection)	9A543	Register (Air Conditioner)	19893
Pump Assy. (Thermactor)	9A486	Register (Air)	18C366
Q		Register (Rear Seat Heater Duct)	18C570
Quadrant (Clutch Pedal Adjuster)	7L583	Register Assy. (Heater Air Distribution)	18C306
Quadrant Assy. (Heater Control)	18K309	Regulator	10316
R		Regulator (Emission Vacuum Control)	9F490
Race & Bearing Assy. (Planet Thrust Rear)	7F473	Regulator (Instrument Cluster Voltage)	10804
Race & Bushing Assy. (Direct Overrunning Clutch)	7G156	Regulator (Oil Pressure)	7A139
Race (Countershaft Rear Thrust Brg.-Front)	7E487	Regulator Assy.	10316
Race (Interm. Clutch)	7F221	Regulator Assy. (Alternator)	10316
Race (Output Shaft Rear Thrust Brg)	7A387	Regulator Assy. (E.G.R.)	9J431
Race (Overrunning Clutch Inner)	7D171	Regulator Assy. (Fuel Charging Pressure)	9C968
Race (Overrunning Clutch)	7D171	Regulator Assy. (Speed Control)	9D757
Race (Planet Assy. - Thrust - Front)	7D423	Reinforcement (Battery Tray Support Side)	10K667
Race (Pump Thrust-Front)	7D423	Reinforcement (Bumper)	17C810
Race (Sun Gear Thrust Bearing)	7D235,7D236	Reinforcement (Dampener Brkt.)	6F024
Race (Thrust Bearing)	7D236	Reinforcement (Electric Antenna Grounding)	18A954
Rack Seal	3F520	Reinforcement (Engine Front Mounting)	6K034
Radiator	8005	Reinforcement (Engine Inlet Plenum)	9E694
Radiator And Support Assy.	8009	Reinforcement (Fog Lamp Bracket)	15K216
Radiator Grille Spring Kit	8C161	Reinforcement (Front Apron)	16A244

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
R — Cont'd		R — Cont'd	
Reinforcement (Front Axle Upper)	3N017	Relay & Bracket Assy. (Fuel Pump)	9C392
Reinforcement (Front Bumper Impact Bar)	17A792	Relay & Bracket Assy. (Suspension Air Spring Compressor)	9C392
Reinforcement (Front Bumper Isolator)	17E760	Relay & Bracket Assy. (Thermactor Solenoid Vacuum Valve)	9J425
Reinforcement (Front Fender Apron Lower)	16060	Relay (Automatic Headlamp Dimmer)	13A025
Reinforcement (Front Fender Apron Upper Outer)	16A246	Relay (Glow Plug)	12A343
Reinforcement (Front Fender Apron Upper)	16154	Relay (Outside Rear View Electric Mirror)	17D736
Reinforcement (Front Fender Apron)	16031	Relay (Turning Lamp)	15A217
Reinforcement (Front Fender Battery Mounting)	16B168	Relay And Bracket Assy. (Horn)	13853
Reinforcement (Front Fender Side Upper)	16D186	Relay And Bracket Assy. (Multiple Function)	14B192
Reinforcement (Front Fender To Radiator Support)	16B072	Relay Assy.	13A253, 14N089
Reinforcement (Front Lamp Opening)	16130	Relay Assy. (Air Conditioner Blower Motor)	19E703
Reinforcement (Front Valance Panel)	17C861	Relay Assy. (Air Conditioner Compressor Clutch Control)	19D572
Reinforcement (Fuel Tank Front Fixing)	9A056	Relay Assy. (Anti Skid)	2C013
Reinforcement (Fuel Tank)	9A061	Relay Assy. (Automatic Temperature Control Solenoid Plenum)	19D671
Reinforcement (Headlamp Cover Hinge)	13C050	Relay Assy. (Automatic Temperature Control)	19D592
Reinforcement (Ignition Module Bracket)	12A346	Relay Assy. (Back Window Heat Control)	18C641
Reinforcement (Oil Pan Flange)	6A674	Relay Assy. (C.B. Radio Speaker)	18B821
Reinforcement (Parking Brake Mounting)	2L624	Relay Assy. (Carburetor Choke Control)	9C972
Reinforcement (Rad. Support Upper Brkt)	8C241	Relay Assy. (Deceleration Fuel Shut-Off)	12B532
Reinforcement (Radiator Air Side Deflector)	8324	Relay Assy. (E.G.R. Solenoid Vacuum Valve)	9G483
Reinforcement (Radiator Grille Opening Panel Lower)	8C008	Relay Assy. (Electronic Control)	12A646
Reinforcement (Radiator Grille Upper Support)	8A200	Relay Assy. (Engine Control Starter Switch)	12A598
Reinforcement (Radiator Support Upper)	16139	Relay Assy. (Engine Cooling Fan Motor)	8B658
Reinforcement (Radiator Support)	8A281	Relay Assy. (Fuel Heater)	9F790
Reinforcement (Rear Axle Bumper Outer Bracket)	4A172	Relay Assy. (Fuel Pump)	9345
Reinforcement (Rear Axle Drive Line Vibration Damper)	4A079	Relay Assy. (Heated Windshield Control)	18D414
Reinforcement (Rear Bumper Center)	17A914	Relay Assy. (Interior Lamp)	13A777
Reinforcement (Rear Bumper Cover Mounting)	17D942	Relay Assy. (Lamp Fail Indicator Sensor)	10C909
Reinforcement (Rear Bumper Isolator Mounting)	17C901	Relay Assy. (Low Oil Level)	6C625
Reinforcement (Rear Spring Front Hanger)	5733	Relay Assy. (Radio Antenna)	15040
Reinforcement (Rear View Outside Mirror)	17K682	Relay Assy. (Seat Belt Warning Indicator)	10B926
Reinforcement (Stabilizer Bar Mounting Bracket)	5A483	Relay Assy. (Security Alarm)	19A367
Reinforcement (Steering Column Bracket)	3B743	Relay Assy. (Shock Absorber Electronic System)	18B019
Reinforcement Assy. (Driveshaft Center Bridge Support)	4A315	Relay Assy. (Starter Motor Cutout)	11433
Reinforcement Assy. (Engine Inlet Plenum)	9E693	Relay Assy. (Trailer Lighting)	13A435
Reinforcement Assy. (Front Bumper Cover)	17E814	Relay Assy. (Turn Signal)	13A366
Reinforcement Assy. (Parking Brake Cable Bracket)	2B618	Relay Assy. (Warning Lamp Indicator)	10C838
Reinforcement Assy. (Parking Brake Equalizer Bracket)	2B619	Relay Assy. (Window Regulator Safety)	14677
Reinforcement Assy. (Radiator Grille Opening Panel)	8A284	Relay Assy. (Window And Seat Regulator Control)	14512
Reinforcement Assy. (Radiator Support At Bumper Opening)	8C296	Relay Assy. (Windshield Wiper)	17C499
Reinforcement Assy. (Strg. Column Mtg. Bracket)	3D630	Relay Assy. (Anti-Skid Brakes And Cooling Fan)	8Z658
Reinforcement Assy. (Radiator Grille Panel Lower Corner)	8C208	Relay And Bracket Assy. (Air Conditioner Compressor Clutch Control)	19E594
Reinforcement Frame Stabilizer Front Rod	5C026	Relay And Bracket Assy. (Fuel Preheat Control)	14B131
Reinforcement Plate (Water Pump Pulley)	8A566	Relay And Bracket Assy. (Radio Antenna Lower)	19A245
Relay & Bracket Assy.	5419		

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
R — Cont'd		R — Cont'd	
Relay And Bracket Assy. (Speed Control)	9C792	Retainer (5Th Speed Synchronizer Insert)	7C396,7G042
Remote Installation Kit (Mobile Telephone)	19B393	Retainer (A/C Evaporator Tube)	19B936
Repair Kit (Brake Bushing)	2L526	Retainer (Accelerator Cable)	9E728
Repair Kit (Crankcase Vent)	6A666	Retainer (Accelerator Shaft)	9D747
Repair Kit (Engine Cooling)	8K501	Retainer (Accumulator Spring)	7B264,7F252
Repair Kit(Oil Pump Relief Valve)	6674	Retainer (Accumulator)	7F247
Repair Kits (Radiator Side Tank)	8080	Retainer (Air Conditioner Blower Motor)	19209
Reservoir (Windshield Washer)	17618	Retainer (Air Conditioner Evaporator Tube Seal)	19D694
Reservoir Assy. (Air Horn Vacuum Supply)	13A888	Retainer (Air Conditioner Register Horizontal Louver)	19B727
Reservoir Assy. (Brake Master Cylinder)	2K478	Retainer (Air Conditioner Register Louver)	19A658
Reservoir Assy. (Exhaust Gas Recirculation Vacuum)	9E453	Retainer (Air Registers)	18A395
Reservoir Assy. (Headlamp Cover)	13A185	Retainer (Bearing)	7085
Reservoir Assy. (Power Steering Oil)	3A697	Retainer (Brake Actuator)	2N183
Reservoir Assy. (Radiator Coolant Recovery)	8A080	Retainer (Brake Anti-Lock Sensor Wiring)	2C218
Reservoir Assy. (Vacuum System)	9J442	Retainer (Brake Master Cylinder Filler Cap)	2B245
Reservoir Assy. P/S Pump Auxiliary	3E764	Retainer (Brake Master Cylinder Push Rod)	2B224
Reservoir Kit	2C246	Retainer (Cable Abutment Grommet)	7L601
Reservoir And Tube Assy. Clutch Fluid	7K500	Retainer (Camshaft Sprocket)	6258
Resistor (Air Conditioner Blower Motor)	19A706	Retainer (Camshaft Thrust Plate Bolt)	6255
Resistor (Engine Cooling Fan Motor)	8L603	Retainer (Clutch Piston Spring)	7A527
Resistor (Radio Receiver Suppression Choke)	18A952	Retainer (Clutch Release Fork)	7562
Resistor Assy (Alternator Warning Lamp Shunt)	10C346	Retainer (Coach Lamp Bezel)	15B444
Resistor Assy.	14A601	Retainer (Control Cable Bracket)	7F137
Resistor Assy. (Alternator Regulator)	10A576	Retainer (Control Cable)	7L116
Resistor Assy. (Heater Switch To Blower Motor)	18591	Retainer (Countershaft Gear Frt. Brg.)	7135
Resistor Assy. (Ignition Coil)	12250	Retainer (Countershaft Rear Brg.)	7195
Resistor Assy. (Ignition Glow Plug)	12A344	Retainer (Crankcase Emission Filter)	9E628
Resistor Assy. (Light Switch Rheostat)	11691	Retainer (Door Lock Switch)	14A667
Resonator (Exhaust Air Supply Pump)	9S458	Retainer (Drive Stop Ring)	11223
Resonator Assy. (Engine Air Intake)	9F763	Retainer (Driveshaft Universal Joint Spider)	4A254
Restrictor & Hose Assy. (Fuel Return)	9J334	Retainer (Engine Control Fastener)	12A534
Restrictor (Frt. Support Insulator)	6L023	Retainer (Fog Lamp Lens)	15206
Restrictor (Fuel Vapor)	9F323	Retainer (Front Bearing)	10A355
Restrictor (Heater Hose Coolant Flow)	18D358	Retainer (Front Shock Absorber Bumper)	18A086
Restrictor Assy. (Distributor Vacuum)	12A225	Retainer (Front Suspension Spring Guide)	3A198
Restrictor Assy. (Eng. Mount)	6F069	Retainer (Front Suspension Spring)	3B025
Restrictor Assy.(Cyl.Head Oil Reservoir)	6F087	Retainer (Front Wheel Drive Inboard Joint)	3B426
Restrictor(Fuel Tank Capacity)	9B264	Retainer (Fuel Injection Inlet Tube)	9C995
Retainer	3D638	Retainer (Fuel Line)	9B307,9E307
Retainer & Spring Assy. (Direct Clutch)	7F235	Retainer (Fuel Pump Filter)	9C378
Retainer & Spring Assy. (Interm. Clutch)	7F222	Retainer (Fuel Pump Mounting Clamp Insulator)	9261
Retainer & Spring Assy. (Overdrive Servo)	7G279	Retainer (Fuel Tank Filler Pipe Restrictor)	9B159
Retainer & Spring Assy. (Reverse Clutch)	7D406	Retainer (Fuel Tank Filler Pipe)	9A108,9B233
Retainer (2-3 Accumulator Spring)	7F252	Retainer (Fuel Tube)	9J278
Retainer (3/2 Shift Timing Valve)	7F194	Retainer (Governor Body)	7A190

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
R — Cont'd		R — Cont'd	
Retainer (Governor Secondary Valve Spring)	7D218	Retainer (Rear Bumper Stone Deflector)	17879
Retainer (Governor Valve Spring)	7D218	Retainer (Rear Hi-Mount Lamp)	13A621
Retainer (Headlamp Bulb)	13N019	Retainer (Rear Lamp Lens)	13539
Retainer (Heater Air Outlet Door)	18A481	Retainer (Rear Lamp Socket)	13513
Retainer (Heater Air Vent Door)	18B284	Retainer (Rear Lamp Wiring)	13A506
Retainer (Heater Control Cable)	18C677	Retainer (Rear Spring Center Mounting Insulator)	5736
Retainer (Heater Control Mounting)	18580	Retainer (Rear Spring Insulator)	5A545
Retainer (Heater Dampener Door Shaft)	18A482	Retainer (Rear Stab. Bar End)	5C498
Retainer (Hood Air Scoop)	16C888	Retainer (Rear Support)	6054
Retainer (Hood Bumper)	16B844	Retainer (Rear Suspension Air Spring)	5602
Retainer (Hood Hinge Housing)	16C766	Retainer (Rear View Outside Mirror Plate)	17A746
Retainer (Hood Insulator)	16774	Retainer (Rear Wheel Bearing Inner)	1180
Retainer (Hood Support Rod)	16B730	Retainer (Rear Wheel Bearing Outer)	4020
Retainer (Input Shaft Bearing)	7050	Retainer (Rear Wheel Spindle)	4W008
Retainer (Inside Rear View Mirror)	17C700	Retainer (Rear Window Regulator Control Switch)	14A125
Retainer (Instrument Cluster Printed Circuit)	10K913	Retainer (Register)	19A950
Retainer (Interior Lamp Lens)	13784	Retainer (Safety Switch)	11N523
Retainer (Intermediate Band Servo Lever)	7E206	Retainer (Side Marker Lamp)	15A210
Retainer (Jack Assembly)	17A012	Retainer (Speed Control Cable To Speed Sensor)	9F718
Retainer (Jack Handle And Wheel Nut Wrench)	17A038, 17A091	Retainer (Speedometer Case Grommet)	17305
Retainer (Low/Int. Servo Return Spring)	7G151	Retainer (Speedometer Driven Gear)	17292
Retainer (Main Drive Gear Bearing)	7050	Retainer (Steering Column Clamp)	3D672
Retainer (Neutral Switch)	7C443	Retainer (Steering Column Position Spring)	3E519
Retainer (O/Drv. Servo Piston)	7G280	Retainer (Steering Column Release Lever)	3E543
Retainer (O/Drv. Solenoid Valve)	7D301	Retainer (Steering Column Shift)	3L579
Retainer (Oil Seal)	7051	Retainer (Steering Column Tube)	3499
Retainer (Overrunning Clutch Spring)	7D191	Retainer (Steering Column Upper Bearing)	3C610
Retainer (Package Tray Radio Speaker Opening Cover)	19A135	Retainer (Steering Gear Rack Bushing)	3F645
Retainer (Parking Brake Cable Grommet)	2B602	Retainer (Steering Wheel Emblem)	3F652
Retainer (Parking Brake Cable Rear)	2A709	Retainer (Stereo Tape Cartridge Container)	19B129
Retainer (Parking Brake Lever Boot)	2405	Retainer (Stop Ring)	11223
Retainer (Parking Brake Lever Pin)	2106	Retainer (Suspension Air Spring Solenoid)	5308
Retainer (Parking Brake Spring)	2A787	Retainer (Timing Belt Tensioner Spring)	8A579
Retainer (Parking Brake-Front)	2K865	Retainer (Tool Hold Down)	17W002
Retainer (Parking Pawl Toggle Lever Pin)	77326	Retainer (Transmission Control Selector Dial)	7D462
Retainer (Parking Pawl Toggle Return Spring)	77323	Retainer (Transmission Gearshift Lever Boot)	7262
Retainer (Piston Pin)	6140	Retainer (Transmission Kickdown Lever Spring)	7C176
Retainer (Power Steering Cylinder Seal)	3A310	Retainer (Transmission Selector Indicator Cable Rear)	7E300
Retainer (Power Steering Hose Mounting Insulator)	3A610	Retainer (Transmission Selector Indicator Cable)	7E299
Retainer (Radiator Tank)	8C251	Retainer (Transmission Selector Rod)	7E149
Retainer (Radio Receiver)	18K863	Retainer (Valve Plug)	7G007
Retainer (Rear Axle Driving Pinion Pilot Bearing)	4627	Retainer (Valve Spring)	6514
Retainer (Rear Axle Shaft)	4133	Retainer (Valve Tappet Guide Plate)	6C515
Retainer (Rear Bumper Anchor)	17B774	Retainer (Warning Indicator Housing)	10K925
Retainer (Rear Bumper Extension)	17A904	Retainer (Warning Indicator-Printed Circuit)	10K943

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
R — Cont'd		R — Cont'd	
Retainer (Wheel Cover)	1A063	Ring (Drive Stop)	11222
Retainer (Windshield Wiper Arm)	17A504	Ring (Forward Clutch Piston Spring Pressure)	7D256
Retainer (Windshield Wiper Pivot)	17D499	Ring (Front Axle Retaining)	3K094
Retainer (Windshield Wiper Switch)	17C491	Ring (Front Axle Shaft Snap)	3K184
Retainer (Wiring Harness)	14A163	Ring (Front Bearing Oil Scoop)	7046
Retainer (Wiring)	14613	Ring (Front Clutch Piston Disc Spring)	77563
Retainer - Radio Antenna (Insert Spring)	19121	Ring (Fuel Pump Retainer Locking)	9C385
Retainer Assy (Rear Axle Wheel Hub)	4B477	Ring (Fuel Tank Sender Retainer Locking)	9A307
Retainer Assy. (Cover)	11A143	Ring (Gear Shift Bushing Retaining)	7C072
Retainer Assy. (Crankshaft Rear Oil Seal)	6335	Ring (Governor Housing Seal)	7D011
Retainer Assy. (Diff. Bearing)	7F447	Ring (Headlamp Bulb Retaining)	13015
Retainer Assy. (Engine Control Junction Box Power Lead)	12A641	Ring (Input Shaft Gear To Case)	7917
Retainer Assy. (Front Axle Wheel Hub)	3B477	Ring (Oil Pump Intermediate Shaft Ret.)	6629
Retainer Assy. (Fuel Injector Pulse Dampener)	9F777	Ring (Output Gear Brg-Snap)	7G287
Retainer Assy. (Jack Front)	17A116	Ring (Output Shaft Locking)	7D238
Retainer Assy. (Radiator Support Upper Bracket)	8C330	Ring (Output Shaft Thrust Washer Retaining)	7A046
Retainer Assy. (Radio Speaker)	19B127	Ring (Primary Sun Gear Retaining)	7R117
Retainer Assy. (Rear Axle Pinion Bearing)	4614	Ring (Retainer)	3W004
Retainer Assy. (Rear Lamp Moulding)	13B430	Ring (Retaining)	2B333,7C122
Retainer Assy. (Steering Column Lower Bearing)	3D681	Ring (Reverse Idler Gear - Retaining)	7156
Retainer Assy. (Steering Column Support)	3B741	Ring (Reverse Planet Retaining)	7G347
Retainer Assy.-(Alternator Cooling Shroud)	10C355	Ring (Rotor Slip)	10328
Retainer Bolt (Hydraulic Control Mount)	2C329	Ring (Rotor Stop)	10370
Retainer Brake Pin Rear	2N386	Ring (Servo Piston Retaining Snap)	7381
Retainer Front Suspension	5C560	Ring (Steering Column Bearing Tolerance Upper)	3L539
Retainer Kit (Brake Adjusting Lever & Pawl)	2B177	Ring (Steering Column Shroud)	3D694
Retainer Kit (Heater Motor Blower)	18A287	Ring (Steering Shaft Lower Bearing Retainer)	3F543
Retainer Kit (Rear Axle Differential)	4K334	Ring (Suspension Height Sensor Control)	3C131
Retainer Parking Brake Lever Boot	2A714	Ring (Synchronizer Blocking)	7107
Retainer Repair Kit (Brake Shoe Hold Down)	2A094	Ring (Wheel Trim)	1210
Retainer Ring Kit (Air Conditioner Compressor)	19D664	Ring Assy. (Headlamp Adjusting)	13118
Retainer Steering Column Brace	3D637	Ring Assy. (Hood Front Air Scoop Opening)	16C878
Retainer(Brake Anti Lock Control Module Mtg.)	2C277	Ring Assy. (Horn Blow)	13A809
Retainer(Fuel Tank Vent)	9B078	Ring Assy. (Steering Column Shroud Support)	3L509
Retaining (Gear)	11A167	Ring Gear And Pinion Kit (Rear Axle Differential)	4209
Retaining Clip (Tensioner Spring)	6B234	Ring Set (Crankshaft Thrust)	6334
Retaining Ring (Inner Stub Shaft To Differential Assy.)	4K184	Ring Set (Piston Complete)	6148,6149
Retaining Ring (Joint Assy To Rear Axle Shaft)	4K184	Ring Set (Piston Partial)	6148
Reverse Clutch	7B164	Rivet (Engine Balance)	6A367
Ring (1St & 2Nd Speed Syn. Retaining)	7160	Rivet (Front License Bracket Mounting)	17Z386
Ring (Accumulator Piston Retaining)	7384	Rivet (Headlamp Body Bracket)	13N094
Ring (Air Conditioner Motor Mounting)	18A581	Rod & Clevis Assy. (Trans. Gearshift)	7B140
Ring (Cigar Lighter Illumination)	15K040	Rod (Accelerator Shaft To Carburetor)	9746
Ring (Crankshaft Thrust)	6334	Rod (Camshaft Oil Flow Control)	6B273
Ring (Direct Clutch Piston)	7G341	Rod (Clutch Interlock)	7R537

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
R — Cont'd		R — Cont'd	
Rod (Clutch Pedal To Equalizer Bar)	7521	Rotor Assy.	10335
Rod (Column Shift Selector Bellcrank Lever To Transmission)	7A024	Rotor Assy. (Distributor)	12200
Rod (Distributor Stator Positioner)	12A335	Rotor Assy. (Power Steering Pump)	3D607
Rod (Frame Stabilizer)	5C024	Rubber Mount (Auxiliary P/S Reservoir)	3Z764
Rod (Fuel Pump Push)	9400	Refer To Group 7A232	7A117
Rod (Gear Selector Valve)	7326	Refer To Group 7D029	7A175
Rod (Hood Support)	16826	Refer To Group 7D189	7A266
Rod (Ignition Switch Actuating)	11A599	Refer To Group 7D418	6572
Rod (Interm. Band Servo Piston)	7D023	Regulator (Emission Vacuum Control)	9D490,9F490
Rod (Kickdown Control Shaft)	7A187	Regulator Assy. (Fuel Pressure)	9C968
Rod (Low & Interm. Servo Piston)	7D190	Regulator Assy. (Fuel Pressure)-	9C968
Rod (Manual Control Selector Connecting)	7326	Regulator Assy. (Fuel Charging Pressure)	9C968
Rod (Manual Lever Actuator)	7N049	Regulator Assy.(E.G.R.)	9J431
Rod (No. 2 Crossmember Reinforcement Rear)	5B112	Relay Assy. (E.G.R Solenoid Vacuum Valve)	9G483
Rod (O/Drv. Servo)	7F203	Reservoir Assy. (E.G.R. Vacuum)	9E453
Rod (O/Drv. Servo) Selective Fit	7F203	Reservoir Assy. (Vacuum System)	9J442
Rod (Park Actuating)	7A232	Restrictor (Jet)	9A521
Rod (Parking Brake Equalizer)	2628	Restrictor Assy. (Idle Channel Fuel)	9A521
Rod (Parking Brake Release Handle)	2A760	Restrictor Assy. (Idle Channel Fuel)-	9A521
Rod (Parking Pawl Actuating)	7D411	Restrictor Assy. (Distributor Vacuum)	12A225
Rod (Servo Piston)	7D190	Retainer	9599
Rod (Servo Piston) Selective Fit	7D190	Retainer (Accelerator Pump Spring)	9599
Rod (Throttle Control Shaft)	9815	Retainer (Accelerator Pump Spring)-	9599
Rod (Throttle Control Valve)	7A380	Retainer (Air Cleaner To Carburetor)	9B672
Rod (Throttle Control)	9S523	Retainer (Air Cleaner)	9B672
Rod (Trans. Control Selector)	7E148	Retainer (Air Cleaner)-Includes Pin	9B672
Rod (Transmission Manual Control Selector Connecting)	7326	Retainer (Choke Lever)	9B527
Rod (Valve Push)	6565	Retainer (Choke Lever)-#4	9B527
Rod - Rear Suspension - Tie	5K848	Retainer (Choke Rod)	9B527
Rod Assy. (Connecting)	6200	Retainer (Choke Rod)-Plastic	9B527
Rod Assy. (Front Wheel Spindle Connecting)	3280	Retainer (Clutch Piston Spring)	7A527
Rod Assy. (Rear Suspension Tie And Bushing)	5K898	Retainer (Float Lever Shaft)	9599
Rod Assy. (Steering Sector Shaft Arm To Idler Arm)	3304	Retainer (Fuel Injector)	9C976
Rod Assy. (Trans. Throttle Valve)	7F332	Retainer (Idle Jet)	9575
Rod Kit (Throttle Control Valve)	7A380	Retainer (Pump Spring Lower)	99704
Rod Or End (Front Wheel Spindle Connecting)	3A130	Retainer (Snap Ring)	9B527
Roller (Countershaft Pilot Bearing)	7121	Retainer (Throttle Shaft)	9688
Roller (Input Shaft Pilot Bearing)	7118	Ring (Choke Housing Clamp)	9842
Roller (Overrunning Clutch)	7190	Rivet (Choke Cap)	9S510
Roller (Park Lever Actuating Rod)	7E433	Rivet (Pop)	9S510
Roller (Rear Clutch Sun Gear Front Bearing)	7C458	Rod & Swivel Assy (Accel Pump)	9F687
Rotor & Plate Kit (Power Steering Pump)	3B607	Rod (Accel. Pump Link To Overtravel)	9B542
Rotor (Front Wheel Disc Brake)	1125	Rod (Accelerator Pump Kit)	9B542
Rotor (Rear Wheel Disc Brake)	2C026	Rod (Accelerator Pump Link To	9B542
Rotor And Shaft Assy. (Oil Pump Drive)	6608	Rod (Accelerator Pump Link)	9B542

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
R — Cont'd		S — Cont'd	
Rod (Accelerator Pump)	9529	Screw (Crankshaft Main Brg. Cap Adjusting)	6C360
Rod (Air By-Pass Plate)	9A973	Screw (Detent Plunger Retainer)	7032
Rod (Bowl Vent)	9A515	Screw (Engine Idle Adjusting)	9B538
Rod (Choke Connector)	9D530	Screw (Front Fender Splash Shield)	15A315
Rod (Choke Control - Deloader)	9A599	Screw (Fuel Filter Air Vent)	9N026
Rod (Choke Control)	9A599	Screw (Gear Shift Knob Attaching)	7B409
Rod (Choke Diaphragm Connector)	9E524	Screw (Headlamp Adjusting)	13032
Rod (Choke Pulldown)	9E524	Screw (Headlamp Cover Hinge)	13A165
Rod (Choke Shaft)	9A766	Screw (Idle Adjusting)	9M530
Rod (Enrichment Metering)	9A993	Screw (License Plate Housing And Bracket)	17392
Rod (Fast Idle Cam)	9D530	Screw (Outside Rear View Mirror Control Knob)	17B721
Rod (Fast Idle Cam) - Tag Code E43E-Va	9D530	Screw (Parking Lamp Lens)	13S341
Rod (Fast Idle Control)	9E524	Screw (Pole Piece)	11415
Rod (Float Bowl Vent)	9A515	Screw (Pole Piece) - Flat Head	11415
Rod (Metering Vacuum)	9B915	Screw (Reverse Band Adjusting)	7A178,7C492
Rod (Metering)	9A526	Screw (Steering Gear Sector Shaft Adjusting)	3577
Rod (Secondary Throttle Control)	9C504	Screw (Throttle Body Idle Adjust)	9541
S		Screw (Torque Tube To Housing)	4A029
Scoop (Hood Air)	16C630	Screw (Valve Rocker Arm Adjusting)	6549
Scoop Assy. (Front Brake)	2C092	Screw (Windshield Wiper Motor)	17A335
Screen (Air Conditioner Air Intake)	19745	Screw Adjusting	7A178
Screen (Air Conditioner Compressor Oil Suction)	19D652	Screw And Washer Assy.	10S843
Screen (Air Conditioner Compressor Suction)	19D729	Screw Assy. (Brake Shoe Adjustment)	2046
Screen (Air Conditioner Water Impingement Foam)	19627	Screw Kit (Brake Adjuster)	2041
Screen (Governor Oil)	7E242	Screw Kit (Pole Shoes To Yoke)	11K140
Screen (Heater Plenum Chamber Air)	18C351	Screw Set	10A396
Screen (Oil Pan)	7A098	Seal	2M063
Screen (Radio Speaker)	18836	Seal & Valve Kit (2-3 Shift)	7F424
Screen (Trans. Low - Interm. Circuit)	7H162	Seal (1-2 Shift-Accum. Piston)	7G095
Screen (Transmission Case Lower)	7A832	Seal (3-4 Accumulator Piston)	7F248
Screen (Transmission Case Upper)	7993	Seal (A/C Evaporator Core - Lower)	19D687
Screen (Transmission Main Control)	7E387	Seal (A/C Outside Air)	19892
Screen (Valve Body Oil Inner)	7N113	Seal (Accumulator Piston - Lower)	7F249
Screen And Cover Assy. (Oil Pump)	6622	Seal (Accumulator Piston - Upper)	7F250
Screen Assy. (A/C Recirculating Air Duct)	19C928	Seal (Accumulator Piston)	7F248
Screen Assy. (By Pass Solenoid)	7G308	Seal (Accumulator Retainer)	7F294
Screen Cover And Tube Assy. (Oil Pump)	6622	Seal (Adjusting Band Stop - Inner)	7Z288
Screw	17B625	Seal (Adjusting Band Stop - Outer)	7Z289
Screw & Washer Assy.	5314	Seal (Air Cleaner To Carburetor)	9K609
Screw (Air Conditioner Compressor Charging Oil Drain Plug)	19D658	Seal (Air Conditioner Air Inlet Door Inner)	19B762
Screw (Antenna Mounting)	18N311	Seal (Air Conditioner Blower Motor Outlet)	19C978
Screw (Backup Lamp)	15503	Seal (Air Conditioner Compressor High Pressure Valve)	19A630
Screw (Brake Cylinder Bleeder)	2208	Seal (Air Conditioner Condenser)	19E572
Screw (Carburetor Air Cleaner Clamp)	9B622	Seal (Air Conditioner Damper Door)	18A492
Screw (Cluster Lens)	10S887	Seal (Air Conditioner Evaporator Case To Dash Panel)	19C593

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Seal (Air Conditioner Evaporator Core To Case)	19A829, 19D578	Seal (Gearshift Rail)	7288
Seal (Air Conditioner Evaporator Core)	19A672	Seal (Governor Cover)	7Z053
Seal (Air Conditioner Evaporator Drain Hose To Floor)	19A989	Seal (Governor Shaft)	7G174
Seal (Air Conditioner Evaporator Drain Tube)	19B739	Seal (Heater Blower Motor Mounting)	18N260
Seal (Air Conditioner Evaporator Inlet)	19B582	Seal (Heater Bracket)	19D916
Seal (Air Conditioner Evaporator Outlet)	19C594	Seal (Heater Core Cover)	18N267
Seal (Air Conditioner Evaporator To Connector Duct)	19B847	Seal (Heater Core To Case L.H.)	18D320
Seal (Air Conditioner Sensor Adapter)	19D858	Seal (Heater Core To Case)	18658
Seal (Air Conditioner Temperature Sensor)	19C960	Seal (Heater Core To Case-Bottom)	18B536
Seal (Air Conditioner Tubes To Dash Panel)	19B588	Seal (Heater Core To Housing Front)	18B551
Seal (Axle Shaft Oil)	3254	Seal (Heater Core Top)	18C676
Seal (Backup Lamp Body)	15533	Seal (Heater Outlet To Panel)	18K412
Seal (Body Side Lamp)	15A447	Seal (Heater To Dash Panel)	18529
Seal (Clutch Cable Abutment)	7L603	Seal (High Clutch Piston-Inner)	7D404
Seal (Clutch Cylinder)	7C099, 7C328, 7D019,7E212	Seal (Hood Side Panel Rear)	16B922
		Seal (Idle Gear Shaft)	7Z001
Seal (Clutch Equalizer Bar)	7K530	Seal (Ignition Multiple Function Control Heatsink)	12B587
Seal (Clutch Pedal Rod)	7A533	Seal (Input Shaft Brg. Retainer)	7A248
Seal (Clutch Piston Inner)	7A294,7D404	Seal (Input Shaft Oil)	7052,7A011, 7A283
Seal (Clutch Piston Oil)	7A548,7D403	Seal (Interm. & Direct Clutch Hub)	7G102
Seal (Clutch Piston Outer Oil)	7A548	Seal (Interm. & Direct Clutch-Inner)	7F225
Seal (Coach Lamp)	15B446	Seal (Interm. & Forward Clutch-Out)	7F224
Seal (Control Sel. Hsg.)	7C370	Seal (Interm. Band Servo Piston Cover)	7D024
Seal (Control Selector)	7F370	Seal (Interm. Band Servo Piston)	7D024,7D025
Seal (Converter Turbine Shaft)	7H018,7N243	Seal (Interm. Band Servo Piston-Large)	7D024
Seal (Crancase Separator Spigot)	6K777	Seal (Interm. Band Servo Piston-Small)	7D025
Seal (Defroster Outlet)	18B644	Seal (Interm. Brake Drum)	7D429
Seal (Downshift Control Lever Oil)	386078	Seal (Interm. Clutch Piston - Inner)	7F225
Seal (Drive Shift Accumulator Piston)	7G275	Seal (Interm. Clutch Piston - Outer)	7F224
Seal (Engine Electronic Control)	12A696	Seal (Lower Accumulator)	7F249
Seal (Extension Housing Oil)	7052	Seal (Manual Control Lever Oil)	7B498
Seal (Front Fender Apron To Frame)	16240, 16D076	Seal (Manual Control Shaft)	7F337
		Seal (Oil Filter Mounting Bolt)	6749
Seal (Front Oil Pump)	7A248	Seal (Oil Pan Front)	6722
Seal (Front Pump Shaft-Front)	7G092	Seal (Oil Pan Rear)	6723
Seal (Front Pump Support)	7L323	Seal (Oil Pan)	6722
Seal (Front Suspension Arm Ball Joint Dust)	3A105	Seal (Oil Pump Body)	6C639
Seal (Front Suspension Upper Mounting Bearing)	3K049	Seal (Oil Pump Bore-Radial)	7G283
Seal (Front Suspension Or Steering Ball Stud Dust)	3332	Seal (Oil Pump Bore-Ring Side)	7G281
Seal (Front Suspension)	5A318	Seal (Oil Pump Shaft-Rear)	7G093
Seal (Front Wheel Hub Cap Grease)	1N135	Seal (Oil)	6700
Seal (Fuel Injection Pump Drive Shaft-Oil)	9B576	Seal (Output Shaft To Case)	7F273
Seal (Fuel Tank Filler Pipe)	9072	Seal (Output Shaft To Direct Clutch Cyl.)	7F274
Seal (Gear Shift Lever - Dust)	7Z206	Seal (Output Shaft To Slip Yoke)	7048
Seal (Gearshift Lever)	7D358	Seal (Output Shaft)	7A292

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Seal (Overdrive Brake Drum)	7D025	Seal (Steering Gear Rack Tube)	3F521
Seal (Piston - Front Brake)	2A418	Seal (Steering Gear Sector Shaft Housing Oil)	3591
Seal (Port Return)	3Z599	Seal (Steering Gear Sector Shaft Oil)	3738
Seal (Power Steering Gear Input Shaft Dust)	3D527	Seal (Tailgate Window Regulator Switch)	14A353
Seal (Power Steering Gear Input Shaft)	3D526	Seal (Thermostat)	8590
Seal (Power Steering Gear Piston)	3805	Seal (Throttle Control Shaft)	9C753
Seal (Power Steering Pump Rotor Shaft Oil)	3B592	Seal (Transmission Control Selector Dial)	7D351
Seal (Power Steering Valve)	3A590	Seal (Transmission Shift Rod)	7E397
Seal (Pressure Regulator Solenoid)	7Z144	Seal (Turbine Shaft)	7G090,7G091
Seal (Primary Sun Gear Oil - Front)	77542	Seal (Turbine Shaft-Front)	7G090
Seal (Primary Sun Gear Oil - Rear)	77543	Seal (Turbine Shaft-Rear)	7G091
Seal (Primary Sun Gear Oil)	7C169	Seal (Turbine Speed Sensor)	7Z101
Seal (Radiator Air Deflector)	8349	Seal (Upper Accumulator)	7F250
Seal (Radiator Side)	8N341	Seal (Valve Rocker Arm Cover Bolt)	6570
Seal (Radiator Tank Transmission Oil Cooler)	8C242	Seal (Valve Stem)	6571
Seal (Radio Speaker Mounting)	18A808	Seal (Vent Air Duct)	19B635, 19N574
Seal (Rear Axle Driving Pinion Bearing Retainer)	4669	Seal (Water By-Pass Tube)	8565
Seal (Rear Band Servo Piston Oil)	7423	Seal (Water Pump)	8K514
Seal (Rear Brake Dust)	2217	Seal (Wheel Bearing Oil Inner)	1177
Seal (Rear Clutch Piston Outer Oil)	7C051	Seal (Windshield Washer Jet)	17634
Seal (Rear Lamp Body)	13520	Seal (Windshield Washer Pump To Reservoir)	17B610
Seal (Rear Lamp Lens)	13W520	Seal (Windshield Wiper Pivot Shaft To Cowl Top)	17A475
Seal (Rear Lamp)	13A495	Seal (Wire Terminal Weather)	12113
Seal (Rear Lube Oil Transfer Tube)	7G085	Seal Assembly (Steering Column Opening)	3D677
Seal (Reverse Band Servo Piston Cover)	7D040	Seal Assy. (Crankshaft Rear Oil)	6701
Seal (Reverse Clutch Cylinder)	7D020	Seal Assy.	11A171
Seal (Reverse Clutch Piston-Inner)	7D404	Seal Assy. (Air Cleaner Air Flow Sensor)	9F855
Seal (Reverse Clutch Piston-Outer)	7D403	Seal Assy. (Air Conditioner Compressor Crankshaft)	19655
Seal (Reverse Clutch Piston-Small)	7D404	Seal Assy. (Camshaft - Front)	6700
Seal (Separator Fuel Vapor)	9B076	Seal Assy. (Camshaft Front)	6K292
Seal (Servo Piston - Large)	7D024	Seal Assy. (Conv. Impeller Hub)	7F401
Seal (Servo Piston - Small)	7D025	Seal Assy. (Extension Housing Oil)	7052
Seal (Shift Control Solenoid)	7Z484	Seal Assy. (Front Wheel Hub-Dust)	1N013
Seal (Shift Lever Shaft)	7693	Seal Assy. (Fuel Tank Filler Pipe)	9008
Seal (Shift Lever Shift)	7693	Seal Assy. (Hood Air Scoop)	16C884
Seal (Shift Shaft Lever)	7693	Seal Assy. (Hood Hinge Splash)	16C902
Seal (Shifter Shaft Oil)	7288	Seal Assy. (Radiator Support To Hood)	16A238
Seal (Shifter Shaft)	7288	Seal Assy. (Rear Axle Driving Pinion Oil)	4676
Seal (Shock Abs. Housing)	18T003	Seal Assy. (Throttle Valve Control Shaft)	7F429
Seal (Speedometer Drive Gear)	17298	Seal Assy. (Vent Hose Relief Discharge)	9008
Seal (Splash Shield)	16A323	Seal Assy. (Yoke To Flange)	4676,7B215
Seal (Steering Column Bearing-Lower)	3K730	Seal Brake Master Cylinder To Booster	2L364
Seal (Steering Column Boot)	3C612	Seal Kit (Air Conditioner Compressor Shaft)	19D665
Seal (Steering Column Opening Weather)	3513	Seal Kit (Brake Master Cylinder Reservoir)	2L074
Seal (Steering Cylinder Tube)	3N524	Seal Kit (Power Steering Cylinder)	3A764

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Seal Kit (Power Steering Gear Input Shaft)	3E502	Sensor And Retainer (Tachometer)	17B384
Seal Kit (Power Steering Gear Sector Shaft)	3E501	Sensor Assy.	5359
Seal Kit (Rear Disc Brake)	2B595	Sensor Assy. (Air Conditioner Ambient Air)	19E642
Seal Kit (Rear Wheel Disc Brake)	2L128	Sensor Assy. (Air Conditioner Sunload)	19E663
Seal Kit (Reservoir)	2C298	Sensor Assy. (Automatic Temperature Control)	19C734
Seal Kit (Transmission Control Select Indicator Lamp)	15837	Sensor Assy. (Barometric And Manifold Absolute Pressure)	12A680
Seal Kit Master Cylinder To Booster	2M049	Sensor Assy. (Camshaft Timing)	6B288
Seal Rear Brake Caliper Adjust	2M000	Sensor Assy. (Carburetor Air Cleaner Air Temperature Control)	9E607
Seal Reservoir To Booster	2M067	Sensor Assy. (Crankshaft Timing)	6C315
Seal And Gasket Kit	7153	Sensor Assy. (Egr Pressure Valve)	9J460
Seal And Gasket Kit (Power Steering Pump To Reservoir)	3D684	Sensor Assy. (Electronic Control Air)	12B529
Seal And Gasket Kit (Power Steering Pump)	3B584	Sensor Assy. (Engine Control Barometric Pressure)	12A644
Seal And Retainer Assy. (Crankshaft Rear Oil)	6K301	Sensor Assy. (Engine Electronic Control Coolant Temperature)	12A648
Seal Or Retainer (Wheel Hub Grease)	1190	Sensor Assy. (Engine Spark Knock Intensity)	12A699
Seal(Water Pump)	8K540	Sensor Assy. (Engine Timing)	6C315
Sealers And Adhesives	P0005,P0006	Sensor Assy. (Fuel Flow)	10D924
Sealers And Undercoats	P0000	Sensor Assy. (Fuel Water Detector)	9J308
Seat (Case Vent Cap)	7E427	Sensor Assy. (Headlamp Dimmer)	13A019
Seat (Child'S Safety)	19E535	Sensor Assy. (Heated Oxygen Sensor) Ho2S	9F472
Seat (Oil Pressure Regulator Valve Spring)	7C062	Sensor Assy. (Intake Air Temperature) - lat	12A697
Seat (Rear Axle Differential Pinion Shaft)	4420	Sensor Assy. (Low Coolant Level Warning)	10D968
Seat (Rear Clutch Piston Spring)	77516	Sensor Assy. (Low Oil Level)	6C624
Seat (Shift Rod Spring)	7D210	Sensor Assy. (Manifold Absolute Pressure)	9F479
Seat (Steering Gear Rack Ball Spring)	3F513	Sensor Assy. (Mass Airflow)	12B579
Seat (Transfer Case Gearshift Lever Spring)	7A138	Sensor Assy. (Rear Brake - Anti-Lock)	2B190
Seat (Valve Rocker Arm Fulcrum)	6A528	Sensor Assy. (Rear Brake Anti Lock)	2C190
Seat (Valve Rocker Arm Shaft Bolt)	6A528	Sensor Assy. (Seat Regulator Control Processor)	14C718
Seat (Valve Spring)	6A536	Sensor Assy. (Shock Absorber Electronic Steering)	18B015
Seat Kit (Rear Spring Upper Retaining)	5781	Sensor Assy. (Speed)	9E731
Seat And Bushing Assy. (Front Suspension Upper Arm Spring)	3388	Sensor Assy. (Speedometer)	17B375
Section Line (Evaporator To Compressor)	19C836	Sensor Assy. (Thermometer)	15A022
Sender & Pump Assy. (Fuel Tank)	9H307	Sensor Assy. (Water Temperature Fuel Injection Pump)	9F789
Sender (Water Temperature Indicator Engine Unit)	10884	Sensor Assy. Rr. Suspension Lvl. Height	5A955
Sender Assy. (Fuel Tank Unit)	9275	Sensor Assy.(Brake Pressure Shock Absorber Control)	2C283
Sender Assy. (Low Temperature-Air Road Surface)	10K936	Sensor Brake Master Cylinder	2B372
Sensor & Bracket Assy. (Front Anti Lock)	2C179	Sensor And Actuator (Seat Belt Tightener)	14K149
Sensor & Bracket Assy.(Crankshaft Timing)	6C351	Sensor And Bracket Assy. (Air Bag - Center)	14B006
Sensor (Anti-Lock Front)	2C204	Sensor And Bracket Assy. (Air Conditioner Ambient Air)	19E702
Sensor (Egr Valve)	9G428	Separator (Ignition Wire)	12297
Sensor (Oil Temp)	7H141	Separator Assy. (Crankcase Vent Oil)	6A785
Sensor (Turbine Speed)	7M101	Separator Assy. (Fuel Vacuum)	9C369
Sensor (Water In Fuel)	9K274	Separator Assy. (Oil)	6B673
Sensor (Windshield Washer Reservoir Fluid Level)	17B649	Servo Assy. (Air Conditioner Automatic Temperature Control)	19D669
Sensor And Bracket Assy. (Air Bag - Rear)	14B007	Servo Assy. (Speed Control)	9C735
Sensor And Bracket Assy. (Air Bag Front)	14B004	Shackle Assy. (Rear Spring)	5776

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Shackle Kit (Rear Spring)	5630	Shaft Assy. (Auxiliary Drive)	6A739
Shade Kit (Window)	18246	Shaft Assy. (Fuel Pump, Oil Pump And Dist. Drive)	6A739
Shaft & Joint Assy. (Front Wheel Drive)	3B436	Shaft Assy. (Headlamp Cover)	13B014
Shaft (5Th Shift Fork Control)	7241	Shaft Assy. (O/Drv. Center)	7A658
Shaft (Accumulator Piston)	7G094	Shaft Assy. (Odometer Drive-Idler)	17B292
Shaft (Air Conditioner Air Inlet Door)	19A819	Shaft Assy. (Odometer Reset)	17A381
Shaft (Air Conditioner Control Extension)	19A986	Shaft Assy. (Oil Pump Drive)	7B328
Shaft (Air Conditioner Damper Door)	19A580	Shaft Assy. (Oil Pump)	7B328
Shaft (Air Conditioner Evaporator Case Outlet Door)	19B752	Shaft Assy. (Output)	11355
Shaft (Air Conditioner Temperature Control)	19D846	Shaft Assy. (Rear Axle)	4234
Shaft (Brake Pedal)	2478	Shaft Assy. (Rear Brake)	2L278
Shaft (Clutch Release)	7510	Shaft Assy. (Steering Column)	3524
Shaft (Clutch And Brake Pedal Pivot)	7506	Shaft Assy. (Transaxle)	4234
Shaft (Control Selector Upper)	7R264	Shaft Assy. (Valve Rocker Arm)	6563
Shaft (Differential Pinion)	4211	Shaft Kit (Front Suspension Upper Arm)	3047
Shaft (Direct Drive)	7F208	Shaft And Control Assy. (Power Steering Gear Input)	3D517
Shaft (Drive Belt Tensioner Pulley)	6B222	Shaft And Offset Lever Assy. (Gearshift)	7358
Shaft (Drive)	11355	Shell	7D064
Shaft (Drive-Pinion)	11355	Shell (Wire Connector)	14A309
Shaft (Front Axle)	3A329	Shield (Accelerator Control Splash)	9E766
Shaft (Front Band Servo Actuating Lever)	7A165	Shield (Air Conditioner Drive Shaft)	19D806
Shaft (Gearshift)	7358	Shield (Air Conditioner Pressure Switch)	19E595
Shaft (Idler Gear)	7F358	Shield (Air Conditioner Tube)	19D727
Shaft (Input Shift)	7L267	Shield (Air Intake)	9E612
Shaft (Input)	7015,7017	Shield (Alternator Fan)	10C348
Shaft (Interm. Clutch)	7F351	Shield (Alternator Heat)	10A346
Shaft (Intermediate Band Actuating Lever)	7D433	Shield (Alternator Splash)	10317
Shaft (Light Switch)	11663	Shield (Ash Receptacle Lamp Light)	13A714
Shaft (Manual Control Lever)	7C493	Shield (Ash Receptacle Light)	15074
Shaft (Oil Pump Drive)	6A618	Shield (Backup Lamp)	15B491
Shaft (Oil Pump Intermediate)	6A618	Shield (Battery Heat)	10A682
Shaft (Output)	7060,7061	Shield (Body Side Lamp Rear)	15B419
Shaft (Parking Pawl)	7D071	Shield (Brake Booster-Heat)	2B485
Shaft (Parking Plate)	7D418	Shield (Brake Tube)	2B085
Shaft (Power Steering Pump Rotor)	3B559	Shield (Carburetor Altitude Compensator Hose)	9B935
Shaft (Rear Band Servo Actuating Lever)	7A171	Shield (Carburetor Heat)	9A462,9S596
Shaft (Reverse Idler Gear)	7140	Shield (Cigar Lighter Protector)	15K042
Shaft (Rotor)	10330	Shield (Cigar Lighter)	15068
Shaft (Shift Fork Control)	7241	Shield (Clutch Cable Heat)	7B627
Shaft (Shift Lever)	7C355	Shield (Clutch Pedal)	7C521
Shaft (Steering Gear Sector)	3575	Shield (Clutch Release Lever Dust)	7513
Shaft (Transaxle Differential Pinion)	4211	Shield (Courtesy Lamp)	13B762
Shaft (Turbine)	7F213	Shield (Crankshaft Timing Sensor Lower)	6C353
Shaft And Joint Assy. (Rear Wheel Drive)	4B436	Shield (Crankshaft Timing Sensor Upper)	6K342
Shaft Assy. (Accelerator Pedal)	9725	Shield (Door Open Warning Switch)	10B985

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Shield (E.E.C. Processor Connector)	12B508	Shield (Rear Bumper Opening)	17C857
Shield (Eng. Charge Air)	6B879	Shield (Rear Bumper Stone Deflector End)	17E838
Shield (Eng. Noise Insulator Side)	6L014	Shield (Rear Lamp)	13A460
Shield (Engine Compartment Wiring)	14A088	Shield (Rear License Plate Lamp)	13508
Shield (Engine Mount Heat)	6C038	Shield (Rear Wheel Disc Brake)	2C028
Shield (Exhaust Air Supply Pump)	9F431	Shield (Spark Plug Heat)	12A406
Shield (Exhaust Manifold)	9A462	Shield (Splash)	6775
Shield (Front Bumper Opening)	17D808	Shield (Steering Column Lock Key)	5K687
Shield (Front Disc Brake Rotor)	2K004	Shield (Steering Column Sensor)	3F724
Shield (Front Disc Brake)	2B116	Shield (Steering Column)	3K687
Shield (Front Fender Splash)	16102	Shield (Steering Shaft U-Joint)	3F540
Shield (Front Side Lamp Opening)	15C418	Shield (Trans. Gear Shift Lever Opening)	7D359
Shield (Front Splash)	16A266, 16A324	Shield (Trans. Heat)	7A434
Shield (Front Susp Housing)	3C134	Shield (Trans. Modulator Heat)	7F013
Shield (Front Suspension)	3B382	Shield (Transmission Console Shift Selector Housing)	7E271
Shield (Front Wheel Grease)	3K070	Shield (Transmission Shift Selector Indicator)	7E130
Shield (Fuel Filter)	9A072	Shield (Turbocharger Heat)	9G478
Shield (Fuel Injector Nozzle Heat)	9M577	Shield (Vacuum Mtr.)	7A786
Shield (Fuel Line Protection)	9S276	Shield (Valve Assy. Vacuum Control)	9H484
Shield (Fuel Pump)	9A397	Shield (Windshield Washer Pump)	17K631
Shield (Fuel Supply Manifold)	9J314	Shield (Windshield Wiper Motor)	17C441
Shield (Fuel Tank Filler Pipe)	9A097	Shield (Wiring)	14A099
Shield (Fuel Tank Heat)	9A032	Shield Assy. (Exhaust Manifold Heat)	9N454
Shield (Fuel Tank Rear)	9B212	Shield Assy. (Fuel Floor Lower)	9E313
Shield (Fuel Tank Stone)	9K036	Shield Assy. (Open Door Warning Switch)	10D882
Shield (Fuel Tank)	9B007	Shield Assy. (Radiator Grille Splash Side)	8A268
Shield (Fuel Tube)	9C291	Shield Assy. (Radiator Upper Sight)	8C291
Shield (Fuel Vapor Canister Inlet Tube)	9E489	Shield Assy. (Radio Static Suppressor Hood)	19A040
Shield (Glove Compartment Light)	15A566	Shield Assy. (Speed Sensor)	9F829
Shield (Headlamp Center)	13C009	Shield Assy. Parking Brake Cable	2B616
Shield (Headlamp Opening)	13B184	Shield Brake Anti-Lock (Battery)	2C314
Shield (Headlamp Splash)	13B159	Shield Engine And Transmission (Splash)	6775
Shield (Hood Front Opening)	16B656	Shield Exh. Conv.	5K287
Shield (Idle Pulley)	3E595	Shield Heat Front	5360
Shield (Idler Pulley Bearing)	8687	Shield Wheel Hub Splash	1A095
Shield (Inertia Fuel Shutoff Switch)	9F315	Shield And Pipe Kit (Fuel Tank Modification)	9B007
Shield (Instrument Panel Light)	13771	Shield-Noise Wrap Converter	5F215
Shield (Intake Manifold)	9471	Shim	5K944
Shield (Muffler Front)	5K200	Shim (Bearing Retainer)	7K084
Shield (Muffler)	5290	Shim (Charge Bracket To Cooler)	6L617
Shield (Power Steering Hose)	3C569	Shim (Drive Pinion Bearing Adjust)	4663
Shield (Radiator Grille Sight)	8C030,8C071	Shim (Drive Pinion)	4109
Shield (Radiator Upper Sight)	8C288	Shim (Front Suspension Lower Arm Strut)	3B400
Shield (Radio Speaker)	18B808	Shim (Front Suspension Upper Arm Mounting)	3043
Shield (Rear Axle Housing Flange)	4A046	Shim (Fuel Injector Pump Nozzle)	9M557

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Shim (Gearshift Lever)	7E018	Sleeve (Gearshift Shaft)	7K424
Shim (Idle Gear Adjusting)	7N112	Sleeve (Oil Distributor)	7C232
Shim (Input Bearing - Front)	7029	Sleeve (Radiator Hose)	8C147
Shim (Preload)	7L172	Sleeve (Rear Spring)	5K829
Shim (Rear Axle Differential Clutch)	4A324	Sleeve (Reverse Syn. 1st Gear)	7072
Shim (Steering Column)	3R665	Sleeve (Speedometer Cable)	17B301
Shim Bar & Axle (Rear)	5L480	Sleeve (Steering Column Shaft)	3C664
Shim Kit (Air Conditioner Compressor Clutch)	2D884	Sleeve (Steering Column Tube Bearing)	3518
Shim Kit (Countershaft Frt. Brg.)	7L172	Sleeve (Synchronizer)	7106
Shim Kit (Drive Pinion)	4109	Sleeve (Trans. Air Baffle)	7L459
Shim Kit (Steering Gear Sector Shaft Adjusting)	3A657	Sleeve (Trans. Control Selector Lever)	7B010
Shim Kit (Steering Gear Shaft Adjusting)	3763	Sleeve (Trans. Gearshift Rod)	7K047
Shims (Rear Axle Differential Bearing)	4067	Sleeve (Transmission Gearshift Connecting Rod Adjustment)	7353
Shims (Transaxle Differential Bearing)	4067	Sleeve (Turn Signal Turn Off Cam)	13B368
Shock Absorber (Front)	18124	Sleeve (Valve Spring Retainer)	6517
Shock Absorber (Rear)	18125	Sleeve (Wiring Connector)	14489
Shock Absorbers (Rear)	18125	Sleeve Bumper (Rear)	5L493
Shoe & Lining Assy. (Park Brake)	2N712	Slide Plate (Instrument Cluster Switch)	10B838
Shoe & Lining Kit (Brake)	2001	Slinger (Crankshaft Oil)	6310
Shoe & Lining Kit (Rear Brake)	2200	Slinger (Driveshaft Stud Yoke)	4791
Shoe And Lining Kit	2001	Slinger (Front Axle Spindle Yoke)	3C132
Shroud (Fan)	8146	Slinger (Rear Axle Driving Pinion Shaft Oil)	4670
Shroud (Steering Column)	3530	Slip Yoke (Driveshaft)	4841
Shroud Assy. (Alternator Air Intake)	10C341	Small Parts Kit(Rear Axle)	4K172
Shroud Assy. (Transmission Select Indicator Lamp)	15A811	Small Parts Repair Kit	7B331
Shroud Kit (Coolant System)	8L146	Snap Ring	7026,7059, 7064,7A577
Shroud And Tube Assy. (Carburetor Air Cleaner Air Duct)	9A603	Snap Ring (3-4 Synchronizer Retaining)	7030
Shutter (Camshaft)	12099	Snap Ring (Bearing Outer)	7030
Sight Shield (Lower Panel)	8N208	Snap Ring (Brake And Clutch Pedal Retaining)	2487
Silencer & Bracket Assy. (Exhaust Air Supply Pump)	9G427	Snap Ring (Clutch Pressure Plate Retainer)	7A577,7D483
Silencer (Air Cleaner)	9F658	Snap Ring (Front Band Servo Piston Guide To Servo)	77366
Silencer (Exhaust Air Supply Reed Valve)	9F449	Snap Ring (Front Clutch Disc Spring Retaining)	77567
Sleeve & Bracket Assy. (Relay Wiring Connector)	14A211	Snap Ring (Governor To Shaft)	7E253
Sleeve (5Th Speed Gear)	7A061	Snap Ring (Output Shaft Ring Gear Retaining)	7C122
Sleeve (5Th Speed Interlock)	7D383	Snap Ring (Pinion Upper)	3Z504
Sleeve (Air Conditioner Hose Protection)	19D631	Snap Ring (Rear Band Servo Piston)	77417
Sleeve (Air Conditioner Manifold Pilot)	19D877	Snap Ring (Rear Clutch Piston Spring Retaining)	77517
Sleeve (Coil Retaining)	11105	Snap Ring (Speedo. Gear Retaining)	7059
Sleeve (Conv. Turbine)	7A878	Snap Ring (Trans. Shift Rod)	7C072
Sleeve (Converter Pilot)	7G371	Snap Ring (Universal Joint Bearing)	4891
Sleeve (Coupling Shaft Center Support)	4826	Snap Ring (Windshield Wiper Output Shaft)	17C554
Sleeve (Front Caliper)	2B393	Snap Ring Pinion Strg Gear	3Z501
Sleeve (Front Wheel Spindle Connecting Rod Adjusting)	3310	Snap Switch And Bracket Assy.	19757
Sleeve (Fuel Vapor Storage Canister Purge)	9E629	Snow Pack Kit (Carburetor Air Cleaner Air Intake Tube)	9E635
Sleeve (Gear Brg.)	7173	Socket (Brake Shoe Adjusting Screw)	2048

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Socket (Dome Lamp)	13B764	Spacer (Accelerator Control Shaft)	9N778
Socket (Exterior Lamp Bulb)	13K371	Spacer (Accessory Drive)	6B250
Socket (Lug Nut)	17K010	Spacer (Air Cleaner)	9E626
Socket (Map Lamp)	15A653	Spacer (Air Conditioner Compressor Clutch Hub)	19D648
Socket (Shift Lever)	7228	Spacer (Air Conditioner Mounting Bracket)	2890
Socket (Steering Control Ball Stud)	3A754	Spacer (Air Conditioner Register Control Knob)	19A963
Socket (Trans. Clutch Shaft Ball)	7517	Spacer (Air Leveler Hose)	5A680
Socket (Transmission Column Shift Selector Lever)	7228	Spacer (Alternator Fan Or Pulley)	10A344
Socket (Wire Assy. Warning Lamp)	14522	Spacer (Brake Booster & Master Cylinder)	2A767
Socket And Wiring Assy. (Window Regulator Switch)	14B171	Spacer (Brake Master Cylinder Push Rod)	2B129
Socket Assy. (Instrument Panel Lamp)	13711	Spacer (Brake Pedal Support Mounting)	2B180
Socket Assy. (Interior Lamp)	13793	Spacer (Brake Pedal)	2A188
Socket And Bulb Assy. (Instrument Panel Lamp)	13B765	Spacer (Bumper Isolator And Bracket)	17765
Socket And Retainer Assy. (Cigar Lighter)	15055	Spacer (Camshaft Rear Cover)	6K291
Socket And Wire (Front Fender Side Lamp)	15A434	Spacer (Camshaft Sprocket)	6265
Socket And Wire Assy. (Body Side Or Coach Lamp)	15A442	Spacer (Carburetor To Intake Manifold)	9A589
Socket And Wire Assy. (Control Lamp)	18541	Spacer (Case Bracket)	7Z032
Socket And Wiring Assy. (Interior Lamp)	13A719	Spacer (Clutch Pedal Outer)	7606
Socket And Wiring Assy. (Lamp)	13410	Spacer (Clutch Pedal Return Spring)	7L519
Socket And Wiring Assy. (Parking Lamp)	13234	Spacer (Clutch Pedal)	7A595
Solenoid & Manifold Assy. (Automatic Temperature Control)	19D611	Spacer (Compressor)	19L969
Solenoid (By-Pass Clutch)	7G136	Spacer (Countershaft Front Bearing)	7C434
Solenoid (Shift)	7M107	Spacer (Countershaft Gear)	7149
Solenoid Assy	11390	Spacer (Countershaft)	7072,7125
Solenoid Assy.	11390	Spacer (Crankshaft Pulley Outer)	6B306
Solenoid Assy. (Air Conditioner Bypass Valve)	19D670	Spacer (Cylinder Front Cover)	6132
Solenoid Assy. (Carburetor Float Bowl Vent)	9B982	Spacer (Cylinder Head)	6A017
Solenoid Assy. (Door Lock)	14021	Spacer (Eng. Balance Shaft Gear)	6K305
Solenoid Assy. (Fuel Filler Door Lock)	9B241	Spacer (Flywheel To Crankshaft)	6434,6K372
Solenoid Assy. (Fuel Shut Off Valve)	9D278	Spacer (Fog Lamp Mounting)	15251
Solenoid Assy. (Heater Water Control)	18C310	Spacer (Front Bumper Mounting)	17A942
Solenoid Assy. (Luggage Compartment Door Lock)	14030	Spacer (Front Spring)	5A343
Solenoid Assy. (O/Drv. - 3/4 Shift)	7F037	Spacer (Front Stabilizer Bar)	5490
Solenoid Assy. (Pressure Regulator)	7H144	Spacer (Front Support Insulator)	6A066
Solenoid Assy. (Shift Control)	7G484	Spacer (Front Suspension Mounting)	3B351
Solenoid Assy. (Starter)	11390	Spacer (Fuel Filter)	9B258
Solenoid Assy. (Turbo Control)	9C728	Spacer (Fuel Injection Pump Camshaft)	9P659
Solenoid Assy. (Turbocharger Boost Pressure Regulator)	9K378	Spacer (Fuel Injector Needle)	9D905
Solenoid Assy. Valve	5311	Spacer (Fuel Injector Nozzle)	9K548
Solenoid And Valve Assy. (Headlamp Cover)	13A161	Spacer (Fuel Tank Mounting)	9071
Spacer	11N004, 7B437,9A435	Spacer (Gearshift Selector-Upper)	7D327
Spacer (2Nd Speed Gear Brg.)	7B320	Spacer (Headlamp Mounting)	13A109
Spacer (3Rd & 4Th Synchronizer)	7N112	Spacer (Idle Gear)	7R194
Spacer (3Rd Speed Gear Brg.)	7728	Spacer (Idle Pulley Bracket)	8A652
Spacer (5Th Speed Syn. Retaining)	7L049	Spacer (Idle Pulley)	8A613

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Spacer (Input Gear)	7K283	Spacer (Windshield Wiper Motor Output Shaft)	17A558
Spacer (Input Shaft Collapsible)	7D114	Spacer (Windshield Wiper Pivot Shaft Mounting)	17514
Spacer (Low Coolant Level Warning Switch)	10K927	Spacer (Wire Connector)	14A468
Spacer (Main Shaft First Gear Thrust)	7071	Spacer Assy. (Egr Valve)	9H474
Spacer (Mounting)	7C286	Spacer Assy. (Fuel Evaporation)	9F732
Spacer (Oil Pan)	6C629	Spacer Assy. (Heater Regulator Control Lever)	18C376
Spacer (Oil Pressure Regulator Valve)	7470	Spacer Assy. (Radio Speaker Mounting)	18B947
Spacer (Output Shaft Collapsible)	7080	Spacer Assy. (Rear Lamp Mounting Bolt)	13B457
Spacer (Park Lever)	7F286	Spacer Rear Spring Seat Lower	5A565
Spacer (Power Steering Control Valve Spool)	3A658	Spacer Sensor Kit	2C258
Spacer (Power Steering Gear Sector Shaft Seal)	3D529	Spacer Thermactor (Air Bypass)	9H314
Spacer (Power Steering Pump Adjusting Bracket)	3D600	Spacer Or Sleeve	7072
Spacer (Power Steering Pump Mounting)	3642	Spacer(Fuel Tank)	9B086
Spacer (Pulley To Fan)	8546	Spare Tire And Carrier Kit (Utility Trailer)	19A404
Spacer (Pump Assy. Exhaust Air Supply)	9B488	Spark Plug Assy.	12405
Spacer (Radiator Grille)	8A188	Speaker Assy. (Mobile Telephone)	19A447
Spacer (Rear Axle Driving Pinion Bearing)	4662	Speaker Assy. (Radio Receiver)	18808
Spacer (Rear Axle Insulating)	4A947	Special Products	P0005,P0006
Spacer (Rear Band Servo Rod)	7D300	Specialties	P0000
Spacer (Rear Bumper)	17C827	Speed Control Kit	9A818
Spacer (Rear Support Insulator)	6A027	Speedometer Assy. (Less Mounting Plate)	17255
Spacer (Reverse Fork)	7482	Speedometer Drive Gear Identification Chart	17285
Spacer (Reverse Idler Gear)	7482	Speedometer Driven Gear Application Chart	99999
Spacer (Seat Belt Retainer Switch)	14B141	Spindle (Adjuster Rear Disc)	2A874
Spacer (Shift Cable Spring)	7323	Spindle (Rear Wheel)	4A013
Spacer (Spare Wheel Hoist Handle)	1A454	Spindle Assy. (Front Wheel)	3105
Spacer (Speedometer Dial)	17A317	Splash Kit (Wheel Guard)	16A550
Spacer (Steering Column Bracket Insulator)	3E742	Spoiler (Air Conditioner)	19E525
Spacer (Steering Column Bracket To Column)	3578	Spoke Replacement Kit (Spoke Wheel)	1A109
Spacer (Steering Column Ignition Lock Key Release Cable)	3F698	Spool	2A858
Spacer (Steering Column Lower Bearing)	3D762	Spotlight Kit	15312
Spacer (Steering Column Tube)	3C686	Spring	7L058
Spacer (Steering Column Upper Bearing)	3D640	Spring & Plunger (Windshield Wiper Lever)	17E475
Spacer (Steering Gear Housing-Upper)	3A572	Spring & Ret. Assy. (Low & Interm. Servo)	7G150
Spacer (Steering Gear Pinion Bearing)	3K599	Spring & Retainer Assy. (Reverse Inhibitor)	7F153
Spacer (Sun Gear)	7D480	Spring & Shock Assy. (Front)	3C098
Spacer (Suspension Air Spring Compressor Bracket)	3C164	Spring (1-2 Accumulator-Inner)	7G326
Spacer (Throttle Pressure Valve Secondary)	7D227	Spring (1-2 Accumulator-Outer)	7G267
Spacer (Timing Belt Cover)	6K291	Spring (1-2 Shift)	7F284
Spacer (Trans Gearshift Lever)	7E097	Spring (2-3 Accumulator Piston)	7F285
Spacer (Tube)	7115	Spring (2-3 Accumulator)	7F247
Spacer (U-Joint Housing)	4819	Spring (2-3 Downshift Control Valve)	7C394
Spacer (Valve Adjusting)	6515	Spring (3-4 Accumulator-Inner)	7F288
Spacer (Valve Rocker Arm)	6590	Spring (3-4 Accumulator-Outer)	7G266
Spacer (Wheel Hub)	1A014	Spring (3-4 Shift Valve)	7F260

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Spring (3Rd & 4Th Bias)	7G046	Spring (Gear Shift Lever)	7K205
Spring (Accelerator Pedal Pivot)	9C804	Spring (Gearshift Lever)	7227,7D294
Spring (Accelerator Retracting)	9737	Spring (Gearshift Selector Tube)	7379
Spring (Accelerator Shaft)	9760	Spring (Governor Primary)	7E467
Spring (Accumulator Piston)	7F285	Spring (Governor Valve)	7A302
Spring (Accumulator)	7G266	Spring (Headlamp Ball Ring)	13031
Spring (Air Conditioner Air Intake Flue Damper Assistant)	19917	Spring (Headlamp Dimmer Control Adjusting Screw)	13654
Spring (Air Conditioner Air Temperature Control Door)	19D964	Spring (Heater Air Vent Door)	18B283
Spring (Air Conditioner Temperature Control Lever)	19760	Spring (Hood Assist)	16C644
Spring (Air Conditioner Tube Lock Coupling)	19E576	Spring (Hood Hinge)	16789
Spring (Brake Pedal Return)	2472	Spring (Hood Support Rod)	16832
Spring (Brake Shoe Adjusting Screw)	2049	Spring (Horn Contact)	13A807
Spring (Brake Shoe Hold Down)	2068,2B454	Spring (Interm. Band Servo Piston)	7D028
Spring (Brake Shoe Retracting)	2035	Spring (Manual Control Valve Detent Lever)	7A261
Spring (Brush)	10349,11059	Spring (Meshlock)	7234
Spring (Camshaft Thrust)	6297	Spring (Neutral - Reverse Accumulator - Inner)	7G395
Spring (Carburetor Fuel Filter Retaining)	9342	Spring (Neutral - Reverse Accumulator)	7D466
Spring (Case Detent)	7A286	Spring (O/Drv. Servo Piston Return)	7F201
Spring (Case To Planet Support)	7F277	Spring (Oil Pressure Regulator Valve)	7D160
Spring (Clutch Cable Tension)	7K576	Spring (Oil Pump Relief Valve)	6670
Spring (Clutch Lever Return)	7K735	Spring (Oil Relief Check Ball)	7R292
Spring (Clutch Pedal Pawl)	7L585	Spring (Park Actuating Lever Rod)	7A124
Spring (Clutch Pedal Return)	7534	Spring (Park Gear)	7N367
Spring (Clutch Piston Disc)	7B070	Spring (Park Pawl Ratcheting)	7A180
Spring (Clutch Piston)	7A480	Spring (Parking Brake Cable Positioning)	2745
Spring (Clutch Release Lever Retracting)	7591	Spring (Parking Brake Equalizer Lever)	2B603
Spring (Clutch Release Lever Rod Retracting)	7523	Spring (Parking Brake Link)	2A601
Spring (Control Selector Lever Plunger)	7B071	Spring (Parking Brake Release Control)	2793
Spring (Control Selector)	7G046	Spring (Parking Brake Release)	2634
Spring (Conv. Drain-Back Valve)	7G315	Spring (Parking Brake Strut)	2L645
Spring (Detent)	7D017	Spring (Parking Pawl Return)	7D070
Spring (Direct Clutch Piston)	7B488	Spring (Parking Pawl Toggle Return)	7E416
Spring (Disc Brake Caliper Support)	2B486	Spring (Parking Plate Torsion)	7D417
Spring (Drive Shift Accumulator - Inner)	7G301	Spring (Plunger Return)	11103
Spring (Drive Shift Accumulator)	7G300,7G301	Spring (Power Steering Control Valve Reaction Limiting)	3C563
Spring (Drive Shift Accumulator-Outer)	7G300	Spring (Power Steering Pump Flow Control Valve)	3D586
Spring (Driveshaft Centering Socket Race Ball)	4A073	Spring (Power Steering Pump Pressure Plate)	3D596
Spring (Fog Lamp Mounting Plate)	15A261	Spring (Power Steering Yoke)	3Z591
Spring (Forward Clutch Return)	7A480	Spring (Pressure)	7E085
Spring (Front Band Servo Piston Retracting)	7A003	Spring (Rear Axle Differential Clutch)	4214
Spring (Front Clutch Piston Disc)	7B070	Spring (Rear Band Servo Piston)	7D474
Spring (Front Coil)	5310	Spring (Rear Brake Auto Adjuster)	2L396
Spring (Fuel Injector Nozzle)	9F537	Spring (Rear Brake Shoe Strut)	2L514
Spring (Fuel Tank Sender Pump Loading)	9L287	Spring (Rear Bumper Stone Deflector)	17E828
Spring (Gear Shift Control Cable)	7B113	Spring (Rear Clutch Piston)	7A480

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Spring (Rear Suspension Air Sprg. Shk. Abs. Torsion)	5A980	Spring Assy. (Rear Bumper - End Moulding)	17E916
Spring (Reverse Band Accumulator)	7E207	Spring Assy. (Rear)	5560
Spring (Reverse Band Servo)	7D031	Spring Bracket (Turbocharge)	9G485
Spring (Reverse Gate)	7219	Spring Centering Kit (Power Steering Control Valve)	3A675
Spring (Reverse Inhibitor)	7K182	Spring Clip (Shift Lever Stop)	7E444
Spring (Reverse Kick Down)	7219	Spring Kit (1-2 Shift)	7F415
Spring (Secondary Throttle Return)	9A538	Spring Park Brake Equalizer Cable	2A651
Spring (Servo Piston Cushion)	7F390	Spring Repair Kit (Drum Brake)	2A225
Spring (Servo Piston)	7D028	Spring Return Park Brake	2456
Spring (Shift Gate Plate Pawl)	7E200	Spring Return Rear	2L642
Spring (Shifter Interlock)	7234	Spring Set (Lever Return)	11103
Spring (Solenoid Plunger)	11103	Spring Washer Retainer (Blend Air Door Cable)	19D624
Spring (Steering Column Balance)	3A505	Spring Wheel Brake Caliper (Rear)	2K393
Spring (Steering Column Lock Actuator Lever)	3F532	Spring(Bracket)	9449
Spring (Steering Column Lock)	3E696	Spring(Valve Rocker Arm Shaft)	6587
Spring (Steering Column Locking Lever)	3B664	Spring-Quadrant Adjusting (Rear Brake)	2L513
Spring (Steering Column Position Lock)	3B768	Sprint (Rear Clutch Piston)	7A480
Spring (Steering Column Position)	3D655	Sprocket (Camshaft)	6256
Spring (Steering Column Upper Bearing)	3520	Sprocket (Crankshaft)	6306
Spring (Steering Gear Rack Adjustment)	3K576	Sprocket Assy (Drive)	7G129
Spring (Synchronizer Blocking)	7109	Sprocket Assy. (Driven)	7G132
Spring (Throttle Positioning Screw)	9578	Stanchion (Radio Antenna)	18919
Spring (Throttle Pressure Booster Valve)	7A331	Starter Cord	10N717
Spring (Throttle Return)	9B569	Starter Motor	11001
Spring (Throttle Valve Lever Return)	7F292	Stator Assy.	10336, 10K343
Spring (Timing Belt Tensioner)	6L273	Stator Assy. (Distributor)	12A112
Spring (Trans. Control Shift Rod)	7C331	Stator And Coil Assy.	10336
Spring (Trans. Throttle Valve Return)	7C471	Steering Gear Repair Kit (Inner)	3L566
Spring (Trans. Throttle Valve)	7K719	Steering Kit (Nibble Correction)	3144
Spring (Transmission Control Selector Lever Plunger)	7B071	Stem (Air Conditioner Clutch Cycling Pressure Switch)	19E562
Spring (Transmission Control Selector Pivot)	7E196	Step (Rear Bumper)	17B807
Spring (Transmission Kickdown Control Shaft Retraction)	7B146	Stop (Accelerator Pedal)	9816
Spring (Transmission Park Lockout Return)	7C300	Stop (Front Bumper Reinforcement)	17C817
Spring (Turn Signal Indicator Lamp)	13A353	Stop (Heater Air Vent Door)	18B409
Spring (Valve Rocker Arm Pin Retaining)	6K532	Stop (Rear Bumper)	17B990
Spring (Valve)	6513	Stop (Reverse Gearshift Lever)	7K003
Spring (Vanity Mirror Cover)	17D683	Stop (Rotor)	10A360
Spring And Shock Absorber Assy. Rear	5A965	Stop (Spare Wheel)	1422
Spring Antirattle (R.H.)	2L035	Stop (Windshield Wiper Arm)	17C549
Spring Assy. (Brake Cylinder Piston Cup)	2204	Stop Assy. (Parking Brake Lever)	2L625
Spring Assy. (Camshaft Thrust)	6B271	Stop Assy. (Windshield Wiper Motor)	17C479
Spring Assy. (Clutch Pedal Lever Assist)	7534	Stopper (Operating Lever Rear Quad)	2B213
Spring Assy. (Ignition Switch Return)	3E746	Stopper-Rubber	5K827
Spring Assy. (Manual Valve Detent)	7E332	Strap (Drive Belt Tensioner)	6B210
Spring Assy. (Radiator Grille)	8C255	Strap (Ignition Coil Mounting)	12043

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
S — Cont'd		S — Cont'd	
Sensor Assy. (Engine Timing)	6C315	Spring (Accel Pump Piston Return)	9J564
Sensor Assy. (Heated Oxygen Sensor) Ho2S	9F472	Spring (Accel. Pump Overtravel)	9A538
Sensor Assy. (Intake Air Temperature)	12A697	Spring (Accelerator Pump Diaphragm Return)	9636
Sensor Assy. (Manifold Absolute Pressure)	9F479	Spring (Accelerator Pump Lever)	9571
Sensor Assy. (Speed)	9E731	Spring (Accelerator Pump Lever Return)	9636
Sensor Assy. (Tachometer)	17B384	Spring (Accelerator Pump Lever)	9636
Sensor Assy. (Water Temperature)-Fuel Injection Pump	9F789	Spring (Accelerator Pump Rod)	9D598
Set Screw (Choke Diaph. Adjust)	9E684	Spring (Accelerator Pump Rod)-Upper	9D598
Shaft & Cam Assy. (Choke)	9A753	Spring (Accelerator Pump Upper)	9D598
Shaft & Lever Assy. (Choke)	9546	Spring (Air Valve)	9H556
Shaft & Lever Assy.-(Choke Hsg.)	9A753	Spring (Bowl Vent)	9560
Shaft (Choke Plate)	9547	Spring (Choke Assist)	9587
Shaft (Float Lever)	9558	Spring (Choke Control Modulator)	9J547
Shaft And Lever Assy. (By-Pass Valve)	9A945	Spring (Choke Diaphragm)	9P652
Shaft And Lever Assy. (Choke Housing)	9A753	Spring (Fast Idle Adjusting Screw)	9578
Shaft And Lever Assy. (Choke)	9546,9A753	Spring (Fast Idle Adjusting Screw)-	9578
Shield (Choke Thermostat)	9861	Spring (Feedback Piston And Diaphragm)	9B504
Shield (Fuel Inlet Seat)	9E845	Spring (Float Bowl Vent)	9560
Shield (Radio Speaker)	18B808	Spring (Float)	9A519
Sleeve (Choke Lever Pin)	9851	Spring (Fuel Bowl Vent)	9H556
Sleeve (Choke Shaft)	9851	Spring (Fuel Enrichment Valve)	9E533,9P652
Sleeve Assy. (Wire Connector)	14489	Spring (Fuel Filter Retaining)	9342
Socket And Wiring Assy. (Window Regulator Switch)	14B171	Spring (Idle Adj. Needle)	9578
Solenoid (Operated Vacuum Throttle)	9S552	Spring (Idle Adjusting Needle)	9578
Solenoid (Throttle)	9D856	Spring (Idle Screw)	9578
Solenoid (Throttle)-Also Refer To 9S553 & 9S520	9D856	Spring (Metering Rod Guide)	9B526
Solenoid And Bracket Assy. (Throttle)	9D856	Spring (Metering Rod Torsion)	9A914
Solenoid Assy.	9D856	Spring (Metering Valve)	9N539
Solenoid Assy. (Cranking Fuel)	9A951	Spring (Primary Float Dampener)	9F570
Solenoid Assy. (Feedback Control)	9S565	Spring (Pump Diaphragm)	9636
Solenoid Assy. (Float Bowl Vent)	9A567	Spring (Pump Diaphragm)-Also Refer To 9B545	9636
Solenoid Assy. (Idle Fuel Shut-Off)	9D856	Spring (Secondary Throttle Diaphragm)	9B504
Solenoid Assy. (Pulse Feed-Back)	9S565	Spring (Throttle Return)	9834,9A538, 9B569
Solenoid Assy. (Throttle Emission)	9D856	Spring (Throttle Return-Primary "B")	9A538
Solenoid Assy. (Throttle Emission Control)	9D856	Spring (Throttle Return-Secondary)	9A538
Solenoid Assy. (Throttle Emission Control)-	9D856	Spring (Trans. Kickdown Control Lever)	7B146
Solenoid Assy. (Turbo Control)	9C728	Spring (Trans. Throttle Valve Ret.)	7C471
Solenoid Assy. (Turbocharger Boost Control Pressure Regulator)	9K378	Spring (Transmission Kickdown)	7B146
Spacer (Choke Index Ring)	9A539	Spring (Venturi Valve Adj. Screw)	9C963
Spacer (Choke Index)	9A539	Spring (Venturi Valve Diaphragm)	9K503
Spacer (Compressor)	19L969	Spring Set	9587
Spacer (Diaphragm)	9B581	Spring Set (Injector)	9935
Spacer (Solenoid Bracket)	9J856	Sprint Assy. (Rear Bumper - End Moulding)	17E916
Spacer Assy. (Fuel Vaporization)	9F732	Stator Assy. (Distributor)-Pip Sensor	12A112
Spring	9587,9636, 9E525	Stud (Air Cleaner To Carburetor)	9A659

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
T — Cont'd		T — Cont'd	
Trunnion (Heater Control)	18K331	Tube (Governor Outlet)	7D469
Trunnion (Trans. Throttle Valve Rod)	7F347	Tube (Heater Hot Water)	18B402
Trunnion (Transmission Gearshift Lever)	7B125	Tube (High Pressure Kit)	2C310
Tube & Flange Assy. (Water Pump Inlet)	8A573	Tube (Insulator)	9E481
Tube & Hose Assy (Eng Oil Cooler Inlet)	6N867	Tube (Intake Manifold Heater Outlet)	9D428
Tube & Hose Assy (Eng Oil Cooler Outlet)	6N866	Tube (Lamp Rear Combination)	13B216
Tube & Hose Assy. (Alternator Air Intake)	10C351	Tube (Lube Oil Inlet-Short)	7A160
Tube & Hose Assy. (Fuel Front)	9H336	Tube (Manifold Vacuum Control)	9G469
Tube & Hose Assy. (Fuel Return Front)	9H338	Tube (Oil Bypass)	7A174
Tube (Air Cleaner Intake Preheater)	9P691	Tube (Oil Cooler - Inlet)	7A030
Tube (Air Cleaner Outlet)	9B659	Tube (Oil Cooler - Outlet)	7A031
Tube (Air Cleaner To Intake Manifold)	9B697	Tube (Oil Cooler Outlet)	6B749
Tube (Air Conditioner Compressor Oil Inlet)	19D645	Tube (Oil Cooler)	7A031
Tube (Air Suspension)	5A911	Tube (Oil Distributor Sleeve)	7D000
Tube (Anti-Backfire Valve Vacuum)	9H563	Tube (Oil Distributor)	7D000
Tube (Automatic Air Leveler Compressor To Valve)	5A718	Tube (Oil Filler Stub Case)	7N463
Tube (Blower Housing To Blower Motor)	19A786	Tube (Oil Filler)	7A228
Tube (Carburetor Air Cleaner Inlet)	9B632	Tube (Oil Pressure Regulator)	7A208
Tube (Carburetor Altitude Compensator Connector)	9F702	Tube (Power Brake Booster Connecting)	2B052
Tube (Clutch & Governor Oil Distributor) - Front	7A173	Tube (Power Steering Gear Rack)	3K762
Tube (Clutch & Governor Oil Distributor) - Rear	7A174	Tube (Rear Axle Torque)	4K605
Tube (Clutch And Governor Oil Distributor)	7A170	Tube (Rear Lube Oil Transfer)	7G084
Tube (Compensator Pressure Oil)	7A206	Tube (Rev. Clutch Apply-Oil Transfer)	7G199
Tube (Crankcase Ventilation)	6758,6759	Tube (Servo Apply Oil Transfer)	7G087
Tube (Distributor Vacuum)	12226	Tube (Servo Release Oil Transfer)	7G088
Tube (Egr Cooler-Inlet)	9F468	Tube (Thermostatic Choke Control Inlet)	9820
Tube (Egr Cooler-Outlet)	9F469	Tube (Thermostatic Choke Control Outlet)	9819
Tube (Engine To Transmission Vacuum Front Or Rear)	7B095	Tube (Transfer Vacuum)	9C789
Tube (Engine To Transmission Vacuum)	7B084	Tube (Transmission Breather)	7A246
Tube (Exhaust Air Supply Cleaner Outlet)	9B427	Tube (Transmission Oil Cooler Inlet And Outlet)	7A030
Tube (Exhaust Control Valve Vacuum)	9E488	Tube (Turbocharger Crossover)	9D428
Tube (Front Band Servo)	77379,7D469	Tube (Turbocharger Oil Return)	9G441
Tube (Front Pump)	7B473	Tube (Turbocharger Oil Supply)	9G440
Tube (Fuel Air Assist)	9S587	Tube (Turbocharger To Throttle Body)	9F695
Tube (Fuel Front)	9A318	Tube (Vacuum High Temperature)	9A428
Tube (Fuel Return Rear)	9G291	Tube (Vacuum)	9D434
Tube (Fuel Tank Vent To Storage Canister)	9A228	Tube (Vent)	9N276
Tube (Fuel Vapor Return)	9B337	Tube (Water By-Pass)	8555
Tube (Fuel Vapor Separator To Fuel Tank Front)	9C288	Tube (Water Turbo Charge Inlet)	8A505
Tube (Fuel Vapor Separator To Fuel Tank Rear)	9C289	Tube (Water Turbo Charge Outlet)	8A520
Tube (Fuel)	9291	Tube And Duct Assy. (Engine Air Cleaner Intake)	9A673
Tube (Governor Feed Oil Transfer)	7G086	Tube Assembly (Exhaust System Flex)	5G203
Tube (Governor Inlet - Inner)	7A170	Tube Assembly (P/S Pump Inlet)	3C633
Tube (Governor Inlet - Outer)	7A174	Tube Assy (Eng Charge Air Cooler Outlet)	6F073
Tube (Governor Oil Feed)	7A173	Tube Assy (Fuel Supply And Return Rear)	9J337

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
T — Cont'd		T — Cont'd	
Tube Assy. (Fuel Supply)	9J280	Tube Assy. (Fuel Return Intermediate)	9J296
Tube Assy. (Eng. Charge Air Cooler Inlet)	6F072	Tube Assy. (Fuel Return To Tank)	9A337
Tube Assy. (Air By-Pass Valve Inlet)	9H308	Tube Assy. (Fuel Return To Tank-Rear)	9C318
Tube Assy. (Air Cleaner Inlet Rear)	9N676	Tube Assy. (Fuel Return)	9A564
Tube Assy. (Air Conditioner Compressor Inlet)	19997	Tube Assy. (Fuel Supply & Return-Dual)	9H334
Tube Assy. (Air Conditioner Compressor Outlet)	19E631	Tube Assy. (Fuel Supply & Vapor)	9S284
Tube Assy. (Anti-Backfire Valve)	9B291	Tube Assy. (Fuel Supply - Return & Vapor)	9J279
Tube Assy. (Brake Anti-Lock - Bundle)	2C296	Tube Assy. (Fuel Supply, Vapor, Return & Brake)	9L291
Tube Assy. (Brake Fluid Distributor)	2C287	Tube Assy. (Fuel Tank Outlet)	9236
Tube Assy. (Brake Master Cylinder Outlet Rear)	2B253	Tube Assy. (Fuel Tank Vent)	9A086
Tube Assy. (Brake Master Cylinder To Connector)	2A040	Tube Assy. (Fuel Tube-Rear)	9327
Tube Assy. (Brake Master Cylinder To Rear Brake Tube Connector)	2A199	Tube Assy. (Fuel Vapor & Brake)	9S294
Tube Assy. (Brake Pressure Control Valve Inlet)	2B112	Tube Assy. (Fuel Vapor Canister Inlet)	9D673
Tube Assy. (Brake Pressure Control Valve Outlet)	2B113	Tube Assy. (Fuel Vapor Return)	9G271
Tube Assy. (Brake Pressure Metering Valve Inlet)	2B162	Tube Assy. (Fuel Vapor Storage Canister Inlet)	9E616
Tube Assy. (Brake And Fuel Line)	2265	Tube Assy. (Fuel Vapor Storage Canister Purge Outlet)	9D668
Tube Assy. (Camshaft Lubrication)	6578	Tube Assy. (Fuel Vapor Storage Canister Purge)	9D667
Tube Assy. (Carburetor Air Cleaner Hot Air)	9652	Tube Assy. (Fuel Vapor)	9B085
Tube Assy. (Carburetor Air Cleaner Intake)	9A624	Tube Assy. (Fuel)	9289
Tube Assy. (Carburetor Inlet)	9D283	Tube Assy. (Fuel-Rear)	9B324
Tube Assy. (Clutch Cylinder)	7T502	Tube Assy. (Intake Manifold Heater Inlet Tube)	9D424
Tube Assy. (Egr Outlet)	9D462	Tube Assy. (Intake Manifold Heater Inlet)	9N445
Tube Assy. (Egr To Back Pressure Valve)	9F459	Tube Assy. (Intake Manifold)	9C482
Tube Assy. (Egr Transducer)	9J429	Tube Assy. (Lower Clutch Slave Cyl.)	7T502
Tube Assy. (Engine Air Intake Resonator Inlet)	9F765	Tube Assy. (Manifold Outlet To Fuel Regulator Vacuum)	9F731
Tube Assy. (Engine Air Outlet)	9B647	Tube Assy. (Manifold Outlet Vacuum)	9F730
Tube Assy. (Exhaust Air Supply Check Valve)	9B480	Tube Assy. (Oil Cooler By-Pass)	7A254
Tube Assy. (Exhaust Air Supply Manifold)	9B449	Tube Assy. (Oil Cooler Return)	6K831
Tube Assy. (Exhaust Air Supply Pump Outlet)	9B457	Tube Assy. (Oil Cooler)	7A031,7E078
Tube Assy. (Exhaust Recirculating Valve To Exhaust Manifold)	9D477	Tube Assy. (Oil Level Indicator)	6754
Tube Assy. (Front Brake Tube To Differential Valve)	2B269	Tube Assy. (Oil Pump)	6615
Tube Assy. (Front Brake)	2263,2A361	Tube Assy. (Power Steering Reservoir Filler)	3F549
Tube Assy. (Front Disc Brake Caliper Inlet)	2B166	Tube Assy. (Radiator Lower Hose)	8291
Tube Assy. (Front Suspension)	5A897	Tube Assy. (Relief Discharge)	9A171
Tube Assy. (Fuel Filter Inlet)	9A322	Tube Assy. (Speed Control Vacuum Supply)	9C764
Tube Assy. (Fuel Filter Supply)	9A274	Tube Assy. (Steering Column)	3514
Tube Assy. (Fuel Filter To Fuel Pump)	9B273,9C330	Tube Assy. (Thermostatic Choke Heater)	9C869
Tube Assy. (Fuel Flow Sensor Inlet)	9J284	Tube Assy. (Transmission Column Shift Selector)	7212
Tube Assy. (Fuel Flow Sensor Outlet)	9J285	Tube Assy. (Vacuum Mtr. To Control)	7A785
Tube Assy. (Fuel Front)	9308	Tube Assy. (Vacuum Pump Distribution)	9J445
Tube Assy. (Fuel Injection)	9A555	Tube Assy. (Water Pump Inlet)	8290
Tube Assy. (Fuel Line)	9A312,9D333	Tube Assy. - Brake Main	2286
Tube Assy. (Fuel Outlet Return Line)	9D287	Tube Assy. - Fuel Inlet	9A321
Tube Assy. (Fuel Pressure Regulator Vacuum)	9F728	Tube Assy. Brake Booster	2420
Tube Assy. (Fuel Pump To Fuel Vapor Separator)	9C372	Tube Assy. Clutch Slave Cyl. To Clutch Master Cyl.	7A512

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
T — Cont'd		V — Cont'd	
Tube Assy.(Fuel Supply Return & Vapor Front)	9S286	Valve (3-2 Kick Down)	7D054
Tube Assy.(Fuel Supply Return & Vapor-Rear)	9S278	Valve (3-4 Shift)	7F259
Tube Assy.(Fuel)	9369	Valve (Air Cleaner Vacuum Control Delay)	9E897
Tube Assy.(Rear Brake)	2267	Valve (Air Conditioner Evaporator Expansion)	19849
Tube Main (Oil Pressure)	77469	Valve (Air Conditioner Vacuum Check)	19A563
Tube And Bolt Assy. (Exhaust Air Supply-Thermactor)	9A484	Valve (Carburetor Air Cleaner Temperature Sensor)	9E862
Tube And Shield Assy. (Fuel Vapor Storage Canister)	9E879	Valve (Carburetor Air Cleaner Vacuum Control)	9A995
Tube Or Hose (Water By-Pass)	8548	Valve (Converter Relief)	7E217
Tube(Vent)	9A085	Valve (Exhaust)	6505
Tube(Water Supply)	8A504	Valve (Fuel Sender Check)	9H318
Tubing (Brake And Fuel Line)	2269	Valve (Governor Primary)	7C054
Tunnion (Gearshift Lever)	7B108	Valve (Heater Water Control)	18495
Turbine Housing Bolt Kit (Turbocharger)	9G486	Valve (Intake)	6507
Turbine Housing And Elbow Kit (Turbocharger)	9G484	Valve (Interm. Servo Accumulator Check)	7D376
Turbocharger Assy.	9G438	Valve (Lube)	7D174
Turret Assy. (Shifter)	7F305	Valve (Main Valve Body Manual Control)	7C389
Throttle Positioner & Bracket Assy.	9S552	Valve (Positive Crankcase Ventilation)	6A666
Timer Assy. (E.G.R. Solenoid Valve)	9J427	Valve (Temperature Regulator)	18502
Tube (Accelerator Pump Transfer)	9A501	Valve (Throttle Control)	7D080
Tube (Float Bowl Connecting)	9534	Valve (Ventilation Headlamp)	13C126
Tube (Fuel Pressure Regulator)	9D909	Valve (Water By-Pass Kit)	8251
Tube (High Speed Air Bleeder)	9G540	Valve (Windshield Washer Control)	17A614
Tube (Main Well)	9991	Valve And Actuator Assy. E.G.R.)	9H473
Tube (Pump Passage)	9544	Valve And Cap Assy.	1700
Tube Assy. (Brake Anti-Lock)	2C296	Valve And Switch Assy. (Temperature Control Lockout)	18D371
Tube Assy. (Fuel Return & Brake)	9L291	Valve Assembly (Distributor Vacuum Control)	12A091
Tube Assy. (Fuel Supply & Vapor)	9S284	Valve Assy (Carburetor Air Cleaner Temperature Sensor Override)	9E862
Tube Assy. (Egr Valve To Exhaust Manifold)	9D477	Valve Assy (Exhaust Gas Recirculation Control)	9D473
Tune Up Kit (Carburetor)	9A586	Valve Assy.	9L490
Tune Up Kit (Fuel Injection)	9F652	Valve Assy. (Air By-Pass Thermactor)	9B289
Turbocharger Assy.	9G438	Valve Assy. (Air Cleaner Duct Vacuum Control Delay)	9E897
U		Valve Assy. (Air Conditioner Compressor Low Pressure)	19752
U Washer (Rear Axle Shaft Retaining)	4N237	Valve Assy. (Air Conditioner Compressor Pressure Relief)	19D644
U-Bolt (Rear Spring)	5705	Valve Assy. (Air Conditioner Compressor)	19A990
U-Bolt (Rear)	5L705	Valve Assy. (Air Conditioner Evaporator Suction Throttle)	19D580
U/Jt. Kit (Rear Axle Shaft Universal)	4249	Valve Assy. (Anti-Backfire)	9B298
Universal Joint Kit (Driveshaft)	4635	Valve Assy. (Brake Master Cylinder Fluid Control)	2C161
Universal Joint Kit (Front Axle Shaft)	3249	Valve Assy. (Brake Pressure Control)	2B091
Universal Joint Kit (Transaxle)	4635	Valve Assy. (Brake Pressure Differential)	2B257
Use With 10A303 Bearing (Front)	10094	Valve Assy. (Carburetor Air Cleaner Vacuum Control)	9A995
Used Car Reconditioning Materials Canadian Usage	P0008	Valve Assy. (Carburetor Float Bowl Vent)	9E589
Used Car Reconditioning Materials U.S. Usage	P0007	Valve Assy. (Carburetor Solenoid Vacuum)	9B998
V		Valve Assy. (Crankcase Ventilation)	6769
Vacuum Reservoir (Speed Control)	9E799	Valve Assy. (Deceleration)	9K793
Valve & Bracket Assy. (Exhaust Air Supply)	9G442	Valve Assy. (Distributor Modulator)	12A170

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
V — Cont'd		V — Cont'd	
Valve Assy. (Distributor Retard Control)	12A208	Valve And Seal Assy. (Heater)	18B669
Valve Assy. (Distributor Vacuum And Vent Control)	12A226	Valve And Transducer Assy. (Egr Back Pressure)	9H495
Valve Assy. (Distributor Vacuum Control Check)	12A197	Valve(Egr Modulator)	9F452
Valve Assy. (E G R Vacuum Load Control)	9F424	Vent (Case)	7034
Valve Assy. (E.G.R. Solenoid Vacuum)	9D474	Vent (Rear Axle Housing)	4022
Valve Assy. (Egr Pressure External)	9F483	Vent Assy. (Relief Discharge)	9170
Valve Assy. (Egr Pressure Internal)	9F482	Venturi Assy. (Air Conditioner Evaporator Air Control)	19E628
Valve Assy. (Egr)	9D460	Valve (Accelerator Pump Check)	9576
Valve Assy. (Engine Idle Speed Control Solenoid Vacuum)	12B507	Valve (Air By-Pass)	9A565
Valve Assy. (Exhaust Air Supply Check)	9A487	Valve (Fuel Return Check)	9576
Valve Assy. (Exhaust Air Supply Control)	9F491	Valve (Pump Discharge)	9572,9576
Valve Assy. (Exhaust Gas Recirculation Vacuum)	9F489	Valve (Vent)	9D583
Valve Assy. (Exhaust Gas Recirculation)	9D475	Valve (Venturi Air By-Pass)	9A936
Valve Assy. (Exhaust Heat Control)	9A427	Valve (Venturi)	9A938
Valve Assy. (Fuel Line Shut Off)	9N176	Valve And Seal Assy. (Fuel Inlet)	9564
Valve Assy. (Fuel Pressure Relief)	9H321	Valve And Seat Assy. (Fuel Inlet)	9564
Valve Assy. (Fuel Vapor Line Shut Off)	9G332	Valve And Seat Assy. (Fuel Inlet)-Incl. Gasket	9564
Valve Assy. (Fuel Vapor Storage Canister Purge Regulator)	9C915	Valve Assy. (Accelerator Pump Temp. Comps.)	9902
Valve Assy. (Fuel Vapor Storage Canister)	9B963	Valve Assy. (E.G.R. Pressure External)	9F483
Valve Assy. (Fuel Vapor)	9B593	Valve Assy. (E.G.R. Pressure External)- Less Evp-Sensor	9H473
Valve Assy. (Headlamp Cover Vacuum Check)	13B064	Valve Assy. (Float Bowl Vent)	9E589
Valve Assy. (Intake Manifold Heat Control)	9G464	Valve Assy. (Float Bowl)	9E589
Valve Assy. (Intake Manifold Pressure Relief)	9J461	Valve Assy. (Fuel Bowl Vent)	9557
Valve Assy. (Integral E.G.R. And Backpressure-Transducer)	9D448	Valve Assy. (Fuel Enrichment)	9A565
Valve Assy. (Power Steering Hydraulic Control)	3A730	Valve Assy. (Fuel Press. Relief)	9H321
Valve Assy. (Power Steering Pump)	3A561	Valve Assy. (Metering)	9N542
Valve Assy. (Power Strg. Check)	3N603	Valve Assy. (Power)	9594
Valve Assy. (Speed Control Metering)	9C727	Valve Assy. (Anti-Backfire)	9B298
Valve Assy. (Speed Control Vacuum)	9C793	Valve Assy. (Fuel Vapor Storage Canister)	9B963
Valve Assy. (Thermactor Air Control Solenoid Vacuum)	9H465	Valve Assy. (Fuel Vapor)	9B593
Valve Assy. (Thermactor Idle Vacuum)	9G328	Valve Kit (Fuel Inlet)	9564
Valve Assy. (Thermactor Vacuum Vent Control)	9H301	Valve And Transducer Assy. (E.G.R. Back Pressure)	9H495
Valve Assy. (Throttle Air Control By-Pass)	9F715	Valve Assy. (E.G.R. Vacuum Control Gradient)	9F489
Valve Assy. (Vacuum Control Module)	9J451	Valve Assy. (E.G.R. Pressure Internal)	9F482
Valve Assy. Brake Load Sensor Proportioning	2B547	Valve Assy. (E.G.R. Solenoid Vacuum)	9D474
Valve Block Brake Pressure Control	2C266	Valve Assy. (E.G.R. Vacuum Control)	9D473
Valve Body Assy. (Main Control)	7A100	Valve Assy. (E.G.R. Vacuum Load Control)	9F424
Valve Kit (1-2 Shift)	7F417	Valve Assy. (E.G.R.)	9D475
Valve Kit (Oil Pressure Regulator)	7B025	Valve Assy. (Air Cleaner Vacuum Control Delay)	9E897
Valve Kit (Power Steering Gear Rear Check Valve)	3D728	Valve Assy. (Carb. Air Cleaner Vacuum Control)	9A995
Valve Kit (Throttle Pressure Limit)	7E368	Valve Assy. (Carburetor Solenoid Vacuum)	9B998
Valve Plate (Air Conditioner Replacement Kit)	19B685	Valve Assy. (Distributor Modulator)	12A170
Valve Repair Kit (Power Steering Hydraulic Control)	3A650	Valve Assy. (Distributor Retard Control)	12A208
Valve And Hose Assy. (Exhaust Air Supply Control)	9H448	Valve Assy. (Distributor Vacuum And Vent Control)	12A226
Valve And Seal Assy. (Heater Air Temperature Control)	18K413	Valve Assy. (Distributor Vacuum Control)	12A091

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
V — Cont'd		W — Cont'd	
Valve Assy. (Exhaust Heat Control)	9A427	Washer (Drive Thrust)	11036
Valve Assy. (Fuel Vapor Storage Canister Purge Regulator)	9C915	Washer (Driven Sprocket Support Thrust-Rear) - Selective Fit	7G273
Valve Assy. (Intake Manifold Heat Control)	9G464	Washer (Driven Sprocket-Thrust)	7G115
Valve Assy. (Integral E.G.R. And Back Pressure-Transducer)	9D448	Washer (Driveshaft Assy.)	4M817
Valve Assy. (Thermactor Air By-Pass)	9B289	Washer (Fan Hub Retaining)	8K653
Valve Assy. (Thermactor Air Control Solenoid Vacuum)	9H465	Washer (Forward Clutch Hub Thrust)	7D090
Valve Assy. (Thermactor Check)	9A487	Washer (Forward Cylinder)	7D090
Valve Assy. (Thermactor Control)	9A491,9F491	Washer (Forward Cylinder)-Also Refer To Group 7A045	7D090
Valve Assy. (Thermactor Idle Vacuum)	9G328	Washer (Front Clutch Hub To Input Shaft Thrust)	77577
Valve Assy. (Thermactor Vacuum Vent Control)	9H301	Washer (Front Clutch Sun Gear Thrust)	7D484
Valve Assy. (Throttle Air By-Pass)	9F715	Washer (Front Fender Splash Shield)	15N411
Valve Assy. (Vacuum Control Check)	12A197	Washer (Front Pump And Center Support Thrust)	7D014
Valve Assy. (Vacuum Control Module)	9J451	Washer (Front Pump Support Thrust) Selective Fit	7D014
Valve Assy.(Air Cleaner Temperature Sensor Override)	9E862	Washer (Front Support Thrust)	7D014
W		Washer (Front Support Thrust) Selective Fit	7D014
W/A Engine Control Module	12K510	Washer (Front Suspension)	3A141,5Z318
Warmer (Car Interior)	18A454	Washer (Front Wheel Outer Bearing Retainer)	1195
Washer	9154	Washer (Fuel Injection Sealing)	9E529
Washer (1St & 2Nd Speed Syn. Thrust)	7117	Washer (Fuel Injector Heat Shield Seal)	9R524
Washer (5Th Speed Synchronizer)	7N037	Washer (Inner Tie Rod)	3Z280
Washer (5Th & Reverse Gear Shift Lever)	7D448	Washer (Input Shaft Thrust)	7019
Washer (5Th & Reverse Syn. - Thrust)	7R482	Washer (Input Shell Thrust)	7D066
Washer (Air Cleaner Retention)	9B690	Washer (Low Oil Level Sensor)	6C626
Washer (Air Conditioner Register Mounting)	19C624	Washer (Manual Shaft)	7Z037
Washer (Axle Differential Side Gear Thrust)	4228	Washer (O/Drv. Overrunning Clutch)	7L339
Washer (Bumper Bolt)	17B838	Washer (One Way Clutch Thrust)	7G400
Washer (Camshaft Sprocket)	6278	Washer (Output Shaft 1St Gear Thrust)	7071
Washer (Center Support Thrust)	7L326	Washer (Output Shaft Hub Thrust)	7D422
Washer (Chain Cover Thrust)	7G096	Washer (Output Shaft Thrust Rear)	7B368
Washer (Clutch And Brake Pedal To Shaft Spring)	7512	Washer (Output Shaft Thrust)	7A385
Washer (Concaved)	5Z994	Washer (Park Rod)	7N357
Washer (Constant Mesh Low Gear)	7071	Washer (Parking Lamp)	13W341
Washer (Control Cable Bracket)	7C487	Washer (Pinion Thrust)	11036
Washer (Countershaft Cluster Gear)	7119	Washer (Planet Carrier Thrust)	7A166
Washer (Countershaft Gear Thrust)	7119	Washer (Planet Gear Bearing Thrust)	7F368
Washer (Countershaft Rear Bearing - Thrust)	7L324	Washer (Planet Pinion Thrust)	7A242
Washer (Countershaft Rev. Gear - Thrust)	7C340	Washer (Rear Axle Differential Pinion Thrust)	4230
Washer (Crankshaft Main Bearing Thrust)	6A355	Washer (Rear Clutch Sun Gear Inner Thrust)	77524
Washer (Crankshaft Pulley Retaining)	6378	Washer (Retainer Front Axle Wheel Hub)	3Z499
Washer (Cylinder Head Bolt)	6L015	Washer (Reverse Drum Thrust)	7C096
Washer (Diff. Carrier Thrust)	7G103	Washer (Reverse Drum To Case)	7D072
Washer (Diff. Carrier Thrust) Selective Fit	7G103	Washer (Reverse Idler Gear Thrust)	7149,7N037
Washer (Direct Clutch Cyl. Thrust)	7F369	Washer (Second Gear)	7119
Washer (Direct Clutch Inner Brg.)	7F237	Washer (Shift Lever)	7Z120
Washer (Drive Sprocket Thrust)	7G099	Washer (Steering Column Socket Thrust)	3C708

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
W — Cont'd		W — Cont'd	
Washer (Sun Gear Thrust)	7D484	Wire Assy. (Backup Lamp Switch To Rear Lamp Feed)	15525
Washer (Throttle Control Lever Pivot)	9N744	Wire Assy. (Block Heater)	6B018
Washer (Thrust) - Selective Fit	7D014	Wire Assy. (Body Side Lamp Or Cornering Lamp)	15B411
Washer (Transaxle Differential Pinion Thrust)	4230	Wire Assy. (Brake Skid Control)	2C055
Washer (Transaxle Side Gear Thrust)	4228	Wire Assy. (Brake Warning Indicator)	2N248
Washer (Valve Rocker Arm Fulcrum)	6K559	Wire Assy. (Cigar Lighter Jumper)	15A056
Washer (Valve Rocker Arm Shaft)	6598	Wire Assy. (Cigar Lighter)	14K006
Washer (Valve Spring)	6K515	Wire Assy. (Circuit Breaker Feed)	15A669
Washer (Vent Cap)	7035	Wire Assy. (Clock Feed)	15A006
Washer (Windshield Washer)	17B551	Wire Assy. (Clock)	15026
Washer (Wiper Pivot Shaft)	17N430	Wire Assy. (Connector)	14370
Washer Kit (Rear Window Wiper - Motor)	17C407	Wire Assy. (Courtesy Lamp Feed)	13B712
Washer Kit (Reverse Clutch Hub Thrust)	7D091	Wire Assy. (Courtesy Lamp)	13B711
Washer Rear Wheel Nut Locking Pinion	1124	Wire Assy. (Dash Panel To Headlamp Junction)	14290
Washer(Grommet Spring)	6A532	Wire Assy. (Dash To Engine Gauge Feed)	14289
Wedge (Rear Axle Adjusting)	5A313	Wire Assy. (Distributor Lead)	12216
Weight (Driveshaft Flange Balance)	4K222	Wire Assy. (Distributor To Spark Plug)	12286
Weight (Governor)	7D324	Wire Assy. (Door Lock Feed Extension)	14A584
Weight (Wheel Balance)	1040	Wire Assy. (Door Lock Feed)	14240
Wheel (Driven Sprocket Speed Sensor)	7H150	Wire Assy. (Door Lock Lead)	14A412
Wheel (Heater Blower)	18504	Wire Assy. (Door Lock Switch Jumper)	14A631
Wheel (Mini Spare)	1K007	Wire Assy. (Engine Control Sensor Extension)	12A522
Wheel Assy.	1007	Wire Assy. (Engine Coolant Temperature Sensor)	12A654
Wheel Assy. (Air Conditioner Blower)	19834	Wire Assy. (Engine To Frame)	14324
Wheel Assy. (Steering)	3600	Wire Assy. (Flasher Warning Lamp)	13R318
Wheel Bearings	4000	Wire Assy. (Fog Lamp Jumper)	14369
Wheel Illustrations	1K007.	Wire Assy. (Fuel Shut Off Solenoid Feed)	9A451
Wheel Kit	1K013	Wire Assy. (Fuel Vapor Purge Solenoid Jumper)	9F759
Wheel Kit (Mini-Spare)	1K007	Wire Assy. (Fuse Junction Panel Feed)	14516
Wheel Nut Kit (Anti-Theft)	1A043	Wire Assy. (Garage Door Actuator)	19A336
Wiper Assy. (Windshield)	17500	Wire Assy. (Glove Compartment Feed)	14A007
Wire	14296	Wire Assy. (Glow Plug)	9A451
Wire (Oil Pressure Indicator Sender Jumper)	9F316	Wire Assy. (Ground)	13N850
Wire (Top Control Feed Jumper)	15A690	Wire Assy. (Headlamp Dimmer Jumper)	13A090
Wire Assy. (A/C Pressure Cut-Off)	19E753	Wire Assy. (Ignition Jumper)	14K082
Wire Assy. (A/C Thermo To Clutch)	19A885	Wire Assy. (Luggage Compartment Lamp)	14A227
Wire Assy. (Accessory Feed)	14A318	Wire Assy. (Main-Jumper)	14A411
Wire Assy. (Air Conditioner Compressor Clutch)	19C602	Wire Assy. (Manifold Absolute Pressure Sensor)	9J443
Wire Assy. (Alternator)-2 1/2" Long	10C307	Wire Assy. (O/Drv. Control)	7E276
Wire Assy. (Ash Receptacle Lamp Fd)	14A012	Wire Assy. (Oil Pressure Indicator Switch)	9F291
Wire Assy. (Automatic Seat Back Latch)	14B724	Wire Assy. (Radio Feed)	18A919
Wire Assy. (Automatic Temperature Control Switch Jumper)	19D570	Wire Assy. (Radio Rear Seat Speaker Extension)	14574
Wire Assy. (Auxiliary Battery Feed)	10K699	Wire Assy. (Radio Receiver Tuner)	14588
Wire Assy. (Back Window Heater Ground)	18C618, 18C620	Wire Assy. (Rear Window Wiper And Washer)	17K400
Wire Assy. (Backup Lamp Socket)	15536	Wire Assy. (Roof Sliding Panel Extension)	15C670

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
W — Cont'd		W — Cont'd	
Wire Assy. (Roof Sliding Panel Feed)	15B673	Wiring Assy. (Air Conditioner Automatic Throttle Control)	19739
Wire Assy. (Rpm Sensor)	7F040	Wiring Assy. (Air Conditioner Blower Motor Feed)	19949
Wire Assy. (Seat Back Latch Extension)	14C691	Wiring Assy. (Air Conditioner Blower Motor Switch Feed)	19945
Wire Assy. (Seat Back Latch)	14C692	Wiring Assy. (Air Conditioner Clutch Coil Lead)	19B573
Wire Assy. (Seat Belt Retractor)	14A380	Wiring Assy. (Air Conditioner Compressor Clutch)	19D950
Wire Assy. (Seat Regulator Feed)	14716	Wiring Assy. (Air Conditioner)	19C603
Wire Assy. (Sliding Roof Control)	15A657	Wiring Assy. (Air Spring Suspension Pressure Indicator Switch)	12614
Wire Assy. (Speed Control Connector)	9D821	Wiring Assy. (Air Spring Suspension Pressure Switch-Jumper)	14B101
Wire Assy. (Speed Control Feed)	9A839	Wiring Assy. (All Wheel Drive Relay To Solenoid)	14B110
Wire Assy. (Speed Control)	9A840	Wiring Assy. (All Wheel Drive Switch To Relay)	14B109
Wire Assy. (Starter Motor Relay To Solenoid)	11A004	Wiring Assy. (Alternator Ground Extension)	10C320
Wire Assy. (Starter Relay Jumper)	11A001	Wiring Assy. (Alternator Rectifier Jumper)	14A676
Wire Assy. (Tester)	9C877	Wiring Assy. (Alternator To Voltage Regulator)	14305
Wire Assy. (Throttle Modulator Extension)	9B911	Wiring Assy. (Back Window Heat Control)	18C617
Wire Assy. (Trailer Brake Control Switch)	14A348	Wiring Assy. (Back Window Heat Feed)	18C619
Wire Assy. (Transmission Control Selector Indicator Jumper)	15A814	Wiring Assy. (Back Window Regulator)	14687
Wire Assy. (Transmission Control Selector Indicator Lamp)	15A808	Wiring Assy. (Body Main)	14A005
Wire Assy. (Vanity Mirror Lamp Feed)	17C710	Wiring Assy. (Brake Anti Skid)	2C054
Wire Assy. (Warning Indicator Extension)	14A382	Wiring Assy. (Brake Control Switch)	2B325
Wire Assy. (Water Temperature Indicator)	10B886	Wiring Assy. (Brake Warning Lamp)	10K845
Wire Assy. (Window Regulator Jumper)	14A630	Wiring Assy. (Carburetor Choke)	9E692
Wire Assy. (Window Regulator-Jumper)	14A488	Wiring Assy. (Carburetor Emission Control Solenoid Ground)	9P664
Wire Assy. Connector	2C011	Wiring Assy. (Carburetor Emission Control Solenoid)	9D857
Wire Assy. Kit (Windshield Wiper Motor)	17C504	Wiring Assy. (Carburetor Idle Thermactor Air Dump Switch)	9E962
Wire Assy. Taillamp Converter Kit (Utility Trailer)	19A407	Wiring Assy. (Carburetor Throttle Module Control)	9E724
Wire Harness (A/C Fan Override)	19D603	Wiring Assy. (Coach Lamp Feed)	15B465
Wire Harness (Blower)	18W586	Wiring Assy. (Control Mobile Telephone)	14A649
Wire Harness (Oil Pressure)	9B278	Wiring Assy. (Courtesy Lamp Jumper)	13B767
Wire Set (Spark Plug)	12259	Wiring Assy. (Courtesy Lamp Switch Extension)	13A724
Wire And Connector Assy. (Distributor And Electronic Ignition Switch Repair)	14A614	Wiring Assy. (Courtesy Or Interior Lamp Switch)	13A709
Wire And Switch Assy. (Vacuum Pump Motor)	2C925	Wiring Assy. (Cylinder Identification Sensor Jumper)	14B067
Wiring (Air Conditioner Jumper)	19D887	Wiring Assy. (Dash Panel To Engine & Alternator Rectifier Wiring-Jumper)	14A676
Wiring (Front Window Regulator)	14630	Wiring Assy. (Dash Panel To Headlamp Junction Extension)	14A408
Wiring (Gearshift Position Switch)	7D307	Wiring Assy. (Door Lock Cylinder Light)	13C724
Wiring (Instrument Cluster)	10B942	Wiring Assy. (Door Open Warning Lamp)	14790,14792
Wiring (Jumper Radio Receiver)	18B971	Wiring Assy. (Door Open Warning Switch Jumper)	10D972
Wiring (Radio Receiver To Rear Seat Speaker)	18A900	Wiring Assy. (E.E.C. Air Sensor)	12B566
Wiring (Rear Door Window Regulator)	14632	Wiring Assy. (E.E.C. Processor Ground)	12B561
Wiring (Starter Motor Circuit Jumper Extension)	11A103	Wiring Assy. (Egr Solenoid Valve Timer)	9J428
Wiring (Trailer Wiring Feed)	13A576	Wiring Assy. (Electric Antenna)	18998
Wiring (Warning Lamp Indicator Panel)	10B923	Wiring Assy. (Emission Vacuum Control)	9S453
Wiring And Connector Assy. (Windshield Washer Pump)	17A622	Wiring Assy. (Engine Compartment Lamp Feed)	15A702
Wiring Assy. (A/C Control Switch)	19A642	Wiring Assy. (Engine Control Sensor Extension)	12A690
Wiring Assy. (Air Bag & Anti-Lock Bezel)	14B175	Wiring Assy. (Engine Control Sensor)	12A581
Wiring Assy. (Air Bag)	14B095	Wiring Assy. (Exhaust Emission Control)	9K499

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
W — Cont'd		W — Cont'd	
Wiring Assy. (Fan Motor To Idle Tracking Relay)	14K095	Wiring Assy. (Radiator Cooling Fan Motor)	14K095
Wiring Assy. (Flash Lamp Recharge)	13C747	Wiring Assy. (Radio Amplifier)	19B113
Wiring Assy. (Fog Lamp Switch Feed)	15223	Wiring Assy. (Radio Extension)	18W862
Wiring Assy. (Fog Lamp)	15A211	Wiring Assy. (Radio Feed Jumper)	19B107
Wiring Assy. (Front Seat Back Pad Adjuster Jumper)	14B122	Wiring Assy. (Radio Interference Suppression Capacitor)	18A832
Wiring Assy. (Fuel Charging)	9D930	Wiring Assy. (Radio Power Boost & Equalizer Amplifier)	18B864
Wiring Assy. (Fuel Filler Door Lock)	9B243,9B244	Wiring Assy. (Radio Rear Seat Speaker Connector)	18A901
Wiring Assy. (Fuel Flow Sensor)	10D964	Wiring Assy. (Radio Speaker Extension)	19A123
Wiring Assy. (Fuel Pump Feed Jumper)	9A340	Wiring Assy. (Radio Speaker Fader Control)	19A093
Wiring Assy. (Fuel Pump Feed)	9A350,9A400	Wiring Assy. (Radio Speaker Jumper)	19A170
Wiring Assy. (Fuel Tank Sender)	14406	Wiring Assy. (Radio Speaker)	19A041
Wiring Assy. (Fuel Tank Sender-Jumper)	14407	Wiring Assy. (Rear Hi-Mount Lamp)	13A625
Wiring Assy. (Fuel Valve Solenoid Control)	9E310	Wiring Assy. (Rear Interior Lamp)	13A710
Wiring Assy. (Fuse Holder Jumper)	14517	Wiring Assy. (Rear Lamp Extension)	14408
Wiring Assy. (Fuse Junction Panel)	14A080	Wiring Assy. (Rear Lamp Jumper)	13A412
Wiring Assy. (Headlamp Dimmer Switch Jumper)	14A320	Wiring Assy. (Rear Lamp)	14405
Wiring Assy. (Headlamp Leads)	13076	Wiring Assy. (Rear License Lamp Feed)	13B440
Wiring Assy. (Heated Windshield Feed)	18D274	Wiring Assy. (Rear License Plate Lamp)	13560
Wiring Assy. (Heated Windshield)	18D273	Wiring Assy. (Rear Window Defogger Switch Feed)	18C496
Wiring Assy. (Heater And Air Conditioner Blower Motor)	18B518	Wiring Assy. (Relay Feed)	14A303
Wiring Assy. (Heater Blower Motor Feed)	18B574	Wiring Assy. (Seat Back Control)	14B719
Wiring Assy. (Heater)	18B604	Wiring Assy. (Seat Belt Interlock Jumper)	14K691
Wiring Assy. (Horn Jumper)	13A840	Wiring Assy. (Seat Belt Retractor Jumper)	14A500
Wiring Assy. (Horn Warning Actuator Jumper)	13A941	Wiring Assy. (Seat Control Feed Jumper)	14A699
Wiring Assy. (Horn Warning Actuator)	13A929	Wiring Assy. (Seat Control Feed)	14C719
Wiring Assy. (Idle Solenoid Extension)	9D555	Wiring Assy. (Seat Regulator Control Processor)	14B152
Wiring Assy. (Ignition Coil Jumper)	12060	Wiring Assy. (Seat Regulator Relay Feed)	14A698
Wiring Assy. (Ignition Coil To Distributor High Tension)	12298	Wiring Assy. (Security Alarm Control)	19A205
Wiring Assy. (Ignition Feed Jumper)	14313	Wiring Assy. (Speed Control Extension)	9C887
Wiring Assy. (Indicator Lamp)	13A705	Wiring Assy. (Speed Control Switch)	9C891
Wiring Assy. (Inside Rear View Mirror)	17K745	Wiring Assy. (Speed Sensor)	9D878
Wiring Assy. (Instrument Cluster Feed)	10817	Wiring Assy. (Starter Circuit Jumper)	12638
Wiring Assy. (Interior Lamp Feed Jumper)	13A718	Wiring Assy. (Starter Switch To Transmission Lock Switch)	14693
Wiring Assy. (Interior Lamp)	14334	Wiring Assy. (Stop Lamp Switch Jumper)	13A427
Wiring Assy. (Light Sensor Feed)	13A106	Wiring Assy. (Temperature Sender Extension)	14K073
Wiring Assy. (Low Oil Indicator Lamp)	14032	Wiring Assy. (Thermactor Control Solenoid Vacuum Valve)	9J424
Wiring Assy. (Low Vacuum Warning Indicator Jumper)	10B847	Wiring Assy. (Thermostat Feed-Jumper)	14K078
Wiring Assy. (Luggage Compartment Lamp)	19B516	Wiring Assy. (Throttle Jumper)	14A595
Wiring Assy. (Luggage Compartment Remote Control Lock Extension)	14276	Wiring Assy. (Trailer Lamps)	15436
Wiring Assy. (Luggage Compartment Remote Control Lock)	19D542	Wiring Assy. (Tripminder Extension)	10D955
Wiring Assy. (Main)	14401	Wiring Assy. (Tripminder Feed)	10D954
Wiring Assy. (Message Center Indicator)	10K923	Wiring Assy. (Tripminder)	10D953
Wiring Assy. (Mobile Telephone Control)	14A469	Wiring Assy. (Warning Indicator)	14A313
Wiring Assy. (P/S Variable Assist Control)	3F720	Wiring Assy. (Warning Lamp Feed-Jumper)	14K067
Wiring Assy. (R/V Outside Mirror Control)	14A684	Wiring Assy. (Water Temp. Ind. Sender)	10A998

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
W — Cont'd		W — Cont'd	
Wiring Assy. (Window Regulator Front Door Jumper)	14B121	Water Temperature Switch	10884
Wiring Assy. (Window Regulator Rear Switch Feed)	14A027	Weight (Pump Discharge Ball)	9B511
Wiring Assy. (Window Regulator Safety Relay To Window Regulator Switch)	14A200	Weight (Pump Discharge)	9B511
Wiring Assy. (Windshield Wiper Intermittent Switch)	17K528	Wiper Assy. (Windshield)	17500
Wiring Assy. (Windshield Wiper Motor)	17A477	Wire Assy. (Cigar Lighter Jumper)	15A056
Wiring Harness Assy. (Engine Control)	12A580	Wiring Assy. (Air Bag & Anti-Lock Bezel)	14B175
Wiring Kit (Engine Cooling Fan)	8C290	Wiring Assy. (Fuel Charging)	9D930
Wiring And Socket (Rear License Lamp)	13412	Y	
Wiring And Socket Assy. (Ash Receptacle Lamp)	13A726	Yoke (Driveshaft Assy. Flange)	4866
Worm Gear And Rack Assy. (Steering Gear Input)	3524	Yoke (Driveshaft Center)	4784
Wrench (Jack Handle And Wheel Nut)	17032	Yoke (Driveshaft Centering Socket)	4782
Washer (Choke Connector Rod)	9S530	Yoke (Sector Shaft Support)	3F515
Washer (Choke Connector Rod-Anti-	9S530	Yoke Assy. (Case)	7B214
Washer (Locking-Special)	9568	Yoke Assy. (Front Axle Inner)	3K193
Washer (Pump Lever)	9A599	Yoke Assy. (Steering Column Lower)	3N725

INDEX

1

Included in the Paint Section are the following:

	U.S.	Page No.	Canada
Certification Label Information			
Exterior Paint Color Codes	2		2
Interior Paint Trim Codes	2		2
Paints, Thinners, etc.,			
Sealers and Undercoats	3		3
Specialties	3		3
Lacquers and Synthetic Enamels			
Interior Paints	3 thru 14		3 thru 14
Exterior Paints			
Listed by Certification Label Code	15 thru 18		15 thru 18
Appearance and Maintenance Materials			
Paints and Refinishing Materials	19		24
Cleaners, Waxes, and Polishes	19,20		24
Clear Vision Aids	20		24
Cooling System Aids	20		24,25
Motor Oils and Lubricants	20 thru 22		25,26
Sealers and Adhesives	22		26
Special Products	22 thru 24		26,27
Used Car Reconditioning Materials	28		28
Ford Specification No. to Part No.			
Cross Reference List	28 thru 30		

LIQUID MEASURE

1

Most liquid measures listed in this catalog are in U.S. sizes; however, those measures which are specified for unique Canadian parts are in Imperial or Metric sizes.

The capacity in ounces and litres for both U.S. and Imperial, measures are specified below:

	1/2 PT.	PINT	QUART	GALLON
Imperial	10 oz. (284.1 ml)	20 oz. (568.2 ml)	40 oz. (1.136 l)	160 oz. (4.55 l)
U.S.	8 oz. (236.6 ml)	16 oz. (473.1 ml)	32 oz. (.946 l)	128 oz. (3.78 l)

1

CERTIFICATION LABEL

MFD. BY FORD MOTOR CO. IN U.S.A.											
DATE:				GWR:				REAR GWR:			
FRONT GWR:											
THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY AND BUMPER STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE											
VEH. IDENT. NO.											
TYPE											
1						1					
EXTERIOR PAINT COLORS						DSO					
BODY	VR	MLDG.	INT. TRIM	A/C	R	S	AX	TR			
2											

1. Exterior paint coding
2. Interior trim code

EXTERIOR PAINT IDENTIFICATION

The 18 spaces, grouped in three sets of six each, provides for identification of up to three exterior colors on a vehicle. For vehicles (except Special Order) the major body color exterior paint code will be shown in the spaces to the left of the first set. On a tu-tone vehicle the secondary color will be listed in the second set. The third set will be used to identify the minor paint code on a vehicle using three exterior colors. See example A. Special order vehicles using M, WT or MX paint codes will have the entire number printed in the available spaces (with the exception of MX numbers). The prefix MX70 is simply reduced to X. See examples B, C and D.

Example A: Regular Production																	
9	A					1	C										
(Body Color)						(Tu-Tone Color)						(Accent Color)					
Example B: M numbers																	
M	1	3	2	6	A	M	1	5	2	4	A	M	1	7	2	4	H
Example C: WT numbers																	
W	T	2	0	0	7	W	T	4	0	4	0	W	T	8	3	0	6
Example D: MX numbers																	
X	0	1	4	0	6	X	4	1	4	0	6	X	0	1	3	9	5

INTERIOR TRIM CODES

The first digit of the interior trim code denotes type of fabric and seat type. The second digit identifies the color.

DESCRIPTION	PART NUMBER	DESCRIPTION	PART NUMBER
P0000 SEALERS and UNDERCOATS - PAINTS, THINNERS, ETC. U.S. and CANADIAN USAGE			
Primer/Filler-exterior--5 oz. aerosol spray-not available in Canada	AL81 1000-H	Plastic Primer-for polypropylene interior parts- 12 oz. aerosol can	E8AZ 19000-A
Lacquer primer-surfacer- medium gray --13 oz.spray can-not avail. in Canada - r/b AL81 1000-H (11/89)	★ M6J 12-H	Plastic primer-for polypropylene interior parts- 13 oz. aerosol can - r/b E8AZ 19000-A (11/89)	★ D7AZ 19000-B
Interior primer-interior parts of electron cure coated ABS plastic - - 13 oz. spray can	D7AZ 19000-C		

P0000 SPECIALTIES - PAINTS, THINNERS, ETC. U.S. and CANADIAN USAGE			
Paint Precleaner-multi-purpose -- 1 qt. child resistant container - N/R (6/91)	★ VC 542-A		
C O D E	INTERIOR TRIM COLOR	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P= Instrument Panel U/P= Upper Instrument Panel S/C= Steering column and console P/T= Package Tray I/C= Other Interior Components
			I/P U/P S/C P/T I/C
			INTERIOR PAINT COLOR PART NUMBER

P0002 LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE

Note: Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1980**A (Ford), MA (Mercury)**

			*	*	*	*	*	Black Black Metallic	★ M4J 1724-H 2083
B	Wedgewood Blue		I/P	U/P	S/C	P/T	I/C	Wedgewood Blue	★ 4117
D	Red		I/P	U/P	▲	P/T	I/C	Red Metallic Red	★ 4020 ★ 4056
F	Cordovan		I/P	U/P	S/C	P/T	I/C	Cordovan	M4J 4079-H
R	Pine		I/P	U/P	S/C	P/T	I/C	Pine	★ 4116
S	Dove Gray		I/P	U/P	S/C	P/T	■ □	Gray Metallic Dove Gray	★ 4051 ★ 4082
Y	Sand		I/P	U/P	S/C	P/T	□ ■	Sand (light) Sand (medium)	★ 4112 ★ 4115

D (Lincoln)

A	Black		*	*	*	*	*	Black Black Metallic	★ M4J 1724-H 2083
B	Midnight Blue				S/C	P/T	I/C	Charcoal Blue Metallic	★ 4121
D	Red				S/C	P/T	⊗ ⊕	Red Metallic Red	★ 4020 ★ 4056
N	White/Red				S/C	P/T	I/C	Red Metallic White	★ 4020 M4J 4076-H
Q	White/Blue				S/C	P/T	I/C	White Charcoal Blue Metallic	★ 4076 ★ 4121
R	Pine				S/C	P/T	I/C	Pine	★ 4116
S	Pewter				S/C	P/T	I/C	Pewter (medium) Pewter (light)	★ 4125 ★ 4128
T	Caramel				S/C	P/T	I/C	Caramel	★ 4129
U	Champagne				S/C	P/T	I/C	Champagne (medium) Champagne (light)	★ 4091 ★ 4092
W	White/Black		*	*	*	*	I/C	Black Black Metallic White	M4J 1724-H 2083 M4J 4076-H

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P = Instrument Panel U/P = Upper Instrument Panel S/C = Steering column and console P/T = Package Tray I/C = Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002 LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd
Note: Code column represents the 2nd digit of the vehicle Trim Code
 ▲ Steering column, Δ Console,
 * Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1980 — Cont'd

D (Lincoln) — Cont'd

Z	Vaquero				S/C	P/T	I/C	Vaquero	★	4113
4	White/Champagne				S/C	P/T	I/C	White Champagne (medium)	★	4076 4091
6	White/Pewter				S/C	P/T	I/C	White Pewter (medium)	★	4076 4125

F (Mustang),J (Capri)

A	Black		*	*	*	*	*	Black Black Metallic	★	M4J 1724-H 2083
B	Wedgewood Blue		I/P	U/P	S/C	P/T	I/C	Wedgewood Blue	★	4117
C	Bittersweet		I/P	U/P	S/C	P/T	I/C	Bittersweet	★	4130
D	Red		I/P	U/P	S/C	P/T	I/C	Red (medium)	★	4131
N	White/Red		I/P	U/P	S/C	P/T	I/C	White Red (medium)	★	4076 4131
Q	White/Blue		I/P	U/P	S/C	P/T	I/C	White Wedgewood Blue	★	4076 4117
T	Caramel		I/P	U/P	S/C	P/T	I/C	Caramel	★	4129
W	White/Black		*	*	*	*		Black Black Metallic White	★	M4J 1724-H 2083 4076
Z	Vaquero		I/P	U/P	S/C	P/T	I/C	Vaquero	★	4113
2	White/Caramel		I/P	U/P	S/C	P/T	I/C	White Caramel	★	4076 4129
9	White/Vaquero		I/P	U/P	S/C	P/T	I/C	White Vaquero	★	4076 4113

G (Granada),MG (Monarch)

			*	*	*	*	*	Black Black Metallic	★	M4J 1724-H 2083
B	Wedgewood Blue		I/P	U/P	S/C	P/T	I/C	Wedgewood Blue	★	4117
D	Red		I/P	U/P	S/C	P/T	I/C	Red Metallic	★	4020
F	Cordovan		I/P	U/P	S/C	P/T	I/C	Cordovan	★	4079
S	Dove Gray		I/P	U/P	S/C	P/T	I/C	Gray Metallic Dove Gray	★	4051 4082
T	Caramel		I/P	U/P	S/C	P/T	I/C	Caramel	★	4129
Y	Sand		I/P	U/P	S/C	P/T	I/C	Sand (light) Sand (medium)	★	4112 4115

K (Mark)

A	Black		*	*	*	*	*	Black Black Metallic	★	M4J 1724-H 2083
B	Midnight Blue				S/C	P/T	I/C	Charcoal Blue Metallic	★	4121
C	Bittersweet				S/C	P/T	I/C	Bittersweet	★	4130

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P= Instrument Panel U/P= Upper Instrument Panel S/C= Steering column and console P/T= Package Tray I/C= Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002

Note:

LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd

Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, △ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1980 — Cont'd

K (Mark) — Cont'd

D	Red				S/C	P/T	⊗ ⊕	Red Metallic Red	★ ★	4020 4056
N	White/Red				S/C	P/T	I/C	Red Metallic White	★ ★	4020 4076
Q	White/Blue				S/C	P/T	I/C	White Charcoal Blue Metallic	★ ★	4076 4121
R	Pine				S/C	P/T	I/C	Pine	★	4116
S	Pewter				S/C	P/T	I/C	Pewter (medium) Pewter (light)	★ ★	4125 4128
T	Caramel				S/C	P/T	I/C	Caramel	★	4129
U	Champagne				S/C	P/T	I/C	Champagne (medium) Champagne (light)	★ ★	4091 4092
Y	Gold				S/C	P/T	I/C	Gold	★	4064
Z	Vaquero				S/C	P/T	I/C	Vaquero	★	4113
4	White/Champagne				S/C	P/T	I/C	White Champagne (medium)	★ ★	4076 4091
6	White/Pewter				S/C	P/T	I/C	White Pewter (medium)	★ ★	4076 4125
8	White/Gold				S/C	P/T	I/C	Gold White	★ ★	4064 4076

L (Pinto),ML (Bobcat)

A	Black			*	*	*	*	*	Black Black Metallic	★	M4J 1724-H 2083
B	Wedgewood Blue			I/P	U/P	S/C	P/T	I/C	Wedgewood Blue	★	4117
D	Red			I/P	U/P	S/C	P/T	I/C	Red (medium)	★	4131
T	Caramel			I/P	U/P	S/C	P/T	I/C	Caramel	★	4129
Z	Vaquero			I/P	U/P	S/C	P/T	I/C	Vaquero	★	4113

MV (Versailles)

				*	*	*	*	*	Black Black Metallic	★	M4J 1724-H 2083
B	Midnight Blue			I/P	U/P	S/C	P/T	I/C	Charcoal Blue Metallic	★	4121
D	Red			I/P	U/P	S/C	P/T	I/C	Red Metallic	★	4020
F	Cordovan			I/P	U/P	S/C	P/T	I/C	Cordovan	★	4079
K	Beryl			I/P	U/P	S/C	P/T	I/C	Beryl Metallic (light) Beryl Metallic (medium)	★ ★	4110 4118
S	Dove Gray			I/P	U/P	S/C	P/T	I/C	Gray Metallic Dove Gray	★ ★	4051 4082
U	Champagne			I/P	U/P	S/C	P/T	I/C	Champagne (medium) Champagne (light)	★ ★	4091 4092

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P= Instrument Panel U/P= Upper Instrument Panel S/C= Steering column and console P/T= Package Tray I/C= Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002 LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd
Note: Code column represents the 2nd digit of the vehicle Trim Code
 ▲ Steering column, Δ Console,
 * Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1981 — Cont'd

K (Mark) — Cont'd

6	White/Pewter				S/C	P/T	I/C	White Pewter (medium)	★ 4076 ★ 4125
8	White/Gold				S/C	P/T	I/C	Gold White	★ 4064 ★ 4076

P (Fairmont),MP (Zephyr)

			*	*	*	*	*	Black Black Metallic	M4J 1724-H ★ 2083
B	Wedgewood Blue		I/P	U/P	S/C	P/T	I/C	Wedgewood Blue	★ 4117
D	Red		I/P	U/P	S/C	P/T	I/C	Red Metallic	★ 4020
T	Caramel		I/P	U/P	S/C	P/T	I/C	Caramel	★ 4129
Y	Sand		I/P	U/P	S/C	P/T	I/C	Sand (light) Sand (medium)	★ 4112 ★ 4115
Z	Vaquero		I/P	U/P	S/C	P/T	I/C	Vaquero	★ 4113

S (Thunderbird),MF (Cougar)

			*	*	*	*	*	Black Black Metallic	M4J 1724-H ★ 2083
B	Wedgewood Blue		I/P	U/P	S/C	P/T	I/C	Wedgewood Blue	★ 4117
D	Red		I/P	U/P	S/C	P/T	I/C	Red (metallic)	★ 4020
L	Fawn		I/P	U/P	S/C	P/T	I/C	Fawn (medium)	★ 4134
N	White/Red		I/P	U/P	S/C	P/T	I/C	Red Metallic White	★ 4020 ★ 4076
P	Pewter		I/P	U/P	S/C	P/T	I/C	Pewter (medium) Pewter (light)	★ 4125 ★ 4128
Q	White/Blue		I/P	U/P	S/C	P/T	I/C	White Wedgewood Blue	★ 4076 ★ 4117
R	Spruce		I/P	U/P	S/C	P/T	I/C	Spruce	★ 4132
S	Dove Gray		I/P	U/P	S/C	P/T	I/C	Gray Metallic Dove Gray	★ 4051 ★ 4082
T	Caramel		I/P	U/P	S/C	P/T	I/C	Caramel	★ 4129
Z	Vaquero		I/P	U/P	S/C	P/T	I/C	Vaquero	★ 4113
3	White/Fawn		I/P	U/P	S/C	P/T	I/C	White Fawn (medium)	★ 4076 ★ 4134
9	White/Vaquero		I/P	U/P	S/C	P/T	I/C	White Vaquero	★ 4076 ★ 4113

W (Escort),MW (Lynx)

A	Black		*	*	*	*	*	Black Black Metallic	M4J 1724-H ★ 2083
B	Wedgewood Blue		I/P		S/C		I/C	Wedgewood Blue	★ 4117
D	Red		I/P		S/C		I/C	Red (medium)	★ 4131
T	Caramel		I/P		S/C		I/C	Caramel	★ 4129

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P = Instrument Panel U/P = Upper Instrument Panel S/C = Steering column and console P/T = Package Tray I/C = Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002

Note:

LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd

Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1982

A (Ford), MA (Mercury)

			*	*	*	*	*	Black Black Metallic	M4J 1724-H 2083
B	Midnight Blue		I/P	U/P	S/C	P/T	I/C	Charcoal Blue Metallic	★ 4121
D	Red		I/P	U/P	S/C	P/T	I/C	Red Metallic	★ 4020
L	Fawn		I/P	U/P	S/C	P/T	I/C	Fawn (medium)	★ 4134
N	Opal/Red		I/P	U/P	S/C	P/T	I/C	Red Metallic Pastel Opal	★ 4020 ★ 4137
Q	Opal/Blue		I/P	U/P	S/C	P/T	I/C	Charcoal Blue Metallic Pastel Opal	★ 4121 ★ 4137
V	French Vanilla		I/P	U/P	S/C	P/T	☐	Pastel French Vanilla French Vanilla (medium)	★ 4138 ★ 4139
3	Opal/Fawn		I/P	U/P	S/C	P/T	I/C	Fawn (medium) Pastel Opal	★ 4134 ★ 4137

C (EXP), MC (LN7)

A	Black		*	*	*	*	*	Black Black Metallic	M4J 1724-H 2083
B	Wedgewood Blue		*	*	*		I/C	Wedgewood Blue	★ 4117
C	Bittersweet		*	*	*		I/C	Bittersweet	★ 4130
D	Red		*	*	*		I/C	Red (medium)	★ 4131
N	Opal/Red		*	*	*		I/C	Red (medium)	★ 4131
Q	Opal/Blue		*	*	*		I/C	Wedgewood Blue	★ 4117
U	Fawn		*	*	*		I/C	Fawn (light)	★ 4135
W	Opal/Black		*	*	*	*	*	Black Black Metallic	M4J 1724-H 2083
7	Opal/Bittersweet		*	*	*		I/C	Bittersweet	★ 4130

DC (Lincoln Continental)

			*	*	*	*	*	Black Black Metallic	M4J 1724-H 2083
B	Midnight Blue			U/P	S/C		I/C	Charcoal Blue Metallic	★ 4121
D	Red			U/P	S/C		I/C	Red Metallic	★ 4020
F	Mulberry			U/P	▲		I/C	Mulberry (dark)	★ 4140
K	Teal			U/P	▲		I/C	Teal (dark)	★ 4141
L	Fawn			U/P	S/C		I/C	Fawn (medium)	★ 4134
S	Pewter			U/P	▲		I/C	Pewter (light)	★ 4128
V	French Vanilla			U/P	S/C		I/C	Pastel French Vanilla French Vanilla (medium)	★ 4138 ★ 4139
6	Opal/Pewter			U/P	S/C		I/C	Pewter (light) Pastel Opal	★ 4128 ★ 4137

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P= Instrument Panel U/P= Upper Instrument Panel S/C= Steering column and console P/T= Package Tray I/C= Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002

Note:

LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd

Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1982 — Cont'd

DT (Lincoln Town Car)

A	Black				*	*	*	Black Black Metallic	M4J 1724-H ★ 2083
B	Midnight Blue			▲	P/T	I/C		Charcoal Blue Metallic	★ 4121
D	Red			▲	P/T	I/C		Red Metallic	★ 4020
F	Mulberry			▲	P/T	I/C		Mulberry (dark)	★ 4140
L	Fawn			▲	P/T	I/C		Fawn (medium)	★ 4134
N	Opal/Red			▲	P/T			Red Metallic Pastel Opal	★ 4020 ★ 4137
Q	Opal/Blue			▲	P/T			Charcoal Blue Metallic Pastel Opal	★ 4121 ★ 4137
S	Pewter			▲	P/T			Pewter (medium) Pewter (light)	★ 4125 ★ 4128
V	French Vanilla			▲	P/T			Pastel French Vanilla French Vanilla (medium)	★ 4138 ★ 4139
W	Opal/Black			*	*			Black Black Metallic Pastel Opal	M4J 1724-H ★ 2083 ★ 4137
3	Opal/Fawn			▲	P/T			Fawn (medium) Pastel Opal	★ 4134 ★ 4137
6	Opal/Pewter			▲	P/T			Pewter (medium) Pastel Opal	★ 4125 ★ 4137
8	Opal/Mulberry			▲	P/T			Pastel Opal Mulberry (dark)	★ 4137 ★ 4140

F (Mustang), J (Capri)

A				*	*	*	*	Black Black Metallic	M4J 1724-H ★ 2083
B	Wedgewood Blue		I/P	U/P	S/C	P/T	I/C	Wedgewood Blue	★ 4117
D	Red		I/P	U/P	S/C	P/T	I/C	Red (medium)	★ 4131
N	Opal/Red		I/P	U/P	S/C	P/T		Red (medium) Pastel Opal	★ 4131 ★ 4137
Q	Opal/Blue		I/P	U/P	S/C	P/T		Wedgewood Blue Pastel Opal	★ 4117 ★ 4137
V	French Vanilla		I/P	U/P	S/C	P/T		Pastel French Vanilla French Vanilla (medium)	★ 4138 ★ 4139
W	Opal/Black		*	*	*	*		Black Black Metallic Pastel Opal	M4J 1724-H ★ 2083 ★ 4137
Z	Vaquero		I/P	U/P	S/C	P/T	I/C	Vaquero	★ 4113
9	Opal/Vaquero		I/P	U/P	S/C	P/T		Vaquero Pastel Opal	★ 4113 ★ 4137

G (Granada)

			*	*	*	*	*	Black Black Metallic	M4J 1724-H ★ 2083
--	--	--	---	---	---	---	---	-------------------------	----------------------

INTERIOR TRIM		MODEL/RESTRICTIONS	INTERIOR LOCATION					INTERIOR PAINT	
C O D E	COLOR		I/P= Instrument Panel U/P= Upper Instrument Panel S/C= Steering column and console P/T= Package Tray I/C= Other Interior Components					COLOR	PART NUMBER
			I/P	U/P	S/C	P/T	I/C		

P0002

Note:

LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd

Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1982 — Cont'd

G (Granada) — Cont'd

B	Midnight Blue			I/P	U/P	S/C	P/T	I/C	Charcoal Blue Metallic	★	4121
D	Red			I/P	U/P	S/C	P/T	I/C	Red Metallic	★	4020
L	Fawn			I/P	U/P	S/C	P/T	I/C	Fawn (medium)	★	4134
R	Spruce			I/P	U/P	S/C	P/T	I/C	Spruce	★	4132
S	Pewter			I/P	U/P	S/C	P/T	I/C	Pewter (medium) Pewter (light)	★ ★	4125 4128
V	French Vanilla			I/P	U/P	S/C	P/T	I/C	Pastel French Vanilla French Vanilla (medium)	★ ★	4138 4139

K (Mark)

A	Black					*	*	*	Black Black Metallic	★	M4J 1724-H 2083
A	Black/Pewter (Trim Codes QA, RA)					▲		I/C	Black Pewter (light)	★	M4J 1724-H 4128
B	Midnight Blue					▲	P/T	I/C	Charcoal Blue Metallic	★	4121
D	Red					▲	P/T	I/C	Red Metallic	★	4020
F	Mulberry					▲	P/T	I/C	Mulberry (dark)	★	4140
L	Fawn					▲	P/T	I/C	Fawn (medium)	★	4134
N	Opal/Red					▲	P/T	I/C	Red Metallic Pastel Opal	★ ★	4020 4137
Q	Opal/Blue					▲	P/T	I/C	Charcoal Blue Metallic Pastel Opal	★ ★	4121 4137
S	Pewter					▲	P/T	I/C	Pewter (medium) Pewter (light)	★ ★	4125 4128
V	French Vanilla						P/T	I/C	Pastel French Vanilla French Vanilla (medium)	★ ★	4138 4139
W	Opal/Black					*	*	I/C	Black Black Metallic Pastel Opal	★ ★	M4J 1724-H 2083 4137
3	Opal/Fawn					▲	P/T	I/C	Fawn (medium) Pastel Opal	★ ★	4134 4137
6	Opal/Pewter					▲	P/T	I/C	Pewter (medium) Pastel Opal	★ ★	4125 4137
8	Opal/Mulberry					▲	P/T	I/C	Pastel Opal Mulberry (dark)	★ ★	4137 4140

P (Fairmont), MP (Zephyr)

				*	*	*	*	*	Black Black Metallic	★	M4J 1724-H 2083
B	Wedgewood Blue			I/P	U/P	S/C	P/T	I/C	Wedgewood Blue	★	4117
D	Red			I/P	U/P	S/C	P/T	I/C	Red Metallic	★	4020
L	Fawn			I/P	U/P	S/C	P/T	I/C	Fawn (medium)	★	4134

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P= Instrument Panel U/P= Upper Instrument Panel S/C= Steering column and console P/T= Package Tray I/C= Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002**Note:****LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd**

Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, △ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1982 — Cont'd**P (Fairmont),MP (Zephyr) — Cont'd**

Y	Sand		I/P	U/P	S/C	P/T	I/C	Sand (light)	★	4112
								Sand (medium)	★	4115
Z	Vaquero		I/P	U/P	S/C	P/T	I/C	Vaquero	★	4113

S (Thunderbird),MF (Cougar)

			*	*	*	*	*	Black		M4J	1724-H
			*	*	*	*	*	Black Metallic	★		2083
B	Midnight Blue		I/P	U/P	S/C	P/T	I/C	Charcoal Blue Metallic	★		4121
D	Red		I/P	U/P	S/C	P/T	I/C	Red Metallic	★		4020
L	Fawn		I/P	U/P	S/C	P/T	I/C	Fawn (medium)	★		4134
N	Opal/Red		I/P	U/P	S/C	P/T		Red Metallic	★		4020
							I/C	Pastel Opal	★		4137
Q	Opal/Blue		I/P	U/P	S/C	P/T		Charcoal Blue Metallic	★		4121
							I/C	Pastel Opal	★		4137
R	Spruce		I/P	U/P	S/C	P/T	I/C	Spruce	★		4132
S	Pewter		I/P	U/P	S/C	P/T		Pewter (medium)	★		4125
							I/C	Pewter (light)	★		4128
V	French Vanilla		I/P	U/P	S/C	P/T	I/C	Pastel French Vanilla	★		4138
								French Vanilla (medium)	★		4139
Z	Vaquero		I/P	U/P	S/C	P/T	I/C	Vaquero	★		4113
3	Opal/Fawn		I/P	U/P	S/C	P/T		Fawn (medium)	★		4134
							I/C	Pastel Opal	★		4137
6	Opal/Pewter		I/P	U/P	S/C	P/T		Pewter (light)	★		4128
							I/C	Pastel Opal	★		4137
9	Opal/Vaquero		I/P	U/P	S/C	P/T		Vaquero	★		4113
							I/C	Pastel Opal	★		4137

W (Escort),MW (Lynx)

A	Black		*		*		*	Black		M4J	1724-H
			*		*		*	Black Metallic	★		2083
B	Wedgewood Blue		I/P		S/C		I/C	Wedgewood Blue	★		4117
D	Red		I/P		S/C		I/C	Red (medium)	★		4131
N	Opal/Red		I/P		S/C			Red (medium)	★		4131
							I/C	Pastel Opal	★		4137
Q	Opal/Blue		I/P		S/C			Wedgewood Blue	★		4117
							I/C	Pastel Opal	★		4137
U	Fawn		I/P		S/C			Fawn (medium)	★		4134
							I/C	Fawn (light)	★		4135
W	Opal/Black		*		*			Black		M4J	1724-H
			*		*			Black Metallic	★		2083
							I/C	Pastel Opal	★		4137
3	Opal/Fawn		I/P		S/C			Fawn (medium)	★		4134
							I/C	Pastel Opal	★		4137

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002

Note:

LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd

Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1983

A (Ford), MA (Mercury)

A	Charcoal		I/P		▲	P/T	I/C	Charcoal (dark)	M4J 4148-H
B	Midnight Blue		I/P		▲	P/T	I/C	Midnight Blue	M4J 4153-H
D	Red		I/P		▲	P/T	I/C	Red (dark)	★ 4151
E	Walnut		I/P		▲	P/T	I/C	Walnut (dark)	★ 4147
V	French Vanilla		I/P		▲	P/T	□	Pastel French Vanilla	★ 4138
							■	French Vanilla (medium)	★ 4139

C (EXP), MC (LN7)

A	Black		I/P		S/C		I/C	Charcoal Black	M4J 4149-H
B	Cadet Blue		I/P		Δ		I/C	Cadet Blue (medium)	★ 4146
					▲			Charcoal Black	M4J 4149-H
D	Red		I/P		Δ		I/C	Charcoal Black	M4J 4149-H
					Δ			Red (medium)	★ 4150
H	Desert Tan		I/P		Δ		I/C	Desert Tan (medium)	M4J 4145-H
					▲			Charcoal Black	M4J 4149-H
V	French Vanilla		I/P		Δ		I/C	Pastel French Vanilla	★ 4138
					▲			French Vanilla (medium)	★ 4139
					▲			Charcoal Black	M4J 4149-H

DC (Lincoln Continental)

A	Charcoal		I/P	U/P	▲		I/C	Charcoal (dark)	M4J 4148-H
B	Cadet Blue		I/P	U/P	▲		I/C	Cadet Blue (medium)	★ 4146
D	Red		I/P	U/P	▲		I/C	Red (dark)	★ 4151
E	Walnut		I/P	U/P	▲		I/C	Walnut (dark)	★ 4147
H	Desert Tan		I/P	U/P	▲		I/C	Desert Tan (medium)	M4J 4145-H
K	Teal		I/P	U/P	▲		I/C	Teal (dark)	★ 4155
N	Opal/Red		I/P	U/P	▲		I/C	Pastel Opal	★ 4137
								Red (dark)	★ 4151
Q	Opal/Blue		I/P	U/P	▲		I/C	Pastel Opal	★ 4137
								Cadet Blue (medium)	★ 4146
V	French Vanilla		I/P	U/P	▲		I/C	Pastel French Vanilla	★ 4138
								French Vanilla (medium)	★ 4139
W	Opal/Charcoal		I/P	U/P	▲		I/C	Pastel Opal	★ 4137
								Charcoal (dark)	M4J 4148-H
2	Opal/Walnut		I/P	U/P	▲		I/C	Pastel Opal	★ 4137
								Walnut (dark)	★ 4147
3	Opal/Tan		I/P	U/P	▲		I/C	Pastel Opal	★ 4137
								Desert Tan (medium)	M4J 4145-H
4	Opal/Teal		I/P	U/P	▲		I/C	Pastel Opal	★ 4137
								Teal (dark)	★ 4155

DT (Lincoln Town Car)

A	Charcoal				▲	P/T	I/C	Charcoal (dark)	M4J 4148-H
B	Cadet Blue				▲	P/T	I/C	Cadet Blue (medium)	★ 4146

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002**Note:**

LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd
 Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1983 — Cont'd**DT (Lincoln Town Car) — Cont'd**

D	Red			▲	P/T	I/C	Red (dark)	★	4151
F	Mulberry			▲	P/T	I/C	Mulberry (dark)	★	4152
H	Desert Tan			▲	P/T	I/C	Desert Tan (medium)	M4J	4145-H
K	Teal			▲	P/T	I/C	Teal (dark)	★	4155
N	Opal/Red			▲	P/T	I/C	Pastel Opal Red (dark)	★ ★	4137 4151
Q	Opal/Blue			▲	P/T	I/C	Pastel Opal Cadet Blue (medium)	★ ★	4137 4146
V	French Vanilla			▲	P/T	I/C	Pastel French Vanilla French Vanilla (medium)	★ ★	4138 4139
W	Opal/Charcoal			▲	P/T	I/C	Pastel Opal Charcoal (dark)	★ M4J	4137 4148-H
3	Opal/Tan			▲	P/T	I/C	Pastel Opal Desert Tan (medium)	★ M4J	4137 4145-H
4	Opal/Teal			▲	P/T	I/C	Pastel Opal Teal (dark)	★ ★	4137 4155
7	Opal/Vanilla			▲	P/T	I/C	Pastel Opal French Vanilla (medium)	★ ★	4137 4139
8	Opal/Mulberry			▲	P/T	I/C	Pastel Opal Mulberry (dark)	★ ★	4137 4152

F (Mustang), J (Capri)

A	Black		I/P		S/C	P/T	I/C	Charcoal Black	M4J	4149-H
B	Cadet Blue		I/P		S/C	P/T	I/C	Cadet Blue (medium)	★	4146
D	Red		I/P		S/C	P/T	I/C	Red (medium)	★	4150
E	Walnut		I/P		S/C	P/T	I/C	Walnut (dark)	★	4147
			I/P		S/C	P/T	I/C	Walnut (dark)	M4J	4147-H
N	Opal/Red		I/P		S/C	P/T	I/C	Pastel Opal Red (medium)	★ ★	4137 4150
Q	Opal/Blue		I/P		S/C	P/T	I/C	Pastel Opal Cadet Blue (medium)	★ ★	4137 4146
W	Opal/Black		I/P		S/C	P/T	I/C	Pastel Opal Charcoal Black	★ M4J	4137 4149-H
2	Opal/Walnut		I/P		S/C	P/T	I/C	Pastel Opal Walnut (dark)	★ ★	4137 4147

G (LTD), MG (Marquis)

A	Charcoal		I/P		S/C	P/T	I/C	Charcoal (dark)	M4J	4148-H
B	Cadet Blue		I/P		S/C	P/T	I/C	Cadet Blue (medium)	★	4146
D	Red		I/P		S/C	P/T	I/C	Red (dark)	★	4151
E	Walnut		I/P		S/C	P/T	I/C	Walnut (dark)	★	4147
K	Teal		I/P		S/C	P/T	I/C	Teal (dark)	★	4155
V	French Vanilla		I/P		S/C	P/T	I/C	Pastel French Vanilla French Vanilla (medium)	★ ★	4138 4139

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P - Instrument Panel U/P - Upper Instrument Panel S/C - Steering column and console P/T - Package Tray I/C - Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002

Note:

LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd

Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1983 — Cont'd

K (Mark)

A	Charcoal					P/T	I/C	Charcoal (dark)	M4J	4148-H
B	Cadet Blue					P/T	I/C	Cadet Blue (medium)	★	4146
D	Red					P/T	I/C	Red (dark)	★	4151
F	Mulberry					P/T	I/C	Mulberry (dark)	★	4152
H	Desert Tan					P/T	I/C	Desert Tan (medium)	M4J	4145-H
K	Teal					P/T	I/C	Teal (dark)	★	4155
N	Opal/Red					P/T	I/C	Pastel Opal Red (dark)	★ ★	4137 4151
Q	Opal/Blue					P/T	I/C	Pastel Opal Cadet Blue (medium)	★ ★	4137 4146
V	French Vanilla					P/T	I/C	Pastel French Vanilla French Vanilla (medium)	★ ★	4138 4139
W	Opal/Charcoal					P/T	I/C	Pastel Opal Charcoal (dark)	★ M4J	4137 4148-H
3	Opal/Tan					P/T	I/C	Pastel Opal Desert Tan (medium)	★ M4J	4137 4145-H
4	Opal/Teal					P/T	I/C	Pastel Opal Teal (dark)	★ ★	4137 4155
7	Opal/Vanilla					P/T	I/C	Pastel Opal French Vanilla (medium)	★ ★	4137 4139
8	Opal/Mulberry					P/T	I/C	Pastel Opal Mulberry (dark)	★ ★	4137 4152

P (Fairmont),MP (Zephyr)

B	Wedgewood Blue		I/P	U/P	S/C	P/T	I/C	Wedgewood Blue	★	4117
D	Red		I/P	U/P	S/C	P/T	I/C	Red Metallic	★	4020
L	Fawn		I/P	U/P	S/C	P/T	I/C	Fawn (medium)	★	4134
Y	Sand		I/P	U/P	S/C	P/T	I/C	Sand (light) Sand (medium)	★ ★	4112 4115
Z	Vaquero		I/P	U/P	S/C	P/T	I/C	Vaquero (medium)	★	4113

S (Thunderbird),MF (Cougar)

A	Charcoal		I/P	U/P	S/C	P/T	I/C	Charcoal (dark)	M4J	4148-H
B	Cadet Blue		I/P	U/P	S/C	P/T	I/C	Cadet Blue (medium)	★	4146
D	Red		I/P	U/P	S/C	P/T	I/C	Red (medium)	★	4150
E	Walnut		I/P	U/P	S/C	P/T	I/C	Walnut (dark)	★	4147
H	Desert Tan		I/P	U/P	S/C	P/T	I/C	Desert Tan (medium)	M4J	4145-H
N	Opal/Red		I/P	U/P	S/C	P/T	I/C	Pastel Opal Red (medium)	★ ★	4137 4150
Q	Opal/Blue		I/P	U/P	S/C	P/T	I/C	Pastel Opal Cadet Blue (medium)	★ ★	4137 4146

INTERIOR TRIM		MODEL/RESTRICTIONS	INTERIOR LOCATION I/P= Instrument Panel U/P= Upper Instrument Panel S/C= Steering column and console P/T= Package Tray I/C= Other Interior Components					INTERIOR PAINT	
C O D E	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002**Note:**

LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd
 Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, △ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1983 — Cont'd**S (Thunderbird),MF (Cougar) — Cont'd**

W	Opal/Charcoal		I/P	U/P	S/C	P/T	I/C	Pastel Opal Charcoal (dark)	★	M4J 4137 4148-H
3	Opal/Tan		I/P	U/P	S/C	P/T	I/C	Pastel Opal Desert Tan (medium)	★	M4J 4137 4145-H

W (Escort),MW (Lynx)

A	Black		I/P		S/C		I/C	Charcoal Black		M4J 4149-H
B	Cadet Blue		I/P		S/C		I/C	Cadet Blue (medium)	★	4146
D	Red		I/P		S/C		I/C	Red (medium)	★	4150
H	Desert Tan		I/P		S/C		I/C	Desert Tan (medium)		M4J 4145-H
N	Opal/Red		I/P		S/C		I/C	Pastel Opal Red (medium)	★	4137 4150
Q	Opal/Blue		I/P		S/C		I/C	Pastel Opal Cadet Blue (medium)	★	4137 4146
W	Opal/Black		I/P		S/C		I/C	Pastel Opal Charcoal Black	★	4137 M4J 4149-H
3	Opal/Tan		I/P		S/C		I/C	Pastel Opal Desert Tan (medium)	★	4137 M4J 4145-H

1984**A (Ford),MA (Mercury)**

B	Midnight Blue		I/P		▲	P/T	I/C	Midnight Blue		M4J 4153-H
D	Canyon Red		I/P		▲	P/T	I/C	Canyon Red (medium)		M4J 4158-H
E	Walnut		I/P		▲	P/T	I/C	Walnut (dark)	★	4147
J	Oxford Gray		I/P		▲	P/T	I/C	Oxford Gray (light)	★	4162
V	French Vanilla		I/P		▲	P/T	□	Pastel French Vanilla	★	4138
							■	French Vanilla (medium)	★	4139

B (Tempo),MB (Topaz)

A	Charcoal		I/P	U/P	S/C	P/T	I/C	Charcoal (dark)		M4J 4148-H
B	Cadet Blue		I/P	U/P	S/C	P/T	I/C	Cadet Blue (medium)	★	4146
D	Red		I/P	U/P	S/C	P/T	I/C	Red (medium)	★	4150
H	Desert Tan		I/P	U/P	S/C	P/T	I/C	Desert Tan (medium)		M4J 4145-H

C (EXP)

A	Charcoal		I/P		△		I/C	Charcoal (dark) Charcoal Black		M4J 4148-H M4J 4149-H
B	Cadet Blue		I/P		△		I/C	Cadet Blue (medium) Charcoal Black	★	4146 M4J 4149-H
D	Canyon Red		I/P		▲		I/C	Charcoal Black Canyon Red (medium)		M4J 4149-H M4J 4158-H
H	Desert Tan		I/P		△		I/C	Desert Tan (medium) Charcoal Black		M4J 4145-H M4J 4149-H

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P - Instrument Panel U/P - Upper Instrument Panel S/C - Steering column and console P/T - Package Tray I/C - Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002 LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd**Note:** Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1984 — Cont'd**DC (Lincoln Continental)**

A	Charcoal		I/P	U/P	▲		I/C	Charcoal (dark)	M4J 4148-H
B	Midnight Blue		I/P	U/P	▲		I/C	Midnight Blue	M4J 4153-H
D	Canyon Red		I/P	U/P	▲		I/C	Canyon Red (medium)	M4J 4158-H
H	Desert Tan		I/P	U/P	▲		I/C	Desert Tan (medium)	M4J 4145-H
J	Oxford Gray		I/P	U/P	▲		I/C	Oxford Gray (light)	★ 4162
M	Gray/White		I/P	U/P	▲		I/C	Oxford Gray (light)	★ 4162
							I/C	Pastel Oxford Gray	M4J 4163-H
P	Sage Green		I/P	U/P	▲		I/C	Sage Green (medium)	★ 4156
R	Wheat		I/P	U/P	▲		I/C	Wheat (light)	★ 4160

DT (Lincoln Town Car)

A	Charcoal				▲		I/C	Charcoal (dark)	M4J 4148-H
B	Midnight Blue				▲		I/C	Midnight Blue	M4J 4153-H
D	Canyon Red				▲		I/C	Canyon Red (medium)	M4J 4158-H
H	Desert Tan				▲		I/C	Desert Tan (medium)	M4J 4145-H
J	Oxford Gray				▲		I/C	Oxford Gray (light)	★ 4162
M	Gray/White				▲		I/C	Oxford Gray (light)	★ 4162
							I/C	Pastel Oxford Gray	M4J 4163-H
P	Sage Green				▲		I/C	Sage Green (medium)	★ 4156
R	Wheat				▲		I/C	Wheat (light)	★ 4160

F (Mustang), J (Capri)

A	Charcoal		I/P		S/C	P/T	I/C	Charcoal (dark)	M4J 4148-H
B	Cadet Blue		I/P		S/C	P/T	I/C	Cadet Blue (medium)	★ 4146
D	Canyon Red		I/P		S/C	P/T	I/C	Canyon Red (medium)	M4J 4158-H
H	Desert Tan		I/P		S/C	P/T	I/C	Desert Tan (medium)	M4J 4145-H
N	White/Red	F-66 Convertible	I/P		S/C		I/C	Canyon Red (medium)	M4J 4158-H
Q	White/Blue	F-66 Convertible	I/P		S/C		I/C	Cadet Blue (medium)	★ 4146
W	White/Charcoal	F-66 Convertible	I/P		S/C		I/C	Charcoal (dark)	M4J 4148-H

G (LTD), MG (Marquis)

A	Charcoal		I/P	U/P	S/C	P/T	I/C	Charcoal (dark)	M4J 4148-H
B	Cadet Blue		I/P	U/P	S/C	P/T	I/C	Cadet Blue (medium)	★ 4146
D	Canyon Red		I/P	U/P	S/C	P/T	I/C	Canyon Red (medium)	M4J 4158-H
H	Desert Tan		I/P	U/P	S/C	P/T	I/C	Desert Tan (medium)	M4J 4145-H
J	Oxford Gray		I/P	U/P	S/C	P/T	I/C	Oxford Gray (light)	★ 4162
R	Wheat		I/P	U/P	S/C	P/T	I/C	Wheat (light)	★ 4160

K (Mark)

A	Charcoal			U/P	▲		I/C	Charcoal (dark)	M4J 4148-H
B	Midnight Blue			U/P	▲		I/C	Midnight Blue	M4J 4153-H
D	Canyon Red			U/P	▲		I/C	Canyon Red (medium)	M4J 4158-H

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002**Note:**

LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd
 Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1984 — Cont'd**K (Mark) — Cont'd**

H	Desert Tan			U/P	▲		I/C	Desert Tan (medium)	M4J 4145-H
J	Oxford Gray			U/P	▲		I/C	Oxford Gray (light)	★ 4162
M	Gray/White			U/P	▲		I/C	Oxford Gray (light)	★ 4162
							I/C	Pastel Oxford Gray	M4J 4163-H
P	Sage Green			U/P	▲		I/C	Sage Green (medium)	★ 4156
R	Wheat			U/P	▲		I/C	Wheat (light)	★ 4160

S (Thunderbird), MF (Cougar)

A	Charcoal		I/P	U/P	S/C		I/C	Charcoal (dark)	M4J 4148-H
B	Cadet Blue		I/P	U/P	S/C		I/C	Cadet Blue (medium)	★ 4146
							I/C	Cadet Blue (dark)	★ 4159
D	Canyon Red		I/P	U/P	S/C		I/C	Canyon Red (medium)	M4J 4158-H
H	Desert Tan		I/P	U/P	S/C		I/C	Desert Tan (medium)	M4J 4145-H
							I/C	Desert Tan (dark)	★ 4166
J	Oxford Gray		I/P	U/P	S/C		I/C	Charcoal (dark)	M4J 4148-H
							I/C	Oxford Gray (light)	★ 4162
R	Wheat		I/P	U/P	S/C		I/C	Wheat (light)	★ 4160

W (Escort), MW (Lynx)

A	Charcoal		I/P		S/C		I/C	Charcoal (dark)	M4J 4148-H
B	Cadet Blue		I/P		S/C		I/C	Cadet Blue (medium)	★ 4146
D	Canyon Red		I/P		S/C		I/C	Canyon Red (medium)	M4J 4158-H
H	Desert Tan		I/P		S/C		I/C	Desert Tan (medium)	M4J 4145-H

1985**A (Ford), MA (Mercury)**

B	Midnight Blue		I/P		▲	P/T	I/C	Midnight Blue	M4J 4153-H
C	Sable		I/P		▲	P/T	I/C	Sable (dark)	★ 4176
D	Canyon Red		I/P		▲	P/T	I/C	Canyon Red (medium)	M4J 4158-H
J	Oxford Gray		I/P		▲	P/T	I/C	Oxford Gray (light)	★ 4162
Y	Sand Beige		I/P		▲	P/T	I/C	Sand (light)	M4J 4175-H

B (Tempo), MB (Topaz)

A	Charcoal		I/P	U/P	S/C	P/T	I/C	Charcoal (dark)	M4J 4148-H
B	Regatta Blue		I/P	U/P	S/C	P/T	I/C	Regatta Blue (medium)	M4J 4177-H
D	Canyon Red		I/P	U/P	S/C	P/T	I/C	Canyon Red (medium)	M4J 4158-H
Y	Sand Beige		I/P	U/P	S/C	P/T	I/C	Sand (light)	M4J 4175-H

C (EXP)

A	Charcoal		I/P		Δ		I/C	Charcoal (dark)	M4J 4148-H
					▲			Charcoal Black	M4J 4149-H
B	Regatta Blue		I/P		▲		I/C	Charcoal Black	M4J 4149-H
					Δ		I/C	Regatta Blue (medium)	M4J 4177-H

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P - Instrument Panel U/P - Upper Instrument Panel S/C - Steering column and console P/T - Package Tray I/C - Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002 LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd
Note: Code column represents the 2nd digit of the vehicle Trim Code
 ▲ Steering column, Δ Console,
 * Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1985 — Cont'd

C (EXP) — Cont'd

D	Canyon Red		I/P		▲		I/C	Charcoal Black Canyon Red (medium)	M4J 4149-H M4J 4158-H
Y	Sand Beige		I/P		▲		I/C	Charcoal Black Sand (light)	M4J 4149-H M4J 4175-H

DC (Lincoln Continental)

A	Charcoal		I/P	U/P	▲		I/C	Charcoal (dark)	M4J 4148-H
B	Midnight Blue		I/P	U/P	▲		I/C	Midnight Blue	M4J 4153-H
D	Canyon Red		I/P	U/P	▲		I/C	Canyon Red (medium)	M4J 4158-H
F	Mulberry		I/P	U/P	▲		I/C	Mulberry (dark)	★ 4152
M	Oxford White/Gray		I/P	U/P	▲		I/C	Oxford Gray (light) Pastel Oxford Gray	★ 4162 M4J 4163-H
N	Oxford White/Red		I/P	U/P	▲		I/C	Canyon Red (medium)	M4J 4158-H
P	Sage Green		I/P	U/P	▲		I/C	Sage Green (medium)	★ 4156
Q	Oxford White/Blue		I/P	U/P	▲		I/C	Midnight Blue	M4J 4153-H
R	Wheat		I/P	U/P	▲		I/C	Wheat (light)	★ 4160
Y	Sand Beige		I/P	U/P	▲		I/C	Sand (light)	M4J 4175-H

DT (Lincoln Town Car)

A	Charcoal				▲		I/C	Charcoal (dark)	M4J 4148-H
B	Midnight Blue				▲		I/C	Midnight Blue	M4J 4153-H
C	Sable				▲		I/C	Sable (dark)	★ 4176
D	Canyon Red				▲		I/C	Canyon Red (medium)	M4J 4158-H
F	Mulberry				▲		I/C	Mulberry (dark)	★ 4152
M	Oxford White/Gray				▲		I/C	Oxford Gray (light) Pastel Oxford Gray	★ 4162 M4J 4163-H
N	Oxford White/Red				▲		I/C	Canyon Red (medium)	M4J 4158-H
Q	Oxford White/Blue				▲		I/C	Midnight Blue	M4J 4153-H
R	Wheat				▲		I/C	Wheat (light)	★ 4160
Y	Sand Beige				▲		I/C	Sand (light)	M4J 4175-H

F (Mustang), J (Capri)

A	Charcoal		I/P		S/C	P/T	I/C	Charcoal (dark)	M4J 4148-H
B	Regatta Blue		I/P		S/C	P/T	I/C	Regatta Blue (medium)	M4J 4177-H
D	Canyon Red		I/P		S/C	P/T	I/C	Canyon Red (medium)	M4J 4158-H
N	White/Red	F-66 Convertible	I/P		S/C		I/C	Canyon Red (medium)	M4J 4158-H
Q	White/Blue	F-66 Convertible	I/P		S/C		I/C	Regatta Blue (medium)	M4J 4177-H
W	White/Charcoal	F-66 Convertible	I/P		S/C		I/C	Charcoal (dark)	M4J 4148-H
Y	Sand Beige		I/P		S/C	P/T	I/C	Sand (light)	M4J 4175-H

G (LTD), MG (Marquis)

A	Charcoal		I/P	U/P	S/C	P/T	I/C	Charcoal (dark)	M4J 4148-H
---	----------	--	-----	-----	-----	-----	-----	-----------------	------------

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P= Instrument Panel U/P= Upper Instrument Panel S/C= Steering column and console P/T= Package Tray I/C= Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002 LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd**Note:** Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, △ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1985 — Cont'd**G (LTD),MG (Marquis) — Cont'd**

B	Regatta Blue		I/P	U/P	S/C	P/T	I/C	Regatta Blue (medium)	M4J	4177-H
C	Sable		I/P	U/P	S/C	P/T	I/C	Sable (dark)	★	4176
D	Canyon Red		I/P	U/P	S/C	P/T	I/C	Canyon Red (medium)	M4J	4158-H
Y	Sand Beige		I/P	U/P	S/C	P/T	I/C	Sand (light)	M4J	4175-H

K (Mark)

A	Charcoal			U/P	▲		I/C	Charcoal (dark)	M4J	4148-H
B	Midnight Blue			U/P	▲		I/C	Midnight Blue	M4J	4153-H
C	Sable			U/P	▲		I/C	Sable (dark)	★	4176
D	Canyon Red			U/P	▲		I/C	Canyon Red (medium)	M4J	4158-H
M	Oxford White/Gray			U/P	▲		I/C	Oxford Gray (light)	★	4162
							I/C	Pastel Oxford Gray	M4J	4163-H
P	Sage Green			U/P	▲		I/C	Sage Green (medium)	★	4156
R	Wheat			U/P	▲		I/C	Wheat (light)	★	4160
Y	Sand Beige			U/P	▲		I/C	Sand (light)	M4J	4175-H

S (Thunderbird),MF (Cougar)

A	Charcoal		I/P	U/P			I/C	Charcoal (dark)	M4J	4148-H
					S/C			Charcoal Black	M4J	4172-H
B	Regatta Blue		I/P	U/P	S/C		I/C	Charcoal Black	M4J	4172-H
							I/C	Regatta Blue (medium)	M4J	4177-H
D	Canyon Red		I/P	U/P	S/C		I/C	Canyon Red (medium)	M4J	4158-H
							I/C	Charcoal Black	M4J	4172-H
J	Oxford Gray		I/P	U/P			I/C	Charcoal (dark)	M4J	4148-H
					S/C		I/C	Oxford Gray (light)	★	4162
								Charcoal Black	M4J	4172-H
W	Oxford White/Charcoal		I/P	U/P	S/C		I/C	Charcoal (dark)	M4J	4148-H
								Charcoal Black	M4J	4172-H
Y	Sand Beige		I/P	U/P	S/C		I/C	Charcoal Black	M4J	4172-H
							I/C	Sand (light)	M4J	4175-H

W (Escort),MW (Lynx)

A	Charcoal	1985	I/P		S/C		I/C	Charcoal (dark)	M4J	4148-H
B	Regatta Blue		I/P		S/C		I/C	Regatta Blue (medium)	M4J	4177-H
D	Canyon Red		I/P		S/C		I/C	Canyon Red (medium)	M4J	4158-H
G	Smoke	1985 1/2	I/P		S/C		I/C	Smoke	M4J	4179-H
Y	Sand Beige		I/P		S/C		I/C	Sand (light)	M4J	4175-H

1986**A (Ford),MA (Mercury)**

B	Midnight Blue		I/P		▲	P/T	I/C	Midnight Blue	M4J	4153-H
C	Sable		I/P		▲	P/T	I/C	Sable (dark)	★	4176

INTERIOR TRIM		MODEL/RESTRICTIONS	INTERIOR LOCATION I/P - Instrument Panel U/P - Upper Instrument Panel S/C - Steering column and console P/T - Package Tray I/C - Other Interior Components					INTERIOR PAINT	
C O D E	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002 LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd

Note: Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1986 — Cont'd

A (Ford), MA (Mercury) — Cont'd

D	Canyon Red		I/P		▲	P/T	I/C	Canyon Red (medium)	M4J	4158-H
G	Smoke		I/P		▲	P/T	I/C	Smoke	M4J	4179-H
Y	Sand Beige		I/P		▲	P/T	I/C	Sand (light)	M4J	4175-H

B (Tempo), MB (Topaz)

B	Regatta Blue		I/P	U/P	S/C		I/C	Regatta Blue (medium)	M4J	4177-H
D	Canyon Red		I/P	U/P	S/C		I/C	Canyon Red (medium)	M4J	4158-H
G	Smoke		I/P	U/P	S/C		I/C	Smoke	M4J	4179-H
Y	Sand Beige		I/P	U/P	S/C		I/C	Sand (light)	M4J	4175-H

DC (Lincoln Continental)

B	Midnight Blue			U/P	▲		I/C	Midnight Blue	M4J	4153-H
D	Canyon Red			U/P	▲		I/C	Canyon Red (medium)	M4J	4158-H
E	Taupe			U/P	▲		I/C	Taupe	★	4188
G	Smoke			U/P	▲		I/C	Smoke	M4J	4179-H
H	Raven (black)			U/P	▲		I/C	Charcoal Black	M4J	4172-H
N	Oxford White/Red			U/P	▲		I/C	Canyon Red (medium)	M4J	4158-H
Q	Oxford White/Blue			U/P	▲		I/C	Midnight Blue	M4J	4153-H
U	Oxford White/Smoke			U/P	▲		I/C	Smoke	M4J	4179-H
Y	Sand Beige			U/P	▲		I/C	Sand (light)	M4J	4175-H
								Sand (medium)	M4J	4178-H

DT (Lincoln Town Car)

B	Midnight Blue				▲		I/C	Midnight Blue	M4J	4153-H
D	Canyon Red				▲		I/C	Canyon Red (medium)	M4J	4158-H
E	Taupe				▲		I/C	Taupe	★	4188
G	Smoke				▲		I/C	Smoke	M4J	4179-H
H	Raven (black)				▲		I/C	Charcoal Black	M4J	4172-H
N	Oxford White/Red				▲		I/C	Canyon Red (medium)	M4J	4158-H
Q	Oxford White/Blue				▲		I/C	Midnight Blue	M4J	4153-H
U	Oxford White/Smoke				▲		I/C	Smoke	M4J	4179-H
Y	Sand Beige				▲		I/C	Sand (light)	M4J	4175-H

E (Taurus), ME (Sable)

	All colors	Sable only		U/P				Black	M4J	1724-H
B	Midnight Blue		I/P	U/P	S/C		I/C	Midnight Blue Regatta Blue (dark)	M4J M4J	4153-H 4184-H
D	Canyon Red		I/P	U/P	S/C		I/C	Canyon Red (medium) Canyon Red (dark)	M4J M4J	4158-H 4185-H
E	Taupe		I/P	U/P	S/C		I/C	Taupe (dark) Taupe	★ ★	4182 4188

C O D E	INTERIOR TRIM COLOR	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P= Instrument Panel U/P= Upper Instrument Panel S/C= Steering column and console P/T= Package Tray I/C= Other Interior Components					INTERIOR PAINT	
			I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002**Note:****LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd**

Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1986 — Cont'd**E (Taurus),ME (Sable) — Cont'd**

G	Smoke		I/P	U/P	S/C		I/C	Charcoal (dark) Smoke	M4J 4148-H M4J 4179-H
Y	Sand Beige		I/P	U/P	S/C		I/C	Sable (dark) Sand (medium)	* 4176 M4J 4178-H

F (Mustang),J (Capri)

A	Charcoal		I/P		S/C	P/T	I/C	Charcoal (dark)	M4J 4148-H
B	Regatta Blue		I/P		S/C	P/T	I/C	Regatta Blue (medium)	M4J 4177-H
D	Canyon Red		I/P		S/C	P/T	I/C	Canyon Red (medium)	M4J 4158-H
N	White/Red	F-66 Convertible	I/P		S/C		I/C	Canyon Red (medium)	M4J 4158-H
Q	White/Blue	F-66 Convertible	I/P		S/C		I/C	Regatta Blue (medium)	M4J 4177-H
W	White/Charcoal	F-66 Convertible	I/P		S/C		I/C	Charcoal (dark)	M4J 4148-H
Y	Sand Beige		I/P		S/C	P/T	I/C	Sand (light)	M4J 4175-H

G (LTD),MG (Marquis)

A	Charcoal		I/P	U/P	▲		I/C	Charcoal (dark)	M4J 4148-H
B	Regatta Blue		I/P	U/P	▲		I/C	Regatta Blue (medium)	M4J 4177-H
C	Sable		I/P	U/P	▲		I/C	Sable (dark)	* 4176
D	Canyon Red		I/P	U/P	▲		I/C	Canyon Red (medium)	M4J 4158-H
Y	Sand Beige		I/P	U/P	▲		I/C	Sand (light)	M4J 4175-H

K (Mark)

B	Midnight Blue			U/P	▲		I/C	Midnight Blue	M4J 4153-H
D	Canyon Red			U/P	▲		I/C	Canyon Red (medium)	M4J 4158-H
E	Taupe			U/P	▲		I/C	Taupe	* 4188
G	Smoke			U/P	▲		I/C	Smoke	M4J 4179-H
H	Raven (black)			U/P	▲		I/C	Charcoal Black	M4J 4172-H
Y	Sand Beige			U/P	▲		I/C	Sand (light) Sand (medium)	M4J 4175-H M4J 4178-H

S (Thunderbird),MF (Cougar)

B	Regatta Blue		I/P	U/P	S/C		I/C	Regatta Blue (medium)	M4J 4177-H
D	Canyon Red		I/P	U/P	S/C		I/C	Canyon Red (medium)	M4J 4158-H
E	Taupe		I/P	U/P	S/C		I/C	Taupe	* 4188
G	Smoke		I/P	U/P	S/C		I/C	Smoke	M4J 4179-H
Y	Sand Beige		I/P	U/P	S/C		I/C	Sand (light)	M4J 4175-H

W (Escort),MW (Lynx)

B	Regatta Blue		I/P		▲		I/C	Charcoal Black Regatta Blue (medium)	M4J 4149-H M4J 4177-H
D	Canyon Red		I/P		▲		I/C	Charcoal Black Canyon Red (medium)	M4J 4149-H M4J 4158-H

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P = Instrument Panel U/P = Upper Instrument Panel S/C = Steering column and console P/T = Package Tray I/C = Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002**Note:****LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd**

Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1986 — Cont'd**W (Escort), MW (Lynx) — Cont'd**

G	Smoke		I/P	▲		I/C	Charcoal Black Smoke	M4J 4149-H M4J 4179-H
Y	Sand Beige		I/P	▲		I/C	Charcoal Black Sand (light)	M4J 4149-H M4J 4175-H

1987**A (Ford), MA (Mercury)**

B	Midnight Blue		I/P	▲		I/C	Midnight Blue	M4J 4153-H
C	Sable		I/P	▲		I/C	Sable (dark)	★ 4176
D	Canyon Red		I/P	▲		I/C	Canyon Red (medium)	M4J 4158-H
G	Smoke		I/P	▲		I/C	Smoke	M4J 4179-H
Y	Sand Beige		I/P	▲		I/C	Sand (light)	M4J 4175-H

B (Tempo), MB (Topaz)

B	Regatta Blue		I/P	U/P	S/C	I/C	Regatta Blue (medium)	M4J 4177-H
D	Scarlet		I/P	U/P	S/C	I/C	Scarlet	M4J 4191-H
G	Smoke		I/P	U/P	S/C	I/C	Smoke	M4J 4179-H
Y	Sand Beige		I/P	U/P	S/C	I/C	Sand (light)	M4J 4175-H

DC (Lincoln Continental)

B	Shadow Blue			U/P	▲	I/C	Regatta Blue (dark)	M4J 4184-H
D	Cabernet			U/P	▲	I/C	Canyon Red (dark)	M4J 4185-H
E	Taupe			U/P	▲	I/C	Taupe	★ 4188
G	Smoke			U/P	▲	I/C	Smoke	M4J 4179-H
H	Raven (black)			U/P	▲	I/C	Charcoal Black	M4J 4172-H
P	Light Sandalwood			U/P	▲	I/C	Sandalwood (light)	M4J 4190-H

DT (Lincoln Town Car)

B	Shadow Blue			▲		I/C	Regatta Blue (dark)	M4J 4184-H
D	Cabernet			▲		I/C	Canyon Red (dark)	M4J 4185-H
E	Taupe			▲		I/C	Taupe	★ 4188
G	Smoke			▲		I/C	Smoke	M4J 4179-H
H	Raven (black)			▲		I/C	Charcoal Black	M4J 4172-H
N	White/Cabernet			▲		I/C	Pastel Oxford Gray Canyon Red (dark)	M4J 4163-H M4J 4185-H
P	Light Sandalwood			▲		I/C	Sandalwood (light)	M4J 4190-H
Q	White/Shadow Blue			▲		I/C	Pastel Oxford Gray Regatta Blue (dark)	M4J 4163-H M4J 4184-H
U	White/Smoke			▲		I/C	Pastel Oxford Gray Smoke	M4J 4163-H M4J 4179-H

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002**Note:****LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd**

Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1987 — Cont'd**E (Taurus), ME (Sable)**

B	Regatta Blue		I/P	U/P	▲		I/C	Regatta Blue (medium) Regatta Blue (dark)	M4J 4177-H M4J 4184-H
D	Scarlet		I/P	U/P	▲		I/C	Canyon Red (dark) Scarlet	M4J 4185-H M4J 4191-H
E	Taupe		I/P	U/P	▲		I/C	Taupe (dark) Taupe	★ 4182 ★ 4188
G	Smoke		I/P	U/P	▲		I/C	Smoke Smoke (dark)	M4J 4179-H M4J 4194-H
Y	Sand Beige		I/P	U/P	▲		I/C	Sand (light) Sable (dark) Sand (medium)	M4J 4175-H ★ 4176 M4J 4178-H

F (Mustang)

B	Regatta Blue		I/P		S/C	P/T	I/C	Regatta Blue (medium)	M4J 4177-H
D	Scarlet		I/P		S/C	P/T	I/C	Scarlet	M4J 4191-H
G	Smoke		I/P		S/C	P/T	I/C	Smoke	M4J 4179-H
N	White/Scarlet	F-66 Convertible	I/P		S/C		I/C	Scarlet	M4J 4191-H
Q	White/Blue	F-66 Convertible	I/P		S/C		I/C	Regatta Blue (medium)	M4J 4177-H
U	White/Smoke	F-66 Convertible	I/P		S/C		I/C	Smoke	M4J 4179-H
Y	Sand Beige		I/P		S/C	P/T	I/C	Sand (light)	M4J 4175-H

K (Mark)

B	Shadow Blue			U/P	▲		I/C	Regatta Blue (dark)	M4J 4184-H
D	Cabernet			U/P	▲		I/C	Canyon Red (dark)	M4J 4185-H
E	Taupe			U/P	▲		I/C	Taupe	★ 4188
G	Smoke			U/P	▲		I/C	Smoke	M4J 4179-H
H	Raven (black)			U/P	▲		I/C	Charcoal Black	M4J 4172-H
P	Light Sandalwood			U/P	▲		I/C	Sandalwood (light)	M4J 4190-H

S (Thunderbird), MF (Cougar)

B	Shadow Blue		I/P	U/P	S/C		I/C	Regatta Blue (dark)	M4J 4184-H
D	Scarlet		I/P	U/P	S/C		I/C	Scarlet	M4J 4191-H
E	Taupe		I/P	U/P	S/C		I/C	Taupe	★ 4188
G	Smoke		I/P	U/P	S/C		I/C	Smoke	M4J 4179-H
H	Raven (black)		I/P	U/P	S/C		I/C	Charcoal Black	M4J 4172-H
Y	Sand Beige		I/P	U/P	S/C		I/C	Sand (light)	M4J 4175-H

W (Escort), MW (Lynx)

B	Regatta Blue		I/P		▲		I/C	Charcoal Black Regatta Blue (medium)	M4J 4149-H M4J 4177-H
D	Scarlet		I/P		▲		I/C	Charcoal Black Scarlet	M4J 4149-H M4J 4191-H

C O D E	INTERIOR TRIM	MODEL/RESTRICTIONS	INTERIOR LOCATION I/P= Instrument Panel U/P= Upper Instrument Panel S/C= Steering column and console P/T= Package Tray I/C= Other Interior Components					INTERIOR PAINT	
	COLOR		I/P	U/P	S/C	P/T	I/C	COLOR	PART NUMBER

P0002 LACQUERS AND SYNTHETIC ENAMELS INTERIOR PAINTS - U.S. USAGE and CANADIAN USAGE — Cont'd**Note:** Code column represents the 2nd digit of the vehicle Trim Code

▲ Steering column, Δ Console,

* Black components may be included in any trim scheme - use M4J 1724-H for black non-metallic and/or M4J 4149-H for charcoal black.

1987 — Cont'd**W (Escort), MW (Lynx) — Cont'd**

G	Smoke		I/P		▲		I/C	Charcoal Black Smoke	M4J 4149-H M4J 4179-H
Y	Sand Beige		I/P		▲		I/C	Charcoal Black Sand (light)	M4J 4149-H M4J 4175-H

1988**A (Ford), MA (Mercury)**

B	Shadow Blue		I/P		▲		I/C	Regatta Blue (dark)	M4J 4184-H
D	Cabernet		I/P		▲		I/C	Canyon Red (dark)	M4J 4185-H
G	Smoke		I/P		▲		I/C	Smoke	M4J 4179-H
P	Light Sandalwood		I/P		▲		I/C	Sandalwood (light)	M4J 4190-H
R	Sandalwood		I/P		▲		I/C	Sandalwood (dark)	★ 4192

B (Tempo), MB (Topaz)

B	Regatta Blue		I/P	U/P	Δ		I/C	Regatta Blue (medium) Regatta Blue (dark)	M4J 4177-H M4J 4199-H
D	Scarlet		I/P	U/P	Δ		I/C	Scarlet Scarlet (dark)	M4J 4191-H M4J 4195-H
G	Smoke		I/P	U/P	Δ		I/C	Smoke Smoke (dark)	M4J 4179-H M4J 4194-H
Y	Sand Beige		I/P	U/P	Δ		I/C	Sand (light) Sand (medium)	M4J 4175-H M4J 4178-H

DC (Lincoln Continental)

A	Titanium			U/P			I/C	Charcoal Black Titanium Titanium (dark)	M4J 4149-H M4J 4200-H M4J 4201-H
B	Shadow Blue			U/P			I/C	Charcoal Black Regatta Blue (dark)	M4J 4149-H M4J 4184-H
D	Cabernet			U/P			I/C	Charcoal Black Canyon Red (dark)	M4J 4149-H M4J 4185-H
K	Cinnabar			U/P			I/C	Charcoal Black Cinnabar Cinnabar (dark)	M4J 4149-H M4J 4197-H M4J 4198-H
P	Light Sandalwood			U/P			I/C	Charcoal Black Sandalwood (medium) Sandalwood (light)	M4J 4149-H M4J 4186-H M4J 4190-H

DT (Lincoln Town Car)

A	Titanium			U/P	▲		I/C	Titanium	M4J 4200-H
B	Shadow Blue			U/P	▲		I/C	Regatta Blue (dark)	M4J 4184-H
D	Cabernet			U/P	▲		I/C	Canyon Red (dark)	M4J 4185-H
H	Raven			U/P	▲		I/C	Charcoal Black	M4J 4172-H
K	Cinnabar			U/P	▲		I/C	Cinnabar	M4J 4197-H

1980/1989 Ford/Lincoln Mercury Cars

SECTION PAINT 37

C O D E	YEAR	NAME	ACRYLIC LACQUER PART NUMBER PREFIX BASE	ACRYLIC LACQUER PART NUMBER SUFFIX	
				1/2 OZ.	5 OZ. SPRAY
P0003 LACQUERS AND SYNTHETIC ENAMELS EXTERIOR PAINTS - U.S. and CANADIAN USAGE — Cont'd o Certification label, ♦ Station wagons, ⊖ Clear coat colors, % Lower Body Side Mldgs. & Bumpers - use with D7AZ-19000-B primer. 5 oz. spray AL81-clr. no. - H not avail. in CANADA					
77	87/ 88	Medium Shadow Blue Metallic	⊖ AL81 6180	B	
78	88	Medium Regatta Blue Metallic	⊖ AL81 5986	B	
79	88/ 89	Medium Titanium Metallic	⊖ AL81 6283	B	H
7A	82	Medium Lime Green Metallic	★ 5898		
7A	85/ 89	Light Regatta Blue	AL81 6047	B	H
7B	81/ 82	Light Spruce Metallic	★ 5819		
7B	86/ 87	Shadow Blue Metallic	AL81 6048	B	
7C	82	Bright Lime Green Metallic	★ 5818		
7C	86	Dark Shadow Blue Metallic	★ 6049		
7E	89	Light Crystal Blue	⊖ AL81 6328	B	H
7F	88/ 89	Twilight Blue	⊖ AL81 6290	B	H
7H	87/ 89	Bright Regatta Blue Metallic	AL81 5979	B	H
7K	88	Dark Shadow Blue Metallic	⊖ AL81 6196	B	H
7L	87/ 88	Medium Cadet Blue Metallic	★ 6219		
7M	80/ 81	Dark Pine Metallic	AL81 5612		H
7N	87/ 89	Dark Shadow Blue Metallic	AL81 6196	B	H
7P	87/ 88	Medium Shadow Blue Metallic	⊖ AL81 6180	B	
7Q	87/ 89	Dark Shadow Blue Metallic	⊖ AL81 6196	B	H
7Y	86/ 87	Argent — for service use — D7AZ 19000-A 13 oz. spray			
7Z	86	Dark Charcoal	AL81 5889	FB	FH
81	85/ 86	Dark Walnut	AL81 6011	B	H
82	87/ 88	Medium Walnut Metallic	★ 6222		
83	84	Medium Desert Tan Metallic	★ 5936		
86	81	Pastel Beige	★ 5551		
86	85/ 86	Medium Light Sand	AL81 5999	B	H
87	82	Medium Light Fawn Metallic	★ 5822		
87	87/ 88	Dark Taupe	★ 6231		
89	81/ 83	Fawn	★ 5726		
8A	80	Dark Chamois Metallic	★ 5667		
8A	86/ 87	Light Sand	★ 6068		
8B	80	Dark Chamois Metallic	★ 5661		
8B	89	Electric Currant Red	⊖ AL81 6425	B	H
8D	80/ 82	Medium Bittersweet Metallic	★ 5736		
8D	86/ 88	Dark Sand Metallic	★ 6056		
8E	80/ 81	Bittersweet Metallic	★ 5656		
8G	82/ 84	Medium Bittersweet Metallic	★ 5897		
8H	85/ 88	Med. Lt. Sand Metallic	⊖ AL81 6010	B	H
8L	81	Med. Dark Nutmeg Metallic	★ 5751		
8L	85/ 88	Light Sand	AL81 5978	B	
8M	85/ 86	Pastel Sand Metallic	★ 5983		
8N	80/ 83	Dark Cordovan Metallic	★ 5496		
8N	88/ 89	Rose Quartz	⊖ AL81 6254	B	
8Q	84	Light Desert Tan	AL81 5934	B	H

C O D E	YEAR	NAME	ACRYLIC LACQUER PART NUMBER PREFIX BASE	ACRYLIC LACQUER PART NUMBER SUFFIX	
				1/2 OZ.	5 OZ. SPRAY
P0003 LACQUERS AND SYNTHETIC ENAMELS EXTERIOR PAINTS - U.S. and CANADIAN USAGE — Cont'd o Certification label, ♦ Station wagons, ⊖ Clear coat colors, % Lower Body Side Mldgs. & Bumpers - use with D7AZ-19000-B primer. 5 oz. spray AL81-clr. no. - H not avail. in CANADA					
8R	87/ 88	Light Walnut	AL81 6170	B	H
8S	84	Pastel Desert Tan	★ 5935		
8S	89	Pastel Adobe	⊖ AL81 6377	B	H
8T	82	Med. Dark Mulberry Metallic	★ 5804		
8T	86	Dark Sand Metallic	⊖ AL81 6071	B	
8U	85/ 86	Medium Sand Metallic	⊖ AL81 5974	B	
8W	80	Chamois Metallic	★ 5739		
8W	85	Dark Walnut Metallic	★ 5991		
8Y	85/ 87	Dark Walnut Metallic	★ 5973		
8Z	85	Medium Sand Metallic	⊖ AL81 5982	B	
8Z	86/ 87	Medium Sand Metallic	⊖ AL81 6114	B	
9	80	Bright Yellow (Fiesta)	★ 1034		
91	83/ 84	Pastel Cadet Blue Metallic	★ 5901		
91	88	Dark Charcoal Metallic	⊖ AL81 6044	B	H
92	83/ 84	Dark Charcoal Metallic	★ 5887		
96	88/ 89	Medium Titanium Metallic	⊖ AL81 6283	B	H
9C	84	Light Copper Metallic	AL81 5943	B	
9D	80/ 83	White	AL81 5418	B	
9G	82	Pastel Opal	★ 5834		
9G	89	Medium Currant Red	⊖ AL81 6381	B	H
9H	88/ 89	Medium Titanium Metallic	⊖ AL81 6283	B	H
9J	83/ 84	Light Desert Tan Metallic	★ 5891		
9L	84/ 89	Pastel White	AL81 5920	B	H
9N	83/ 84	Med. Desert Tan Metallic	AL81 5916	B	H
9P	83	Medium Desert Tan	★ 5853		
9P	88	Dark Cabernet	★ 6317		
9Q	83/ 84	Light Desert Tan	★ 5852		
9S	83/ 84	Dark Walnut Metallic	★ 5922		
9W	84	Dark Charcoal Metallic	★ 5888		
9Y	86	Dark Walnut Metallic	AL81 5858	B	H
9Z	83	Dark Cadet Blue Metallic	★ 5880		
9Z	88/ 89	Light Charcoal Metallic	⊖ AL81 6041	B	
A0	89	Matisse Blue	★ 1024		
A1	88/ 89	Silver Metallic	★ 1012		
A2	88/ 89	Medium Fire Red	AL81 5945	B	
A3	88	Biscay	★ 1017		
A5	88/ 89	Dark Taupe Metallic	★ 6059		
A6	88	Mimosa Yellow (Canadian Tracer only)	★ 6316		
A7	88/ 89	Brt. Regatta Blue Metallic	★ 1016		
A8	89	Driftwood	⊖ AL81 6351	B	
A9	88/ 89	Pastel White	AL81 5920	B	H
AF	89/	Medium Titanium (Lincoln Town Car, Taurus, Sable) bumpers & lower body color	AL81 6432	GB	
AT	89	Nautilus Grey	⊖ AL81 1025	B	H

C O D E	YEAR	NAME	ACRYLIC LACQUER PART NUMBER PREFIX BASE	ACRYLIC LACQUER PART NUMBER SUFFIX	
				1/2 OZ.	5 OZ. SPRAY

P0003

LACQUERS AND SYNTHETIC ENAMELS EXTERIOR PAINTS - U.S. and CANADIAN USAGE — Cont'd

o Certification label, ♦ Station wagons, ⊖ Clear coat colors, % Lower Body Side Mldgs. & Bumpers - use with D7AZ-19000-B primer. 5 oz. spray AL81-clr. no. - H not avail. in CANADA

B	80	White (Fiesta)	AL81 691	B	H
B1	88/ 89	Graphite Metallic	★ 1013		
B2	88/ 89	Bright Red	★ 1015		
B7	89	Twilight Blue	⊖ AL81 6290	B	
B8	89	Medium Sandalwood Metallic	⊖ AL81 1019	B	H
B9	88	Pastel White (Canadian Tracer only)	AL81 5920	B	
C	80	Light Green (Fiesta-before 8/1/80)	★ 1362		
C	80	Dove Grey (Fiesta-from 8/1/80)	★ 1491		
C1	89	Black	AL81 1724	B	H
C2	89	Rosso Red	AL81 1933	B	H
C7	89	Bright Blue Metallic	★ 1018		
C9	89	Pastel White	AL81 5920	B	H
D	80	Terra Cotta (Fiesta)	★ 1396		
D1	89	Light Charcoal Metallic	⊖ AL81 6041	B	
D2	89	Medium Red	⊖ AL81 6158	B	
E	80	Green (Fiesta)	★ 1379		
E1	89	Dark Titanium	⊖ AL81 6182	B	H
E2	89	Dark Red Opal	★ 6230		
F1	89	Crystal	★ 6069		
F2	88	Light Canyon Red (Canadian Tracer only)	AL81 5944	B	
H	80	Gold (Fiesta)	★ 1366		
K	80	Prairie Yellow (Fiesta)	★ 1488		
O	80	Bright Red (Fiesta)	★ 1383		
P	80	Light Beige (Fiesta-before 8/1/80)	★ 1390		
P	80	Sunburst Red (Fiesta-from 8/1/80)	★ 1493		
R	80	Venetian Red (Fiesta)	★ 1136		
S	80	Aztec Bronze (Fiesta)	★ 1469		
T	80	Light Blue (Fiesta)	★ 1401		
V	80	Silver Metallic (Fiesta)	⊖ AL81 6041	B	
X	80	Midnight Blue (Fiesta)	★ 1246		
YH	89/	Dark Titanium (Taurus, Sable) bumpers & lower body color	AL81 6433	GB	

PART NUMBER

DESCRIPTION

PART NUMBER

DESCRIPTION

P0005

PAINTS and REFINISHING MATERIALS - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE

D7AZ	19000-A	Paint (argent lacquer) - - 13oz. aerosol spray can	E7FZ	19000-B	Paint-Silver Metallic-used to paint polycast wheels - - 13 oz. aerosol spray can
E4AZ	19000-A	Paint-Charcoal - - 12-3/4 oz. spray can -use for crash pad repair	E7FZ	19000-C	Paint-Argent-used to paint polycast wheels - - 13 oz. aerosol spray can
E4AZ	19000-B	Paint-Cadet Blue - - 12-3/4 oz. spray can -use for crash pad repair	F2AZ	19503-A	Paint assortment - "Lacquer" - - (24) 1/2 oz. touch-up tubes of 1992 exterior colors for Ford car models
E4AZ	19000-C	Paint-Desert Tan - - 12-3/4 oz. spray can -use for crash pad repair	F2AZ	19503-B	Paint assortment - "Lacquer" - - (24) 5 oz. spray cans of 1992 exterior colors for Ford car models
★ E4AZ	19000-D	Paint-Canyon Red - - 12-3/4 oz. spray can - use for crash pad repair - NR	F2AZ	19503-C	Paint assortment - "Lacquer" - (12) 13 oz. spray cans of 1992 interior colors for Ford car models
E7FZ	19000-A	Paint-Gloss Argent-used to paint polycast wheels - - 13 oz. aerosol spray can	F2MY	19503-A	Paint assortment - "Lacquer" - - (24) 1/2 oz. touch-up tubes of 1992 exterior colors for Lincoln-Mercury models

PART NUMBER		DESCRIPTION	PART NUMBER	DESCRIPTION
P0005 PAINTS and REFINISHING MATERIALS - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE — Cont'd				
F2MY	19503-B	Paint assortment - "Lacquer" - - (24) 5 oz. spray cans of 1992 exterior colors for Lincoln-Mercury models	★ E4AZ 19554-A	Kit-crash pad repair-for Industrial use only-consists of (1) 1/2 oz. plastisol, (1) pc. grainmold paper, (1) pc. 400 grain paper, (1) applicator - NR
F2MY	19503-C	Paint assortment - "Lacquer" - (12) 13 oz. spray cans of 1992 interior colors for Lincoln-Mercury models		
F3AZ	19503-B	Paint assortment - "Lacquer" - (12) 13 oz. spray cans of 1993 interior colors for Ford car models		
P0005 CLEANERS, WAXES and POLISHES - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE				
B7A	19520-AA	Tar and road oil remover - - (12) 16 oz. cans	E8AZ 19526-A	Soil and Spot Lifter-for use on most automotive pile-type fabrics (12) 8 oz. plastic bottles
B7A	19521-AA	Spot and stain remover - - (12) 1 pt. cans	F2AZ 19526-AA	Triple Clean-for leather and vinyl trim- -vinyl and convertible tops -not for use on cloth fabrics - - (1) 1 gal. "liqui-box" container
E0AZ	19521-AA	Cleaner (leather and vinyl) - - (12) 16 oz. Plastic bottles		
F2AZ	19521-WA	Deluxe Leather/Vinyl cleaner - (12) 16 oz. Plastic bottles	B7A 19530-B	New car prep. - - (2) 1 gal. cans
F2VY	19521-AA	Cleaner (leather and vinyl) - - (1) 5 gallon liquid-box container	B7AZ 19530-AA	Custom silicone gloss polish - - (12) 16 fl. oz. bottles
F3AZ	19521-WA	Spot and stain remover - - (12) 1 pt. sprayer bottle	★ E6AZ 19530-A	Vinyl Protectant - used to enhance the beauty of interior and exterior vinyl, rubber, leather and plastic surfaces - - (12) 12 fl. oz. pump spray plastic bottles - r/b E6AZ 19530-AA (6/91)
★ 8A	19522	Bright metal cleaner - - (12) 1 pt. cans -r/b 8A 19522-A (7/89)		
8A	19522-A	Custom Bright Metal Cleaner - - (12) 16 fl. oz. bottles	E6AZ 19530-AA	Custom Vinyl Protectant - used to enhance the beauty of interior and exterior vinyl, rubber, leather and plastic surfaces - - (12) 12 fl. oz. bottles w/pump spray
B8A	19523-AA	Multi-Purpose Cleaner concentrate - - for -vinyl and leather trim -white sidewall tires -vinyl and convertible tops -automobile rugs and upholstery -automobile exteriors - - (12) 1 qt. plastic bottles	★ E6AZ 19530-B	Vinyl Protectant - used to enhance the beauty of interior and exterior vinyl, rubber, leather and plastic surfaces - - (4) 1 gal. (3.7856) plastic bottles - N/R (9/91)
B8A	19523-B	Multi-Purpose Cleaner concentrate - - for -vinyl and leather trim -white sidewall tires -vinyl and convertible tops -automobile rugs and upholstery -automobile exteriors - - (6) 1 gal. plastic bottles	F1AZ 19530-A	Clearcoat polish - for use on all vehicles with clearcoat paint - - (12) 16 fl. oz. bottles
B8A	19523-C	Multi-Purpose Cleaner concentrate - - for -vinyl and leather trim -white sidewall tires -vinyl convertible tops -automobile rugs and upholstery -automobile exteriors - - 55 gal. drum	F2AZ 19530-A	Custom Vinyl Protectant - used to enhance the beauty of interior and exterior vinyl, rubber, leather and plastic surfaces - - (12) 12 fl. oz. bottles w/pump spray
C9AZ	19523-A	Wash and wax concentrate - - (4) 1 gal. plastic containers	F2LY 19530-AA	Clearcoat polish - for use on all vehicles with clearcoat paint - - (1) 5 gal. "liqui-box" container
★ D6AZ	19523-A	Wash and wax concentrate - - (12) 16 oz. plastic containers - r/b D6AZ 19523-AA (11/89)	F2SZ 19530-AA	Custom Vinyl Protectant - used to enhance the beauty of interior and exterior vinyl, rubber, leather and plastic surfaces - - (1) 5 gal. "liqui-box" container
D6AZ	19523-AA	One-Step Wash and Wax concentrate - - (12) 16 fl. oz. bottles	F2VY 19530-A	Super Premium Tire & Trim Dressing - used to add a brilliant, long lasting shine to tires, rubber and trim - - (12) 16 fl. oz. bottles w/sprayer.
E8AZ	19523-AA	Upholstery Cleaner (extra strength)- - (12) 14 oz. aerosol cans	F2VY 19530-B	Super Premium Tire & Trim Dressing - used to add a brilliant, long lasting shine to tires, rubber and trim - - (4) 1 gal. bottles.
F2AZ	19523-A	One-Step Wash and Wax concentrate - - (12) 16 fl. oz. bottles	F2VY 19530-WA	Super Premium Tire & Trim Dressing - used to add a brilliant, long lasting shine to tires, rubber and trim - - (1) 5 gal.liquid-box container
F2AZ	19523-B	Wash and wax concentrate - - (4) 1 gal. plastic containers	F2ZZ 19530-AA	Custom silicone gloss polish - - (1) 5 gal. "liqui-box" container
F2AZ	19523-C	Wash and wax concentrate - - (1) 5 gal. "liqui-box" container	★ B4A 19534-A	Custom paste wax - - (12) 8 oz. cans - r/b B4A 19534-AA (6/91)
F2DZ	19523-AA	Multi-Purpose Cleaner - - for vinyl and leather trim, white sidewall tires, vinyl and convertible tops, automobile carpets and upholstery, automobile exteriors - - (1) 5 gal. "liqui-box" container		
E0AZ	19526-AA	Triple Clean-for leather and vinyl trim- -vinyl and convertible tops -not for use on cloth fabrics - - (12) 16 oz. bottles-w/pump spray	B4A 19534-AA	Custom Paste Wax - - (12) 8 oz. cans
★ E0AZ	19526-B	Cleaner-whitewall tire - - (12) 16 oz. plastic spray bottles - r/b E0AZ 19526-BA (6/91)	★ E4AZ 19534-A	Custom Cream Wax - - w/applicator - - (12) 8 oz. containers -r/b E4AZ 19534-AA (11/89)
E0AZ	19526-BA	Whitewall Tire Cleaner-extra-strength - - (12) 16 fl. oz. bottles	E4AZ 19534-AA	Custom Cream Wax - - w/applicator - - (12) 8 oz. cans
E0AZ	19526-C	Whitewall Tire Cleaner - - (4) 1 gal. jugs	E3AZ 19F535-A	Vinyl Hardtop cleaner and reconditioner - - (12) 16 oz. containers
★ E2AZ	19526-A	Automotive Fabric Spot Lifter-for use on most automotive cloth fabrics and carpets- (12) 6.5 oz. aerosol cans w/brush cap - r/b E8AZ 19526-A (11/89)	E3AZ 19F535-B	Vinyl Hardtop cleaner and reconditioner - - 1 gal. container

PART NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION
P0005 CLEAR VISION AIDS - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE			
E4AZ 19C507-AA	Ultra-Clear Spray Glass Cleaner -- (12) 18 oz. aerosol cans	C9AZ 19550-BA	Ultra Clear Windshield Washer - concentrate -- (12) 32 oz. plastic bottles
C9AZ 19550-AA	Ultra Clear Windshield Washer - concentrate -- (12) 16 oz. plastic bottles		

P0005 COOLING SYSTEM AIDS - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE			
★ D6AZ 19A503-AA	Cooling System Flush (non acid) -- (12) 12 fl. oz. cans - r/b F1AZ 19A503-A (12/91)	D9AZ 19558-A *RA 1	Protector Pellets (cooling system)--2 pellets per card, 24 cards per carton
F1AZ 19A503-A	Cooling System Flush (non acid) -- (12) 11 fl. oz. cans	D9AZ 19558-PAK *RA 1000	Kit-Protector Pellets(cooling system)-consist of 48 pellet cards and 1 fender cover
E2FZ 19549-AA	Cooling System Fluid (permanent anti-freeze) -- (6) 1 gal. (3.796) containers		
E2FZ 19549-B	Cooling System Fluid (permanent anti-freeze) -- 55 gal. (2086) drum	E6AZ 19558-A *RA-2	Protector powder (cooling system) - - (20) 3/4 oz. tubular plastic containers on a display carton

PART NUMBER	FORD SPECIFICATION NUMBER	DESCRIPTION
-------------	---------------------------	-------------

P0005 MOTOR OILS and LUBRICANTS - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE

Note: Always refer to the owners manual or Ford shop manual to verify the proper specification number before ordering.

C6AZ 19542-AA	ESA M6C25-A	Brake and hydraulic clutch fluid (extra heavy duty)- for vehicles w/disc or drum brakes - - (24) 16 oz. (473.12 ml.) cans
C6AZ 19542-BA	ESA M6C25-A	Brake and hydraulic clutch fluid (extra heavy duty)- for vehicles w/disc or drum brakes - - (12) 1 qt. (0.946 litres) cans
C8AZ 19B546-A	EST M2C118-A	Additive-friction modifier-hypoid gear-for locking rear axles - - (12) 4 oz. (118.28 ml.) plastic bottles
★ D8DZ 19C547-A	ESP M2C83-C	Lubricant (for manual 3 and 4 speed trans. and Fiesta manual transaxle) - - 5 gal. (18.9l) pail - r/b F2ZZ 19C547-A (12/91)
E5RY 19C547-A	ESD M2C175-A	Manual trans. fluid for Merkur manual trans. - - (6) 1 qt. screw top containers
F2ZZ 19C547-A	ESP M2C83-C	Lubricant (80W-for manual 3 and 4 speed trans. and Fiesta manual transaxle) - - 1 qt. (0.946 litre) bottle
C0AZ 19553-AA	ESR M13P4-A	Silicone lubricant (jell type) - - 8 oz. (226.80 g.) tube
D3AZ 19553-A	ESF M2C113-A	Lubricant (mini-vent window) - - 4 oz. (118.28 ml.) plastic bottle
D7AZ 19553-AA	ESR M13P4-A	Silicone lubricant - - 15 oz. (443.55 ml.) aerosol spray can
E25Y 19553-A	ESF M99B112-A	Lubricant (rubber)-for suspension insulators - - 2 oz. tube
E2SZ 19553-A	ESE M2C160-A	Dry Film Lubricant - reduces friction resulting from metal to metal contact and helps provide corrosion resistance - - 4 oz. can
C3AZ 19578-A	ESW M1C87-A	Steering gear grease - - (4)-14 1/2 oz. (411.075 g.) cartridges
D8AZ 19578-A	ESA M1C175-A	Steering gear grease-for manual rack and pinion str. gear - - 1 lb. (0.453 kg.) can
B7A 19579-C	ESR M99C80-A	Crankcase conditioner-for gasoline engines only - - (12) 16 oz. (473.12 ml.) cans
★ D9AZ 19579-CA	ESR M99C80-A	Oil conditioner-for gasoline engines only - - (12) 16 fl. oz. cans - r/b D9AZ 19579-D (9/91)
D9AZ 19579-D	ESR M99C80-A	Engine assemble lubricant-for gasoline engines only - - (12) 16 fl. oz. cans
★ E4AZ 19579-G	ESR M2C179-A	Motor oil - 20W50 - for racing purposes only - - (6) 1 gal. plastic containers - r/b XO 20W50-GR (6/91)
E4AZ 19579-H	ESE M2C153-C3	Motor oil - 5W30 High Performance (Synthetic) - - (6) 1 gal. plastic containers
★ E0AZ 19580-AA	ESP M2C154-A	Hypoid gear lubricant-(for Traction-Lok rear axles use with C8AZ-19B546-A) (12) 1 qt. (0.946 litre) plastic containers with spouts - r/b XY 90-QL (10/90)
★ E0AZ 19580-B	ESP M2C154-A	Hypoid gear lubricant - (for Traction-Lok rear axles use with C8AZ-19B546-A) - - (6) 1 gal. containers - NR (6/91)
★ E0AZ 19580-C	ESP M2C154-A	Hypoid gear lubricant - (for Traction-Lok rear axles use with C8AZ-19B546-A) - - 120 lb. keg - NR (6/91)
D2AZ 19581-A	ESF M1C160-A	Speedometer cable lubricant--1 lb. (0.453 kg) can
★ E4AZ 19582-D	ESP M2C164-A	Automatic Trans. Fluid-Type "MV"-for ATX A/T to improve cold weather engine starting - - (2) 2.5 gal. (9.46 litres) plastic containers-NR (2/86)
★ E4AZ 19582-E	ESP M2C166-H	Automatic Trans. Fluid-Type "H"-for C5, AXOD, 1986/ AOT, ATX, C6, A/T only- consult owners guide for proper application - - (24) 1 qt. (0.946) cans- r/b XT 2-QDX (9/87)
E6AZ 19582-AA	ESR M2C165-A	Premium Power Steering Fluid - use in P/S pumps requiring ESW M2C33-F type "F" A/T fluid. Can also be used to top-off A/T requiring type "F" fluid. Consult owners guide for proper application - - (48) 12 fl. oz. long neck plastic bottles.
D9AZ 19583-A	ESR M99B135-A	Rubber lubricant (triple purpose) - - (4) 1 gal. (3.785 kg.) containers - - use to mount & demount tires, remove rubber squeaks and clean rubber parts
D0AZ 19584-AA	ESR M1C159-A	Multi-purpose grease - - (4) 4 oz. (113.40 g.) aluminum tubes w/plastic cut off spout
D7AZ 19584-AA	ESR M1C159-A	Multi-purpose grease - - 15 oz. (443.45 ml.) spray can
F0AZ 19584-A	ESA M1C232-A	Grease-Ignition Lock - - 10.8 oz. (306 gram) spray can

PART NUMBER	FORD SPECIFICATION NUMBER	DESCRIPTION
P0005 Note: MOTOR OILS and LUBRICANTS - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE — Cont'd Always refer to the owners manual or Ford shop manual to verify the proper specification number before ordering.		
F2AZ 19584-A	ESB M1C158-A	Grease-Electrical - - 2 oz. (56.7g) tube
D8AZ 19587-AA	ESB M2C20-A	Lock Lubricant - - (12) 3.5 oz. aerosol cans w/snorkel
★ C1AZ 19590-BA	ESA M1C75-B	Lubricant long life - - (4) 14 1/2 oz. cartridges - NR (9/90)
★ C1AZ 19590-C	ESA M1C75-B	Lubricant long life - - 120 lb. keg - NR (6/91)
★ C1AZ 19590-D	ESA M1C75-B	Lubricant long life - - 25 lb. pail - NR (6/91)
★ C1AZ 19590-E	ESA M1C75-B	Lubricant long life - - (4) 5 lb. (2.26 kg.) pails-NR
D7AZ 19590-A	ESA M1C172-A	Lubricant (disc brake caliper slide grease) - - (4) 4 oz. (113.40 g.) tubes
E0AZ 19590-A	ESE M12A5-A	Graphite Lubricant-for 4.2L intake manifold gaskets - - 4 fl. oz. (.118 litre) container w/brush
★ E1AZ 19590-A	ESA M1C189-A	Speed control slip ring grease (str. whl. mounted) - - 8 oz. (.226 kg) tube - r/b E8AZ 19590-A (10/89)
E2FZ 19590-B	ESP M1C187-A	Grease-C.V.U.-Joint -- 90 gram tube
E43Z 19590-A	ESP M1C207-A	Grease-C.V.U.-Joint Hi Temp.(Blue) - - 90 gram tube
E7FZ 19590-A	ESB M1C111-A	Lubricant-teslon grease-for Escort, Lynx, passive restraint system - - 1/2 oz. tube
E8AZ 19590-A	ESA M1C221-A	Grease-Speed Control Slip Ring - used with str. whl. mounted speed control -- 1 oz. (28.4 grams) tube
★ D1RY 19592-A	ESEA M1C1014	Grease (disc brake lubricant-for 1971/77 Capri disc brake squeal - - 125 gram tube - NR
★ XO 10W30-BP	ESR M2C127-B	Motor oil (Premium)-10W30 - - 1 gal. (bulk) - - for all gas engines & diesel engines exc. turbo-r/b XO 10W30-BSP (1/90)
★ XO 10W30-DP	ESR M2C127-B	Motor oil (Premium)-10W30 - - 55 gal. (208.2 l) drum - - for all gas engines & diesel engines exc. turbo-r/b XO 10W30-DSP (1/90)
★ XO 10W30-QP	ESR M2C127-B	Motor oil (Premium)-10W30 - - (12) 1 qt. (0.946 l) cans - - for all gas engines & diesel engines exc. turbo-r/b XO 10W30-QSP (1/90)
* XG 1-C	ESA M1C75-B	Grease-Premium Long Life - - (40) 14 oz. (369 g) cartridges
* XG 1-K	ESA M1C75-B	Grease-Premium Long-Life--120 lb. keg
* XO 10W30-BSP	ESR M2C129-C	Motor oil (Super Premium)-10W30 - - 1 gal. (bulk) - - for gas engines only
* XO 10W30-DSP	ESR M2C129-C	Motor oil (Super Premium)-10W30 - - 55 gal. (208.2 l) drum - - for gas engines only
* XO 10W30-QSP	ESR M2C129-C	Motor oil (Super Premium)-10W30 - - (12) 1 qt. (0.946 l) cans - - for gas engines only
* XO 10W40-BSP	ESR M2C129-C	Motor oil (Super Premium)-10W40 - - 1 gal. (bulk) - - for gas engines only
* XO 10W40-DSP	ESR M2C129-C	Motor oil (Super Premium)-10W40 - - 55 gal. (208.2 l) drum - - for gas engines only
* XO 10W40-QSP	ESR M2C129-C	Motor oil (Super Premium)-10W40 - - (12) 1 qt. (0.946 l) cans - - for gas engines only
* XO 15W40-BSD	ESR M2C171-A	Motor oil (Super Duty)-15W40 - - 1 gal. (bulk) - - for all gas and diesel engines
* XO 15W40-DSD	ESR M2C171-A	Motor oil (Super Duty)-15W40 - - 55 gal. (208.2 l) drum - - for all gas and diesel engines
* XO 15W40-QSD	ESR M2C171-A	Motor oil (Super Duty)-15W40 - - (12) 1 qt. (0.946 l) cans - - for all gas and diesel engines
* XO 20W40-BP	ESR M2C127-B	Motor oil (Premium)-20W40 - - 1 gal. (bulk) - - for all gas engines & diesel engines exc. turbo
* XO 20W40-DP	ESR M2C127-B	Motor oil (Premium)-20W40 - - 55 gal. (208.2 l) drum - - for all gas engines & diesel engines exc. turbo
* XO 20W40-QP	ESR M2C127-B	Motor oil (Premium)-20W40 - - (12) 1 qt. (0.946 l) cans - - for all gas engines & diesel engines exc. turbo
* XO 20W50-GR	ESR M2C179-A	Motor oil - 20W50 - for racing purposes only - - (6) 1 gal. plastic containers
* XO 20W50-QR	ESR M2C179-A	Motor oil - 20W50 - for racing purposes only - - (12) 1 qt. plastic containers
* XO 30-BSD	ESR M2C171-A	Motor oil (Super Duty)-30W - - 1 gal. (bulk) - - for all gas and diesel engines
* XO 30-DSD	ESR M2C171-A	Motor oil (Super Duty)-30W - - 55 gal. (208.2 l) drum - - for all gas and diesel engines
* XO 30-QSD	ESR M2C171-A	Motor oil (Super Duty)-30W - - (12) 1 qt. (0.946 l) cans - - for all gas and diesel engines
* XO 5W30-BSP	ESR M2C129-C	Motor oil (Super Premium)-5W30 - 1 gal. (bulk) - - for gas engines only
* XO 5W30-DSP	ESR M2C129-C	Motor oil (Super Premium)-5W30 - 55 gal. (208.2L) drum - - for gas engines only
* XO 5W30-QSP	ESR M2C129-C	Motor oil (Super Premium)-5W30 - - (12) 1 qt. (0.946 l) cans - - for gas engines only
* XT 1-BF	ESR M2C165-A	Automatic Trans. Fluid-Type "F"-for FMX and 1980-C3 A/T only - - Power Steering Fluid-for Ford CII P/S pump only - also see 19582 P/S fluid - - 1 gal. (bulk)
* XT 1-DF	ESW M2C33-F	Automatic Trans. Fluid-Type "F"-for FMX and 1980-C3 A/T only - - Power Steering Fluid-for Ford CII P/S pump only - also see 19582 P/S fluid - - 55 gal. (208.2 litres) drum-consult owners guide for proper application
* XT 1-QF	ESW M2C33-F	Automatic Trans. Fluid-Type "F"-for FMX and 1980-C3 A/T only - - Power Steering Fluid-for Ford CII P/S pump only - also see 19582 P/S fluid - - (12) 1 qt. (0.946 litres) cans-consult owners guide for proper application

PART NUMBER	FORD SPECIFICATION NUMBER	DESCRIPTION
P0005 Note: MOTOR OILS and LUBRICANTS - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE — Cont'd Always refer to the owners manual or Ford shop manual to verify the proper specification number before ordering.		
* XT 2-BDX	MERCON®	Automatic Trans. Fluid-Type MERCON® - for JATCO, C4, C6, A4LD 1980-85 AOT, 1981-85 ATX, 1981-86 C3, 1984-85 ZF A/T only-also lubricant for MTX and 5OD M/T- consult owners guide for proper application -- 1 gal. (bulk)
* XT 2-DDX	MERCON®	Automatic Trans. Fluid-MERCON® - for JATCO, C4, C6, A4LD 1980-85 AOT, 1981-85 ATX, 1981-86 C3, 1984-85 ZF A/T only-also lubricant for MTX and 5OD M/T- consult owners guide for proper application -- 55 gal. (208.2 l) drum
* XT 2-QDX	MERCON®	Automatic Trans. Fluid-MERCON® - for JATCO, C4, C6, A4LD 1980-85 AOT, 1981-85 ATX, 1981-86 C3, 1984-85 ZF A/T only-also lubricant for MTX and 5OD M/T- consult owners guide for proper application -- (12) 1 qt. (0.946 l) cans
* XY 90-KL	ESP M2C154-A	Premium Rear Axle Lubricant- SAE90 (for Traction-Lok rear axles use with C8AZ-19B546-A) -- 16 gal. drum
* XY 90-QL	ESP M2C154-A	Premium Rear Axle Lubricant-SAE 90 (for Traction-Lok rear axles use with C8AZ-19B546-A) (12) 1 qt. (0.946 litre) plastic containers

PART NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION
P0005 SEALERS and ADHESIVES - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE			
★ D7AZ 19B508-AA	Gasket and Trim Adhesive -- 16 fl. oz. can w/brush - r/b D7AZ 19B508-B (1/91)	D6AZ 19560-A	Caulking cord -- (8) 80 ft. rolls-3/16" dia.
D7AZ 19B508-B	Gasket and Trim Adhesive -- 16 fl. oz. bottle w/brush	★ D2FZ 19562-A	Seal windshield and backlite glass-foam tape -- 1/4" x 5/8" x 13' - NR (6/91)
★ E4AZ 19C548-A	Automatic transmission sealer -- (6) 11 fl. oz. (0.325 l) containers - NR (9/91)	D2FZ 19562-B	Seal quarter window-foam tape -- 1/4" x 3/8" x 5'
★ C0AZ 19552-AA	Weatherstrip Adhesive (light colored) -- (12) 5 fl. oz. tubes- r/b E8AZ 19552-AA (10/89)	D6AZ 19562-AA	Silicone Rubber Adhesive/Sealant clear -- 3 fl. oz. tube
E8AZ 19552-A	Weatherstrip and Rubber Adhesive-synthetic light colored --(12) 5 fl. oz. tubes	D6AZ 19562-BA	Silicone Rubber Adhesive/Sealant black -- 3 fl. oz. tube
B5A 19554-A	Perfect seal sealing compound -- 4 oz. can	★ D8RZ 19562-A	Windshield sealant kit-for windshield replacement on Fiesta vehicles - NR (6/91)
C9AZ 19554-B	Sealer (liquid butyl)-black-for sealing butyl installed windshield and backlite -- 1 pt. can	D9AZ 19562-A	Butyl tape kit -- "I" beam section (233")-for windshield replacement on vehicles (exc. Bobcat, Pinto) prior to being licensed by dealer
D7AZ 19554-BA	Perfect Seal Sealing Compound -- (12) 13.2 oz. aerosol cans	D9AZ 19562-B	Windshield glass seal kit -- (5/16") round (233") incl. glass primer-(exc. Pinto, Bobcat)
D7AZ 19554-C	414 Adhesive kit-used for repair of loose vinyl inserts to body side mouldings-consists of (5) .33 fl. oz. bottles of 414 adhesive and (1) 4 oz. aerosol can of accelerator	E0AZ 19562-A	Windshield seal kit-urethane-for w/shields with urethane seal -- use with D9AZ 19562-A,B or E4AZ 19627-C. - For industrial use only
D8AZ 19554-A	Sealant-pipe (with teflon) -- 1.69 fl. oz. tube	E1FZ 19562-A	Gasket eliminator-used to seal cover on MTX trans. -- 0.2 fl. oz. (6 ml.) tube
D9AZ 19554-CA	Rear view mirror Adhesive Kit - req'd to attach rear view mirror brkt. -- consists of (10) one shot pkgs. of .01 fl. oz. (2.957 ml) adhesive & .02 fl. oz. (5.914 ml) accelerator	★ E1ZZ 19562-A	Glass Primer Kit - used to attach rear window louver - for industrial use only - NR (4/91)
E0AZ 19554-AA	Thread lock and sealer -- (10) .20 fl. oz. (6 ml.) tubes	E2AZ 19562-B	Gasket Maker-for use when specified in the replacement of gaskets and the sealing of flanges-not for use on oil pans, rocker covers and MTX trans. -- 1.7 fl. oz. (50 ml) tube
E0AZ 19554-BA	Stud and Bearing Mount-high-strength thread locker-stops loosening and leakage -- (10) .20 fl. oz. (6 ml.) tubes	★ E3AZ 19562-A	Silicone gasket and sealant (RTV) -- 10.3 fl. oz. caulking cartridge -r/b E8AZ 19562-A (3/89)
E2FZ 19554-B	Thread lock 262 -- used to prevent vibration loosening of nuts, bolts or screws -- 0.34 fl. oz. (10 ml)	E69Z 19562-A	Seal - pressure sensitive urethane foam - used to seal modular windows -- 25 ft. roll
★ E6AZ 19554-A	Adhesive - air conditioning sealer (biocide) -- 6 fl. oz. - NR	E6AZ 19562-A	Silicone Gasket Adhesive - used to seal silicone gaskets -- 8 fl. oz. (0.2366) can with brush
E7AZ 19554-A	Compound-aluminum wheel (leak) repair - 5/8" dia. x 5" stick -- 1 oz.	E8AZ 19562-A	Silicone Gasket and Sealant (RTV) -- 5 fl. oz. (.150 liters) caulking cartridge
E8AZ 19554-A	Instant Adhesive-used for repair of loose vinyl inserts to body side mouldings-- (12) .06 fl. oz. (1.77 ml) tubes	F1AZ 19562-A	Silicone gasket and sealant -- 5 oz. caulking tube
★ E8OY 19554-A	Adhesive/Sealant-used to secure ball stud (5C561)--10ml bottle-Campaign # 88S44 - NR (6/91)	F1VY 19562-A	Headliner Adhesive Kit -- contains (2) 12 fl. oz. (355ml) caulking cartridges with nozzles
F2AZ 19554-AA	Perfect seal sealing compound -- 12 oz. can spray can		
F3AZ 19554-AA	Sealant 509-10 ml plastic tube		

P0005 SPECIAL PRODUCTS - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE			
D7AZ 19A331-A *WA-10	Silicone Dielectric Compound - for distributor rotor tip and Duraspark ignition cable -- 3 oz. tube	E7AZ 19A426-A	Heat Transfer Compound-for Ford integral alternators-aids heat transfer between rectifier and alternator housing -- 5 oz. (142 g) tube

PART NUMBER		DESCRIPTION	PART NUMBER		DESCRIPTION
P0005 SPECIAL PRODUCTS - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE — Cont'd					
★ D7AZ	19A501-A	Rust penetrant and inhibitor -- (6) 12 oz. aerosol cans - r/b D7AZ 19A501-AA (12/91)	F2AZ	19K530-WA	Quality Car Care Kit - (1) dusting cloth, (1) 4 oz. can tire & trim dressing, (1) 8 oz. bottle clear coat polish, (1) 4 oz. can glass cleaner in packing container
D7AZ	19A501-AA	Rust Penetrant and Inhibitor-helps free parts frozen by rust and corrosion -- (6) 12 oz. aerosol cans	F3AZ	19530-WA	Polish - Custom clear coat - (12) 16 oz. bottles
E8AZ	19A501-AA	Choke and Linkage Cleaner-used to clean- free auto. choke, carb. linkage and manifold heat controls -- (12) 13 oz. aerosol cans w/snorkel	★ C8AZ	19C544-B	Gas Line Antifreeze -- (24) 12 oz. containers - r/b C8AZ 19C544-BA (6/91)
E8AZ	19A501-B	Penetrating Lubricant-cleans,lubricates,protects,displaces moisture and frees rusty parts--(12) 9 oz. aerosol cans w/ 5" snorkel	★ C8AZ	19C544-BA	Gas Line Antifreeze - helps prevent carb. icing and condensation from freezing in tank and gas lines -- (24) 12 fl. oz. bottles - NR
F2AZ	19A501-A	Rust Penetrant and Inhibitor-helps free parts frozen by rust and corrosion -- (6) 12 oz. aerosol cans	★ C9AZ	19C544-AA	Engine Starting Fluid -- (12) 8.3 oz. aerosol cans - NR
D7AZ	19515-A	Super Seal Anti-Corrosion Compound - (Sprayable) -- 16 gal.	E8AZ	19C544-A	Gas Stabilizer - used for seasonally stored vehicles to prevent the necessity of draining gas tank and lines -- (12) 8 fl. oz. plastic bottles
D8AZ	19515-BA	Super Seal Anti-Corrosion Compound -- (12) 16 oz. aerosol spray cans	D8AZ	19562-AA	Rear Window Defroster Repair - repairs small open-circuit breaks in electrically heated, grid type, rear window defrosters -- 1/8 oz. bottle
★ D9AZ	19515-A	Abrasion Resistant Coating -- (6) 1 qt. (0.946 liter) cans - NR	E7DZ	19562-A	Kit-heated backlite repair for Taurus, Sable s/wags. -- consists of 6 pcs. of tape
E4AZ	19515-A	Super Seal Anti-Corrosion Compound -- 55 gal. drum	C9AZ	19577-B	Refrigerant compressor oil-used with York or Tecumseh compressors -- 1 qt. can
E7AZ	19515-A	Super Seal fabric protector-for dealer use only-not for retail sale-for cloth trim -- (12) 16 oz. cans with screw top	★ D1VY	19577-B	Refrigerant compressor oil - use w/Frigidaire compressor -- 1 qt. can - NR (6/91)
E7AZ	19515-B	Super Seal fabric protector-for dealer use only-not for retail sale-for cloth trim -- 5 gal. pail with pull-up spout/handle	E73Z	19577-A	A/C Compressor Oil-used w/FS-6,FX-15 or Nippodenso compressor -- 1 qt. can
E9AZ	19515-A	Undercoating-water base airless spray-for industrial use only--16 gal.(60.56 litres) drum	E9SZ	19577-A	Synthetic Supercharger Fluid-used on T/Bird,Cougar w/3.8L S/C engine--4 fl. oz. (0.118 l)
E9AZ	19515-B	Undercoating-water base airless spray-for industrial use only--55 U.S. gal drum	D9AZ	19579-AA	Carburetor Tune-Up Cleaner - for gasoline engines only - (12) 18 oz. aerosol cans
E9AZ	19515-C	Undercoating-solvent base airless spray-for industrial use only--16 gal.(60.56 litres) drum	★ D9AZ	19579-B	Carburetor Tune-Up Cleaner - for gasoline engines only -- (12) 16 oz. cans - r/b D9AZ 19579-BA (6/91)
E9AZ	19515-D	Undercoating-solvent base airless spray-for industrial use only--55 U.S. gal. drum	D9AZ	19579-BA	Carburetor Tune-Up Cleaner - for gasoline engines only - (12) 16 fl. oz. cans
F3AZ	19515-SA	Super Seal Anti-Corrosion Compound -- (12) 16 oz. aerosol spray cans	E6AZ	19579-AA	Fuel Injector Cleaner - used to reduce deposit related to engine knock and cleans dirty injectors -- (12) 12 oz. (0.35L) cans
B7A	19517-B	Wax Treated Dusting Cloth -- carton of (100)	E6AZ	19579-BA	Cleaner-metal brake parts - for use only for off-vehicle cleaning of metal brake parts. Do not use on rubber parts or brake pads or linings or painted surfaces -- (12) 16 oz. (454 g) aerosol can w/5" extension nozzle
D3AZ	19517-AA	Wax Treated Dusting Cloth -- plastic bag container of 24	E6AZ	19579-C	Power Flush Injector Fluid - for use with Rotunda fuel injector cleaner/tester DO NOT add this product to the vehicle fuel tank -- (12) 8 fl. oz. (0.2376) bottle
D3AZ	19517-B	Buffing and Polishing Pad -- carton of (12)	F2AZ	19579-A	Premium Fuel Injector Cleaner - used to reduce deposit related to engine knock and cleans dirty injectors -- (12) 12 oz. cans
E0AZ	19517-B	Wax Treated Dusting Cloth-bulk roll -- 15" wide x 90 ft. long	F2AZ	19579-SA	Fuel Injector Cleaner-12 oz.bottle and cleans dirty injectors -- (12) 12 oz. cans
★ E6AZ	19517-A	Rotary car washing brush kit - NR (6/91)	F2ZZ	19579-AA	Cleaner-metal brake parts - for use only for off-vehicle cleaning of metal brake parts. Do not use on rubber parts or brake pads or linings or painted surfaces -- (12) 19 oz. aerosol can.
F2AZ	19517-SA	Chamois - Premium Synthetic - approx. 13" x 17"	F3AZ	19579-SA	Cleaner-non-chlorinated metal brake parts for use only for off-vehicle cleaning of metal brake parts. Do not use on rubber parts or brake pads or linings or painted surfaces - (12) 17 oz. aerosol can.
★ F3AZ	19B519-SA	Refrigerant "12" (air conditioner) -- 30 lb.cylinder	C6AZ	19627-A	Tape (vinyl foam)-1/8" x 7/8" -- 50 ft. roll- used to shim weatherstrip roof rails, doors and convertible side rails
★ D2AZ	19523-A	Hand cleaner-waterless -- (12) 14 oz. cans - NR (6/91)	D4AZ	19627-A	Tape (A/C insulation) -- 1/8" x 2" -- 15 ft. roll
★ D2AZ	19523-B	Hand cleaner-waterless -- (2) 5 lb. cans - NR (6/91)			
★ D5AZ	19523-PBK	Hand cleaner - waterless -- (8) 5 lb. cans- includes dispenser - NR			
E8AZ	19523-AA	Upholstery Cleaner - (12) 14 oz. aerosol can			
F1AZ	19523-A	Hand cleaner - cream -- (6) 5.5 lb. cans			
F1AZ	19523-B	Hand cleaner - lotion w/grit -- (12) 7.5 oz. bottles			
F1AZ	19523-C	Hand cleaner - lotion w/grit -- (4) 1 gal. containers - includes pump			
F1AZ	19523-D	Hand cleaner - lotion (orange) -- (12) 7.5 oz. bottles			
F1AZ	19523-E	Hand cleaner - lotion (orange) w/grit -- (4) 1 gal. containers - includes pump			

PART NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION
P0005 SPECIAL PRODUCTS - APPEARANCE and MAINTENANCE MATERIALS U.S. USAGE — Cont'd			
D6AZ 19627-A	Tape (pressure sensitive) - black water proof- 3" wide - - 60 yd. roll	C8AZ 19628-F *WA-6	Tape (elec. insulating)-black (individual metal can) (12)-3/4" x 66 ft. rolls
D8AZ 19627-A	Tape-clear urethane film (pressure sensitive) - - 12" wide - 60 1/2" long	★ C8AZ 19628-G *WA-7	Tape (electrical insulating)-black (individual skin pkg.) (12)-3/4" x 20 ft. rolls -- NR (6/92)
★ D9ZZ 19627-A	Tape-(pressure sensitive)-butyl rubber - - 3" (76.2 mm.) wide - - 10 ft. long-use to seal spare tire well drain hole - NR (6/91)	C8AZ 19628-H *WA-8	Tape (elec. insulating)-black (individual skin pkg.) (12)-3/4" x 66 ft. rolls
E4AZ 19627-A	Tape-PVC foam (low density)-used to eliminate water leaks, wind noise, squeaks and rattles - - 1/8" thick x 3/4" wide x 100 ft. roll	E0AZ 19628-A *WA-15	Tape-(electrical repair)-flame retardant- automotive use only-3/4" (19.50 mm.) wide - - 100 ft. (30.48 meters) long-(10) roll skin pkg.
E4AZ 19627-B	Tape-PVC foam (low density)-used to eliminate water leaks, wind noise, squeaks and rattles - - 1/4" thick x 3/4" wide x 50 ft. roll	E7AZ 19E725-B *YN-8-A	Air Conditioning Odor Treatment Kit - for all vehicles exc. Tracer - for use in all States except California
E4AZ 19627-C	Tape-PVC foam-used with E0AZ 19562-A for windshield replacement - - 6mm x 6mm x 12 ft. long	E9AZ 19E725-A *YN-10	Air Conditioning Disinfectant Kit - for all vehicles exc. Tracer - for use in California only
★ E53Z 19627-A	Pad (foam insulator) - - 1 1/2" x 2 1/2" x 3/8" thick-used on Tempo/Topaz to eliminate air resonator vibration noise - NR (6/91)	★ F2AZ 19577-AB *YN-12-A	PAG Refrigerant Compressor Oil --8 oz. plastic bottle
★ C8AZ 19628-D *WA-4	Tape (electrical insulating)-black (display pack) (12) 3/4" x 20 ft. rolls -- NR (6/92)	★ YN 7	Refrigerant "12" (air conditioner) - - 30 lb. cylinder
		★ YN 11	Refrigerant "134a" (air conditioner) - - 15 lb. cylinder

P0006 PAINTS and REFINISHING MATERIALS - APPEARANCE MAINTENANCE MATERIALS CANADIAN USAGE

D7AZ 19000-A	Paint (argent lacquer) - - 13 oz. aerosol spray can	★ CD2AZ 19500-AH	Engine enamel-black gloss - - 16 oz. spray bomb - NR (6/91)
E4AZ 19000-A	Paint-Charcoal - - 12-3/4 oz. spray can - use for crash pad repair	★ CD2AZ 19500-AJ	Engine enamel-chassis black (dull) - - 16 oz. spray bomb - NR (6/91)
E4AZ 19000-B	Paint-Cadet Blue - - 12-3/4 oz. spray can - use for crash pad repair	★ CD5AZ 19500-A	Alkyd enamel-Maroon Metallic - - 6 oz. spray can - NR (6/91)
E4AZ 19000-C	Paint-Desert Tan - - 12-3/4 oz. spray can - use for crash pad repair	★ CD5AZ 19500-B	Alkyd enamel-Light Green Gold Metallic - - 6 oz. spray can - NR (6/91)
★ E4AZ 19000-D	Paint-Canyon Red - - 12-3/4 oz. spray can - use for crash pad repair - NR (6/91)	★ CD5AZ 19500-C	Alkyd enamel-Light Green - - 6 oz. spray can - NR (6/91)
E7FZ 19000-A	Paint-Gloss Argent-used to paint polycast wheels - - 13 oz. aerosol spray can	★ CD5AZ 19500-D	Alkyd enamel-White - - 6 oz. spray can - NR (6/91)
E7FZ 19000-B	Paint-Silver Metallic-used to paint polycast wheels - - 13 oz. aerosol spray can	★ C5AZ 19E548-A	Tinting assort. - - (12) 1 pt. cans of acrylic enamel repair tinting colors - NR (6/91)
E7FZ 19000-C	Paint-Argent-used to paint polycast wheels - - 13 oz. aerosol spray can	★ E4AZ 19554-A	Kit - crash pad repair-for Industrial use only-consists of (1) 1/2 oz. plastisol, (1) pc. grainmold paper, (1) pc. 400 grain paper, (1) applicator - NR (6/91)
★ CD2AZ 19500-AB	Engine enamel-corporate blue - - 16 oz. spray bomb - NR (6/91)		

P0006 CLEANERS, WAXES and POLISHES - APPEARANCE and MAINTENANCE MATERIALS CANADIAN USAGE

★ 8A 19522	Bright metal cleaner - - (12) 1 pt. cans- r/b 8A 19522-A (7/89)	E8AZ 19526-A	Soil and Spot Lifter-for use on most automotive pile-type fabrics - - (12) 227 gram (6.5 oz.) plastic bottles
8A 19522-A	Custom Bright Metal Cleaner - - (12) 16 fl. oz. bottles	F2MY 19526-AA	Whitewall Tire Cleaner-extra-strength - - (1) 5 gallon liquid-box container
★ CD4AZ 19522-A	Chrome cleaner - - 1 gal. -NR (6/91)	B7A 19530-B	Custom silicone gloss (new car prep.) - - (2) 1 gal. cans (U.S.)
CC9AZ 19523-A20L	Upholstery cleaner - - 20 litre container	CBAC 19530-AM	Body polish - - (12) 500 ml. containers
★ CB9CZ 19525-A	Upholstery cleaner (spray on) - - 1 gal. can -NR (6/91)	★ CC5AZ 19530-A	Polish-buffer(reconditioning polish) - - 1 gal. can - NR (6/91)
★ CC0AZ 19525-B	Upholstery cleaner (spray on) - - 5 gal. can - NR (6/91)	CC9AZ 19530-B4L	Cleaner and polish - - 4 litre container
E0AZ 19526-AA	Triple Clean-for vinyl and leather trim -vinyl and convertible tops -not for use on cloth fabrics - - (12) 16 oz. bottles w/pump spray	F1AZ 19530-A	Clearcoat polish - for use on all vehicles with clearcoat paint - - (12) 16 fl. oz. bottles
★ E0AZ 19526-B	Whitewall Tire Cleaner - - (12) 16 oz. plastic spray bottles - NR (6/91)	★ E4AZ 19534-A	Cream auto wax-w/applicator - - (12) 8 oz. containers- r/b E4AZ 19534-AA (11/89)
E0AZ 19526-BA	Whitewall Tire Cleaner-extra-strength - - (12) 16 fl. oz. bottles	E4AZ 19534-AA	Custom Cream Wax-w/applicator - - (12) 8 oz. cans
★ E2AZ 19526-A	Automotive Fabric Spot Lifter-for use on most automotive cloth fabrics and carpets - - (12) 6.5 oz. aerosol cans w/brush cap - r/b E8AZ 19526-A (11/89)	E3AZ 19F535-A	Vinyl top cleaner and reconditioner - - (12) 16 oz. containers

PART NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION
P0006 CLEANERS, WAXES and POLISHES - APPEARANCE and MAINTENANCE MATERIALS CANADIAN USAGE — Cont'd			
E3AZ 19F535-B	Vinyl top cleaner and reconditioner -- 1 gal. container	* CXC 91	Liquid car polish -- (12) 500 ml plastic bottles
* CXC 12	Tar and road oil remover -- (12) 500 ml. cans	* CXC 92	Car polish-spray -- (12) 500 ml plastic bottles with trigger
* CXC 20	Car wash -- 20 litre pail	* CXC 93	Vinyl cleaner-pump spray -- (12) 500 ml plastic bottles
* CXC 21	Car wash -- 4 litre jug	* CXC 94	Vinyl conditioner-spray -- (12) 500 ml plastic bottles with trigger
* CXC 68-A	Fabric cleaner-spotless -- (4) 4 litre cans	* CXC 95	Car wash and wax -- (12) 500 ml plastic bottles
* CXC 83	Car wash -- (12) 500 ml containers	* CXC 112	Car wash -- 20 litre pail (phosphate free)
* CXC 84	Car wash -- 205 litre plastic drum		
P0006 CLEAR VISION AIDS - APPEARANCE and MAINTENANCE MATERIALS CANADIAN USAGE			
CB9CZ 19550-A	Windshield washer anti-freeze -- 16 oz. bottle	* CXC 69	Windshield washer anti-freeze -- (12) 500 ml. plastic containers
* CC5AZ 19550-B	Windshield washer anti-freeze -- 5 gal. pail - NR (6/91)		
* CXC 36	Windshield washer anti-freeze -- 20 litre pail	* CXC 100	Glass cleaner -- (12) 500 g. aerosol cans
P0006 COOLING SYSTEM AIDS - APPEARANCE and MAINTENANCE MATERIALS CANADIAN USAGE			
* CXC 44	Bar's Leak (cooling system protector) -- (12) 400 g. glass bottles - NR (6/91)	* CXC 8-B	Cooling System Fluid (permanent anti-freeze) -- (4) 4 litre containers
* C000 19558-A	Bar's Leak (cooling system protector) -- 6 oz. jar - r/b CXC-43 (6/91)	* CXC 9-B	Cooling System Fluid (permanent anti-freeze) -- 205 litre container
* C000 19558-B	Bar's Leak (cooling system protector) -- 15 oz. bottle - r/b CXC-44 (6/91)	* CXC 43	Bar's leak (cooling system protector) -- (12) 150 g. cans
D9AZ 19558-A *RA1	Protector Pellets (cooling system)--2 pellets per card,24 cards per carton	* CXC 85	Cooling System Cleaner and Conditioner Kit -- Consists of (1) CXC-86 Fast Flush, (1) CXC-87 Rust Inhibitor, (1) CXC-88 Stop Leak
D9AZ 19558-PAK *RA 1000	Kit-Protector Pellets (cooling system) - consist of 48 pellet cards and 1 fender cover	* CXC 86	Radiator Fast Flush -- (12) 350 ml cans
E6AZ 19558-A *RA-2	Protector powder (cooling system) -- (20) 3/4 oz. tubular plastic containers on a display carton	* CXC 87	Radiator Rust Inhibitor -- (12) 350 ml cans
		* CXC 88	Radiator Stop Leak -- (12) 350 ml cans
P0006 MOTOR OILS and LUBRICANTS - APPEARANCE and MAINTENANCE MATERIALS CANADIAN USAGE			
* CXT 1-LF	Automatic trans. fluid-Type "F"-for FMX and 1980-C3 A/T only -- Power steering fluid-for Ford CII P/S -Consult owners guide for proper application -- (24) 1 litre cans - NR (6/91)	* CC4AZ 19579-A	Engine oil conditioner -- 40 oz. can -for gasoline engines only - NR (6/91)
* CXT 4-LH16	Automatic trans. fluid-Type "H" for C5, AXOD, 1986/ AOT, ATX, C6 A/T only-consult owners guide for proper application -- (16) 1 qt. (0.9466) cans - NR (6/91)	* CD6AZ 19579-A	Motor Oil-10W-40-Super Premium -- 45 gal. drum - NR (6/91)
* CXO 30-L	Motor oil-30W-single grade -- (24) 1 litre cans - NR (6/91)	* MGCA 19579-B	Fuel system cleaner -- 6 oz. can - NR (6/91)
C8AZ 19B546-A	Additive-friction modifier-hypoid gear-for locking rear axles -- (12) 4 oz. (118.28 ml.) plastic bottles	CE0AZ 19580-A	Hypoid gear lubricant-(for Traction-Lok rear axles use with C8AZ-19B546-A) -- (12) 1 litre plastic containers with spouts
CE0DZ 19C547-A	Lubricant (for manual 3 and 4 speed trans. and Fiesta manual transaxle) -- 20 litre pail	CE0AZ 19580-B	Hypoid gear lubricant-(for Traction-Lok rear axles use with C8AZ-19B546-A) -- (4) 4 litre containers
E5RY 19C547-A	Manual Trans. Fluid for Merkur manual trans. -- 1 qt. (U.S.) screw top container	CE0AZ 19580-C	Hypoid gear lubricant-(for Traction-Lok rear axles use with C8AZ-19B546-A) -- 50 kg. keg.
C0AZ 19553-AA	Silicone lubricant -- 8 oz. (227g) tube	D2AZ 19581-A	Speedometer cable lubricant--0.453 kg (1 lb.) can
D3AZ 19553-A	Lubricant (mini-vent window) - 4 oz. plastic bottle	E6AZ 19582-B	Automatic trans. fluid-DEXRON®II- synthetic-for use in C3, C5, C6, AOD, ATX and A4LD auto. trans. design to use Dexron II or type "H" fluid when ambient temperature drops to arctic temperatures -- (12) 1 qt. (.946 l) plastic containers
E25Y 19553-A	Lubricant (rubber)-for suspension insulators -- 2 oz. tube	D9AZ 19583-A	Rubber lubricant-triple purpose -- 4 (1) gal. containers - use to mount and demount tires, remove rubber squeaks, and clean rubber parts
E2SZ 19553-A	Dry Film Lubricant-reduces friction resulting from metal to metal contact and helps provide corrosion resistance -- 4 oz. can	D0AZ 19584-AA	Multi-Purpose Grease -- 4 oz. aluminum tube w/plastic cut off spout
C3AZ 19578-A	Steering gear lubricant(lifetime) -- (4)- 14 1/2 oz. cartridges	D7AZ 19584-AA	Multi-Purpose Grease -- 15 oz. spray can
D8AZ 19578-A	Steering Gear Grease-for manual rack and pinion str. gear -- 1 lb. can	F0AZ 19584-A	Grease - Ignition Lock -- 10.8 oz. (306 gram) spray can
* CB8A 19579-C	Heat rust solvent -- 10.8 oz. aerosol can - NR (6/91)	F2AZ 19584-A	Grease - Electrical -- 2 oz. (56.7g) tube
CB9AZ 19579-C	Engine purge -- 40 oz. can	D8AZ 19587-AA	Lock Lubricant -- (12) 3.5 oz. aerosol cans w/snorkel
		* C1AZ 19590-BA	Lubricant long life -- (4)- 14 1/2 oz. cartridges-NR

PART NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION
P0006 MOTOR OILS and LUBRICANTS - APPEARANCE and MAINTENANCE MATERIALS CANADIAN USAGE — Cont'd			
★ C1AZ 19590-C	Lubricant long life -- 120 lb. keg - NR (6/91)	* CXO 5W30-4LSP	Motor oil-5W30 Super Premium-for gas engines only -- (4) 1 litre containers
★ C1AZ 19590-D	Lubricant long life -- 25 lb. pail -NR (6/91)	* CXO 5W30-LSP12	Motor oil-5W30 Super Premium-for gas engines only -- (12) 1 litre containers
D7AZ 19590-A	Lubricant (disc brake caliper slide grease) -- (4) 4 oz. tubes	* CXO 10W40-4LSP	Motor oil-10W40 Super Premium -for gas engines only -- (4) 1 litre containers
E0AZ 19590-A	Graphite lubricant-for 4.2L intake manifold gaskets -- 4 fl. oz. (.118 litre) container w/brush	* CXO 10W40-DSP	Motor oil-10W40-Super Premium -- 205 litre drum
★ E1AZ 19590-A	Speed control slip ring grease (str. whl. mounted) -- 8 oz. (.226 kg.) tube - r/b E8AZ 19590-A (10/89)	* CXO 10W40-LSP12	Motor oil-10W40 Super Premium -for gas engines only -- (12) 1 litre containers
E2FZ 19590-B	Grease-C.V.U.-Joint -- 90 gram tube	* CXO 15W40-4LSD	Motor oil-15W40 Super Duty -for all gas & all diesel engines -- (4) 1 litre containers
E43Z 19590-A	Grease-C.V.U.-Joint Hi Temp (blue) -- 90 gram tube	* CXO 15W40-LSD12	Motor oil-15W40 Super Duty -for all gas & all diesel engines -- (12) 1 litre containers
E7FZ 19590-A	Lubricant-TEFLON grease-for Escort, Lynx passive restraint system -- 1/2 oz. tube	* CXO 20W50-LP12	Motor oil-20W50 Premium -for all gas engines & all diesel exc. turbo -- (12) 1 litre containers
E8AZ 19590-A	Grease-Speed Control Slip Ring - used with str. whl. mounted speed control --28.4 grams (1 oz.) tube	* CXT 1-DF	Automatic trans. fluid-Type "F" for-FMX and 1980-C3 A/T only -- Power steering fluid-for Ford CII P/S -Consult owners guide for proper application -- 205 litre drum
★ D1RY 19592-A	Grease (disc brake lubricant)-for 1971/78 Capri disc brake squeal -- 125 gram tube - NR (6/91)	* CXT 1-LF12	Automatic trans. fluid-Type "F" -for FMX & 1980 C3 A/T only -- P/steering fluid for Ford CII P/S -Consult owners guide for proper application -- (12) 1 litre containers
* CXC 31	Brake and hydraulic clutch fluid (extra heavy duty)-for vehicles w/disc or drum brakes -- (24) 500 ml. cans	* CXT 2-DM	Automatic trans. fluid-"MERCON"-for low temperature usage on all 1983 and newer vehicles-consult owners guide for proper application -- 205 litre drum
* CXC 32	Brake and hydraulic clutch fluid (extra heavy duty)-for vehicles w/disc or drum brakes -- (12) 1 litre cans	* CXT 2-LM12	Automatic trans. fluid-"MERCON"-for low temperature usage on all 1983 and newer vehicles-consult owners guide for proper application -- (12) 1 litre containers
* CXC 51-A	Penetrating Fluid -- (12) 290 g. aerosol cans	* CXT 5-DM	Automatic trans. fluid-"MERCON"-for JATCO, C4, C6, A4LD, 1980-85 AOT, 1981-85 ATX, 1981-86 C3 A/T only-also lubricant for MTX and 5 OD M/T-consult owners guide for proper application -- 205 litre drum
* CXC 54	Fuel system cleaner -- (12) 250 ml. cans	* CXO 9-L	Motor oil-10W30-Super Premium (Bulk)
* CXC 55-A	Engine purge -- (12) 500 ml cans	* CXO 10-L	Motor Oil-10W40-Super Premium -- per litre bulk
* CXC 56	Break-in lubricant -- (12) 500 ml. cans	* CXO 30-D	Motor oil-30W-single grade -- 205 litre drum
* CXC 90	Silicone lubricant -- (12) 425 gram aerosol spray can	* CXO 30-LSD12	Motor oil-30W Super Duty -for all gas & all diesel engines -- (12) 1 litre containers
* CXG 2	Grease-Anti Seize-used to lubricate throttle body hub pin(recall 90S02)--283 gram brush top can	* CXO 10W30-4LP	Motor oil-10W30 Premium-for all gas engines & all diesel engines exc. turbo -- (4) 1 litre containers
* CXO 9-L	Motor oil-10W30-Super Premium (Bulk)	* CXO 10W30-4LSP	Motor oil-10W30-Super Premium -- (4) 4 litre cans
* CXO 10-L	Motor Oil-10W40-Super Premium -- per litre bulk	* CXO 10W30-DP	Motor oil-10W30-Premium -- 205 litre drum
* CXO 30-D	Motor oil-30W-single grade -- 205 litre drum	* CXO 10W30-DSP	Motor oil-10W30-Super Premium -- 205 litre drum
* CXO 30-LSD12	Motor oil-30W Super Duty -for all gas & all diesel engines -- (12) 1 litre containers	* CXO 10W30-LP	Motor oil-10W30-Premium -- (24) 1 litre. cans
* CXO 10W30-4LP	Motor oil-10W30 Premium-for all gas engines & all diesel engines exc. turbo -- (4) 1 litre containers	* CXO 10W30-LP12	Motor oil-10W30 Premium-for all gas engines & all diesel engines exc. turbo -- (12) 1 litre containers
* CXO 10W30-4LSP	Motor oil-10W30-Super Premium -- (4) 4 litre cans	* CXO 10W30-LSP12	Motor oil-10W30 Super Premium-for all gas engines -- (12) 1 litre containers
* CXO 10W30-DP	Motor oil-10W30-Premium -- 205 litre drum		
* CXO 10W30-DSP	Motor oil-10W30-Super Premium -- 205 litre drum		
* CXO 10W30-LP	Motor oil-10W30-Premium -- (24) 1 litre. cans		
* CXO 10W30-LP12	Motor oil-10W30 Premium-for all gas engines & all diesel engines exc. turbo -- (12) 1 litre containers		
* CXO 10W30-LSP12	Motor oil-10W30 Super Premium-for all gas engines -- (12) 1 litre containers		

P0006 SEALERS and ADHESIVES - APPEARANCE and MAINTENANCE MATERIALS CANADIAN USAGE

★ D7AZ 19B508-AA	Gasket and Trim Adhesive -- 16 fl. oz. can w/brush - r/b D7AZ 19B508-B (1/91)	★ E6AZ 19554-A	Adhesive - air conditioning sealer (biocide) -- 6 fl. oz. - NR (6/91)
D7AZ 19B508-B	Gasket and Trim Adhesive -- 16 fl. oz. bottle w/brush	E7AZ 19554-A	Compound-aluminum wheel (leak) repair- 5/8" dia. x 5" stick -- 1 oz.
CC3AZ 19552-B	Windshield and backlite sealer -- 12 3/4 oz. tube	★ E80Y 19554-A	Adhesive/Sealant-used to secure ball stud(5C561)--10ml bottle-Campaign # 88S44 - NR (6/91)
★ CBM 19553-A	Sealer-caulking cord - NR (6/91)	AB 19560-A	Caulking cord -- (6) 80 ft. rolls-3/16" dia.
C9AZ 19554-B	Sealer (liquid butyl)-black-for sealing butyl installed windshield and backlite -- 16 oz. can	★ D2FZ 19562-A	Seal windshield and backlite glass-foam tape -- 1/4" x 5/8" x 13' - NR (6/91)
E2FZ 19554-B	Ford thread lock 262-used to prevent vibration loosening of nuts, bolts or screws -- 0.34 fl. oz. (10 ml.)	D2FZ 19562-B	Seal quarter window-foam tape -- 1/4" x 3/8" x 5'

PART NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION
P0006 SEALERS and ADHESIVES - APPEARANCE and MAINTENANCE MATERIALS CANADIAN USAGE — Cont'd			
★ D8RZ 19562-A	Windshield sealant kit-for windshield replacement on Fiesta vehicles - NR (6/91)	★ CXC 39	Weatherstrip adhesive (light color) - - (12) .150 ml. tubes
D9AZ 19562-A	Butyl tape kit - - "I" beam section-(233") for windshield replacement on vehicles (Exc. Pinto, Bobcat) prior to being licensed by dealer	★ CXC 41	Perfect seal sealing compound - - (12) 283 gram aerosol cans
D9AZ 19562-B	Windshield glass seal kit - - (5/16") round (233") incl. glass primer-(exc. Pinto, Bobcat)	★ CXC 49	Auto. trans. seal conditioner - - (12) .350 ml. cans
E0AZ 19562-A	Windshield seal kit-urethane-for w/shields with urethane seal - - use with D9AZ 19562-A, B or E4AZ 19627-C. For industrial use only	★ CXC 70	Sealant-thread locker (Loctite 242) - used for alternator, starter and ring gear mounts - - (10) 6 ml. containers
★ E1ZZ 19562-A	Glass Primer Kit - used to attach rear window louver - for industrial use only - NR (4/91)	★ CXC 72	Sealant - pipe w/teflon-use to secure fittings & plugs - - (10) 50 cc containers
E2AZ 19562-B	Ford Gasket Maker-for use when specified in the replacement of gaskets and the sealing of flanges-not for use on oil pans, rocker covers and MTX trans. - - 1.7 fl. oz. (50 ml) tube	★ CXC 73	Sealer-thread w/teflon - - (10) 6 ml. containers
★ E3AZ 19562-A	Silicone gasket and sealant (RTV) - - 10.3 fl. oz. caulking cartridge - r/b E8AZ 19562-A (3/89)	★ CXC 74	Adhesive-Superbinder (instant)-used for bonding vinyl trim, w/strip rubber bumper guards - - (10) 3 ml. tubes
E69Z 19562-A	Seal - pressure sensitive urethane foam- 25 ft. roll	★ CXC 74-C	Adhesive-Superbinder (instant)-used for bonding vinyl trim, w/strip rubber bumper guards - - (10) 3 ml. tubes
E8AZ 19562-A	Silicone Gasket and Sealant (RTV) - - .150 liters (5 fl. oz.) caulking cartridge	★ CXC 75	Adhesive (Loctite)-used to attach rear view mirror brkt. to w/s - - (10) display packages-each pkg. contains 5 ml. adhesive and 6 ml. accelerator
F1AZ 19562-A	Silicone gasket and sealant - - 5 oz. caulking tube	★ CXC 76	Sealant-Histrength adhesive-stud n'brg. mount - - (10) 6 ml. tubes
F1VY 19562-A	Headliner Adhesive Kit - - contains (2) 12 fl. oz. (355ml) caulking cartridges with nozzles	★ CXC 78	Sealer-gasket eliminator (515)-used to seal cover on MTX trans. - - (10) 6 ml. tubes
★ CC2CZ 19573-A	Automatic transmission sealer - - 8 oz. can - NR (6/91)	★ CXC 79	Sealant-gasket eliminator (Loctite 515) - - (10) 50 ml. tubes
★ CXC 38	Rubber cement (black) - - (12) .150 ml. tubes	★ CXC 81	Gasket seal - (12) 113 gram cans
		★ CXC 96	Silicone Rubber - clear - - 90 ml. tube
		★ CXC 97	Silicone Rubber - black - - 90 ml. tube

P0006 SPECIAL PRODUCTS - APPEARANCE and MAINTENANCE MATERIALS CANADIAN USAGE			
★ CXC 77	Klean and Prime-use w/Loctite gasket eliminator on aluminum parts, zinc and cadmium plated parts and non-metals - - (10) 6 oz. aerosol cans -NR (6/91)	★ E6AZ 19517-A	Rotary car washing brush kit - NR (6/91)
D7AZ 19A331-A *WA-10	Silicone Dielectric Compound-for distributor rotor tip and Duraspark ignition cable - - 3 oz. tube	★ D4AZ 19B519-A *YN-1-A	Refrigerant (air conditioner) - - (12) 14 oz. cans - NR
E7AZ 19A426-A	Heat Transfer Compound-for Ford integral alternators-aids heat transfer between rectifier and alternator housing - - 5 oz. (142 g) tube	★ CECG 19524-A	Engine shampoo - - 5 gal. can - NR (6/91)
★ D7AZ 19A501-A	Rust Penetrant and Inhibitor - - (6) 12 oz. aerosol cans - r/b D7AZ 19A501-AA (12/91)	CECG 19524-B	Engine shampoo - - 45 gal. can
D7AZ 19A501-AA	Rust Penetrant and Inhibitor - - helps free parts frozen by rust and corrosion - - (6) 12 oz. aerosol cans	★ CC6AZ 19528-A	Concrete floor cleaner and degreaser - - 40 lb. pack - NR (6/91)
F2AZ 19A501-A	Rust Penetrant and Inhibitor - - helps free parts frozen by rust and corrosion - - (6) 12 oz. aerosol cans	★ C000 19535-A	Carburetor cleaner - - 5 gal. pail - NR (6/91)
CB8A 19512-A	Wash mitt	★ C000 19535-B	Carburetor cleaner - - 4 gal. pail (w/basket) - NR (6/91)
★ CC3AZ 19514-A	Starting fluid - - 11 oz. spray can - NR (6/91)	E8AZ 19C544-A	Gas Stabilizer - used for seasonally stored vehicles to prevent the necessity of draining gas tank and lines - - (12) .236 liter (8 oz.) plastic bottles
★ D9AZ 19515-A	Vinyl coat-abrasion resistant - - (6) 1 qt. (0.946 litre) cans - NR	CE3AZ 19554-A	Kit-heated beacklite wiring repair -used to repair bus bar terminal - to - window bond separation (TSB #82-25-10)
E7AZ 19515-A	Fabric protector-for dealer use only -not for retail sale-for cloth trim - - (12) 16 oz. cans with screw top	D8AZ 19562-AA	Rear Window Defroster Repair -repairs small open-circuit breaks in electrically heated, grid type, rear window defrosters - - 1/8 oz. bottle
E7AZ 19515-B	Fabric protector-for dealer use only -not for retail sale-for cloth trim - - 5 gal. pail with pull-up spout/handle	E7DZ 19562-A	Kit-heated backlite repair for Taurus or Sable station wagons - - consists of 6 pcs. of tape
B7A 19517-B	Wax Treated Dusting Cloth - - carton of (100)	C9AZ 19577-B *YN-2	Refrigerant compressor oil-used with York or Tecumseh compressors - - 1 qt. can (U.S.)
★ CBJ 19517-A	Polishing cloth-lintless - - 5 yds. - NR (6/91)	★ D1VY 19577-B *YN-4	Refrigerant compressor oil-use w/ Frigidaire compressors - - 1 qt. can - NR (6/91)
CC3AZ 19517-A	Chamois-super sheen - - approx. 20" x 22"	E73Z 19577-A *YN-9	A/C Compressor Oil-used w/FS-6,FX-15 or Nippodenso compressor - - 1 qt. can (U.S.)
D3AZ 19517-AA	Wax Treated Dusting Cloth - - plastic bag container of 24	E9SZ 19577-A	Synthetic Supercharger Fluid-used on T/Bird,Cougar w/3.8L S/C engine--0.118 liters (4 fl. oz.) tube
D3AZ 19517-B	Buffing and Polishing Pad - - carton of (12)		
E0AZ 19517-B	Wax Treated Dusting Cloth-bulk roll - - 15" wide x 90 ft. long		

PART NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION
P0006 SPECIAL PRODUCTS - APPEARANCE and MAINTENANCE MATERIALS CANADIAN USAGE — Cont'd			
E6AZ 19579-AA	Fuel Injector Cleaner -used to reduce deposit-related to engine knock and cleans dirty injectors - - (12) 12 fl. oz. (0.356) long neck bottles	E7AZ 19E725-B *YN-8-A	Air Conditioning Odor Treatment Kit-for all vehicles exc. Tracer
E6AZ 19579-C	Power Flush Injector Fluid - for use with Rotunda fuel injector cleaner/tester DO NOT add this product to the vehicle fuel tank - - (12) 8 fl. oz. (0.2376) bottle	* CBB 14-L	Electrolyte (acid)-battery fluid - - 20 litre container
★ MGCA 19579-A	Combustion chamber conditioner - - 16 oz. can - NR (6/91)	* CXC 1-A	Super Seal Anti-Corrosion Compound - - (12) 475 g. aerosol cans
★ C1A 19584	Penetrating fluid - - 8 oz. can - NR (6/91)	* CXC 1-B	Super Seal Anti-Corrosion Compound - - (12) 475 g. aerosol cans
★ CB8A 19584-A	Penetrating fluid - - 1 gal. can - NR (6/91)	* CXC 6-A	Parts Immersion Cleaner-consists of a 15 litre fill in a 20 litre pail
CB9CZ 19586-A	Door ease-stick lubricant-shop size - - (6 to carton)	* CXC 11	Starting fluid - - (12) 235 gram aerosol cans
C6AZ 19627-A	Tape (vinyl foam) - - 1/8" x 7/8"-50 ft. roll- used to shim weatherstrip roof rails, doors and convertible side rails	* CXC 11-A	Starting fluid - - (12) 210 gram aerosol cans
★ CD7AZ 19627-A	Tape-Urethane film (pressure sensitive) - - 11 1/2" wide-144" long - NR (6/91)	* CXC 16-A	Hand cleaner-waterless - - (12) 400g tins
D4AZ 19627-A *YZ-1	Tape (A/C insulation) - - 1/8" x 2" - - 15 ft. roll	* CXC 17	Hand cleaner-waterless - - (6) 4.5 lb. cans
D6AZ 19627-A	Tape (pressure sensitive) - black water proof- 3" wide - - 60 yd. roll	* CXC 22	Engine shampoo - - 20 litre pail
D8AZ 19627-A	Tape-clear urethane film (pressure sensitive - - 12" wide-60 1/2" long	* CXC 23	Engine shampoo - - 205 litre drum
★ D9ZZ 19627-A	Tape-(pressure sensitive)-butyl rubber - - 3" (76.2 mm.) wide - - 10 ft. (3.048 meters) long-use to seal spare tire well drain hole - NR (6/91)	* CXC 26	Concrete floor cleaner and degreaser - - 20 kg. pail
E4AZ 19627-A	Tape-PVC foam (low density)-used to eliminate water leaks, wind noise, squeaks and rattles - - 1/8" thick x 3/4" wide x 100 ft. roll	* CXC 28-A	Gas line anti-freeze - - (40) 150 ml. bottles
E4AZ 19627-B	Tape-PVC foam (low density)-used to eliminate water leaks, wind noise, squeaks and rattles - - 1/4" thick x 3/4" wide x 50 ft. roll	* CXC 29-A	Gas line anti-freeze - - (12) 500 ml. bottles
E4AZ 19627-C	Tape-PVC foam-used with E0AZ 19562-A for windshield replacement - - 6mm x 6mm x 12 ft. long	* CXC 45-A	Hand cleaner lotion (with grit) - - (12) 225 ml squeeze bottles
★ E53Z 19627-A	Pad (foam insulator) - - 1 1/2" x 2 1/2" x 3/8" thick-used on Tempo/Topaz to eliminate air resonator vibration noise - NR (6/91)	* CXC 46	Hand cleaner lotion (with grit) - - (4) 12.8 fl. oz. (3.786) bottles
E0AZ 19628-A *WA-15	Tape (electrical repair)-flame retardant- automotive use only-3/4" (19.50 mm.) wide - - 100 ft. (30.48 meters) long-(10) roll skin pkg.	* CXC 52-B	Tune-Up Cleaner - - (12) 385 g. aerosol cans
		* CXC 53	Combustion chamber conditioner - - (12) 500 ml. cans
		* CXC 60	Penetrating fluid - - (4) 4 litre cans
		* CXC 66-A	Engine Shampoo - - (12) 380 g. aerosol cans
		* CXC 89-A	Brake/Choke Cleaner-(12) 425 gram aerosol cans
		* CXC 108	Rubber Coating(Red)-used to coat hand tools for gripping power, color coding, cushioning, etc.--429 ml can
		* CXC 109	Rubber Coating(Orange)-used to coat hand tools for gripping power, color coding, cushioning, etc.--429 ml can
		* YN 7	Refrigerant (air conditioner) - - 30 lb. cylinder
P0007 USED CAR RECONDITIONING MATERIALS U.S. USAGE			
D4AZ 19530-A	Used-car reconditioning polish - - 1 gal. can	D8AZ 19A536-AA	Automotive engine shampoo and degreaser- (for exterior use only) - (12) 19 oz. aerosol spray cans
C0AZ 19A536-D	Engine shampoo (cleaner and degreaser) - - 5 gal. drum	F2FZ 19A536-RA	Engine shampoo water base(cleaner and degreaser)--5 gal.liquid-box container
C0AZ 19A536-F	Engine shampoo (cleaner and degreaser) - - 55 gal. drum		
P0008 USED CAR RECONDITIONING MATERIALS CANADIAN USAGE			
★ CC9AZ 19000-A	Clear sheen - - 1 gal. container - NR (6/91)	★ CD5AZ 19A547-D	Body filler - red - - (4) 1 gal. container - NR (6/91)
★ CC9AZ 19000-A4L	Clear sheen - - (4) 4 litre containers - NR (6/91)	★ CD6AZ 19A547-A	Body filler - white - 1 qt. - includes hardener - NR (6/91)
★ CB9CZ 7003105-A	Glass scratch remover kit-consists of - - (1) hydro grinding pad and scratch remover compound - NR (6/91)	★ CD6AZ 19A547-B	Body filler - white - 1 gal. - includes hardener - NR (6/91)
★ CXC 164	Body filler-white - - (2) 7.25 kg. cans- includes hardener - NR (6/91)	★ CE3AZ 19562-A	Super spot putty-red - - 3 lb. tin - NR (6/91)
★ CC0AZ 19525-A	D-5 convertible top cleaner - - 1 qt. jug - NR (6/91)	* CXC 156	Body filler-white - - (4) 4 litre cans- includes hardener
D4AZ 19530-A	Polish-(used for reconditioning exterior automotive finishes) - - 1 gal. (U.S.) can	* CXC 157	Body filler-white - - (12) 1 litre cans- includes hardener
		* CXC 351	Cream Hardener-114 gram tube

SPECIFICATION NO.		PART NUMBER	SPECIFICATION NO.		PART NUMBER
P0009 CROSS REFERENCE LIST					
Note: In Specification basic number sequence					
* Motorcraft No. ★ No Longer Serviced % Service Equivalent					
ESA M1B6-A	%	D9AZ 19583-A	ESW M2C57-A	★	C2AZ 19580-D
ESA M1C25-A	%	C1AZ 19590-B	ESW M2C83-B	%	D8DZ 19C547-A
ESF M1C34-A	%	COAZ 19553-A	ESP M2C83-C		D8DZ 19C547-A F2ZZ 19C547-A
ESB M1C35-B		C4AZ 19D530-A	ESW M2C105-A		C6AZ 19580-E
ESW M1C39-A	%	C1AZ 19590-B	ESW M2C105-B	%	C6AZ 19580-E
ESA M1C45-A	%	D0AZ 19584-AA	EST M2C108-C	%	C6AZ 19580-E
EST M1C53-A	★	C7AZ 19590-B	ESF M2C113-A		D3AZ 19553-A
ESF M1C66-A	%	C4AZ 19590-A	EST M2C118-A		C8AZ 19B546-A
ES M1C75-A		D8RZ 19590-A	ESW M2C119-A	★	D3AZ 19580-A
ESA M1C75-B		C1AZ 19590-BA-C-D- XG 1-C-K	ESR M2C127-B	★	XO 10W30-BP,DP, QP
ESW M1C87-A		C3AZ 19578-A		★	XO 20W40-BP,DP, QP
ESA M1C92-A	★	D4AZ 19590-A		★	XO 30-D-Q
ESB M1C93-A	%	D0AZ 19584-AA	ESW M2C128-D		D6AZ 19582-A E4AZ 19582-A
ESB M1C111-A		D2AZ 19590-A E7FZ 19590-A	ESR M2C129-A		D2AZ 19579-C
ESW M1C113-A	★	C6AZ 19590-B	ESR M2C129-C	★	XO 5W30-BSP, DSP,QSP
ESB M1C119-A	%	C3AZ 19578-A		★	XO 10W30-BSP, DSP,QSP
ESA M1C155-A	%	D7AZ 19590-A		★	XO 10W40-BSP, DSP, QSP
ESR M1C159-A		D0AZ 19584-AA D7AZ 19584-AA	ESP M2C138-CJ	% ★	XT 2-DDX-QDX
ESF M1C160-A		D2AZ 19581-A	ESE M2C153-B	★	XO 10W30-QSP
ESA M1C167-A	%	D7AZ 19590-A		★	XO 10W40-DSP, QSP
ESA M1C171-A		D7AZ 19A331-A WA 10		★	XO 20W40-DSP, QSP
ESA M1C172-A		D7AZ 19590-A		★	XO 30-D-Q
ESA M1C175-A		D8AZ 19578-A	ESP M2C154-A		E0AZ 19580-AA,B,C XY 90-KL,QL
ESA M1C177-A	%	C1AZ 19590-B	ESP M2C158-A		E0AZ 19580-D
ESB M1C185-A	%	D7AZ 19590-A	ESE M2C160-A		E2SZ 19553-A
ESP M1C187-A		E2FZ 19590-A E2FZ 19590-B	ESR M2C163-A2		E6AZ 19582-B
ESA M1C189-A	★	E1AZ 19590-A	ESP M2C164-A	★*	XT 3-MV E4AZ 19582-D
ESL M1C193-A		E1TZ 19590-A	ESR M2C165-A	★	E6AZ 19582-A
ESA M1C194-A	%	D7AZ 19590-A		★	E6AZ 19582-AA
ESP M1C207-A		E43Z 19590-A		★	XT 1-BF
ESP M1C216-A2	%	E2FZ 19590-B	ESP M2C166-H	★	XT 4-H
ESA M1C221-A		E8AZ 19590-A	ESR M2C171-A	★	XO 15W40-BSD, DSD, QSD
ESA M1C232-A		F0AZ 19584-A		★	XO 30-BSD,DSD, QSD
ESEA M1C1014		D1RY 19590-A	ESD M2C175-A	★	E5RY 19C547-A
SQ M1C9004-A		D8RZ 19590-A	ESR M2C179-A	★	XO 20W50-GR,QR
ESB M2C20-A		D8AZ 19587-AA	ESB M2G14-A	★	C0AZ 19552-AA
ESW M2C28-BA		C2AZ 19580-F E2HZ 19580-A	ESB M2G17-A	★	D8AZ 19C525-A
ESA M2C31-A		C9AZ 19577-B YN 2	ESE M2G52-A	%	D7AZ 19B508-A
ESH M2C31-A2		E73Z 19577-A YN 9	ESH M2G78-B		D9AZ 19554-A
ESW M2C33-F	★	XT 1-DF-QF		★	E6AZ 19554-A
ESW M2C50-A	%	C6AZ 19580-E	ESA M2G140-A1		D7AZ 19554-C

1980/1989 Ford/Lincoln Mercury Cars

SECTION PAINT 51

SPECIFICATION NO.	PART NUMBER	SPECIFICATION NO.	PART NUMBER
P0009 CROSS REFERENCE LIST — Cont'd Note: In Specification basic number sequence * Motorcraft No. ★ No Longer Serviced % Service Equivalent			
ESB M2G176-A	★ D9AZ 19554-B	ESE M4G234-A2	★ E2AZ 19562-A E2AZ 19562-B
ESB M2G193-A	% D7AZ 19554-C	ESA M4G280-A	E7AZ 19554-A
ESB M2G202-A	D9AZ 19C525-A	ESU M4G2501-A	E1FZ 19562-A
ESB M2G222-A	% E0AZ 19562-A	WSK M4G320-A2	F1AZ 19562-A
ESB M2G224-A	% E0AZ 19562-A	ESB M4J58-A	D8AZ 19562-AA
ESB M2G234-A	% E0AZ 19562-A	ESR M5B106-A	B7A 19520-AA
ESB M2G246-A	% E0AZ 19562-A	ESR M5B194-B	★ 8A 19522-A
ESB M2G355-A	F1VY 19562-A	ESR M5B196-A	★ D8AZ 19A501-B
ESR M2P92-A	D7AZ 19000-A	ESR M5B197-A	B7A 19521-AA
ESR M2P93-A	M4J Clr.No.-H D7AZ 19000-C	ESR M5B202-A	★ D8AZ 19A501-B
ESR M2P94-B	★ M6J 12-H	ESR M5B255-A	D2AZ 19523-A-B D5AZ 19523-PBK F1AZ 19523-A-B F1AZ 19523-C-D-E
ESR M2P100-B	AL81 Clr.No.-B-H	ESB M5B280-A	% E0AZ 19562-A
ESB M2P115-A	★ VC 542-A	ESA M6C25-A	C6AZ 19542-AA-BA
ESB M3G5-A	C8AZ 19628-D-F-G-H ★ WA 4 ★ WA 6 ★ WA 7 ★ WA 8	ESL M6C51-A	CE6TZ19542-A
ESB M3G58-A	D6AZ 19627-A	ESR M6J130-A	★ D7AZ 19000-B E8AZ 19000-A
ESB M3G60-B	D9ZZ 19627-A	ESR M7C54-A	D7AZ 19515-A ★ D8AZ 19515-A D8AZ 19515-B,BA E4AZ 19515-A
ESB M3G71-A	E0AZ 19628-A ★ WA 15	ESR M11B23-B	B4A 19534-AA B8A 19534-A
ESB M3G77-A	C6AZ 19627-A	ESR M11B26-A	B7A 19530-B B7AZ 19530-AA D4AZ 19530-A ★ D8AZ 19534-A E4AZ 19534-AA
ESB M3G102-A	D2FZ 19562-A-B E4AZ 19627-A-B	ESR M11P15-A	★ C9AZ 19627-A-C
ESB M3G137-A	E4AZ 19627-C	ESP M11P16-A	★ 8A 19552-B
ESB M3G143-A1	E69Z 19562-A	ESR M11P17-A	D7AZ 19B508-AA D7AZ 19B508-B
ESB M4G32-A	D6AZ 19560-A	ESE M12A4-A	% E9PZ 6F091-A
ESH M4G32-B	★ D9AZ 19560-A	ESE M12A5-A	E0AZ 19590-A
ESE M4G63-C	% E0AZ 19554-A	ESR M13P4-A	C0AZ 19553-AA D7AZ 19553-AA
ESB M4G92-A	D6AZ 19562-AA-BA	ESR M14P3-A	C0AZ 19A536-D-F D8AZ 19A536-AA
ESE M4G1115-A	% D7AZ 19554-BA	ESR M14P4-A	★ D4AZ 19521-B ★ E0AZ 19521-A E0AZ 19521-AA B8A 19523-AA-B-C E0AZ 19526-AA
ESE M4G120-A	% E0AZ 19554-A	ESR M14P5-A	★ D8AZ 19C507-A E4AZ 19C507-AA
EST M4G148-A	% C9AZ 19554-B	ESR M14P6-A	★ C8AZ 19F535-A-B E3AZ 19F535-A-B
EST M4G150-A	★ C6TZ 19554-A	ESR M14P7-A	D6AZ 19A503-AA
ESB M4G162-A	C9AZ 19554-B	ESR M14P9-A	D9AZ 19579-AA,BA E6AZ 19579-C
ESE M4G167-A2	E0AZ 19554-BA	ESR M14P10-A	★ D8AZ 19A501-AA E8AZ 19A501-AA
ESE M4G168-A	★ D0AZ 19554-C		
ESG M4G194-A	% D8AZ 19554-A		
ESE M4G195-A	% D6AZ 19562-A		
ESE M4G195-B	E8AZ 19562-A		
ESE M4G195-C	E3AZ 19562-A		
ESE M4G203-A1	% E1LY 1A109-A E8OY 19554-A		
ESE M4G204-A2	% E0AZ 19554-AA		
ESE M4G204-A3	E2FZ 19554-B		
ESP M4G214-A	% E0AZ 19554-AA		
ESB M4G221-A	★ D9AZ 19515-A		
ESP M4G228-A	E1FZ 19562-A		

SPECIFICATION NO.	PART NUMBER	SPECIFICATION NO.	PART NUMBER
P0009 CROSS REFERENCE LIST — Cont'd Note: In Specification basic number sequence * Motorcraft No. ★ No Longer Serviced % Service Equivalent			
ESR M14P12-A	C9AZ 19523-A D6AZ 19523-AA	ESE M99B37-B	D9AZ 19558-A
ESR M14P13-A	E2AZ 19526-A	ESE M99B170-A	E6AZ 19558-A
ESR M14P15-A	E0AZ 19526-BA-C	ESF M99B112-A	E25Y 19553-A
ESE M14P16-A	E6AZ 19579-AA	ESR M99B135-A	D9AZ 19583-A
ESF M16B5-A	* BB 14 * BB 16	ESR M99C50-B	* C2RZ 19C548-A E4AZ 19C548-A
ESA M17B2-A	D4AZ 19B519-A * YN 1-A * YN 7	ESR M99C56-A	D7AZ 19A501-AA
ESR M17P1-A	* D3AZ 19C544-B	ESR M99C80-A	B7A 19579-C D9AZ 19579-CA D9AZ 19579-D
ESR M17P2-A	C8AZ 19C544-BA	ESE M99C112-A	E8AZ 19C544-A
ESR M17P3-A	C9AZ 19C544-AA	ESE M99C115-A	E9SZ 19577-A
ESR M17P5-A	C9AZ 19550-AA,BA	ESA M99G50	D4AZ 19627-A YZ 1
ESR M17P6-A	* 8A 19546-C	ESR M99H93-B	B7A 19517-B D3AZ 19517-AA * E0AZ 19517-A E0AZ 19517-B
ESR M18P1-A	* D2AZ 19B542-A	ESR M99J300-A	E4AZ 19000-A-B-C-D
ESR M18P2-A	B5A 19554-A D7AZ 19554-BA	ESR M99P3-A	D3AZ 19517-B
ESB M18P5-A	EPB M18P5-A EPB 1618-B	ESR M99P4-B	* D0AZ 19515-A-B
ESR M18P7-A	D8AZ 19554-A	ESR M99P4-C	* E6AZ 19515-A E9AZ 19515-A-B-C-D
ESE M97B18-C	* 8A 19549-A % E2FZ 19549-B E6HZ 19549-A	ESR M99P10-A	D7AZ 19515-A
ESA M97B23-B	* D2TZ 19577-A	DEXRON III	* XT 2-DDX-QDX
ESE M97B43-A	% E2FZ 19549-A	MERCON	* XT 2-BDX,DDX, QDX
ESE M97B44-A	E2FZ 19549-AA,B		

IDENTIFICATION NO.	SERVICE NO.
1007	
77FB 1007-TA	★ D8RZ 1007-D
83BB 1007-AC	E7RY 1007-C
83BB 1007-HA	E7RY 1007-C
85GB 1007-KA	E7RY 1007-B
86GB 1007-AB	E7RY 1007-A
87BB 1007-BC	E6RY 1007-A
8BB4 37192-0	E8GY 1007-A
8BD1-37600	E8BZ 1007-B
8BK1-37600	E92Z 1007-A
8BK2-37600	E92Z 1007-B
9965 22402-0	E8BZ 1007-B
9965 34403-0	E8BZ 1007-A
99650 44520-0	★ E8BZ 1007-C
	r/b E8BZ 1007-G
99650-4452	★ E8BZ 1007-E
99651 24040-0	E7GZ 1007-A
99651-14050	E92Z 1007-C
99652240-20	★ E8BZ 1007-F
99653-74030	F1BZ 1007-A
99655 55030-0	E7GZ 1007-B
99656 55030-0	E8GY 1007-B
9965C-15540	E92Z 1007-D
D6EA 1007-EA	★ D4ZZ 1007-A
D7DA 1007-CA	★ D8DZ 1007-C
D7DC 1007-BA	★ D6DZ 1007-C
D7EC 1007-BA	★ D5FZ 1007-A
D7YC 1007-AB	★ D7YY 1007-A
E0AC 1007-AA	E8AZ 1007-D
E0AC 1007-AB	E8AZ 1007-D
E0AC 1007-BA	E8AZ 1007-D
E0AC 1007-DA	D9AZ 1007-A
E0AC 1007-FA	D9AZ 1007-C
E0BC 1007-DA	D8BZ 1007-A
E0DC 1007-AA	★ D7BZ 1007-A
E0DC 1007-CA	★ D8DZ 1007-A
E0ZC 1007-BA	★ D9ZZ 1007-B
E0ZC 1007-CA	★ D9ZZ 1007-A
E1BC 1007-AB	★ E1BZ 1007-A
E1CC 1007-AA	★ E1CY 1007-A
E1LC 1009-AD	E2VY 1007-B
E25C 1007-AA	E25Y 1007-A
E25C 1009-AC	E5LY 1007-D
E2EC 1007-AA	E1FZ 1007-B
E2GC 1007-AB	★ E2GZ 1007-C
E2VC 1009-AA	E2VY 1007-B
E3AC 1007-MA	E9AZ 1007-B
E3DC 1007-BA	E2DZ 1007-A
E3EC 1007-CA	E3FZ 1007-B
E3EC 1007-DA	E3FZ 1007-C
E3EC 1007-GA	E3FZ 1007-F
E3EC 1007-JA	★ E2FZ 1007-A
E3SC 1007-BA	E3SZ 1007-B
E3SC 1007-DA	E3SZ 1007-D
E3SC 1007-FA	E3SZ 1007-A
E3SC 1007-GB	E3SZ 1007-C
E3WC 1007-BB	★ E3WY 1007-A
E3ZC 1007-BA	D9BZ 1007-B
E3ZC 1007-DA	E3ZZ 1007-B

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
1007 CONT'D	
E43C 1007-EA	E43Z 1007-C
E46C 1007-AC	E46Y 1007-A
E4AC 1007-AA	E2AZ 1007-A
E4AC 1007-BA	D9AZ 1007-C
E4DC 1007-AB	E4DZ 1007-A
E4DC 1007-CA	E4DZ 1007-B
E4LC 1007-BA	E5LY 1007-B
E4LC 1007-CA	E5LY 1007-C
E4SC 1007-AA	E4SZ 1007-A
E4ZX 1007-AB	E4ZZ 1007-A
E53C 1007-AA	E53Z 1007-A
E53C 1007-BA	E4GZ 1007-A
E53C 1007-CA	E43Z 1007-B
E53C 1007-DA	E53Z 1007-B
E56C 1007-AA	★ E56Y 1007-A
E56C 1007-BA	★ E56Y 1007-B
E5DC 1007-EA	★ E5DZ 1007-A
E5EC 1007-CA	E5FZ 1007-A
E5EC 1007-DA	E5FZ 1007-B
E5EC 1007-EA	E43Z 1007-A
E5LC 1007-BA	E5LY 1007-B
E5LC 1007-CA	E5LY 1007-C
E5LC 1007-FA	E5LY 1007-A
E5LC 1009-BA	E5LY 1007-D
E5SC 1007-BB	E7SZ 1007-A
E5SC 1007-HA	E6SZ 1007-B
E5SC 1007-JA	E3DZ 1007-B
E5SC 1007-JA	E7SZ 1007-E
E5WC 1007-EA	E7SZ 1007-D
E5WC 1007-FA	E6WY 1007-B
E5ZC 1007-CA	E5WY 1007-B
E63C 1007-CA	E63Z 1007-A
E63C 1007-DA	E63Z 1007-B
E65C 1007-AB	★ E65Y 1007-A
	r/b E65Y 1K007-B
E6AC 1007-AA	★ FOVY 1007-D
	r/b E9AZ 1007-B
E6DC 1007-AA	E6DZ 1007-D
E6DC 1007-CA	E7DZ 1007-C
E6EC 1007-AA	E6FZ 1007-A
E6EC 1007-BA	E6FZ 1007-B
E6SC 1007-AA	E7SZ 1007-C
E6YC 1007-AA	E6YZ 1007-A
E6ZC 1007-AA	E6ZZ 1007-A
E74C 1007-AWA	E74Y 1007-A
E76C 1007-AA	E76Y 1007-A
E7DC 1007-AA	★ E7DZ 1007-A
E7DC 1007-CA	E7DZ 1007-C
E7DC 1007-EA	E7DZ 1007-C
E7SC 1007-CA	E7SZ 1007-A
E7SC 1007-DA	E7SZ 1007-B
E7SC 1007-FA	E7SZ 1007-C
E7SC 1007-HA	E7SZ 1007-E
E7SC 1007-JA	E7SZ 1007-D
E7WC 1007-AA	E7WY 1007-A
E8AC 1007-CA	E8AZ 1007-C
E8AC 1007-DA	E8AZ 1007-D
E8DC 1007-AA	E6DZ 1007-E
E8EC 1007-AB	E8FZ 1007-A

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
1007 CONT'D	
E8EC 1007-CA	E8FZ 1007-C
E8G6 1007-AB	E8GY 1007-C
E8LC 1007-AB	E8LY 1007-A
E8OC 1007-AA	E8OY 1007-A
E8OC 1007-CA	E8OY 1007-C
E8SC 1007-CA	E3SZ 1007-D
E8WC 1007-AC1AA	E8WY 1007-A
E8WC 1007-AO4WA	E8WY 1007-C
E8WC 1007-AP5DA	E8WY 1007-B
E8WC 1007-BA	E7ZZ 1007-A
E94C 1007-AA	E94Y 1007-A
E96C 1007-AA	E96Y 1007-A
E9AC 1007-AA	E9AZ 1007-B
E9AC 1007-BA	★ E9AZ 1007-A r/b E9AZ 1007-B
E9DC 1007-AB	E9DZ 1007-A
E9DC 1007-CA	E6DZ 1007-C
E9DC 1007-EA	★ E9DZ 1007-B r/b FODZ 1007-E
E9EC 1007-AA	E9FZ 1007-A
E9EC 1007-CA	E8FZ 1007-B
E9SC 1007-BA	E9SZ 1007-A
E9SC 1007-CA	E9SZ 1007-B
E9SC 1007-DA	E9SZ 1007-C
E9WC 1007-AA	E9WY 1007-A
E9ZC 1007-AA	E9ZZ 1007-A
EDE5LC 1007-BA	E5LY 1007-B
EDE5LC 1007-CA	E5LY 1007-C
FOVC 1007-DA	E6DZ 1007-C
1K007	
E65C 1007-BA	E65Y 1K007-B
1011	
E5EC 1K011-AA	E5FZ 1011-A
1A100	
E5EC 1A100-AA	E5FZ 1A100-A
1102	
E45C 1K002-AA	E6LY 1102-A
E5LY 1K002-AB	E6LY 1102-A
1104	
GJ21 33061-C	E92Z 1104-A
GJ25 33061-C	E92Z 1104-B
1107	
GJ21 33062	E92Z 1107-B
H260 26113	E92Z 1107-A
1125	
87BB 1125-EA	E7RY 1125-C
GJ55 3325X-A	E92Z 1125-A
1126	
GJ21 25251-A	E92Z 1126-A
1130	
77FB 1137-AB	D8RZ 1130-D
78BB 1000-AA	★ D8RZ 1130-C
85BB 1000-AA	E5RY 1130-A
86GB 1130-AA	E7RY 1130-A
B15637170	E7GZ 1130-A
B15637190	E7GZ 1130-C
D1E53C 1A097-AA	E2GZ 1130-A
D5BA 1130-BA	D5DZ 1130-B

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
1130 CONT'D	
D6DA 1A096-AA	★ D5DZ 1130-J
D6DA 1A096-BA	★ D6DZ 1130-A
D6EA 1A096-BA	★ D6FZ 1130-B
D6EA 1A096-CA	D6FZ 1130-C
D7EC 1130-AA	★ D7FZ 1130-A
D8BC 1130-CA	D8BZ 1130-F
D8BC 1130-FA	D8BZ 1130-E
D8BC 1A096-AB	E1ZZ 1130-A
D8DC 1130-BA	★ D5DZ 1130-D
D8LC 1A096-AA	D8LY 1130-C
D94C 1A096-AA	★ D94Y 1130-B
D9AC 1130-EC	★ D9AZ 1130-E
D9AC 1130-FE	D9AZ 1130-B
D9AC 1130-KA	★ D9AZ 1130-C
D9BC 1130-AA	D9BZ 1130-A
D9CC 1A096-BC	★ D9ZZ 1130-A
D9DC 1130-AB	★ D9DZ 1130-A
D9DC 1130-B30RA	★ E1DZ 1130-F
D9DC 1130-B34HA	★ E1DZ 1130-G
D9DC 1130-B35UA	★ E1DZ 1130-H
D9DC 1130-B39AA	D8DZ 1130-F
D9DC 1130-B51WA	★ D8DZ 1130-G
D9DC 1130-B54FA	★ D8DZ 1130-H
D9DC 1130-BF5BA	★ D8DZ 1130-B
D9DC 1130-BF7BA	★ D9DZ 1130-B
D9DC 1130-BH2TA	★ E1DZ 1130-M
D9EC 1130-CC	★ D9FZ 1130-A
D9ZC 1130-FB	★ D9ZZ 1130-D
D9ZC 1A096-CC	D9ZZ 1130-C
D9ZC 1A096-CD	D9ZZ 1130-C
D9ZC 1A096-EE	D9ZZ 1130-H
E1AC 1130-BC	E3AZ 1130-B
E1BC 1A096-AA	★ E2BZ 1130-B
E1CC 1A096-AA	★ E1CY 1130-B
E1DC 1130-EC	E14Y 1130-C
E1DC 1130-GC	★ E1DZ 1130-L r/b E3AZ 1130-B
E1DC 1A096-AA	★ E2BZ 1130-B
E1EC 1A096-AB	E1FZ 1130-C
E1EC 1A096-AC	E1FZ 1130-C
E1EC 1A096-BD	★ E1FZ 1130-D
E1EC 1A096-CB	E1FZ 1130-B
E1EC 1A096-DB	D9ZZ 1130-H
E1SC 1130-AA	★ E1SZ 1130-B
E1SC 1130-AC	★ E1SZ 1130-D
E1SC 1130-BB	★ E1SZ 1130-E
E1SC 1130-DC	★ E1SZ 1130-F
E1ZC 1130-AA	★ E1ZZ 1130-E r/b E34Y 1130-C
E1ZC 1A096-AA	E1ZZ 1130-A
E1ZC 1A096-BA	E1ZZ 1130-B
E2AC 1130-DA	D9AZ 1130-B
E2BC 1A096-AA	★ E2BZ 1130-A r/b E2BZ 1137-A
E2DC 1130-AA	E14Y 1130-C
E2DC 1130-CA	E14Y 1130-C
E2EC 1A096-AA	E1FZ 1130-F
E2EC 1A096-AB	E1FZ 1130-F
E2EC 1A096-BA	★ E1FZ 1130-D

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
1130 CONT'D	
E2EC 1A096-BB	★ E1FZ 1130-D
E2EC 1A096-CA	E1FZ 1130-C
E2GC 1A097-AA	E2GZ 1130-A
E2SC 1A096-AA	★ E2BZ 1130-B
E2ZC 1130-AA	★ E2ZZ 1130-A
	r/b E34Y 1130-C
	r/b E2BZ 1137-A
E3AC 1130-DA	E3AZ 1130-A
E3AC 1130-EA	E3AZ 1130-B
E3AC 1130-FA	E3AZ 1130-B
E3AC 1130-GA	E3AZ 1130-D
E3AC 1130-HA	★ E3AZ 1130-F
	r/b E3AZ 1130-G
E3DC 1130-BA	★ E3DZ 1130-A
E3DC 1130-BB	★ E3DZ 1130-C
E3DC 1130-CA	E3DZ 1130-B
E3EC 1A096-AB	E3FZ 1130-E
E3EC 1A096-CA	E3FZ 1130-E
E3EC 1A096-DA	E3FZ 1130-F
E3SC 1130-BA	E3SZ 1130-A
E3SC 1130-CA	E3SZ 1130-B
E3SC 1A096-AB	E3SZ 1130-C
E3SC 1A096-AC	E3SZ 1130-C
E3VC 1A096-BA	D8LY 1130-C
E3ZC 1130-AA	E3ZZ 1130-A
E43C 1130-CA	E43Z 1130-A
E46C 1130-AB	E46Z 1130-A
E46C 1A097-BA	E46Y 1130-B
E46C 1A097-CA	E46Y 1130-B
E4AC 1130-BA	★ E3AZ 1130-F
	r/b E3AZ 1130-G
E4CC 1130-AA	E1CY 1130-A
E4MC 1130-BA	★ E1MY 1130-D
	r/b E1MY 1130-F
E4SC 1A096-AA	E4SZ 1130-A
E53C 1130-AA	★ E53Z 1130-A
	r/b E53Z 1130-B
	r/b E53Z 1137-A
E56C 1130-AA	★ E56Y 1130-B
	r/b E56Y 1137-A
E56C 1A097-AA	E56Y 1130-A
E5CC 1A096-AA	E5CY 1130-A
E5DC 1130-AA	E5DZ 1130-A
E5DC 1130-BA	E3SZ 1130-D
E5DC 1130-CA	E3SZ 1130-D
E5DC 1A097-BA	E5DZ 1130-B
E5LC 1A096-AB	E5LY 1130-A
E5SC 1130-EA	E5SZ 1130-C
E5SC 1A096-BA	E5SZ 1130-B
E5SC 1A097-BA	E5SZ 1130-A
E5WC 1A097-BA	E5WY 1130-C
E5ZC 1130-AA	E3SZ 1130-D
E5ZC 1A097-AA	E5ZZ 1130-A
E5ZC 1A097-AB	E5ZZ 1130-A
E5ZC 1A097-BA	E5ZZ 1130-B
E63C 1130-BA	E63Z 1130-A
E64C 1130-FB	E64Y 1130-F
E64C 1A096-AA	E64Y 1130-C
E6DC 1130-AA	E6DZ 1130-A
E6DC 1130-EA	E6DZ 1130-D
E6DC 1130-FA	E6DZ 1130-C

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
1130 CONT'D	
E6DC 1A096-AA	E6DZ 1130-J
E6DC 1A096-BA	E7DZ 1130-C
E6DC 1A096-BB	E7DZ 1130-C
E6EC 1A097-AA	E6FZ 1130-B
E6EC 1A097-BA	E6FZ 1130-A
E6ZC 1A097-AA	E6ZZ 1130-A
E74C 1130-AA	E74Y 1130-C
E74C 1130-BA	E74Y 1130-C
E74C 1130-BA	E7DZ 1130-E
E74C 1A096-A04WA	E74Y 1130-B
E7DC 1130-AA	E7DZ 1130-E
E7DC 1A096-AA	E7DZ 1130-A
E7DC 1A096-BA	E7DZ 1130-C
E7DC 1A097-BA	★ E7DZ 1130-D
E7EC 1A097-AA	E5FZ 1130-A
E7SC 1130-AA	E7SZ 1130-B
E7SC 1A097-AA	E7SZ 1130-A
E7SC 1A097-BA	E7SZ 1130-A
E7SC 1A097-CA	E7SZ 1130-C
E7VC 1A096-AA	E8VY 1130-C
E7VC 1A096-BA	E8VY 1130-C
E7WC 1130-AA	E7WY 1130-A
E7WC 1A096-BA	E7WY 1130-B
E7ZC 1130-AA	E7SZ 1130-A
E83C 1130-AB	E83Z 1130-B
E86C 1130-AB	E86Y 1130-C
E8AC 1130-BA	E8AZ 1130-A
E8AC 1130-CA	E8AZ 1130-B
E8AC 1A096-AA	E8AZ 1130-D
E8GC 1A097-AA	E8GY 1130-B
E8LC 1A096-BA	E8LY 1130-B
E8MC 1130-BB	E8MY 1130-A
E8MC 1130-CA	★ E8MY 1130-B
	r/b E8AZ 1130-B
E8MC 1A096-AA	E8MY 1130-D
E8OC 1130-CC	E8OY 1130-A
E8OC 1130-DB	E8OY 1130-F
E8OC 1130-FA	E8OY 1130-F
E8VC 1A096-AA	E8VY 1130-C
E8VC 1A096-BA	E8VY 1130-C
E94C 1130-AC	E94Y 1130-A
E9DC 1130-AC	★ E9DZ 1130-B
	r/b F1DZ 1130-B
E9DC 1130-BA	★ E9DZ 1130-C
	r/b F1DZ 1130-B
E9DC 1A096-AC	E9DZ 1130-A
E9EC 1130-AB	E9FZ 1130-A
E9SC 1130-CA	E9SZ 1130-D
E9SC 1130-DA	E9SZ 1130-C
E9SC 1A096-AB	E9SZ 1130-A
E9SC 1A096-BB	E9SZ 1130-B
E9WC 1130-AA	E9WY 1130-A
E9WC 1A096-AA	E9WY 1130-C
EDD70A 1130-AA	D9OZ 1130-A
EDE1AC 1130-CB	★ E2AZ 1130-D
EDE2BC 1A096-AA	★ E2BZ 1130-B
EDE2WC 1130-AA	E14Y 1130-C
EDE34C 1130-BA	E34Y 1130-C
EDE8EC 1130-AB	E9FZ 1130-A
EDE8LC 1A096-BA	E8LY 1130-B

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
1130 CONT'D	
F0DC 1130-AA	E6DZ 1130-B
F0EC 1130-AA	E9FZ 1130-A
F0ZC 1A096-AA	E7ZZ 1130-B
1131	
G211 26071	E92Z 1131-A
1137	
KA1O 37192 A	E92Z 1137-B
KA01 37192	E92Z 1137-A
1210	
E4DC 1210-AA	E2BZ 1210-A
E8EC 1210-AB	E8FZ 1210-A
1443	
BJ38 56210-C	★ E8GY 1443-A
1453	
B218 56220-A	E8GY 1453-A
1487	
B923 20828	E8GY 1487-A
2884	
85B6 19D629-AA	* E5RY 2884-A YB-303
85GG 19D649-AA	* E5RY 2884-A YB-303
D52H 2981-A1A	* D6FZ 2884-A YB-192
D52H 2981-A2A	* D6FZ 2884-A YB-192
D5DH 2981-A1A	★ D5DZ 2884-B * YB-162 r/b D5DZ 2884-A
D5DH 2981-A2A	★ D5DZ 2884-B * YB-162 r/b D5DZ 2884-A
D8BH 2981-AA	★ D8BZ 2884-A * YB-200
D9ZH 19D649-AC	* D9ZZ 2884-A YB-211
E0VH 19D629-AA	* E3AZ 2884-A YB-280
E0VH 19D786-AA	★ E3DZ 2884-A * YB-276 r/b MAT 85010
E1AH 19D629-A1A	* E3AZ 2884-A YB-280
E1AH 19D629-A2A	* E4ZZ 2884-A YB-298
E1AH 19D629-AA	* E3AZ 2884-A YB-280
E1AH 19D629-AB	* E3AZ 2884-A YB-280
E1AH 19D629-AC	* E3AZ 2884-A YB-280
E1AH 19D629-BA	* E4ZZ 2884-A YB-298
E1AH 19D629-CA	* E3AZ 2884-A YB-280
E1AH 19D786-AA	* E4ZZ 2884-A YB-298
E1BH 19D649-AA	* D6FZ 2884-A YB-192
E1EH 19D629-AA	* E4ZZ 2884-A YB-298

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
2884 CONT'D	
E1EH 19D629-AB	* E4ZZ 2884-A YB-298
E1EH 19D629-AC	* E4ZZ 2884-A YB-298
E1EH 19N689-BA	* E1FZ 2884-C YB-246
E1EH 19N689-DA	* E1FZ 2884-E YB-256
E1SH 19D649-AA	★ D5DZ 2884-B * YB-162 r/b D5DZ 2884-A
E1SH 19D649-BA	★ D8BZ 2884-A * YB-200
E1VH 19D629-AA	* E3AZ 2884-A YB-280
E27H 19D629-AB	* E3AZ 2884-A YB-280
E2BH 19D649-AA	* D6FZ 2884-A YB-192
E2BH 19D649-BA	★ D8BZ 2884-A * YB-200
E2EH 19D629-AA	* E4ZZ 2884-A YB-298
E2SH 19D649-AA	★ D5DZ 2884-B * YB-162 r/b D5DZ 2884-A
E2TH 19D629-AA	* E3AZ 2884-A YB-280
E2TH 19D629-FA	* E3AZ 2884-A YB-280
E2ZH 19D629-AA	* E3AZ 2884-A YB-280
E2ZH 19D629-BA	* E43Z 2884-A YB-289
E35H 19D629-AA	* E3AZ 2884-A YB-280
E35H 19D629-BA	* E3LY 2884-A YB-294
E3AH 19D629-AA	* E3AZ 2884-A YB-280
E3AH 19D629-AB	* E3AZ 2884-A YB-280
E3DH 19D629-BA	* E4SZ 2884-A YB-288
E3DH 19D629-CA	* E3AZ 2884-A YB-280
E3DH 19D629-DA	* E3LY 2884-A YB-294
E3DH 19D629-EA	* E3LY 2884-A YB-294
E3EH 19D629-AA	* E4ZZ 2884-A YB-298
E3EH 19D629-BA	* E4ZZ 2884-A YB-298
E3LH 19D629-AA	* E3AZ 2884-A YB-280
E3LH 19D629-BA	* E3LY 2884-A YB-294
E3LH 19D786-AA	* E3AZ 2884-A YB-280
E3LH 19D786-AA	* E3LY 2884-A YB-294
E3SH 19D629-AA	* E3LY 2884-A YB-294

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
2884 CONT'D	
E3SH 19D629-BA	E4SZ 2884-A * YB-288
E3SH 19D629-BB	E4SZ 2884-A * YB-288
E3SH 19D786-AA	★ E3SZ 2884-A * YB-274 r/b E4SZ 2884-A
E3TH 19D629-AA	E3LY 2884-A * YB-294
E3TH 19D629-AB	E3LY 2884-A * YB-294
E3TH 19D629-BA	E3LY 2884-A * YB-294
E3TH 19D629-CA	E3LY 2884-A * YB-294
E3TH 19D629-CB	E3LY 2884-A * YB-294
E3TH 19D629-DA	E3LY 2884-A * YB-294
E3TH 19D629-EA	E3AZ 2884-A * YB-280
E3TH 19D629-FA	E3LY 2884-A * YB-294
E3VH 19D629-AA	E3AZ 2884-A * YB-280
E3ZH 19D629-AA	E4ZZ 2884-A * YB-298
E43H 19D629-AA	E43Z 2884-A * YB-289
E43H 19D629-BA	E43Z 2884-A * YB-289
E43H 19D629-CA	E43Z 2884-A * YB-289
E43H 19D629-DA	E43Z 2884-A * YB-289
E43H 19D629-EA	E43Z 2884-A * YB-289
E43H 19D786-AA	E43Z 2884-A * YB-289
E4EH 19D629-CA	E43Z 2884-A * YB-289
E4EH 19D629-DA	E43Z 2884-A * YB-289
E4EH 19D629-EA	E43Z 2884-A * YB-289
E4LH 19D629-AA	E3LY 2884-A * YB-294
E4SH 19D629-AA	E4SZ 2884-A * YB-288
E4SH 19D629-AA	F1OY 2884-A * YB-406
E4SH 19D629-AB	E4SZ 2884-A * YB-288
E4SH 19D629-AC	E4SZ 2884-A * YB-288
E4SH 19D629-AD	E4SZ 2884-A * YB-288
E4SH 19D629-BA	E4SZ 2884-A * YB-288
E4SH 19D629-BB	E4SZ 2884-A * YB-288
E4SH 19D786-AA	E4SZ 2884-A * YB-288
E4TH 19D629-AA	E3LY 2884-A * YB-294

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
2884 CONT'D	
E4TH 19D629-BA	E3LY 2884-A * YB-294
E4TH 19D629-CA	E3LY 2884-A * YB-294
E4TH 19D629-DA	E3LY 2884-A * YB-294
E4UH 19D629-AA	E3LY 2884-A * YB-294
E4UH 19D629-BA	E3LY 2884-A * YB-294
E4UH 19D629-CA	E4ZZ 2884-A * YB-298
E4UH 19D629-DA	E4UZ 2884-A * YB-307
E57H 19D629-AA	E4SZ 2884-A * YB-288
E5DH 19D629-AA	E4SZ 2884-A * YB-288
E5ZH 19D629-AA	E43Z 2884-A * YB-289
E6DH 19D629-AA	E3LY 2884-A * YB-294
E6HH 19D629-AA	E3LY 2884-A * YB-294
E6HH 19D629-DA	E3LY 2884-A * YB-294
E6LH 19D629-AA	E3LY 2884-A * YB-294
E6LH 19D629-DA	E3LY 2884-A * YB-294
E6TH 19D629-AA	E3LY 2884-A * YB-294
E6TH 19D629-BA	E3LY 2884-A * YB-294
E6UH 19D629-AA	E3LY 2884-A * YB-294
E6UH 19D629-BA	E3LY 2884-A * YB-294
E6VH 19D629-AA	E3LY 2884-A * YB-294
E73H 19D629-AA	E43Z 2884-A * YB-289
E73H 19D629-BA	E43Z 2884-A * YB-289
E77H 19D629-AA	E4UZ 2884-A * YB-307
E77H 19D629-CA	E4ZZ 2884-A * YB-298
E77H 19D629-DA	E4UZ 2884-A * YB-307
E7DH 19D629-AA	E43Z 2884-A * YB-289
E7DH 19D629-CA	E3LY 2884-A * YB-294
E7EH 19D629-AA	E43Z 2884-A * YB-289
E7EH 19D629-DA	E43Z 2884-A * YB-289
E7HH 19D629-AA	E3LY 2884-A * YB-294
E7SH 19D629-AA	E4SZ 2884-A * YB-288
E7TH 19D629-BA	E4UZ 2884-A * YB-307
E7TH 19D629-CA	E4ZZ 2884-A * YB-298

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
2884 CONT'D	
E7UH 19D629-AA	* E4ZZ 2884-A * YB-298
E80H 19D629-AA	* E43Z 2884-A * YB-289
E83H 19D629-AA	* E43Z 2884-A * YB-289
E8DH 19D629-AA	* E3LY 2884-A * YB-294
E8DH 19D629-AB	* E3LY 2884-A * YB-294
E8EH 19D629-AA	* E43Z 2884-A * YB-289
E8EH 19D629-BA	* E43Z 2884-A * YB-289
E8EH 19D629-CA	* E43Z 2884-A * YB-289
E8SH 19D629-AA	* E43Z 2884-A * YB-289
E8SH 19D629-BA	* E4SZ 2884-A * YB-288
E8SH 19D629-CA	* E4SZ 2884-A * YB-288
E8SH 19D629-CB	* E4SZ 2884-A * YB-288
E8SH 19D629-DA	* E4SZ 2884-A * YB-288
E8TH 19D629-AA	* E3LY 2884-A * YB-294
E8VH 19D629-AA	* E3LY 2884-A * YB-294
E9DH 19D629-AD	* E9SZ 2884-A * YB-372
E9DH 19D629-BB	* E43Z 2884-A * YB-289
E9VH 19D629-AB	* E9VZ 2884-A * YB-371
F0C6 19D629-AB	* F1CZ 2884-A * YB-392
F0CH 19D629-BA	* F1CZ 2884-B * YB-395
F0SH 19D629-BA	* E9SZ 2884-A * YB-372
F0ZH 19D629-BA	* E43Z 2884-A * YB-289
F1OH 19D629-AD	* E9SZ 2884-A * YB-372
F1OH 19D629-AE	* F1OY 2884-A * YB-406
F1SH 19D629-AB	* E9SZ 2884-A * YB-372
F1SH 19D629-BB	* E9SZ 2884-A * YB-372
F1VH 19D629-AB	* F1VY 2884-A * YB-404
3C111	
E8OF 3C111-AA	E8OY 3C111-A
E8OF 3C111-BA	E8OY 3C111-B
E8OF 3C111-CA	E8OY 3C111-C
E8OF 3C111-DA	E8OY 3C111-D
E8OF 3C111-EA	E8OY 3C111-E
E8OF 3C111-FA	E8OY 3C111-F
E8OF 3C111-GA	E8OY 3C111-G
E8OF 3C111-HA	E8OY 3C111-H

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
3C111 CONT'D	
E8OF 3C111-JA	E8OY 3C111-J
E8OF 3C111-KA	E8OY 3C111-K
03166	
GG	D8VY 6003166-A
03406	
DR	D5DZ 6603406-A
3B436	
	* F4DZ 3B436-A * TX-233
3494	
D8DC 3494-AA	D8DZ 3494-A
D8DC 3494-BA	D8DZ 3494-A
3504	
SMA-AC	★ EODZ 3504-A
SMA-AH	★ EODZ 3504-B
SMA-AJ	★ EO4Y 3504-A
SMA-AJ	★ EODZ 3504-A
SMA-Y	★ D6DZ 3504-A
SMC-AB	E1DZ 3504-A
SMC-AE	★ E6FZ 3504-B
SMC-AF	★ E6FZ 3504-B
SMC-AJ	★ E6FZ 3504-B
SMC-AN	★ E6FZ 3504-B
SMC-AR	E5FZ 3504-C
SMC-AT	E2DZ 3504-B
SMC-AW	E5FZ 3504-C
SMC-AY	★ E6FZ 3504-B
SMC-AZ	E5FZ 3504-C
SMC-S	★ D9FZ 3504-B
SMC-T	E1DZ 3504-A
SMC-X	★ D9FZ 3504-B
SPA-BU	★ D9AZ 3504-A
SPA-CL	★ D9AZ 3504-A
SPA-DL	E8AZ 3504-A
SPA-DV	★ E7AZ 3504-A r/b E8AZ 3504-A
SPA-DV	E8AZ 3504-A
SPA-EE	E8AZ 3504-A
SPR-AC	★ EOFZ 3504-A
SPR-AD	★ EOZZ 3504-A
SPR-AE	★ E1BZ 3504-B
SPR-AE	EOZZ 3504-B
SPR-AK	★ EOZZ 3504-A
SPR-AT	★ E2ZZ 3504-A r/b E5DZ 3L547-B
SPR-AT	★ E2ZZ 3504-B r/b E5DZ 3L547-B r/b D8BZ 3A776-A
SPR-AV	★ E4DZ 3504-C r/b E5SZ 3L547-A r/b E5SZ 3L547-C
SPR-AY	★ E3DZ 3504-B r/b E5DZ 3L547-B
SPR-AY	★ E3SZ 3504-C r/b E5SZ 3L547-C
SPR-BA	E6FZ 3504-A
SPR-BB	★ E3SZ 3504-A r/b E5DZ 3L547-A

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.	
3504 CONT'D		
SPR-BB	★ E4DZ	3504-C
	r/b E5SZ	3L547-A
	r/b E5SZ	3L547-C
SPR-BD	★ E3BZ	3504-A
	r/b E4DZ	3L547-A
SPR-BH	★ E3SZ	3504-A
	r/b E5DZ	3L547-A
SPR-BJ	★ E3BZ	3504-A
	r/b E4DZ	3L547-A
SPR-BK	★ E4DZ	3504-C
	r/b E5SZ	3L547-A
	r/b E5SZ	3L547-C
SPR-BS	★ E3SZ	3504-A
	r/b E5DZ	3L547-A
SPR-BS	★ E3SZ	3504-D
	r/b E5SZ	3L547-C
SPR-BT	★ E4DZ	3504-C
	r/b E5SZ	3L547-A
	r/b E5SZ	3L547-C
SPR-BV	★ E4SZ	3504-B
	r/b E5DZ	3L547-A
SPR-BX	E6FZ	3504-A
SPR-CB	★ E4DZ	3504-C
	r/b E5SZ	3L547-A
	r/b E5SZ	3L547-C
SPR-CD	★ E4DZ	3504-D
	r/b E4DZ	3L547-A
SPR-CE	★ E4SZ	3504-D
	r/b E4SZ	3L547-B
SPR-CF	★ E4ZZ	3504-A
	r/b E5ZZ	3L547-B
	r/b D8BZ	3A766-A
SPR-CG	★ E4DZ	3504-D
	r/b E4DZ	3L547-A
SPR-CH	★ E4DZ	3504-D
	r/b E4DZ	3L547-A
SPR-CY	★ E6DZ	3504-A
	r/b E8DZ	3L547-A
	r/b E8DZ	3A717-B
SPR-DX	E6FZ	3504-A
3C511		
E8DE-DA	★ E9DZ	3C511-B
	r/b F3DZ	3C511-C
3D517		
SPR-DT	★ E9DZ	3D517-B
	r/b F3DZ	3L547-A
	r/b E8DZ	3L547-A
3L547		
SPR-DB	E5DZ	3L547-A
SPR-DJ	E8DZ	3L547-A
SPR-DL	E9SZ	3L547-A
SPR-DN	E9DZ	3L547-A
SPR-DS	E5DZ	3L547-B
SPR-DT	E8DZ	3L547-A
SPR-EB	E8DZ	3L547-A
SPR-EC	E9DZ	3L547-A
SPR-ER	E9SZ	3L547-A
SPR-EV	E5DZ	3L547-A
SPR-FK	F1OY	3L547-A
3A674		
BP44 32600-A	E8GY	3A674-A
HBC-AS	★ EODZ	3A674-A
HBC-EK	E5LY	3A674-A

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.	
3A674 CONT'D		
HBC-EM	★ E8FZ	3A674-B
	r/b FOFZ	3A674-A
HBC-EN	FO3Z	3A674-A
HBC-EU	E63Z	3A674-A
HBC-EV	E5LY	3A674-A
HBC-FJ	E5LY	3A674-A
HBC-FM	★ E6SZ	3A674-A
	r/b FOZZ	3A674-A
HBC-FN	E8SZ	3A674-B
HBC-FU	★ E8VY	3A674-A
	r/b FOAZ	3A674-B
HBC-FV	E8AZ	3A674-A
HBC-FW	E5LY	3A674-A
HBC-FX	E9ZZ	3A674-B
HBC-FY	E5LY	3A674-B
HBC-FZ	★ E6DZ	3A674-A
	r/b FODZ	3A674-A
HBC-GA	E9LY	3A674-A
	r/b FOLY	3A674-A
HBC-GB	★ FOOY	3A674-A
	r/b FOOY	3A674-B
HBC-GC	E8ZZ	3A674-A
HBC-GD	★ E8FZ	3A674-A
	r/b E9FZ	3A674-B
HBC-GF	★ E6DZ	3A674-A
	r/b FODZ	3A674-A
HBC-GG	E8SZ	3A674-B
HBC-GJ	FO3Z	3A674-A
HBC-GK	★ E6SZ	3A674-A
	r/b FOZZ	3A674-A
HBC-GL	★ E8FZ	3A674-A
	r/b E9FZ	3A674-B
HBC-GM	★ E8FZ	3A674-B
	r/b FOFZ	3A674-A
HBC-GR	★ E8VY	3A674-A
	r/b FOAZ	3A674-B
HBC-GS	E8AZ	3A674-A
HBC-GT	E9LY	3A674-A
	r/b FOLY	3A674-A
HBC-GU	E9ZZ	3A674-B
HBC-GV	★ FOOY	3A674-A
	r/b FOOY	3A674-B
HBC-GW	E8SZ	3A674-A
HBC-HB	★ E8FZ	3A674-B
	r/b FOFZ	3A674-A
HBC-HD	E8SZ	3A674-B
HBC-HE	FO9Z	3A674-A
HBC-HF	FODZ	3A674-A
HBC-HK	★ E8LY	3A674-A
	r/b E9LY	3A674-A
HBC-HM	★ FOOY	3A674-A
	r/b FOOY	3A674-B
HBC-HR	E9SZ	3A674-A
HBC-HS	★ E9SZ	3A674-B
	r/b E9SZ	3A674-D
HBC-HX	E8ZZ	3A674-A
HBC-HY	FODZ	3A674-A
HBC-JA	E9SZ	3A674-A
HBC-JB	★ E9SZ	3A674-B
	r/b E9SZ	3A674-D
HBC-JC	★ E8LY	3A674-A
	r/b E9LY	3A674-A

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
3A674 CONT'D	
HBC-JF	★ E8FZ 3A674-B r/b FOFZ 3A674-A
HBC-JG	★ FOOY 3A674-A r/b FOOY 3A674-B
HBC-JN	FODZ 3A674-A
HBC-JU	★ FOOY 3A674-A r/b FOOY 3A674-B
HBC-KD	FO3Z 3A674-A
HBC-KE	FO9Z 3A674-A
3A713	
85GB 3A713-AA	E7RY 3A713-A
85GB 3A713-AB	E7RY 3A713-A
85GB 3A713-AC	E8RY 3A713-A
D6DW 3A713-BB	D6DZ 3A713-E
D6DW 3A713-CA	D6DZ 3A713-E
D6DW 3F595-AA	★ D6DZ 3A713-A
D6DW 3F595-BA	★ D6DZ 3A713-A
D8EC 3C566-AA	★ D8FZ 3A713-A
D9AC 3A563-AB	D9AZ 3A713-A
D9BC 3A713-CA	EOBZ 3A713-C
D9BC 3A713-DA	★ EOBZ 3A713-D
D9DC 3A713-AA	★ D9DZ 3A713-A
E0AC 3A563-AA	EOAZ 3A713-A
E0ZC 3A563-AA	★ EOZZ 3A713-D
E0ZC 3A563-BA	★ EOZZ 3A713-E
E1BC 3A563-AA	★ E1BZ 3A713-C
E1SC 3A563-AA	★ E1SZ 3A713-A
E25C 3A713-AA	★ E25Y 3A713-B
E25C 3F595-AD	E25Y 3A713-C
E2EC 3A563-AA	E6FZ 3A713-A
E2ZC 3A563-AA	E2ZZ 3A713-A
E43C 3A563-AA	E43Z 3A713-B
E43C 3A563-AB	E43Z 3A713-B
E43C 3A713-BC	E43Z 3A713-A
E4DC 3A563-AA	E7LY 3A713-A
E4EC 3A563-AA	E6FZ 3A713-A
E4EC 3A713-AB	E4FZ 3A713-A
E4EC 3A713-BB	★ E4FZ 3A713-B
E4LC 3A713-AA	E4LY 3A713-A
E4ZX 3A563-AA	E2ZZ 3A713-A
E5LC 3F595-AA	E5LY 3A713-C
E5RD 3A713-BC	E5RY 3A713-A
E6DC 3A713-AB	E6DZ 3A713-A
E6DC 3A713-AC	E6DZ 3A713-A
E6DC 3A713-BB	E6DZ 3A713-B
E6DC 3A713-BE	E6DZ 3A713-C
E6EC 3A563-AA	E6FZ 3A713-A
E73C 3A563-AA	E43Z 3A713-B
E73C 3A713-AA	E73Z 3A713-A
E7AC 3A563-AA	EOAZ 3A713-A
E7AC 3A563-BA	D9AZ 3A713-A
E7EC 3A563-AA	E7FZ 3A713-A
E7EC 3A563-AC	E7FZ 3A713-A
E7EC 3A563-BA	E7FZ 3A713-D
E7EC 3A563-CA	E7FZ 3A713-C
E7EC 3A563-CB	E7FZ 3A713-D
E7EC 3A713-AA	E7FZ 3A713-B
E7EC 3A713-BA	E7FZ 3A713-C
E7LC 3A563-AA	E7LY 3A713-A

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
3A713 CONT'D	
E8DC 3A713-AA	E8DZ 3A713-A
E8DC 3A713-CA	E8DZ 3A713-B
E8OC 3493-AA	E8OY 3A713-C
E8OC 3493-AB	E8OY 3A713-C
E8OC 3A713-CA	E8OY 3A713-A
E8OC 3A713-DA	★ E8OY 3A713-B r/b E9OY 3A713-A
E8OC 3A713-DB	★ E8OY 3A713-B r/b E9OY 3A713-A
E8OC 3A713-DC	★ E8OY 3A713-B r/b E9OY 3A713-A
E9DC 3493-AA	E9DZ 3A713-A
E9DC 3493-CA	E9DZ 3A713-A
E9DC 3493-CC	E9DZ 3A713-A
E9DC 3A713-BA	E9DZ 3A713-B
E9DC 3A713-CA	E9DZ 3A713-B
E9OC 3F731-AA	E9OY 3A713-A
E9SC 3493-CA	E9SZ 3A713-A
E9SC 3493-DA	E9SZ 3A713-D
E9SC 3493-FA	E9SZ 3A713-F
E9SC 3593-EA	E9SZ 3A713-F
E9SC 3A563-BA	E9SZ 3A713-C
E9SC 3A713-CA	E9SZ 3A713-D
F13C 3493-AB	E73Z 3A713-A
F3DC 3A713-DA	E8OY 3A713-A
3A714	
85GB 3A714-AA	E5RY 3A714-A
D8BC 3D702-AA	★ D8BZ 3A714-A
D8DC 3A714-AA	D8DZ 3A714-A
E1BC 3D702-AA	D9BZ 3A714-A
E1EC 3D702-AB	E1FZ 3A714-A
E4DC 3D702-AA	E4DZ 3A714-A
E6DC 3A702-AA	E6DZ 3A714-A
E7EC 3D702-AA	E7FZ 3A714-A
E8DC 3D702-AA	E8DZ 3A714-A
E8DC 3D702-AB	E8DZ 3A714-A
E9SC 3D702-CA	E9SZ 3A714-A
3A717	
85BG 3A717-CA	E6RY 3A717-A
85GB 3A717-AA	E5RY 3A717-A
D7EA 3E576-AA	D7FZ 3A717-A
D8BC 3D701-AA	D8BZ 3A717-A
D8BC 3D701-AB	D8BZ 3A717-A
D8DC 3A717-AA	D8DZ 3A717-A
E1BC 3D701-AA	D9BZ 3A717-A
E1EC 3D701-AB	E1FZ 3A717-A
E4DC 3D701-AA	E4DZ 3A717-A
E6DC 3D701-AA	E6DZ 3A717-A
E8DC 3D701-BA	E8DZ 3A717-A
E8DC 3D701-BB	E8DZ 3A717-A
E9SC 3D701-CA	E9SZ 3A717-A
3A719	
86GB 3A719-AA	E8RY 3A719-B
86GB 3A719-AB	E8RY 3A719-B
86GB 3A719-AC	E8RY 3A719-B
D7DC 3A719-EA	D7DZ 3A719-G
D7DC 3A719-FA	D7DZ 3A719-H
D8DC 3F523-BA	★ D8DZ 3A719-F
D8EC 3A719-DA	D8FZ 3A719-D

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.		SERVICE NO.		IDENTIFICATION NO.		SERVICE NO.	
3A719 CONT'D				3A719 CONT'D			
D9BC 3A715-BD		EOBZ	3A719-B	E63C 3A719-BA		E93Z	3A719-C
D9BC 3A719-BD		EOBZ	3A719-B	E63C 3F524-AA		E63Z	3A719-A
D9ZC 3A719-CB		D9ZZ	3A719-C	E6DC 3A718-AD		E6DZ	3A719-C
D9ZC 3A719-EC		EOZZ	3A719-E	E6DC 3A718-BA		E7DZ	3A719-B
D9ZC 3A719-FA	★	D9ZZ	3A719-E	E6DC 3F524-AJ		E6DZ	3A719-C
E0AC 3A719-AA		EOAZ	3A719-A	E6DC 3F524-BG		E7DZ	3A719-B
E0DC 3A719-AB	★	EODZ	3A719-A	E73C 3A719-DA		E93Z	3A719-B
E0DC 3A719-BA	★	EODZ	3A719-B	E73C 3E576-BA		E93Z	3A719-A
E1BC 3A719-CA	★	D9ZZ	3A719-E	E73C 3F524-CA		E93Z	3A719-C
E1EC 3A719-DA		E1FZ	3A719-A	E73C 3F524-DA		E93Z	3A719-B
E1EC 3A719-DB		E1FZ	3A719-A	E7AC 3A719-AA		EOAZ	3A719-A
E1EC 3B712-CA		E1FZ	3A719-C	E7DC 3A719-AA	★	E7DZ	3A719-A
E1EC 3B712-DA		E1FZ	3A719-B	E7DC 3A719-FA		E8DZ	3A719-C
E1SC 3A715-AA	★	E1SZ	3A719-A	E7DC 3F524-DA		E7DZ	3A719-B
E25C 3F523-AD		E25Y	3A719-A	E7DC 3F524-FA		E8DZ	3A719-C
E25C 3F524-AD		E25Y	3A719-B	E7EC 3A719-DB		E9FZ	3A719-A
E2EC 3B712-AA		E1FZ	3A719-C	E7EC 3A719-EA		E7FZ	3A719-G
E2SC 3A719-BA		E2SZ	3A719-B	E7EC 3E576-EA		E7FZ	3A719-B
E2SC 3A719-CA	★	E2SZ	3A719-C	E7EC 3E576-FA		E7FZ	3A719-A
E2ZC 3A719-AA		E2ZZ	3A719-A	E7EC 3E576-GA		E7FZ	3A719-E
E3SC 3A719-BA		E3SZ	3A719-B	E7LC 3A715-AA		E7LY	3A719-A
E3ZC 3A719-AA		E3SZ	3A719-B	E7SC 3A719-EA		E7SZ	3A719-E
E43C 3A719-BA		E43Z	3A719-B	E7ZC 3A715-BB		E7SZ	3A719-D
E43C 3A719-BB		E43Z	3A719-B	E7ZC 3A719-BA		E7ZZ	3A719-A
E43C 3A719-BC		E43Z	3A719-B	E7ZC 3F524-BA		E7ZZ	3A719-A
E43C 3A719-CA		E63Z	3A719-A	E8DC 3A719-GA	★	E8DZ	3A719-A
E43C 3A719-CB		E63Z	3A719-A		r/b	E8DZ	3A719-D
E43C 3A719-CC		E63Z	3A719-A	E8DC 3A719-JA		E8DZ	3A719-C
E43C 3E576-BC	★	E43Z	3A719-A	E8DC 3A719-KA	★	E8DZ	3A719-A
	r/b	E73Z	3A719-A		r/b	E8DZ	3A719-D
E43C 3E576-BD	★	E43Z	3A719-A	E8DC 3A719-LA		E8DZ	3A719-D
	r/b	E73Z	3A719-A	E8DC 3F524-FA	★	E8DZ	3A719-A
E4AC 3A719-AA		EOAZ	3A719-A		r/b	E8DZ	3A719-D
E4DC 3A719-AA	★	E3DZ	3A719-B	E8DC 3F524-JA		E8DZ	3A719-C
E4DC 3A719-BA		E4DZ	3A719-A	E8DC 3F524-KA		E8DZ	3A719-D
E4DC 3A719-BB		E4DZ	3A719-A	E8OC 3A719-CA		E8OY	3A719-B
E4DC 3A719-CA		E4DZ	3A719-C	E8OC 3A719-DA		E8OY	3A719-B
E4DC 3A719-CB		E4DZ	3A719-C	E8SC 3A719-AA		E7SZ	3A719-D
E4DC 3A719-EA		E3SZ	3A719-B	E8SC 3A719-BA		E7SZ	3A719-B
E4EC 3A719-AA		E4FZ	3A719-C	E9DC 3A719-CA		E9DZ	3A719-A
E4EC 3A719-AB		E4FZ	3A719-C	E9DC 3A719-EA		E9DZ	3A719-B
E4EC 3A719-BA		E4FZ	3A719-D	E9DC 3F524-BA		E9DZ	3A719-A
E4EC 3A719-BB		E4FZ	3A719-D	E9DC 3F524-CA		E9DZ	3A719-B
E4EC 3B712-CA		E1FZ	3A719-B	E9SC 3E576-BA		E9SZ	3A719-A
E4EC 3E576-AB		E4FZ	3A719-A	E9SC 3F524-JA		E9SZ	3A719-B
E4EC 3E576-AC		E4FZ	3A719-A	E9SC 3F524-KA		E9SZ	3A719-C
E4EC 3E576-BB		E4FZ	3A719-B	E9SC 3F524-LA		E9SZ	3A719-D
E4EC 3E576-BC		E4FZ	3A719-B	E9SC 3F524-MA		E9SZ	3A719-B
E4LC 3F523-AA		E4LY	3A719-A	E9SC 3F524-NA		E9SZ	3A719-C
E4LC 3F523-BA		E4LY	3A719-B	E9SC 3F524-PA		E9SZ	3A719-D
E4LC 3F524-AA		E4LY	3A719-C	E9SC 3F524-RA		E9SZ	3A719-D
E4LC 3F524-BA		E4LY	3A719-D	EDE1EC 3A719-DB		E1FZ	3A719-A
E4ZX 3A719-AA		E4ZZ	3A719-A	EDE63C 3A719-BA		E63Z	3A719-A
E4ZX 3A719-AB		E4ZZ	3A719-A	EDE73C 3A719-DA		E73Z	3A719-C
E53C 3A719-AA		E63Z	3A719-A	EDE73C 3E576-BA		E73Z	3A719-A
E5DC 3A719-AA	★	E5DZ	3A719-A	EDE73C 3F524-CA		E63Z	3A719-A
E5DC 3A719-BA	★	E5DZ	3A719-B	EDE73C 3F524-DA		E73Z	3A719-C
E5LC 3F523-AA		E5LY	3A719-A	EDE7EC 3A719-DB		E6FZ	3A719-A
E5RD 3A719-AB		E5RY	3A719-A	EDE7EC 3E576-GA		E7FZ	3A719-F
E63C 3A719-AA		E63Z	3A719-A	GJ25 3245X		E92Z	3A719-E

— LAYOUT CONTINUED —

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
3A733	
7AA	C7AZ 3A733-A
AB-2	E1FZ 3A733-A
C5AR-B	C5AZ 3A733-B
D0AR-A	DOAZ 3A733-A
D42W-AA	D4ZZ 3A733-A
D4ZW-AA	D4ZZ 3A733-A
D5ZW-AA	D5ZZ 3A733-A
D8DC-BA	D8DZ 3A733-B
D8ZC-AA	D8ZZ 3A733-A
D9AC 3D673-A1A	D9AZ 3A733-A
D9AC-A1A	D9AZ 3A733-A
D9AC-A2A	D9AZ 3A733-A
D9AC-A3A	D9AZ 3A733-A
D9AC-A3B	D9AZ 3A733-A
D9ZC-AA	D9ZZ 3A733-A
E0BC-AA	★ EOBZ 3A733-A
E1EC-AA	E1FZ 3A733-A
E1EC-AB	E1FZ 3A733-A
E1EC-BB	E1FZ 3A733-A
E2SC-AA	E2SZ 3A733-A
E2SC-CA	D5ZZ 3A733-A
E3EC-AA	E3FZ 3A733-A
E3EC-AA-2	E3FZ 3A733-A
E3SC-AA	E5DZ 3A733-A
E4EC-AA	E4FZ 3A733-A
E4EC-BA	E4FZ 3A733-B
E57C 3D673-BA	E57Y 3A733-A
E57C-BA	E57Y 3A733-A
E5DC-AA	E5DZ 3A733-A
E5DE-AA	E5DZ 3A733-B
E5ZC-AA	E5ZZ 3A733-A
E9DE-BA	E9DZ 3A733-B
3D746	
D8BC 3D746-AA	D8BZ 3D746-A
D8EC 3D746-AA	★ D8FZ 3D746-A
D9ZC 3D746-BA	D9ZZ 3D746-B
E1EC 3D746-BA	E1FZ 3D746-A
E3DC-AB	E3DZ 3D746-A
4006	
N/A	E5RY 4006-C
N/A	E5RY 4006-D
N/A	E7RY 4006-A
N/A	E7RY 4006-B
S205-F	E6ZW 4006-CA
S219-A	E6ZW 4006-CA
S230-F	★ E6ZW 4006-BA
S266-D	E7ZW 4006-BA
S414-E	★ E6LW 4006-GA
S421-E	★ E6LW 4006-CA
S422-E	★ E6LW 4006-DA
S423-E	★ E6LW 4006-EA
S424-E	★ E6LW 4006-FA
S431-A	E7SW 4006-BA
S433-A	E7SW 4006-CA
S465-C	★ E7SW 4006-DB
S914-B	★ E4SW 4006-RA
S939-C	E4DW 4006-AHA
V016-A	E6AW 4006-BA

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
4006 CONT'D	
V016-B	E6AW 4006-BA
V016-C	E6AW 4006-BA
V016-D	E6AW 4006-BA
V017-A	★ E6AW 4006-CA
V017-B	★ E6AW 4006-CA
V017-C	★ E6AW 4006-CA
V017-D	★ E6AW 4006-CA
V018-A	★ E3AW 4006-JA
V036-A	★ E3AW 4006-JA
V038-A	E6AW 4006-BA
V038-B	E6AW 4006-BA
V038-C	E6AW 4006-BA
V038-D	E6AW 4006-BA
V039-A	★ E6AW 4006-CA
V039-B	★ E6AW 4006-CA
V039-C	★ E6AW 4006-CA
V039-D	★ E6AW 4006-CA
V466-B	★ E7SW 4006-DB
V467-B	E5SW 4006-JA
V481-B	E7SW 4006-EA
V483-B	E7SW 4006-HA
V486-B	★ E7SW 4006-FB
WFC-A	★ E1ZW 4006-AA
WFC-AA	E3SW 4006-DA
WFC-B	★ E1ZW 4006-AA
WFC-D	E1BW 4006-DA
WFC-E	E1BW 4006-DA
WFC-V	E3BW 4006-BA
WFC-Z	E3SW 4006-CA
WGX-AM	E3BW 4006-AA
WGX-AM	E3BW 4006-EA
WGX-AN	E3BW 4006-CA
WGX-AR	★ E3SW 4006-AA
WGX-Y	★ E1BW 4006-EA
WGY-N2	★ E3AW 4006-JA
4010	
WFC-R,AK	★ E2ZZ 4010-A
WFC-ZX	E4ZZ 4010-A
4209	
C4OW 4610-B	★ C4OZ 4209-H
C6OW 4610-A	C4OZ 4209-K
C7AW 4610-H	★ EO4Y 4209-A
D1AW 4210-A	★ EO4Y 4209-A
D1AW 4210-A/C7AW 4610-H	★ EO4Y 4209-A
D1OW 4210-A	C4OZ 4209-K
D1OW 4210-A/C6OW 4610-A	C4OZ 4209-K
D1OW 4210-B	★ C4OZ 4209-H
D1OW 4210-B/C4OW 4610-B	★ C4OZ 4209-H
D7AW 4210-CA	D8AZ 4209-B
D7AW 4210-CA/D7AW 4610-CA	D8AZ 4209-B
D7AW 4610-CA	D8AZ 4209-B
D8BW 4210-AA/D8BW 4610-AB	★ D8BZ 4209-A
	r/b E5SZ 4209-A
D9AW 4210-AA/D9AW 4610-FA	★ D9AZ 4209-A
	r/b E3AZ 4209-A
D9AW 4210-BA/D9AW 4610-GA	★ D9AZ 4209-D
	r/b E7TZ 4209-A
D9AW 4210-EA	★ D9AZ 4209-F
D9AW 4210-EA/D9AW 4610-JA	★ D9AZ 4209-F

— LAYOUT CONTINUED —

CONT'D				0			
IDENTIFICATION NO.		SERVICE NO.		IDENTIFICATION NO.		SERVICE NO.	
4209 CONT'D				4621			
D9AW 4610-JA		★	D9AZ 4209-F	M86649		CODW 4621-A	
D9BW 4210-AB		★	D9ZZ 4209-D	4628			
D9BW 4210-AB/D9ZW 4610-CB		★	D9ZZ 4209-D	HM88610		CODW 4628-A	
D9BW 4210-BA			EOAZ 4209-A	M802011		C7AZ 4628-A	
D9BW 4210-BA/D9BW 4610-DB		★	D9BZ 4209-B	4630			
		r/b	EOAZ 4209-A	HM88648		D9BZ 4630-A	
D9BW 4210-BA/E0AW 4610-BA			EOAZ 4209-A	M802048		C7AZ 4630-A	
D9BW 4610-EA		★	D9BZ 4209-C	4784			
D9ZW 4210-BA		★	D9BZ 4209-C	All		C9TZ 4784-A	
D9ZW 4210-BA/D9BW 4610-EA		★	D9BZ 4209-C	All		EOWY 4784-A	
D9ZW 4610-CB		★	D9ZZ 4209-D	4791			
E0AW 4210-AA/E0AW 4610-AA			D9BZ 4209-D	All		D94Y 4791-A	
E0AW 4210-AA/E0AW 4610-AA		★	EOSZ 4209-A	4797			
		r/b	E25Y 4209-A	All		E5RY 4797-D	
E0AW 4610-BA			EOAZ 4209-A	4812			
E25W 4210-AA/E25W 4610-AA			E25Y 4209-A	All		E5RY 4812-A	
E2AW 4210-AA/E2AW 4610-AA		★	E2AZ 4209-A	All		E7RY 4812-A	
		r/b	E3TZ 4209-J	4L817			
E2AW 4210-AA/E3AW 4610-AA		★	E3AZ 4209-B	All rear axles		E6TZ 4L817-A	
		r/b	E2AZ 4209-A	4M817			
E2BW 4210-AA/E2BW 4610-AA		★	D9ZZ 4209-B	All rear axles		E6TZ 4M817-A	
		r/b	E25Y 4209-B	4819			
E2BW 4210-AA/E2BW 4610-AA			E25Y 4209-B	All		DORY 4819-A	
E35W 4210-AA		★	E35Y 4209-A	4826			
		r/b	E5LY 4209-A	All		★ E5RY 4826-A	
E35W 4210-AA/E35W 4610-AA		★	E35Y 4209-A			r/b E7RY 4826-B	
		r/b	E5LY 4209-A	All		E7RY 4826-A	
E35W 4610-AA		★	E35Y 4209-A	4841			
		r/b	E5LY 4209-A	All rear axles		E73Z 4841-A	
E37W 4210-AB/E37W 4610-AA			E4SZ 4209-A	5E212			
E3TW 4210-BA/E3TW 4610-BA			E3AZ 4209-A	77FB 5E211-EB		★ D8RZ 5E212-A	
E3TW 4210-CA/E3TW 4610-CA		★	E3AZ 4209-C	77FB 5E211-FB		★ D8RZ 5E212-B	
		r/b	E3TZ 4209-H	80FB 5E211-GA		EORZ 5E212-A	
E3TW 4210-DA/E3TW 4610-DA		★	E3TZ 4209-C	80FB 5E211-HA		EORZ 5E212-A	
		r/b	E3TZ 4209-J	87GB 5E212-GC		★ E7RY 5E212-A	
E47W 4210-AA/E7SW 4610-AA			E7SZ 4209-A			r/b E8RY 5E212-A	
E5DW 4210-AA/E5DW 4610-AA			E5LY 4209-A	87GB 5E212-GC		E8RY 5E212-A	
E5SW 4210-AA/E5SW 4610-AA			E6LY 4209-B	87GB 5E212-GD		★ E7RY 5E212-A	
E6ZW 4210-AA/E6ZW 4610-AA			E7AZ 4209-A			r/b E8RY 5E212-A	
E7TW 4210-AA/E7TW 4610-AA			E7TZ 4209-A	87GB 5E212-GD		E8RY 5E212-A	
E7TW 4210-BA/E7TW 4610-BA			E7TZ 4209-B	87GB 5E212-HA		E8RY 5E212-A	
E7TW 4210-BA/E7TW 4610-BB			E7TZ 4209-B	89JA 5E212-AA		E9JY 5E212-A	
4221				89JA 5E212-BA		E9JY 5E212-B	
LM102949			C9AZ 4221-A	B303 20600		E8BZ 5E212-A	
LM501349			B7A 4221-A	B304 20600		E8BZ 5E212-B	
LM603049			B7A 4221-B	B376 20600		FOBZ 5E212-A	
4222				B630 20600		E8GY 5E212-A	
LM102910			C9AZ 4222-A	B630 20600		E8GZ 5E212-A	
LM501310			B7A 4222-A	D5AE 5E212-AE		D5AZ 5E212-A	
LM501314			C6TZ 4222-A	D5AE 5E212-AF		D5AZ 5E212-A	
LM603012			D9AZ 4222-A	D5AE 5E212-BE		D5AZ 5E212-B	
4R602				D5AE 5E212-BF		D5AZ 5E212-B	
All rear axles		★	E73Z 4R602-A	D5AE 5E212-CA		D5AZ 5E212-A	
		r/b	E83Z 4R602-A	D5AE 5E212-CB		D5AZ 5E212-A	
All rear axles			E83Z 4R602-A	D5AE 5E212-GB		★ D5AZ 5E212-G	
4K605				D5AE 5E212-KB		★ D5AZ 5E212-G	
All			E73Z 4K605-A	D5DE 5E212-CF		★ D5DZ 5E212-C	
All		★	E73Z 4K605-B	D5DE 5E212-FB		★ D6DZ 5E212-B	
		r/b	E83Z 4K605-B	D5DE 5E212-FC		★ D6DZ 5E212-B	
All			E83Z 4K605-A				
4616							
M86610			CODW 4616-A				

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
5E212 CONT'D	
D5DE 5E212-GA	★ D6DZ 5E212-B
D5DE 5E212-GB	★ D6DZ 5E212-B
D5DE 5E212-JA	★ D5DZ 5E212-C
D5DE 5E212-KA	D5DZ 5E212-F
D5DE 5E212-KB	D5DZ 5E212-F
D5DE 5E212-LA	★ D6DZ 5E212-B
D5DE 5E212-LB	★ D6DZ 5E212-B
D5OE 5E212-AE	★ D5OZ 5E212-B
D5OE 5E212-AF	★ D5OZ 5E212-B
D5OE 5E212-BE	D6OZ 5E212-C
D5OE 5E212-BF	D6OZ 5E212-C
D6AE 5E214-EA	★ D5AZ 5E212-G
D6AE 5E214-HA	★ D5AZ 5E212-G
D6ZE 5E214-BA	★ D6ZZ 5E212-B
D6ZE 5E214-BB	★ D6ZZ 5E212-B
D6ZE 5E214-BD	★ D6ZZ 5E212-B
D6ZE 5E214-CA	★ D6ZZ 5E212-D
D6ZE 5E214-CB	★ D6ZZ 5E212-D
D6ZE 5E214-DA	★ D6ZZ 5E212-E
D6ZE 5E214-DB	★ D6ZZ 5E212-E
D6ZE 5E214-DC	★ D6ZZ 5E212-E
D6ZE 5E214-DE	D6ZZ 5E212-L
D6ZE 5E214-DF	D6ZZ 5E212-L
D6ZE 5E214-EA	D6ZZ 5E212-L
D7OE 5E214-AC	D7OZ 5E212-C
D7OE 5E214-CA	D7OZ 5E212-C
D7AE 5E212-BC	★ D7AZ 5E212-D
D7AE 5E212-GB	★ D7AZ 5E212-D
D7AE 5E212-JB	★ D7AZ 5E212-D
D7AE 5E214-BB	★ D7AZ 5E212-C
D7AE 5E214-BC	★ D7AZ 5E212-C
D7AE 5E214-CC	★ D7AZ 5E212-B
D7AE 5E214-EA	★ D7AZ 5E212-B
D7AE 5E214-FA	★ D7AZ 5E212-C
D7AE 5E214-FB	★ D7AZ 5E212-C
D7AE 5E214-HA	★ D7AZ 5E212-F
D7SE 5E214-BC	★ D7SZ 5E212-C
D7SE 5E214-CC	★ D7SZ 5E212-B
D7SE 5E214-DA	★ D7SZ 5E212-B
D7SE 5E214-EA	★ D7SZ 5E212-C
D8AE 5E212-HA	★ D8AZ 5E212-C
D8BE 5E211-BA	D8BZ 5E212-F
D8BE 5E212-FA	★ D8BZ 5E212-A
D8BE 5E212-JA	★ D8BZ 5E212-D
D8BE 5E212-LA	D8BZ 5E212-F
D8DE 5E212-CA	★ D8OZ 5E212-A
D8EE 5E212-BB	D8FZ 5E212-A
D8EE 5E212-HA	D8FZ 5E212-C
D8OE 5E214-AA	★ D8DZ 5E212-B
D8VE 5E212-BA	★ D8VY 5E212-B
D8VE 5E214-BA	★ D8VY 5E212-B
D9AE 5E212-CA	★ D9AZ 5E212-B
	r/b D9MY 5E212-D
D9AE 5E212-CA	★ D9AZ 5E212-B
	r/b D9MY 5E212-D
D9AE 5E212-GB	★ D9AZ 5E212-D
	r/b D9AZ 5E212-H
D9AE 5E212-GC	★ D9AZ 5E212-G
D9AE 5E212-GC	★ D9AZ 5E212-H

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
5E212 CONT'D	
D9AE 5E212-GC	E9AZ 5E212-H
D9AE 5E212-JC	★ D9AZ 5E212-G
D9AE 5E212-KA	★ D9AZ 5E212-F
D9AE 5E212-KB	★ D9AZ 5E212-F
D9AE 5E212-KC	★ D9AZ 5E212-F
D9AE 5E214-BB	D9MY 5E212-C
D9AE 5E214-EA	★ D9AZ 5E212-H
D9AE 5E214-EB	★ D9AZ 5E212-H
D9AE 5E214-GA	★ D9AZ 5E212-D
	r/b D9AZ 5E212-H
D9AE 5E214-GA	★ D9AZ 5E212-H
D9AE 5E214-HA	★ D9AZ 5E212-E
D9AE 5E214-HB	★ D9AZ 5E212-E
D9AE 5E214-HC	★ D9AZ 5E212-E
D9AE 5E214-HD	★ D9AZ 5E212-E
D9BE 5E212-EA	★ D9BZ 5E212-A
D9BE 5E212-GA	★ D9BZ 5E212-C
	r/b EOBZ 5E212-K
D9BE 5E212-JA	D9BZ 5E212-D
D9BE 5E212-JB	D9BZ 5E212-D
D9ME 5E212-AA	DD9MY 5E212-A
D9ME 5E212-AC	DD9MY 5E212-A
D9ME 5E212-CA	D9MY 5E212-G
D9ME 5E212-CB	D9MY 5E212-G
D9ME 5E212-CC	D9MY 5E212-E
D9ME 5E212-CD	D9MY 5E212-G
D9ME 5E212-DA	★ D9MY 5E212-J
	r/b D9MY 5E212-A
D9ME 5E212-DB	★ D9MY 5E212-J
	r/b D9MY 5E212-A
D9ME 5E214-AA	D9MY 5E212-C
D9ME 5E214-AB	D9MY 5E212-C
D9ME 5E214-AC	D9MY 5E212-C
D9ME 5E214-BA	D9MY 5E212-B
D9ME 5E214-BC	D9MY 5E212-B
D9ME 5E214-CA	D9MY 5E212-E
D9ME 5E214-CB	D9MY 5E212-E
D9ME 5E214-CC	D9MY 5E212-E
D9ME 5E214-CD	D9MY 5E212-E
D9ME 5E214-DB	D9MY 5E212-B
D9OE 5E214-DA	★ D8OZ 5E212-C
D9ZE 5E211-EA	D9ZZ 5E212-B
D9ZE 5E211-FA	D9ZZ 5E212-C
D9ZE 5E211-G1A	D9ZZ 5E212-C
D9ZE 5E211-GB	D9ZZ 5E212-C
D9ZE 5E211-GC	D9ZZ 5E212-C
D9ZE 5E211-GD	D9ZZ 5E212-C
D9ZE 5E211-GE	D9ZZ 5E212-C
D9ZE 5E211-GF	D9ZZ 5E212-C
D9ZE 5E212-B1C	D9ZZ 5E212-A
D9ZE 5E212-BB	D9ZZ 5E212-A
D9ZE 5E212-DA	D9ZZ 5E212-D
E1AE 5E212-DA	★ E1AZ 5E212-P
	r/b E1MY 5E212-L
E1AE 5E212-FA	E1AZ 5E212-D
E1AE 5E212-GA	★ E1AZ 5E212-E
E1AE 5E212-KB	★ E1AZ 5E212-P
	r/b E1MY 5E212-L
E1AE 5E212-KB	E1MY 5E212-L

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
5E212 CONT'D	
E1AE 5E214-DA	★ E1AZ 5E212-R r/b E1MY 5E212-M
E1AE 5E214-EA	E1MY 5E212-G
E1AE 5E214-FA	E1AZ 5E212-H
E1AE 5E214-GA	E1AZ 5E212-J
E1AE 5E214-GB	E1MY 5E212-M
E1AE 5E214-KB	★ E1AZ 5E212-R r/b E1MY 5E212-M
E1AE 5E214-KB	E1MY 5E212-M
E1BE 5E211-DA	E1BZ 5E212-B
E1BE 5E211-DA	E1BZ 5E212-G
E1BE 5E212-AA	E1BZ 5E212-C
E1BE 5E212-BA	E1BZ 5E212-E
E1BE 5E212-CA	E1BZ 5E212-B
E1BE 5E212-DA	E1BZ 5E212-E
E1BE 5E212-DB	E1BZ 5E212-E
E1DE 5E212-BA	E1DZ 5E212-A
E1DE 5E212-CA	★ E1DZ 5E212-C
E1DE 5E212-DA	★ E1DZ 5E212-C
E1DE 5E212-DB	★ E1DZ 5E212-C
E1EE 5E211-DC	★ E1FZ 5E212-D
E1EE 5E212-AF	★ E1FZ 5E212-B
E1EE 5E212-CB	★ E1FZ 5E212-E
E1EE 5E212-DB	★ E1FZ 5E212-C
E1ME 5E212-AA	E1MY 5E212-A
E1ME 5E212-BA	E1MY 5E212-M
E1ME 5E212-CA	★ E1MY 5E212-C r/b E3MY 5E212-C
E1ME 5E212-CA	E3MY 5E212-C
E1ME 5E212-EA	E1MY 5E212-D
E1ME 5E212-FB	E1MY 5E212-J
E1ME 5E212-FB	★ E1MY 5E212-R
E1ME 5E212-GB	E1MY 5E212-L
E1ME 5E214-AA	E1MY 5E212-E
E1ME 5E214-BA	★ E1MY 5E212-F
E1ME 5E214-CA	E1MY 5E212-G
E1ME 5E214-EA	E1MY 5E212-H
E1ME 5E214-GB	E1MY 5E212-M
E1SE 5E212-AA	E1SZ 5E212-H
E1SE 5E212-BA	★ E1SZ 5E212-B
E1SE 5E212-CA	E1SZ 5E212-C
E1SE 5E212-DA	E1SZ 5E212-G
E1SE 5E212-EA	E1SZ 5E212-H
E1SE 5E212-FA	E1SZ 5E212-J
E1SE 5E212-GA	E1SZ 5E212-G
E1VE 5E212-AA	E1VY 5E212-A
E1ZE 5E211-AA	★ E1ZZ 5E212-A
E1ZE 5E211-BA	★ E2ZZ 5E212-B
E1ZE 5E211-CA	★ E1ZZ 5E212-C
E1ZE 5E212-AA	★ E1ZZ 5E212-H
E1ZE 5E212-BA	E1ZZ 5E212-F
E1ZE 5E212-DA	E1ZZ 5E212-D
E1ZE 5E212-EA	E1ZZ 5E212-F
E1ZZ 5E212-A	★ E1ZZ 5E212-A
E2SE 5E212-AA	E2SY 5E212-A
E2SE 5E212-BA	E2SY 5E212-B
E2BE 5E211-AA	E2BZ 5E212-D
E2BE 5E211-CA	E1BZ 5E212-G
E2BE 5E212-AA	★ E2BZ 5E212-A
E2BE 5E212-BA	E2BZ 5E212-B

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
5E212 CONT'D	
E2DC 5E212-JA	E2DZ 5E212-H
E2DC 5E212-KA	E2DZ 5E212-J
E2DC 5E212-LA	E2DC 5E212-K
E2DC 5E212-MA	E3DZ 5E212-B
E2DE 5E212-AA	★ E2DZ 5E212-A
E2DE 5E212-BA	★ E2DZ 5E212-B
E2DE 5E212-CA	★ E2DZ 5E212-C
E2DE 5E212-DA	E2DZ 5E212-D
E2DE 5E212-EA	E2DZ 5E212-H
E2DE 5E212-FA	E2DZ 5E212-F
E2DE 5E212-GA	E2DZ 5E212-G
E2DZ 5E212-BA	★ E2DZ 5E212-B
E2EE 5E212-EA	E2FZ 5E212-A
E2EE 5E212-FA	E2FZ 5E212-B
E2EE 5E212-FB	E2FZ 5E212-B
E2GE 5E212-AA	★ E2GZ 5E212-B
E2GE 5E212-AB	★ E2GZ 5E212-B
E2GE 5E212-AC	★ E2GZ 5E212-B
E2GE 5E212-CA	★ E2GZ 5E212-C
E2GE 5E212-CA	★ E2GZ 5E212-D
E2GE 5E212-DA	★ E2GZ 5E212-D
E2SE 5E211-CA	E2SZ 5E212-L
E2SE 5E211-DA	E1SZ 5E212-E
E2SE 5E211-EA	E1SZ 5E212-E
E2SE 5E212-AA	★ E2SZ 5E212-A
E2SE 5E212-BA	★ E2SZ 5E212-B
E2SE 5E212-CA	★ E2SZ 5E212-C
E2SE 5E212-DA	E2SE 5E212-J
E2SE 5E212-EA	E2SE 5E212-H
E2SE 5E212-FA	E2SE 5E212-E
E2SE 5E212-GA	E2SE 5E212-G
E2SE 5E212-HA	E2SE 5E212-F
E2SE 5E212-JA	E2SE 5E212-D
E2SE 5E212-KA	★ E2SZ 5E212-M
E2ZE 5E211-AA	★ E2ZZ 5E212-B
E2ZE 5E211-AB	★ E2ZZ 5E212-B
E2ZE 5E212-AB	EOBZ 5E212-F
E2ZE 5E212-BA	E2ZZ 5E212-C
E35C 5E212-AA	E35Y 5E212-A
E3AC 5E212-AA	E35Y 5E212-A
E3AC 5E212-AA	★ E3AZ 5E212-A r/b E3MY 5E212-A
E3AC 5E214-AA	★ E3AZ 5E212-B r/b E3MY 5E212-B
E3AC 5E214-AA	E3MY 5E212-B
E3DC 5E211-AA	★ E3DZ 5E212-D
E3DC 5E211-BA	E3DZ 5E212-E
E3DC 5E212-AA	E3DZ 5E212-C
E3DC 5E212-BA	E3DZ 5E212-A
E3DC 5E212-CA	E3DZ 5E212-B
E3DC 5E212-DA	E3DZ 5E212-A
E3DC 5E212-EA	E3DZ 5E212-B
E3DC 5E212-FA	E3DZ 5E212-C
E3DE 5E212-AA	★ E2DZ 5E212-A
E3DX 5E211-AA	★ E3DZ 5E212-F
E3EC 5E212-FA	★ E3FZ 5E212-D
E3EC 5E212-FB	★ E3FZ 5E212-D
E3EC 5E212-FC	★ E3FZ 5E212-D
E3EC 5E212-GA	E3FZ 5E212-N
E3EC 5E212-GB	E3FZ 5E212-N

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
5E212 CONT'D	
E3EC 5E212-HA	E3FZ 5E212-F
E3EC 5E212-HB	E3FZ 5E212-F
E3EC 5E212-JA	E3FZ 5E212-J
E3EC 5E212-KA	E3FZ 5E212-H
E3EC 5E212-LA	E3FZ 5E212-G
E3EC 5E212-LB	E3FZ 5E212-G
E3EC 5E212-MA	E3FZ 5E212-N
E3EC 5E212-MB	E3FZ 5E212-N
E3EC 5E212-NA	E3FZ 5E212-F
E3EC 5E212-NB	E3FZ 5E212-F
E3EC 5E212-RA	E3FZ 5E212-F
E3EC 5E212-RB	E3FZ 5E212-F
E3EC 5E212-RC	E3FZ 5E212-F
E3EC 5E212-RD	E3FZ 5E212-F
E3EC 5E212-SA	E3FZ 5E212-G
E3EC 5E212-SB	E3FZ 5E212-G
E3EC 5E212-SC	E3FZ 5E212-G
E3EC 5E212-TA	★ E3FZ 5E212-M
E3EC 5E212-TB	★ E3FZ 5E212-M
E3EE 5E212-BA	★ F3FZ 5E212-A
E3EE 5E212-BB	★ F3FZ 5E212-A
E3EE 5E212-CA	E3FZ 5E212-N
E3EE 5E212-CB	E3FZ 5E212-N
E3EE 5E212-EA	E3FZ 5E212-F
E3MC 5E212-AA	E3MY 5E212-A
E3MC 5E214-AA	E3MY 5E212-B
E3SC 5E212-CA	★ E3SZ 5E212-B
E3SC 5E212-DA	★ E3SZ 5E212-A
E3SE 5E212-AA	★ E3SZ 5E212-A
E3SE 5E212-BA	★ E3SZ 5E212-B
E3ZC 5E211-AA	★ E3DZ 5E212-D
E3ZC 5E212-HA	E3ZZ 5E212-J
E3ZC 5E212-KA	E3ZZ 5E212-J
E3ZC 5E212-LA	E3ZZ 5E212-L
E3ZC 5E212-MA	E3ZZ 5E212-L
E3ZE 5E212-AA	★ E3ZZ 5E212-A
E3ZE 5E212-BA	E3ZZ 5E212-C
E3ZE 5E212-BA	★ E3ZZ 5E212-D
	r/b E3ZZ 5E212-C
E3ZE 5E212-CA	E3ZZ 5E212-C
E43C 5E212-AA	E43Z 5E212-A
E43C 5E212-BA	E43Z 5E212-A
E43C 5E212-BB	E43Z 5E212-A
E43C 5E212-CA	E43Z 5E212-A
E43C 5E212-DA	E43Z 5E212-C
E43C 5E212-DB	E43Z 5E212-C
E43C 5E212-EA	E43Z 5E212-A
E43C 5E212-EB	E43Z 5E212-A
E43C 5E212-EC	E43Z 5E212-A
E43C 5E212-FA	★ E43Z 5E212-E
E43C 5E212-GA	E43Z 5E212-C
E43C 5E212-GC	E43Z 5E212-C
E43C 5E212-HA	E43Z 5E212-D
E43C 5E212-ZA	E43Z 5E212-F
E4AC 5E212-AA	E4MY 5E212-B
E4AC 5E214-AA	E4MY 5E212-A
E4DC 5E212-DA	★ E6ZZ 5E212-A
	r/b E8ZZ 5E212-A

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
5E212 CONT'D	
E4DC 5E212-EA	★ E4DZ 5E212-C
	r/b E8ZZ 5E212-A
E4DC 5E212-FA	★ E4DZ 5E212-B
	r/b E8ZZ 5E212-B
E4DC 5E212-FA	E8ZZ 5E212-B
E4DC 5E212-GA	E4DZ 5E212-A
E4EC 5E212-AA	E4FZ 5E212-A
E4EC 5E212-BC	E4FZ 5E212-A
E4EC 5E212-CB	E3FZ 5E212-N
E4MC 5E212-AA	E4MY 5E212-B
E4MC 5E214-AA	E4MY 5E212-A
E4SC 5E212-AA	★ E4SZ 5E212-A
E4SC 5E212-BA	★ E4SZ 5E212-B
E4SC 5E212-EA	★ E4SZ 5E212-A
E4SC 5E212-EB	★ E4SZ 5E212-A
E4SC 5E212-FA	★ E4SZ 5E212-B
E4SC 5E212-FB	★ E4SZ 5E212-B
E4ZC 5E212-DA	E4ZZ 5E212-A
E5EC 5E212-AA	E5FZ 5E212-A
E5SC 5E212-CA	E5SZ 5E212-A
E5SC 5E212-DA	E6SZ 5E212-E
E5ZC 5E212-AA	E5ZZ 5E212-A
E5ZC 5E212-BA	E5ZZ 5E212-B
E63C 5E212-AA	E63Z 5E212-A
E6AC 5E214-BA	FOAZ 5E212-B
E6DC 5E212-BA	★ E6DZ 5E212-A
	r/b FODZ 5E212-C
E6EC 5E212-AD	E6FZ 5E212-A
E6EC 5E212-CB	★ E6FZ 5E212-C
	r/b E9FZ 5E212-A
E6LC 5E212-BA	★ E6LY 5E212-A
	r/b E8LY 5E212-A
E6SC 5E212-BA	★ E6SZ 5E212-B
	r/b E8SZ 5E212-C
E6SC 5E212-DA	E6SZ 5E212-E
E6SC 5E212-EA	E6SZ 5E212-E
E73C 5E212-AA	★ E73Z 5E212-B
	r/b FO3Z 5E212-C
E73X 5E212-AB	★ E73Z 5E212-A
	r/b FO3Z 5E212-D
E73X 5E212-AD	★ E73Z 5E212-A
	r/b FO3Z 5E212-D
E73X 5E212-AE	★ E73Z 5E212-A
	r/b FO3Z 5E212-D
E7DC 5E212-DA	★ E7DZ 5E212-D
	r/b E7DZ 5E212-E
E7DC 5E212-EA	E7DZ 5E212-E
E7EC 5E211-AA	★ E7FZ 5E212-A
	r/b E8FZ 5E212-A
E7EC 5E211-AA	★ E8FZ 5E212-A
	r/b FOFZ 5E212-A
E7SC 5E212-CA	★ E7SZ 5E212-C
	r/b E8SZ 5E212-B
E7ZC 5E212-AB	★ E7ZZ 5E212-A
	r/b FOZZ 5E212-A
E8AC 5E212-AA	E8AZ 5E212-A
E8AC 5E212-EA	★ E8AZ 5E212-C
	r/b FOAZ 5E212-A
E8AC 5E214-AA	E8AZ 5E212-B
E8AC 5E214-FA	E8AZ 5E212-D
E8AZ 5E212-EA	★ E8AZ 5E212-C
	r/b FOAZ 5E212-A

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
5E212 CONT'D	
E8DC 5E212-CA	E8DZ 5E212-B
E8EC 5E211-AB	★ E8FZ 5E212-A r/b FOFZ 5E212-A
E8EC 5E211-AB	FOFZ 5E212-A
E8SC 5E212-AA	★ E8SZ 5E212-A r/b E8SZ 5E212-C
E8SC 5E212-BA	E8SZ 5E212-B
E9EC 5E212-AA	E9FZ 5E212-A
E9ZC 5E212-BA	★ E9ZZ 5E212-A r/b FOZZ 5E212-A
E9ZC 5E212-BB	★ E9ZZ 5E212-B r/b FOZZ 5E212-A
EOAE 5E212-AA	EOAZ 5E212-E
EOAE 5E212-AEA	★ EOAY 5E212-A
EOAE 5E212-BA	★ EOAZ 5E212-F
EOAE 5E212-CA	★ EOAZ 5E212-B
EOAE 5E212-EA	★ EOAZ 5E212-G r/b E1MY 5E212-L
EOAE 5E212-FA	★ EOAZ 5E212-H r/b EOMY 5E212-C
EOAE 5E212-GA	★ EOAZ 5E212-S r/b EOAZ 5E212-E
EOAE 5E212-HA	EOAZ 5E212-E
EOAE 5E212-KA	★ EOAY 5E212-A
EOAE 5E212-MA	★ EOAZ 5E212-F
EOAE 5E212-NA	★ EOAZ 5E212-B
EOAE 5E212-RA	★ EOAZ 5E212-M
EOAE 5E212-SA	EOAZ 5E212-P
EOAE 5E212-YA	★ EOAZ 5E212-U
EOAE 5E214-AA	★ EOAZ 5E212-C
EOAE 5E214-ARA	★ EOAY 5E212-B
EOAE 5E214-BA	EOAZ 5E212-D
EOAE 5E214-CA	★ EOAZ 5E212-A
EOAE 5E214-EA	EOAZ 5E212-K
EOAE 5E214-FA	EOMY 5E212-D
EOAE 5E214-GA	★ EOAZ 5E212-C
EOAE 5E214-HA	★ EOAZ 5E212-C
EOAE 5E214-KA	★ EOAY 5E212-B
EOAE 5E214-MA	EOAZ 5E212-D
EOAE 5E214-NA	★ EOAZ 5E212-A
EOAE 5E214-RA	★ EOAZ 5E212-N
EOAE 5E214-SA	EOAZ 5E212-R
EOAE 5E214-YA	EOAZ 5E212-T
EOBE 5E211-AA	★ EOBZ 5E212-C
EOBE 5E211-AB	★ EOBZ 5E212-C
EOBE 5E211-BB	★ EOBZ 5E212-B
EOBE 5E211-EA	★ EOBZ 5E212-D
EOBE 5E211-FA	★ EOBZ 5E212-E
EOBE 5E211-GA	EOBZ 5E212-G
EOBE 5E211-GC	EOBZ 5E212-G
EOBE 5E211-HA	★ EOBZ 5E212-B
EOBE 5E211-JA	★ EOBZ 5E212-C
EOBE 5E211-KA	EOBZ 5E212-P
EOBE 5E211-MA	★ EOBZ 5E212-C
EOBE 5E211-NA	★ EOBZ 5E212-B
EOBE 5E211-PA	★ EOBZ 5E212-U
EOBE 5E211-SA	★ EOBZ 5E212-W
EOBE 5E212-AA	EOBZ 5E212-F
EOBE 5E212-BA	★ EOBZ 5E212-B
EOBE 5E212-CB	★ EOBZ 5E212-A
EOBE 5E212-DA	EOBZ 5E212-J

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
5E212 CONT'D	
EOBE 5E212-HA	EOBZ 5E212-L
EOBE 5E212-JA	★ EOBZ 5E212-M r/b E1BZ 5E212-E
EOBE 5E212-LA	★ EOBZ 5E212-T r/b E1BZ 5E212-E
EOBE 5E212-UA	★ EOBZ 5E212-S
EODE 5E211-AA	★ EODZ 5E212-A r/b EODZ 5E212-D
EODE 5E211-AB	★ EODZ 5E212-A r/b EODZ 5E212-D
EODE 5E211-CA	★ EODZ 5E212-B
EODE 5E211-EA	★ EODZ 5E212-D
EODE 5E211-FA	EODZ 5E212-E
EODE 5E211-GA	EODZ 5E212-E
EODE 5E211-HA	★ EODZ 5E212-A r/b EODZ 5E212-D
EODE 5E212-CA	★ EODZ 5E212-C
EODE 5E212-KA	EODZ 5E212-F
EOEE 5E211-AA	EOFZ 5E212-A
EOEE 5E211-AB	EOFZ 5E212-A
EOEE 5E211-AC	EOFZ 5E212-A
EOEE 5E211-AD	EOFZ 5E212-A
EOEE 5E211-AE	EOFZ 5E212-A
EOEE 5E211-CB	EOFZ 5E212-A
EOEE 5E211-CE	EOFZ 5E212-A
EOEE 5E212-AA	★ EOFZ 5E212-C
EOEE 5E212-BA	★ EOFZ 5E212-B
EOEE 5E212-CA	EOFZ 5E212-E
EOEE 5E212-DB	★ EOFZ 5E212-D
EOEE 5E212-EA	★ EOFZ 5E212-H
EOEE 5E212-HA	★ EOFZ 5E212-F
EOME 5E212-AA	★ EOMY 5E212-A r/b E1MY 5E212-L
EOME 5E212-BA	EOMY 5E212-C
EOME 5E214-AA	★ EOMY 5E212-B
EOME 5E214-BA	EOMY 5E212-D
EOSE 5E211-AA	EOSZ 5E212-E
EOSE 5E211-BA	EOSZ 5E212-F
EOSE 5E212-AA	★ EOSZ 5E212-C
EOSE 5E212-BA	EOSZ 5E212-B
EOSE 5E212-CA	EOSZ 5E212-A
EOSE 5E212-CB	EOSZ 5E212-A
EOSE 5E212-DA	★ EOSZ 5E212-C
EOSE 5E212-EA	EOSZ 5E212-B
EOSE 5E212-HA	EOSZ 5E212-D
EOSE 5E212-KA	★ EOSZ 5E212-G
EOSE 5E212-LA	★ EOSZ 5E212-H
EOVE 5E212-AA	★ EOZY 5E212-A
EOVE 5E214-AA	★ EOZY 5E212-B
EOZE 5E211-AA	★ EOZZ 5E212-A
EOZE 5E211-BA	★ EOZZ 5E212-A
EOZE 5E211-CA	★ EOZZ 5E212-C
EOZE 5E211-CB	★ EOZZ 5E212-C
EOZE 5E211-DA	★ EOZZ 5E212-A
EOZE 5E211-EA	★ EOZZ 5E212-A
EOZE 5E211-GA	EOZZ 5E212-G
EOZE 5E211-GC	EOZZ 5E212-G
EOZE 5E211-HA	EOZZ 5E212-H
EOZE 5E211-JA	EOZZ 5E212-J
EOZE 5E212-AA	★ EOZZ 5E212-D
F201 20600-A	E92Z 5E212-B

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
5E212 CONT'D	
F202 20600-A	E92Z 5E212-C
F222 20600-A	E92Z 5E212-A
F201 20600-A	E92Z 5E212-B
FO3C 5E212-GA	FO3Z 5E212-C
FOAC 5E212-AA	FOAZ 5E212-A
FOAC 5E214-AA	FOAZ 5E212-B
FODC 5E212-BA	FODZ 5E212-B
FOZC 5E212-AA	FOZZ 5E212-A
	E3DZ 5E212-B
	EOZZ 5E212-F
5230	
86GB 5230-CC	E7RY 5230-A
88BB 5K254-DA	E5RY 5230-B
89JA 5K214-BA	★ E9JY 5230-B r/b FOJY 5230-B
B303 40100	E9BZ 5230-B
D9AC 5230-AC	★ D9AZ 5230-A
D9AC 5230-AE	★ D9AZ 5230-A
D9AC 5230-BE	★ D9AZ 5230-B
D9AC 5230-BF	★ D9AZ 5230-B
D9AC 5230-CD	★ D9AZ 5230-C
D9AC 5230-DC	D9AZ 5230-D
D9AC 5230-DD	D9AZ 5230-D
D9AC 5230-ED	EOAZ 5230-A
D9AC 5230-EE	EOAZ 5230-A
D9BC 5230-AC	★ D9BZ 5230-A
D9BC 5230-AD	★ D9BZ 5230-A
D9BC 5230-AF	★ D9BZ 5230-A
D9BC 5230-AG	★ D9BZ 5230-A
D9BC 5230-BD	★ D9BZ 5230-B
D9BC 5230-BF	★ D9BZ 5230-B
D9BC 5230-BG	★ D9BZ 5230-B
D9BC 5230-CA	★ D9BZ 5230-C
D9BC 5230-DA	D9BZ 5230-D
D9BC 5230-ED	★ D9BZ 5230-E
D9BC 5230-EF	★ D9BZ 5230-E
D9BC 5230-EG	★ D9BZ 5230-E
D9BC 5230-FA	★ D9BZ 5230-F
D9BC 5230-GA	★ D9BZ 5230-G
D9BC 5230-HA	E9BZ 5230-H
D9BC 5230-JC	★ D9BZ 5230-J
D9BC 5230-JE	★ D9BZ 5230-J
D9BC 5230-LC	★ D9BZ 5230-K
D9BC 5230-LE	★ D9BZ 5230-K
D9BC 5230-LF	★ D9BZ 5230-K
D9BC 5230-MC	★ D9BZ 5230-L
D9BC 5230-ME	★ D9BZ 5230-L
D9BC 5230-RB	★ D9BZ 5230-M
D9BC 5230-RD	★ D9BZ 5230-M
D9BC 5230-RE	★ D9BZ 5230-M
D9BC 5230-SB	★ D9BZ 5230-N
D9BC 5230-SD	★ D9BZ 5230-N
D9BC 5230-SE	★ D9BZ 5230-N
D9BC 5230-TB	★ D9BZ 5230-R
D9BC 5230-TC	★ D9BZ 5230-R
D9BC 5230-TD	★ D9BZ 5230-R
D9EC 5230-AA	D7FZ 5230-B
D9EC 5230-BB	★ D9FZ 5230-C
D9EC 5230-EB	★ D9FZ 5230-A

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
5230 CONT'D	
D9EC 5230-FA	★ D9FZ 5230-G
D9EC 5230-GA	★ EOFZ 5230-D
D9EC 5230-GC	★ EOFZ 5230-D
D9EC 5230-HA	★ D9FZ 5230-E
D9EC 5230-HC	★ D9FZ 5230-E
D9OC 5230-AD	★ D9OZ 5230-A
D9OC 5230-BE	★ D9OZ 5230-B
D9OC 5230-CC	★ D9OZ 5230-C
D9OC 5230-DD	★ D9OZ 5230-D
D9ZC 5230-AF	★ D9ZZ 5230-A
D9ZC 5230-AJ	★ D9ZZ 5230-A
D9ZC 5230-BA	D9ZZ 5230-B
D9ZC 5230-CF	★ D9ZZ 5230-C
D9ZC 5230-CJ	★ D9ZZ 5230-C
D9ZC 5230-DC	★ D9ZZ 5230-N
D9ZC 5230-GA	★ D9ZZ 5230-S
D9ZC 5230-GD	★ D9ZZ 5230-S
D9ZC 5230-HA	D9ZZ 5230-T
D9ZC 5230-HD	D9ZZ 5230-T
D9ZC 5230-JA	★ D9ZZ 5230-N
D9ZC 5230-JC	★ D9ZZ 5230-N
D9ZC 5230-JD	★ D9ZZ 5230-N
D9ZC 5C257-HA	★ D9ZZ 5230-M
D9ZC 5C257-HC	★ D9ZZ 5230-M
D9ZC 5C257-HD	★ D9ZZ 5230-M
D9ZC 5C257-JA	★ D9ZZ 5230-N
D9ZC 5C257-JC	★ D9ZZ 5230-N
D9ZC 5C257-JD	★ D9ZZ 5230-N
D9ZC 5C257-LA	★ D9ZZ 5230-R
D9ZC 5C257-LC	★ D9ZZ 5230-R
D9ZC 5C257-LD	★ D9ZZ 5230-R
E04C 5C257-AA	★ E04Y 5230-A
E1BC 5230-BB	★ E1BZ 5230-B
E1BC 5230-CA	★ E1BZ 5230-C r/b E2DZ 5230-C
E1BC 5230-CA	★ E2DZ 5230-C
E1BC 5230-DA	★ E1BZ 5230-D
E1BC 5230-EA	★ E1BZ 5230-E
E1BC 5230-FA	★ E1BZ 5230-F
E1BC 5230-GA	★ E1BZ 5230-G r/b E2DZ 5230-D
E1BC 5230-GA	★ E2DZ 5230-D
E1BC 5230-HA	★ E1BZ 5230-H
E1BC 5230-JA	★ E1BZ 5230-J r/b E2BZ 5230-B
E1BC 5230-JA	E2BZ 5230-B
E1BZ 5230-D	★ E1BZ 5230-D
E1DC 5230-AB	★ E1DZ 5230-A
E1DC 5230-BA	★ E1DZ 5230-B
E1DC 5230-BA	★ E2DZ 5230-B
E1DC 5230-CA	★ E1DZ 5230-C
E1EC 5230-AF	★ E1FZ 5230-A
E1EC 5230-DE	E1FZ 5230-E
E1EC 5230-GA	E1FZ 5230-G
E1SC 5230-BB	★ E1SZ 5230-B
E1SC 5230-CB	E1SZ 5230-C
E1SC 5230-DA	E1SZ 5230-D
E1SC 5230-EA	★ E1SZ 5230-E
E1ZC 5230-BA	E1ZZ 5230-E

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
5230 CONT'D	
E1ZC 5230-CA	E1ZZ 5230-C
E1ZC 5230-DA	★ E1ZZ 5230-D
E1ZC 5230-EA	★ E1ZZ 5230-G
E1ZC 5C257-BA	★ E1ZZ 5230-F
E1ZC 5C257-CA	★ E1ZZ 5230-A
E2AC 5230-AA	★ E2AZ 5230-A
E2AC 5230-AA	★ E2AZ 5230-D
	r/b E9AZ 5230-B
E2AC 5230-BA	★ E2AZ 5230-B
E2AC 5230-BA	★ E2AZ 5230-E
E2AC 5230-CA	E2AZ 5230-C
E2BC 5230-AA	★ E2BZ 5230-A
E2BC 5230-BA	E2BZ 5230-B
E2DC 5230-AA	★ E2DZ 5230-A
E2DC 5230-AB	★ E2DZ 5230-A
E2DC 5230-BA	★ E2DZ 5230-E
E2DC 5230-CA	★ E2DZ 5230-B
E2DC 5230-DA	★ E2DZ 5230-C
E2DC 5230-EA	★ E2DZ 5230-D
E2DC 5230-FA	★ E2DZ 5230-F
E2DC 5230-GA	★ E2DZ 5230-G
E2EC 5230-AA	E2FZ 5230-A
E2EC 5230-AB	E2FZ 5230-A
E2EC 5230-AD	E2FZ 5230-A
E2GC 5230-AA	E2GZ 5230-F
E2GC 5230-AC	E2GZ 5230-F
E2GC 5230-AD	E2GZ 5230-F
E2GC 5230-BA	E2GZ 5230-F
E2GC 5230-BB	E2GZ 5230-F
E2GC 5230-BC	E2GZ 5230-F
E2GC 5230-BD	E2GZ 5230-F
E2GC 5230-BE	E2GZ 5230-F
E2GC 5230-BG	E2GZ 5230-F
E2GC 5230-BL	E2GZ 5230-F
E2GC 5230-CA	E2GZ 5230-C
E2GC 5230-CB	E2GZ 5230-C
E2GC 5230-CC	E2GZ 5230-C
E2GC 5230-CD	E2GZ 5230-C
E2GC 5230-CF	E2GZ 5230-C
E2GC 5230-CG	E2GZ 5230-C
E2GC 5230-CK	E2GZ 5230-C
E2GC 5230-DB	E2GZ 5230-D
E2GC 5230-DC	E2GZ 5230-D
E2GC 5230-EB	E2GZ 5230-E
E2LC 5C258-AA	★ E2LY 5230-C
	r/b E5VY 5230-B
E2LC 5C258-AA	E5VY 5230-B
E2SC 5230-AA	★ E2SZ 5230-A
E2SC 5230-AB	★ E2SZ 5230-A
E2SC 5230-BA	★ E2SZ 5230-C
E2SC 5230-CA	★ E2SZ 5230-B
E2SC 5230-CB	★ E2SZ 5230-B
E2SC 5230-DA	★ E2SZ 5230-C
E2SC 5230-DB	★ E2SZ 5230-C
E2ZC 5230-AA	★ E2ZZ 5230-A
E2ZC 5230-AC	★ E2ZZ 5230-A
E2ZC 5230-BA	★ E2ZZ 5230-B
E2ZC 5230-BB	★ E2ZZ 5230-B
E2ZC 5230-CA	★ E2ZZ 5230-C
E2ZC 5230-CB	★ E2ZZ 5230-C

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
5230 CONT'D	
E2ZC 5230-DA	★ E2ZZ 5230-D
E2ZC 5230-DC	★ E2ZZ 5230-D
E2ZC 5230-EA	E2ZZ 5230-E
E2ZC 5230-EB	E2ZZ 5230-E
E2ZC 5230-FA	★ E2ZZ 5230-F
E2ZC 5230-HA	E2ZZ 5230-H
E2ZC 5E209-BA	★ E2ZZ 5230-J
E35C 5230-AB	E35Y 5230-A
E35C 5230-AC	E35Y 5230-A
E35C 5230-AD	E35Y 5230-A
E35C 5230-BB	★ E35Y 5230-B
E35C 5230-BC	★ E35Y 5230-B
E35C 5230-BD	★ E35Y 5230-B
E35C 5230-CB	E35Y 5230-C
E35C 5230-DB	E35Y 5230-D
E35C 5230-EA	★ E35Y 5230-E
E3AC 5230-AA	★ E3AZ 5230-A
	r/b E5AZ 5230-A
E3AC 5232-AA	★ E3AZ 5230-B
	r/b E6AZ 5230-B
E3AC 5232-AA	E6AZ 5230-B
E3AC 5232-BA	★ E5AZ 5230-E
E3BC 5230-AA	★ E3BZ 5230-A
E3BC 5230-BA	★ E3BZ 5230-B
E3BC 5230-CA	★ E3BZ 5230-C
E3BC 5230-DA	★ E3BZ 5230-D
E3BC 5230-EA	E3BZ 5230-E
E3BC 5230-FA	E3BZ 5230-F
E3BC 5230-GA	★ E3BZ 5230-G
E3DC 5230-AB	★ E3BZ 5230-A
E3DC 5230-AB	★ E3DZ 5230-A
E3DC 5230-BB	★ E3DZ 5230-B
E3DC 5230-CB	★ E3DZ 5230-C
E3DC 5230-DB	★ E3DZ 5230-D
E3DC 5230-EB	★ E3DZ 5230-E
E3DC 5230-EC	★ E3DZ 5230-E
E3DC 5230-FB	★ E3DZ 5230-F
E3DC 5230-GB	★ E3DZ 5230-G
E3DC 5230-HB	★ E3DZ 5230-H
	r/b E4DZ 5230-L
E3DC 5230-HB	E4DZ 5230-L
E3DC 5230-JB	E3DZ 5230-J
E3DC 5230-KB	★ E3DZ 5230-K
E3DC 5230-LB	★ E3DZ 5230-L
E3DC 5230-MB	★ E3DZ 5230-M
E3DX 5230-AB	E3DZ 5230-N
E3EC 5230-AB	E3FZ 5230-A
E3EC 5230-AD	E3FZ 5230-A
E3EC 5230-AE	E3FZ 5230-A
E3EC 5230-AF	E3FZ 5230-A
E3EC 5230-AH	E3FZ 5230-A
E3EC 5230-AK	E3FZ 5230-A
E3EC 5230-BA	★ E3FZ 5230-B
E3EC 5230-BB	★ E3FZ 5230-B
E3EC 5230-BC	★ E3FZ 5230-B
E3EC 5230-BD	★ E3FZ 5230-B
E3EC 5230-BE	★ E3FZ 5230-B
E3EC 5230-BF	★ E3FZ 5230-B
E3EC 5230-BH	★ E3FZ 5230-B
E3EC 5230-BJ	★ E3FZ 5230-B

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
5230 CONT'D	
E3EC 5230-CB	★ E3FZ 5230-C
E3EC 5230-CC	★ E3FZ 5230-C
E3EC 5230-CD	★ E3FZ 5230-C
E3EC 5230-CE	★ E3FZ 5230-C
E3EC 5230-CF	★ E3FZ 5230-C
E3EC 5230-CG	★ E3FZ 5230-C
E3EC 5230-DB	E5FZ 5230-D
E3EC 5230-DC	E5FZ 5230-D
E3EC 5230-DD	E5FZ 5230-D
E3EC 5230-DE	E5FZ 5230-D
E3EC 5230-DG	E5FZ 5230-D
E3EC 5230-DH	E5FZ 5230-D
E3EC 5230-EA	E5FZ 5230-E
E3EC 5230-EB	E5FZ 5230-E
E3EC 5230-EC	E5FZ 5230-E
E3EC 5230-FB	E3FZ 5230-A
E3EC 5230-GB	★ E3FZ 5230-B
E3EC 5230-HB	★ E3FZ 5230-C
E3EC 5230-JB	E5FZ 5230-D
E3EC 5230-KB	E5FZ 5230-E
E3GC 5230-AB	★ E3GZ 5230-A
E3GC 5230-AC	★ E3GZ 5230-A
E3GC 5230-AD	★ E3GZ 5230-A
E3GC 5230-AE	★ E3GZ 5230-A
E3GC 5230-AG	★ E3GZ 5230-A
E3GC 5230-AH	★ E3GZ 5230-A
E3GC 5230-BB	★ E3GZ 5230-B
E3GC 5230-BC	★ E3GZ 5230-B
E3GC 5230-BD	★ E3GZ 5230-B
E3GC 5230-BE	★ E3GZ 5230-B
E3GC 5230-CB	★ E3GZ 5230-C
E3GC 5230-CC	★ E3GZ 5230-C
E3GC 5230-CD	★ E3GZ 5230-C
E3GC 5230-CE	★ E3GZ 5230-C
E3GC 5230-CF	★ E3GZ 5230-C
E3GC 5230-CG	★ E3GZ 5230-C
E3GC 5230-DB	★ E3GZ 5230-D
E3GC 5230-DC	★ E3GZ 5230-D
E3GC 5230-DD	★ E3GZ 5230-D
E3GC 5230-EA	E3GZ 5230-E
E3GC 5230-EB	E3GZ 5230-E
E3GC 5230-EC	E3GZ 5230-E
E3GC 5230-ED	E3GZ 5230-E
E3GC 5230-EF	E3GZ 5230-E
E3GC 5230-EG	E3GZ 5230-E
E3GC 5230-FA	★ E3GZ 5230-F
E3GC 5230-FB	★ E3GZ 5230-F
E3GC 5230-FC	★ E3GZ 5230-F
E3GC 5230-FD	★ E3GZ 5230-F
E3GC 5230-GA	E3GZ 5230-G
E3GC 5230-GB	E3GZ 5230-G
E3GC 5230-GC	E3GZ 5230-G
E3GC 5230-HB	★ E3GZ 5230-A
E3GC 5230-JB	E3GZ 5230-E
E3GC 5230-KB	E3GZ 5230-G
E3SC 5230-AA	★ E3SZ 5230-C
E3SC 5230-BB	★ E3SZ 5230-D r/b E4SZ 5230-C
E3SC 5230-CB	★ E3SZ 5230-B

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
5230 CONT'D	
E3SC 5230-CC	★ E3SZ 5230-B
E3SC 5230-DA	★ E3SZ 5230-D r/b E4SZ 5230-C
E3SC 5230-EA	★ E3SZ 5230-B
E3SC 5230-EB	★ E3SZ 5230-B
E3SC 5230-EC	★ E3SZ 5230-B
E3SC 5230-FA	★ E3SZ 5230-D r/b E4SZ 5230-C
E3SC 5230-FA	E4SZ 5230-C
E3SC 5230-FB	★ E3SZ 5230-D r/b E4SZ 5230-C
E3SC 5230-FB	E4SZ 5230-C
E3SC 5230-FC	★ E3SZ 5230-D r/b E4SZ 5230-C
E3SC 5230-FC	E4SZ 5230-C
E3SC 5230-GA	★ E4SZ 5230-B
E3SC 5230-HB	★ E4SZ 5230-B
E3SC 5230-HC	★ E4SZ 5230-B
E3SC 5230-KA	E3SZ 5230-G
E3ZC 5230-AB	★ E3ZZ 5230-B
E3ZC 5230-AC	★ E3ZZ 5230-B
E3ZC 5230-AD	★ E3ZZ 5230-B
E3ZC 5230-AE	★ E3ZZ 5230-B
E3ZC 5230-BB	E3ZZ 5230-C
E3ZC 5230-BC	E3ZZ 5230-C
E3ZC 5230-BD	E3ZZ 5230-C
E3ZC 5230-BE	E3ZZ 5230-C
E3ZC 5230-BF	E3ZZ 5230-C
E3ZC 5230-CB	E3ZZ 5230-D
E3ZC 5230-CC	E3ZZ 5230-D
E3ZC 5230-CD	E3ZZ 5230-D
E3ZC 5230-CE	E3ZZ 5230-D
E3ZC 5230-DB	★ E3ZZ 5230-A
E3ZC 5230-DC	★ E3ZZ 5230-A
E3ZC 5E209-AB	★ E3ZZ 5230-A
E3ZC 5E209-AC	★ E3ZZ 5230-A
E3ZC 5E209-CA	E3ZZ 5230-F
E3ZC 5E209-CB	E3ZZ 5230-F
E3ZC 5E209-CC	E3ZZ 5230-F
E3ZC 5E209-CD	E3ZZ 5230-F
E3ZC 5E209-CE	E3ZZ 5230-G
E3ZC 5E209-DA	★ E3ZZ 5230-A
E3ZC 5E209-EB	E3ZZ 5230-H
E3ZC 5E209-FA	★ E3ZZ 5230-A
E3ZC 5E209-FB	★ E3ZZ 5230-A
E43C 5230-AD	E53Z 5230-A
E43C 5230-AH	E53Z 5230-A
E43C 5230-CD	★ E43Z 5230-C
E43C 5230-DA	★ E43Z 5230-D r/b E3GZ 5A231-B
E43C 5230-EA	★ E43Z 5230-C
E43C 5230-GA	★ E43Z 5230-D r/b E3GZ 5A231-B
E43C 5230-GB	★ E43Z 5230-D r/b E3GZ 5A231-B
E43C 5230-GC	★ E43Z 5230-D r/b E3GZ 5A231-B
E45C 5230-AB	★ E45Y 5230-A
E45C 5232-AB	★ E45Y 5230-B
E45C 5232-BA	★ E45Y 5230-C

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
5230 CONT'D	
E4DC 5230-EA	E4DZ 5230-B
E4DC 5230-FA	E4DZ 5230-C
E4DC 5230-GA	E4DZ 5230-D
E4DC 5230-HA	E4DZ 5230-E
E4DC 5230-JA	E4DZ 5230-A
E4EC 5230-BA	★ E4FZ 5230-A r/b E5FZ 5230-A
E4EC 5230-BA	E5FZ 5230-A
E4EC 5230-BB	★ E4FZ 5230-A r/b E5FZ 5230-A
E4EC 5230-BB	E5FZ 5230-A
E4EC 5230-CB	★ E4FZ 5230-B r/b E3GZ 5A231-B
E4EC 5230-CB	★ E5FZ 5230-B
E4EC 5230-DB	★ E4FZ 5230-C r/b E5FZ 5230-C r/b E3GZ 5A231-B
E4EC 5230-DB	E5FZ 5230-C
E4EC 5230-EB	★ E4FZ 5230-D
E4EC 5230-FB	★ E4FZ 5230-E
E4EX 5230-AA	★ E4FZ 5230-F r/b E5FZ 5230-F
E4EX 5230-AA	E5FZ 5230-F
E4GC 5230-AB	★ E4GZ 5230-B
E4GC 5230-BB	E4GZ 5230-C
E4GC 5230-CB	★ E4GZ 5230-D
E4GX 5230-AA	★ E5GZ 5230-B
E4SC 5230-AB	E4SZ 5230-D
E4SC 5230-BA	E4SZ 5230-D
E4SC 5230-CA	E4SZ 5230-C
E4SC 5230-DA	E4SZ 5230-D
E4SC 5230-EA	★ E4SZ 5230-B
E4ZC 5230-BA	E4ZZ 5230-C
E4ZC 5230-CA	★ E4ZZ 5230-B
E4ZC 5230-DA	E4ZZ 5230-E
E4ZC 5230-EE	E4ZZ 5230-G
E4ZC 5230-GA	★ E5ZZ 5230-B
E4ZC 5E209-AB	★ E4ZZ 5230-A
E4ZX 5E209-AA	E4ZZ 5230-F
E53C 5230-AA	E53Z 5230-A
E53C 5230-BA	★ E53Z 5230-B
E5AC 5230-AA	E5AZ 5230-A
E5AC 5230-BA	★ E5AZ 5230-B r/b E9AZ 5230-A r/b E8VY 5260-A
E5AC 5230-CA	E5AZ 5230-C
E5AC 5230-CA	FOAZ 5230-E
E5AC 5230-DA	★ E5AZ 5230-B r/b E9AZ 5230-A r/b E8VY 5260-A
E5AC 5232-AA	★ E5AZ 5230-F r/b E6AZ 5230-B
E5AC 5232-AA	E6AZ 5230-B
E5AC 5232-BA	★ E5AZ 5230-E
E5EC 5230-AA	E5FZ 5230-A
E5EC 5230-BA	★ E5FZ 5230-B
E5EC 5230-CA	E5FZ 5230-C
E5EC 5230-DA	E5FZ 5230-D
E5EC 5230-EA	E5FZ 5230-E
E5EC 5230-FA	E5FZ 5230-F
E5GC 5230-AA	E5GZ 5230-A

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
5230 CONT'D	
E5GC 5230-BA	★ E5GZ 5230-B
E5LC 5230-AA	E5LY 5230-A
E5LC 5232-AA	★ E5LY 5230-B
E5RD 5K254-AC	E5RY 5230-B
E5SC 5230-BB	E5SZ 5230-A
E5VC 5C257-AA	E5VY 5230-A
E5VC 5C258-AA	E5VY 5230-B
E5ZC 5E209-BA	★ E5ZZ 5230-C
E63C 5230-DA	E63Z 5230-A
E64C 5232-AC	★ E64Y 5230-A
E64C 5232-BD	E64Y 5230-B
E6DC 5232-AA	E6DZ 5230-A
E6DC 5232-BA	E6DZ 5230-B
E6EC 5230-GA	E7FZ 5230-A
E6LC 5230-AA	★ E6LY 5230-A r/b E8LY 5230-A
E6LC 5230-AA	E8LY 5230-A
E6LC 5232-AA	E6LY 5230-B
E6LC 5232-CA	E6LC 5230-C
E6VC 5C257-AA	★ E6VY 5230-A
E6VC 5C258-AA	★ E6VY 5230-B
E6ZC 5230-AA	★ E6ZZ 5230-B
E6ZC 5230-GA	E6ZZ 5230-A
E6ZC 5232-EA	E6ZZ 5230-D
E6ZC 5232-FA	E6ZZ 5230-E
E6ZC 5232-GA	★ E6ZZ 5230-F
E6ZC 5232-HA	E6ZZ 5230-C
E73X 5230-AC	E63Z 5230-D
E74C 5232-AB	★ E74Y 5230-A
E74C 5232-BA	E74Y 5230-B
E74C 5232-CA	E84Y 5230-C
E7AC 5230-FA	E8ZZ 5230-A
E7DC 5232-BA	E7DZ 5230-B
E7DC 5232-CB	E7DZ 5230-C
E7DC 5232-DA	E7DZ 5230-D
E7DC 5232-FA	E8DZ 5230-E
E7DC 5232-GA	E8DZ 5230-F
E7DC 5232-HA	★ E8DZ 5230-G r/b E8DZ 5230-J
E7DC 5232-HA	E8DZ 5230-J
E7DC 5232-JA	E8DZ 5230-H
E7EC 5230-AA	E7FZ 5230-A
E7SC 5230-AA	E7FZ 5230-A
E7SC 5230-AA	E7SZ 5230-A
E7SC 5230-AB	E7FZ 5230-A
E7SC 5230-AB	E7SZ 5230-A
E7SC 5232-AA	E7SZ 5230-B
E7SC 5232-BA	E7SZ 5230-C
E7SC 5232-BB	E7SZ 5230-C
E7SC 5232-CA	★ E7SZ 5230-D
E7SC 5232-DA	E7SZ 5230-E
E7SC 5232-EA	E7SZ 5230-F
E7SC 5232-EB	E7SZ 5230-F
E7ZC 5230-AA	★ E7ZZ 5230-A
E7ZC 5230-FA	E8ZZ 5230-A
E7ZC 5230-GA	E8ZZ 5230-B
E7ZC 5232-AB	★ E1ZZ 5230-A
E7ZC 5232-AB	E7ZZ 5230-C
E7ZC 5232-BA	E7ZZ 5230-B

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
5230 CONT'D	
E7ZC 5232-FA	★ E8ZZ 5230-C r/b E8ZZ 5230-F
E7ZC 5232-FA	E8ZZ 5230-F
E7ZC 5232-GA	E8ZZ 5230-D
E7ZC 5232-HA	★ E1ZZ 5230-A
E7ZC 5232-HA	E7ZZ 5230-C
E83C 5230-AA	E63Z 5230-D
E83C 5230-AB	E63Z 5230-D
E83C 5230-AC	E63Z 5230-D
E83C 5C258-AA	★ E83Z 5230-A r/b F23Z 5230-D
E83C 5C258-AB	★ E83Z 5230-A r/b F23Z 5230-D
E83C 5C258-AC	★ E83Z 5230-A r/b F23Z 5230-D
E83C 5C258-AD	★ E83Z 5230-A r/b F23Z 5230-D
E84C 5C258-BA	E84Y 5230-B
E8CZ 52300-AA	E8ZZ 5230-E
E8DC 5C258-CA	E8DZ 5230-C
E8DC 5C258-DA	E8DZ 5230-D
E8EC 5230-AA	E7FZ 5230-A
E8EC 5C258-BA	E8FZ 5230-A
E8LC 5230-AA	E8LY 5230-A
E8LC 5232-AA	E8LY 5230-B
E8OC 5C258-AF	E8OZ 5230-A
E8SC 5230-BA	E8SZ 5230-A
E8SC 5232-BA	E8SY 5230-B
E8ZC 52300-AA	E8ZZ 5230-E
E8ZC 5E212-A	E8ZZ 5230-E
E94C 5232-AB	E94Y 5230-A
E9DC 5232-AB	E9DZ 5230-A
E9DC 5232-BB	E9DZ 5230-B
E9DC 5232-CA	E8DZ 5230-J
E9DC 5G211-BB	E9DZ 5230-C
E9OC 5C258-AF	E9OY 5230-A
E9OC 5C258-AG	E9OY 5230-A
E9SC 5232-CF	E9SZ 5230-B
E9SC 5G211-DD	E9SZ 5230-A
E9ZC 5230-CA	E8ZZ 5230-F
EO4C 5C257-AA	★ EO4Y 5230-A
EO4C 5C257-BA	★ EO4Y 5230-B
EOAC 5230-EA	EOAZ 5230-A
EOAC 5230-FA	EOAZ 5230-B
EOAC 5230-GA	EOAZ 5230-C
EOAC 5C257-BA	★ EOZZ 5230-D
EOAC 5C257-BB	★ EOZZ 5230-D
EOAC 5C257-BC	★ EOZZ 5230-D
EOAC 5E209-AA	★ EOAZ 5230-D
EOBC 5230-CA	★ E1DZ 5230-A
EOBC 5230-CB	★ E1DZ 5230-A
EOBC 5230-CC	★ E1DZ 5230-A
EOBC 5230-CD	★ E1DZ 5230-A
EOBC 5230-CE	★ E1DZ 5230-A
EOBC 5230-CF	★ E1DZ 5230-A
EOBC 5230-GE	★ E1BZ 5230-C r/b E2DZ 5230-C
EOBC 5230-GF	★ E1BZ 5230-C r/b E2DZ 5230-C

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
5230 CONT'D	
EOBC 5230-HE	★ E1BZ 5230-G r/b E2DZ 5230-D
EOBC 5230-JC	★ E1BZ 5230-D
EOBC 5230-JD	★ E1BZ 5230-D
EOBC 5230-JE	★ E1BZ 5230-D
EOBC 5230-KC	EOBZ 5230-M
EOBC 5C257-AA	★ EOBZ 5230-W
EOBC 5C257-AD	★ EOBZ 5230-W
EOBC 5C257-BA	★ EOBZ 5230-B
EODC 5C257-AA	★ EODZ 5230-D
EODC 5C257-BA	★ EODZ 5230-E
EOEC 5230-AA	★ EOFZ 5230-A
EOEC 5230-AB	★ EOFZ 5230-A
EOEC 5230-BA	★ EOFZ 5230-C
EOEC 5230-BB	★ EOFZ 5230-C
EOEC 5230-DA	★ EOFZ 5230-B
EOEC 5230-DB	★ EOFZ 5230-B
EOLC 5C257-AA	★ E4VY 5230-A r/b E5VY 5230-A
EOLC 5C257-AB	★ E4VY 5230-A r/b E5VY 5230-A
EOLC 5C257-BA	★ EOLY 5230-A r/b E4VY 5230-A
EOLC 5C257-BB	★ EOLY 5230-A r/b E4VY 5230-A
EOSC 5230-AC	★ EOSZ 5230-E
EOSC 5C258-AA	EOSZ 5230-A
EOSC 5C258-AB	EOSZ 5230-A
EOSC 5C258-BA	EOSZ 5230-A
EOSC 5C258-CA	★ EOSZ 5230-C
EOSC 5C258-DA	★ EOSZ 5230-C
EOZC 5230-AA	EOZZ 5230-N
EOZC 5230-BA	EOZZ 5230-C
EOZC 5230-BC	EOZZ 5230-C
EOZC 5230-CA	EOZZ 5230-M
EOZC 5230-CB	EOZZ 5230-M
EOZC 5230-DA	★ EOZZ 5230-F
EOZC 5230-DB	★ EOZZ 5230-F
EOZC 5230-EA	E1ZZ 5230-C
EOZC 5230-GA	★ E1ZZ 5230-D
EOZC 5C257-AB	★ EOZZ 5230-B
EOZC 5C257-CA	★ EOZZ 5230-E
EOZC 5C257-DA	EOZZ 5230-AB
EOZC 5C257-DC	EOZZ 5230-AB
EOZC 5C257-DE	EOZZ 5230-AB
EOZC 5C257-EA	EOZZ 5230-M
EOZC 5C257-EB	EOZZ 5230-M
EOZC 5C257-EC	EOZZ 5230-M
EOZC 5C257-FA	★ EOZZ 5230-K
EOZC 5C257-FC	EOZZ 5230-FC
EOZC 5C257-SA	★ EOZZ 5230-AA
F1VC 5C258-AB	★ F1VY 5230-C r/b F1VY 5230-F
F201 40100-B	E92Z 5230-B
F201 40100-B	E92Z 5230-C
F204 40100-B	E92Z 5230-D
FOAC 5230-AC	FOAZ 5230-A
FOAC 5230-BB	FOAZ 5230-E
5246	
77FB 5246-DC	★ D8RZ 5246-A

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.	IDENTIFICATION NO.	SERVICE NO.
5246 CONT'D		5246 CONT'D	
80FB 5246-AA	★ D8RZ 5246-A	E3EE 5246-AB	E3FZ 5246-A
86GB 5246-CF	E7RY 5246-A	E3ZD 5246-AA	★ E3ZZ 5246-A
86GB 5246-CF	E9RY 5246-A	E3ZD 5246-BA	E3ZZ 5246-B
B303 40500	E8BZ 5246-A	E45C 5246-AA	★ E45Y 5246-A
B309 40500-A	E9BZ 5246-A	E4DC 5246-AA	E4DZ 5246-A
B303 40500	E8BZ 5246-A	E4EC 5246-BA	E4FZ 5246-A
B601 40500-C	E7GZ 5246-A	E4EC 5246-BB	E4FZ 5246-A
D5ZA 5248-AA	★ D5ZZ 5246-V	E4EC 5246-BC	E4FZ 5246-A
D8BC 5246-AE	★ D8BZ 5246-A	E4EC 5246-CA	E3FZ 5246-C
D8BC 5246-BB	★ D8BZ 5246-A	E4EX 5246-AA	★ E4FZ 5246-B
D8BC 5246-CB	D8BZ 5246-C	E4EX 5246-AC	★ E4FZ 5246-B
D8DC 5246-BA	D7DZ 5246-S	E5RD 5246-AD	E5RY 5246-A
D8DC 5246-CA	★ D7DZ 5246-H	E5RD 5246-BB	E5RY 5246-B
D8DC 5246-DA	★ D7DZ 5246-J	E5VC 5246-AA	E5VY 5246-A
D8DC 5246-FA	★ D7DZ 5246-N	E6AC 5246-BA	E5AZ 5246-A
D8EC 5246-AA	D7FZ 5246-B	E6AC 52466-BA	E5AZ 5246-A
D8EC 5246-BA	D7FZ 5246-A	E6EC 5246-BA	E5FZ 5246-A
D8OC 5246-AA	★ D8OZ 5246-A	E7DC 5246-BA	E6DZ 5246-A
D8OC 5246-BA	★ D8OZ 5246-B	E7DC 5246-CB	E7DZ 5246-C
D8OC 5246-CA	D8OC 5246-C	E7EC 5246-AB	E7FZ 5246-A
D8OC 5246-DA	D8OZ 5246-D	E7SC 5246-AA	E7SZ 5246-A
D8OC 5246-EA	★ D8OZ 5246-E	E8DC 5246-AA	E8DZ 5246-A
D8OC 5246-FA	★ D8OZ 5246-F	E8DC 5246-BA	E8DZ 5246-B
D8ZC 5246-AA	★ D7ZZ 5246-D	E8SC 5246-BA	E8SZ 5246-A
D8ZC 5246-BA	★ D7ZZ 5246-B	EOBC 5246-BB	EOBZ 5246-B
D9AC 5246-AA	D9AE 5246-A	EOBC 5246-CA	★ EOBZ 5246-C
D9AC 5246-AA	★ D9AZ 5246-A	EOBC 5246-DC	★ EOBZ 5246-K
D9AC 5246-AB	★ D9AZ 5246-A	EOBC 5246-EC	★ EOBZ 5246-E
D9AC 5246-AC	★ D9AZ 5246-A	EOBC 5246-FA	★ EOBZ 5246-F
D9AC 5246-AD	★ D9AZ 5246-A	EOBD 5246-BA	★ EOBZ 5246-H
D9AC 5246-AE	★ D9AZ 5246-A	EODC 5246-BB	★ EODZ 5246-B
D9AC 5246-BA	★ D9AZ 5246-B	EODD 5246-DB	★ EODZ 5246-C
D9AC 5246-CA	★ D9AZ 5246-C	EODD 5246-EA	★ EODZ 5246-D
D9DC 5246-AB	★ D9DZ 5246-B	EOEC 5246-CB	★ EOFZ 5246-D
D9EC 5246-CA	D9FZ 5246-A	EOEC 5246-DA	EOFZ 5246-C
D9ZC 5246-AA	D9ZZ 5246-A	EOLC 5246-AA	★ EOLY 5246-A
D9ZC 5246-AB	D9ZZ 5246-A	EOLC 5246-EB	★ EILY 5246-B
D9ZC 5246-BA	D9ZZ 5246-B	EOSC 5246-AA	EOSE 5246-A
D9ZC 5246-BB	D9ZZ 5246-B	EOSC 5246-AA	EOSZ 5246-A
D9ZC 5246-BC	D9ZZ 5246-B	F203 40500	E92Z 5246-C
D9ZC 5246-CA	★ D9ZZ 5246-C	F220 40500-A	E92Z 5246-D
D9ZC 5246-CB	★ D9ZZ 5246-C	F251 40500-A	E92Z 5246-E
D9ZC 5246-CC	★ D9ZZ 5246-C		
D9ZC 5246-DA	★ D9ZZ 5246-D		
D9ZC 5246-DB	★ D9ZZ 5246-D		
E0LC 5246-EB	★ E1LY 5246-B		
E1AC 5246-AA	★ E1AZ 5246-A		
	r/b E6AZ 5246-A		
E1AC 5246-AA	E6AZ 5246-A		
E1BC 5246-AA	E1BZ 5246-B		
E1BE 5246-AA	E1BZ 5246-B		
E1LC 5246-AA	E1LY 5246-A		
E35C 5246-AA	★ E35Y 5246-A		
E35C 5246-BA	★ E35Y 5246-B		
E35C 5246-CA	★ E35Y 5246-C		
E3EC 5246-AA	E3FZ 5246-A		
E3EC 5246-AB	E3FZ 5246-A		
E3EC 5246-AC	E3FZ 5246-A		
E3EC 5246-AD	E3FZ 5246-A		
E3EE 5246-AA	E3FZ 5246-A		

— LAYOUT CONTINUED —

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.	
5F250	CONT'D	
E2ZE 5F250-AA	★ E2ZZ	5F250-A
	r/b E3ZZ	5F250-A
E2ZE 5F250-AA	★ E3ZZ	5F250-A
E35C 5F250-AA	★ E35Y	5F250-B
E35C 5F250-AA	E3SZ	5F250-A
E35C 5F250-BA	★ E35Y	5F250-A
E35C 5F250-BA	E3SZ	5F250-A
E35C 5F250-BB	★ E35Y	5F250-A
E35C 5F250-CA	★ E35Y	5F250-C
E35C 5F250-CA	E3SZ	5F250-A
E35C 5F250-DA	★ E35Y	5F250-A
E35C 5F250-EA	★ E35Y	5F250-C
E35C 5F250-FA	★ E35Y	5F250-C
E35C 5F250-GA	★ E35Y	5F250-D
E3ZC 5F250-AA	★ E3ZZ	5F250-A
E45C 5F250-AA	E45Y	5F250-A
E45C 5F250-BA	E45Y	5F250-A
E4DC 5F250-AA	E4DZ	5F250-A
E4SC 5F250-AA	E4SZ	5F250-A
E4ZC 5F250-AA	E4ZZ	5F250-A
E5DC 5F250-AA	★ E6SZ	5F250-B
	r/b E8SZ	5F250-A
E5DC 5F250-AA	E8SZ	5F250-A
E6DC 5F250-AB	FODZ	5F250-A
E6DC 5F250-DA	★ E7DZ	5F250-C
	r/b FODZ	5F250-A
E6DC 5F250-DA	FODZ	5F250-A
E6LC 5F250-BA	★ E6LY	5F250-B
	r/b FOLY	5F250-A
E6LC 5F250-BA	FOLY	5F250-A
E6LC 5F250-CB	E6LY	5F250-A
E6LC 5F250-CC	E6LY	5F250-A
E6SC 5F250-AA	E6SZ	5F250-A
E6SC 5F250-BA	★ E6SZ	5F250-B
	r/b E8SZ	5F250-A
E6SC 5F250-BA	E8SZ	5F250-A
E6ZC 5F250-BB	★ E6ZZ	5F250-A
	r/b FOZZ	5F250-A
E7DC 5F250-KA	FODZ	5F250-A
E7DC 5F250-LA	★ E7DZ	5F250-C
	r/b FODZ	5F250-A
E7DC 5F250-LA	FODZ	5F250-A
E7LC 5F250-CA	★ E6LY	5F250-B
	r/b FOLY	5F250-A
E7LC 5F250-CA	FOLY	5F250-A
E7ZC 5F250-DA	★ E6ZZ	5F250-A
	r/b FOZZ	5F250-A
E7ZC 5F250-DA	FOZZ	5F250-A
E8DC 5F250-BA	E8DZ	5F250-B
E8SC 5F250-AA	E8SZ	5F250-A
E8ZC 5F250-DA	★ E8ZZ	5F250-A
	r/b FOZZ	5F250-A
E8ZC 5F250-DA	FOZZ	5F250-A
E9DC 5F250-ED	★ E9DZ	5F250-A
	r/b F2DZ	5F250-A
E9DC 5F250-FB	E9DZ	5F250-B
E9SC 5G214-SC	★ E9SZ	5F250-G
	r/b FOSZ	5F250-C
E9SC 5G214-SC	FOSZ	5F250-C
E9SC 5G214-UD	★ E9SZ	5F250-J
	r/b FOSZ	5F250-J

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.	
5F250	CONT'D	
E9SC 5G214-VD	E9SZ	5F250-K
EDE9SZ 5G214-TC	★ E9SZ	5F250-H
	r/b FOSZ	5F250-D
EDE9SZ 5G214-TC	FOSZ	5F250-D
EOBC 5F250-BE	★ EOBZ	5F250-B
EOBC 5F250-FC	★ EOBZ	5F250-E
EOBE 5F250-AA	★ EOBZ	5F250-A
EOBE 5F250-AB	★ EOBZ	5F250-A
EOBE 5F250-AD	★ EOBZ	5F250-A
EOBE 5F250-BA	★ EOBZ	5F250-B
EOBE 5F250-BB	★ EOBZ	5F250-B
EOBE 5F250-BC	★ EOBZ	5F250-B
EOBE 5F250-DA	★ EOBZ	5F250-C
EOBE 5F250-FA	★ EOBZ	5F250-E
EOBE 5F250-GA	EOBZ	5F250-F
EOBE 5F250-GC	EOBZ	5F250-F
EODE 5F250-AC	EOSZ	5F250-C
EODE 5F250-BA	★ EODZ	5F250-B
EODE 5F250-BB	★ EODZ	5F250-B
EODE 5F250-EA	★ EODZ	5F250-D
EODE 5F250-FA	★ EODZ	5F250-E
EODE 5F250-FA	★ EODZ	5F250-F
EODE 5F250-GB	★ EODZ	5F250-E
EODE 5F250-HA	★ EODZ	5F250-G
EODE 5F250-JA	★ EODZ	5F250-H
EODE 5F250-JB	★ EODZ	5F250-H
EODE 5F250-JC	★ EODZ	5F250-H
EODE 5F250-JD	★ EODZ	5F250-H
EODE 5F250-KA	★ EODZ	5F250-K
EODE 5F250-KC	★ EODZ	5F250-K
EODE 5F250-MA	★ EODZ	5F250-L
EODE 5F250-NA	★ EODZ	5F250-N
EODE 5F250-NB	★ EODZ	5F250-N
EODE 5F250-PA	★ EODZ	5F250-K
EODE 5F250-RA	★ EODZ	5F250-P
EODE 5F250-SA	★ EODZ	5F250-M
EODE 5F250-SB	★ EODZ	5F250-M
EOSE 5F250-AA	EOSZ	5F250-C
EOSE 5F250-AB	EOSZ	5F250-C
EOSE 5F250-EA	EOSZ	5F250-E
EOSE 5F250-EB	EOSZ	5F250-E
EOSE 5F250-FA	EOSZ	5F250-F
EOSE 5F250-FB	EOSZ	5F250-F
F0DC 5F250-BA	F0DZ	5F250-A
F0DC 5F250-CA	E9DZ	5F250-B
F0LC 5F250-BA	FOLY	5F250-A
F0DC 5F250-BA	FODZ	5F250-A
F0DC 5F250-CA	E9DZ	5F250-B
FOLC 5F250-BA	FOLY	5F250-A
FOSC 5G214-CA	FOSZ	5F250-C
FOSC 5G214-DA	FOSZ	5F250-D
FOSC 5G214-EA	FOSZ	5F250-E
FOZC 5F250-CA	FOZZ	5F250-A
	★ EOBZ	5F250-B
6023		
E1TE 6M025-AB	★ E3AZ	6023-A
	r/b FITZ	6023-A
E3TE 6M025-AA	★ E3AZ	6023-A
	r/b FITZ	6023-A

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
6312	
E27E 6312-AB	E3TZ 6312-A
E27E 6312-CA	E4TZ 6312-A
6A312	
D3AE 6312-AA	D4AZ 6A312-A
D3AE 6312-BA	★ D4TZ 6A312-B
D3AE 6312-CA	D4AZ 6A312-A
D6OE 6312-BA	D4AZ 6A312-A
D8AE 6312-AA	D4AZ 6A312-A
DOAE 6312-B	D4AZ 6A312-A
DOAE 6312-C	D4AZ 6A312-A
E4ZE 6312-BA	E5ZZ 6A312-A
E5AE 6312-AA	E5AZ 6A312-A
6316	
D2AE 6316-AA	D2AZ 6316-A
D6ZE 6316-AA	★ D7ZZ 6316-A
D8TE 6316-FA	D8TZ 6316-B
DOOE 6316-C	D2AZ 6316-A
E0AE 6316-DA	★ EOAZ 6316-B
E0AE 6316-EA	★ EOAZ 6316-C
E0AE 6316-FA	EOAZ 6316-A
E1AE 6316-AA	E1AZ 6316-A
E1AE 6316-BA	★ E1AZ 6316-B
E1SE 6316-AA	E1SZ 6316-A
E1TE 6316-BA	E1TZ 6316-A
E25E 6316-AA	★ E2SZ 6316-A
E25E 6316-BA	★ E25Y 6316-A
E45E 6316-AA	E45Y 6316-A
E4TE 6316-AA	E4TZ 6316-A
E4TE 6316-BA	E4TZ 6316-B
EOAE 6316-FA	EOAZ 6316-A
6B321	
E25E 6B321-AA	★ E2DZ 6B321-A
E25E 6B321-BA	★ E25Y 6B321-A
E3AE 6B321-BB	E3DZ 6B321-A
E3AE 6B321-DA	E3DZ 6B321-B
E3SE 6B321-AA	E3SZ 6B321-A
E3SE 6B321-BA	E3SZ 6B321-B
6375	
E27R-AA	★ E3TZ 6375-A 1/b FOZZ 6375-A
7E005	
RF EOAP 7E005-AC	EOAZ 7E005-A
7D036	
EOAP 7D281-AA	EOAZ 7D036-A
7A039	
RFE1TP 7A040-AA	E1TZ 7A039-B
RFE0AP 7A040-BD	EOSZ 7A039-A
7052	
75DT 7052-A3A	D5ZZ 7052-A
7B067	
EOAP 7D051-AB	EOAZ 7B067-A
7C096	
84GT 7D428-AA	E5TZ 7C096-A
7C099	
EOAP 7F234-AA	EOAZ 7C099-B
7F200	
RF-EOAP 7F202-BA	EOAZ 7F200-B

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
7230	
E1ER 7230-AA	E1FZ 7230-B
E1ER 7C114-AA	E1FZ 7230-A
7F236	
EOAP 7F236-AB	EOAZ 7F236-B
7A248	
84GT 7A248-A3A	E5TZ 7A248-A
7F251	
EOAP 7F251-AB	EOAZ 7F251-A
7A262	
EOAP 7C117-AA	EOAZ 7A262-B
RF-EOAP 7L140-AA	EOAZ 7A262-A
7D307	
D9ZB 7C078-AA	E1SZ 7D307-A
E0BB 7C078-AA	E1SZ 7D307-A
E1SB 7C078-AA	E1SZ 7D307-A
E1SB 7C078-AB	E1SZ 7D307-A
E1SB 7C078-AC	E1SZ 7D307-A
E9AB 7C078-AA	E9AZ 7D307-A
E9AB 7C078-BA	E9AZ 7D307-B
E9AB 7C078-CB	E9AZ 7D307-C
E9SB 7C078-AB	E9SZ 7D307-A
E9VB 7C078-AB	E9VY 7D307-A
F2SB 7C078-MA	E9SZ 7D307-A
7A377	
83DT 7A377-D1B	E5TZ 7A377-C * TM-74
83DT 7A377-D2B-SAD	E5TZ 7A377-C * TM-74
7D402	
EOAP 7E099-AA	EOAZ 7D402-A
7D422	
74DT 7D422-AA	D4ZZ 7D422-B
7A441	
E5DP 7A441-AA	E4AZ 7A441-A
7A548	
EOAP 7C000-AA	EOAZ 7A548-B
EOAP 7F227-AA	EOAZ 7A548-A
8005	
77FB 8005-GC	★ D8RZ 8005-A
77FB 8005-GD	★ D8RZ 8005-A
77FB 8005-GE	★ D8RZ 8005-A
D8BH 8005-AAA	★ EOZZ 8005-E
D8BH 8005-ABA	★ EOZZ 8005-E
D8BH 8005-APA	★ E2ZZ 8005-A
D8BH 8005-ARA	★ EOZZ 8005-E
D8EH 8005-AA	★ D5FZ 8005-A
D8EH 8005-BA	★ D5FZ 8005-A
D8EH 8005-CA	★ D5FZ 8005-A
D8EH 8005-EA	★ D5FZ 8005-B
D8EH 8005-FA	★ D5FZ 8005-B
D9AH 8005-CA	★ D9AZ 8005-B
D9AH 8005-FA	★ D9AZ 8005-D
D9AH 8005-GA	★ D9AZ 8005-D
D9AH 8005-HA	★ D9AZ 8005-D
D9DH 8005-CA	★ D9DZ 8005-B
D9EH 8005-AA	★ D5FZ 8005-B
E0AH 8005-DA	★ EOAZ 8005-B
E0BH 8005-CA	★ EOZZ 8005-D
E0BH 8005-EA	★ EOZZ 8005-D

— LAYOUT CONTINUED —

CONT'D

0

IDENTIFICATION NO.	SERVICE NO.
8005 CONT'D	
E0BH 8005-GA	★ EOZZ 8005-D
E0BH 8005-HA	★ EOZZ 8005-A
E0BH 8005-LA	★ EOZZ 8005-A
E0BH 8005-MA	★ EOZZ 8005-B
E0BH 8005-PA	★ EOZZ 8005-D
E0BH 8005-RA	★ EOZZ 8005-D
E0BH 8005-SA	★ EOZZ 8005-D
E0BH 8005-UA	★ EOZZ 8005-D
E0BH 8005-VA	★ EOZZ 8005-D
E0BH 8005-YA	★ EOZZ 8005-A
E0DH 8005-AA	★ EODZ 8005-A
E0DH 8005-BA	★ D9DZ 8005-B
E0DH 8005-CA	EODZ 8005-B
E0DH 8005-DA	EODZ 8005-B
E0DH 8005-EA	EODZ 8005-B
E0SH 8005-BA	★ EOZZ 8005-A
E0SH 8005-CA	★ EOZZ 8005-B
E0SH 8005-DA	★ EOZZ 8005-B
E0SH 8005-EA	★ EOZZ 8005-D
E0VH 8005-AA	★ D9AZ 8005-D
E0VH 8005-BA	★ D9AZ 8005-D
E0ZH 8005-AA	★ EOZZ 8005-B
E0ZH 8005-CA	★ EOZZ 8005-B
E0ZH 8005-DA	★ EOZZ 8005-B
E0ZH 8005-GA	★ EOZZ 8005-D
E0ZH 8005-KA	★ EOZZ 8005-A
E0ZH 8005-LA	★ EOZZ 8005-A
E0ZH 8005-MA	★ EOZZ 8005-D
E0ZH 8005-NA	★ EOZZ 8005-B
E0ZH 8005-PA	★ EOZZ 8005-E
E0ZH 8005-RA	★ EOZZ 8005-A
E1AH 8005-DA	★ EOAZ 8005-B
E1EH 8005-FB	E3FZ 8005-A
E1EH 8005-GE-GF	E3FZ 8005-A
E1EH 8005-HE	E3FZ 8005-A
E1EH 8005-JE	E3FZ 8005-A
E1EH 8005-KD	E3FZ 8005-A
E1EH 8005-KE	E3FZ 8005-A
E1EH 8005-LA-LB	E3FZ 8005-A
E1EH 8005-MA-MB	E3FZ 8005-A
E1EH 8005-NA	E3FZ 8005-A
E1EH 8005-PA	E3FZ 8005-A
E1EH 8005-RA-RB	E3FZ 8005-A
E1EH 8005-VA	E3FZ 8005-A
E1SH 8005-AA	★ EOZZ 8005-D
E1ZH 8005-AA	★ EOZZ 8005-A
E1ZH 8005-BA	★ EOZZ 8005-B
E1ZH 8005-CA	★ EOZZ 8005-E
E2BH 8005-RA	★ E2ZZ 8005-A
E2EH 8005-AA	E3FZ 8005-A
E2EH 8005-BA	E3FZ 8005-A
E2EH 8005-CA	E3FZ 8005-A
E2EH 8005-DA	E3FZ 8005-A
E2EH 8005-EA	E3FZ 8005-A
E2EH 8005-FA	E3FZ 8005-A
E2EH 8005-GA	E3FZ 8005-A
E2EH 8005-JA	E3FZ 8005-A
E2GH 8005-AA	E3FZ 8005-A

— LAYOUT CONTINUED —

IDENTIFICATION NO.	SERVICE NO.
8005 CONT'D	
E2GH 8005-BA	E3FZ 8005-A
E2ZH 8005-GA	★ E2ZZ 8005-A
E35H 8005-AA	E3ZZ 8005-A
E35H 8005-CA	E4DZ 8005-A
E3BH 8005-AA	E3ZZ 8005-A
E3BH 8005-BA	E3ZZ 8005-A
E3BH 8005-CA	E3ZZ 8005-A
E3BH 8005-DA	E3ZZ 8005-A
E3BH 8005-EA	E3ZZ 8005-A
E3BH 8005-FA	E3ZZ 8005-A
E3DH 8005-BA	E3ZZ 8005-A
E3DH 8005-CA	E3ZZ 8005-A
E3DH 8005-EA	E3ZZ 8005-A
E3DH 8005-FA	E3ZZ 8005-A
E3EH 8005-EA	E3FZ 8005-B
E3EH 8005-FA	E3FZ 8005-B
E3EH 8005-GA	E3FZ 8005-A
E3EH 8005-HA	E3FZ 8005-A
E3EH 8005-LA	E3FZ 8005-A
E3EH 8005-MA	E3FZ 8005-A
E3EH 8005-NA	E3FZ 8005-A
E3EH 8005-PA	E3FZ 8005-A
E3GH 8005-EA	E3FZ 8005-B
E3GH 8005-FA	E3FZ 8005-B
E3SH 8005-AA	E3ZZ 8005-A
E3SH 8005-CA	E3ZZ 8005-A
E3SH 8005-DA	E3ZZ 8005-A
E3SH 8005-EA	E3ZZ 8005-A
E3SH 8005-FA	E3ZZ 8005-A
E3SH 8005-GA	E3ZZ 8005-A
E3SH 8005-HA	E5LY 8005-B
E3SH 8005-JA	E3ZZ 8005-A
E3ZH 8005-JA	E3ZZ 8005-A
E3ZH 8005-LA	E3ZZ 8005-A
E3ZH 8005-MA	E3ZZ 8005-A
E3ZH 8005-NA	★ E2ZZ 8005-A
E3ZH 8005-RA	E3ZZ 8005-A
E3ZH 8005-TA	E3ZZ 8005-A
E43H 8005-AA	E3FZ 8005-A
E43H 8005-BA	E3FZ 8005-A
E43H 8005-CA	E3FZ 8005-A
E4DH 8005-AA	E3ZZ 8005-A
E4DH 8005-DA	E3ZZ 8005-A
E4LH 8005-BA	E4LY 8005-A
E4ZH 8005-AA	E3ZZ 8005-A
E53H 8005-KA	E3FZ 8005-A
E53H 8005-PA	E63Z 8005-C
E63H 8005-AA	E63Z 8005-A
E63H 8005-BA	E63Z 8005-B
E6AH 8005-BB	E6AZ 8005-A
E6AH 8005-DB	★ E6AZ 8005-B
E6RD 8005-AA	E6RY 8005-A
E6RD 8005-BA	E6RY 8005-B
E7AH 8005-AA	E7AZ 8005-A
E7AH 8005-BA	E7AZ 8005-B
E7AH 8005-CA	E7AZ 8005-C
E7AH 8005-DA	E7AZ 8005-D
E7DH 8005-BA	E7DZ 8005-B

— LAYOUT CONTINUED —

CONT'D

0001

PART NAME	GROUP NUMBER
B CONT'D	
Brace(Windshield Wiper Mounting Panel)	020B26
Brace(Brake Pedal Support To Cowl)	01554
Brace(Brake Pedal Support To Instrument Panel)	015A08
Brace(Brake Pedal Support)	01524, 015A48
Brace(Cowl Top Inner Panel) And 023a41	023A40
Brace(Dash Panel Extension)	016A64
Brace(Dash Panel To Cowl Side)	01784
Brace(Dash Panel To Cowl)	01785
Brace(Instrument Panel Lower Center)	043B56
Brace(Instrument Panel Lower Extension Center)	043A84
Brace(Instrument Panel Lower Flange To Cowl Inner Panel)	04672
Brace(Instrument Panel To Dash)	044F48
Brace(Instrument Panel To Floor)	04598
Brace(Instrument Panel)	04510
Brace(Package Tray Strainer)	46912
Brace(Quarter Panel To Rear Floor)	27726
Brace(Quarter Wheelhouse)	278D40
Brace(Quarter Window Regulator Panel)	29794
Brace(Rear Seat Back Hanger Bracket)	667A10
Brace Assy.(Passenger Air Bag Support)	045F84
Brace Assy.(Floor Cross)	108A78
Brace Assy.(Front End Cross)	108A74
Brace Assy.(Bike Adapter Arm)	550A90
Brace Top Carrier	50512
Bracket(Console Mounting Center Front) And 045b37	045B36
Bracket(Front Seat Adjusting Tube) And 618a89	618A88
Bracket(Front Seat Back Latch Solenoid) And 625a57	625A56
Bracket(Front Seat Back Side Shield Upper Support) And 621a11	621A10
Bracket(Front Seat Track Motor Mounting) And 617b49	617B48
Bracket(Front Seat Track Mounting Rear) And 618b43	618B42
Bracket(Front Seat Track Switch Mounting) And 617b59	617B58
Bracket(Instrument Panel) And 043c50	043C50
Bracket(Liftgate Bumper) And 40131	40130
Bracket(Luggage Compartment Cover) And 428a11	428A10
Bracket(Luggage Compartment Door Hinge To Wheelhouse) And 42739	42738
Bracket(Luggage Compartment Door Lift On Door) And 41837	41836
Bracket(Package Tray Strainer To Wheelhouse) And 46609	46608
Bracket(Package Tray Support Rear) And 465k03	465K02
Bracket(Package Tray To Inner Roof Rail) And 46633	46632
Bracket(Rear Door Glass Channel Front) And 263a53	263A52
Bracket(Rear Door Inside Handle Mount) 266a23	266A22
Bracket(Rear Door Latch Actuator Rod) And 26495	26494
Bracket(Rear Door Window Division Bar Center) And 263a95	263A94
Bracket(Rear Floor Cross Member) And 106a59	106A58
Bracket(Rear Seat Back Frame) And 624a39	624A38
Bracket(Rear Seat Back Stop To Wheelhouse) And 631a03	631A02
Bracket(Rear Seat Back) And 631b29	631B28
Bracket(Rear Seat Cushion Pivot Link Lower) And 624a89	624A88

— LAYOUT CONTINUED —

PART NAME	GROUP NUMBER
B CONT'D	
Bracket(Rear Seat Cushion Pivot Link Upper) And 624a85	624A84
Bracket(Rear Seat Support To Floor) And 62443	62442
Bracket(Rear Spoiler) And 41683	41682
Bracket(Seat Quarter Panel) And 612a71	612A70
Bracket(Stowage Compartment Door Front Latch) And 117a03	117A02
Bracket(Back Window Glass) And 422b19	422B18
Bracket(Center Body Pillar Inside Finish) And 243a97	243A96
Bracket(Convertible Top)	31366
Bracket(Cowl Bar) And 021a89	021A88
Bracket(Cowl Side To Instrument Panel) And 020a33	020A32
Bracket(Cowl Side Vapor Cannister Mounting)	021B32
Bracket(Cowl Top Panel To Front Fender Apron) And 02295	02294
Bracket(Door Inside Panel At Belt) And 202a55	202A54
Bracket(Door Trim Panel) And 23835	23834
Bracket(Door Vent Window Glass) And 22255	22254
Bracket(Door Window Stop) And 21765	21764
Bracket(Folding Top Lift Motor Mounting)	50757
Bracket(Front Airfoil Inner) And 001a09	001A08
Bracket(Front Airfoil Outer) And 001a11	001A10
Bracket(Front Door Arm Rest Mounting) And 24117	24116
Bracket(Front Door Lock Control Knob) And 21883	21882
Bracket(Front Door Scuff Plate) And 13281	13280
Bracket(Front Door Vent Window Division Bar) And 222a15	222A14
Bracket(Front Door Window Channel) And 23289	23288
Bracket(Front Door Window Glass Rear) And 21431	21430
Bracket(Front Door Window Upstop Front) And 21743	21742
Bracket(Front Seat Adjusting To Seat) And 618k85	618K84
Bracket(Front Seat Back Latch) And 62615	62614
Bracket(Front Seat Track To Floor)	61702
Bracket(Front Seat Track) And 62045	62044
Bracket(Instrument Panel Center) And 045a56	045A55
Bracket(Instrument Panel Flange Reinforcement Brace At Floor) And 045g89	045G88
Bracket(Lining Board Retainer)	45598
Bracket(Lower Back Panel)	403E20
Bracket(Number Two Bow - Center) And 53145	53144
Bracket(Pillar) And 022a25	022A24
Bracket(Quarter Panel Rear Extension) And 280a53	280A52
Bracket(Quarter Trim Panel Retainer Rear) And 311a23	311A22
Bracket(Quarter Trim Panel Retainer) And 31285	31284
Bracket(Quarter Trim Panel Upper Center) And 311a79	311A78
Bracket(Quarter Trim Panel) And 311a25	311A24
Bracket(Quarter Window Glass Run Retainer) And 30047	30046
Bracket(Quarter Window Stop Lower) And 30571	30570
Bracket(Quarter Window Stop) And 30089	30088
Bracket(Rear Corner Inner Finish Upper) And 404b71	404B70
Bracket(Rear Door Arm Rest) And 27535	27534
Bracket(Rear Door Glass Run Lower) And 25737	25736
Bracket(Rear Lamp Opening Reinforcement) And 279a21	279A20
Bracket(Rear Seat Back Pivot On Wheelhouse) And 613a63	613A62
Bracket(Rear Seat Back Pivot) And 60515	60514

— LAYOUT CONTINUED —

CONT'D

0001

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
B CONT'D		B CONT'D	
Bracket(Rear Seat Back Pivot) And 613a45	613A44	Bracket(Front/Rear Door Arm Rest)	22606
Bracket(Rear Seat Cushion Pivot Inner) And 605b05	605B04	Bracket(Fuel Filler Door Hinge On Body)	40586
Bracket(Rear Seat Cushion Pivot) And 60521	60520	Bracket(Fuel Filler Door Hinge On Door)	405A16
Bracket(Rear Seat Headrest Trim) And 613k65	613K64	Bracket(Instrument Panel Finish Panel Center)	047A06
Bracket(Rear Seat) And 605a21	605A20	Bracket(Instrument Panel Finish Panel)	044B49
Bracket(Regulator Motor) And 233b95	233B94	Bracket(Instrument Panel Glove Compartment Door Hinge)	06192
Bracket(Roof Assist Strap Attachment Rear) And 312a53	312A52	Bracket(Instrument Panel Glove Compartment Door Latch Mounting)	06136
Bracket(Roof Opening Glass Handle Spring) And 53713	53712	Bracket(Instrument Panel Insulator)	043A98
Bracket(Roof Side Inner Rail To Wheelhouse) And 51211	51210	Bracket(Instrument Panel Locator)	045F94
Bracket(Roof Side Outer Front Rail Extension) And 51263	51262	Bracket(Instrument Panel Lower Extension)	043A82
Bracket(Roof Side Rail To Wheelhouse)	513A56	Bracket(Instrument Panel Mounting Lower)	044L33
Bracket(Roof Side Trim) And 519b97	519B96	Bracket(Instrument Panel Mounting)	045C06
Bracket(Roof Sliding Panel Lifter)	502P30	Bracket(Instrument Panel Radio Opening)	044F80
Bracket(Sun Roof) And 502k51	502K50	Bracket(Instrument Panel Reinforcement)	042K50
Bracket(Top Front) And 52153	52152	Bracket(Instrument Panel To Cowl Top Inner)	044F36
Bracket(Airfoil Front Center)	002A18	Bracket(Instrument Panel To Cowl Top)	043C32
Bracket(Assist Strap)	312A48	Bracket(Instrument Panel To Cowl)	04366
Bracket(Back Window Lift)	42146	Bracket(Instrument Panel To Dash)	044B72
Bracket(Back Window Regulator Arm)	44074	Bracket(Instrument Panel To Floor Brace)	044G22
Bracket(Back Window Upper Stop)	42202	Bracket(Instrument Panel To Floor)	042C51, 042C74
Bracket(Brake Pedal Support)	01556	Bracket(Instrument Panel Upper To Heater Housing)	044F39
Bracket(Coat Hook)	29019	Bracket(Instrument Panel)	044F12, 044K50, 045B00
Bracket(Console Glove Compartment Mounting)	044D68	Bracket(Junction Instrument Panel)	04440
Bracket(Console Mounting Center Front)	047A18	Bracket(Knee Protector)	044K20
Bracket(Console Mounting Center)	045B38	Bracket(Lower Back Panel)	45450
Bracket(Console Mounting Front)	045A46	Bracket(Luggage Compartment Door Hinge To Wheelhouse)	42744
Bracket(Console Panel Arm Rest Mounting)	045C52	Bracket(Luggage Compartment Door Latch Striker)	43235
Bracket(Console Panel Front Support)	043B92	Bracket(Luggage Compartment Door Latch)	43268
Bracket(Console Panel Gear Shift Lever Opening Support)	047A00	Bracket(Luggage Compartment Door Lift On Body)	427A48
Bracket(Console Panel Mounting Front)	045B32	Bracket(Luggage Compartment Door Locator Pin)	40178
Bracket(Console Panel Mounting Rear)	045B34	Bracket(Luggage Compartment Door Lock Striker Mounting)	43258
Bracket(Console Tray Front)	042B52	Bracket(Luggage Compartment Door Trim Panel)	46312
Bracket(Console Tray Rear)	042B54	Bracket(Luggage Door Latch Adjusting)	42722
Bracket(Cowl Side Panel Upper)	020A93	Bracket(Package Tray Anchor Outer)	46686
Bracket(Cowl Top Inner Panel Brace Lower)	023A38	Bracket(Package Tray Retainer Front)	46916
Bracket(Cowl Top Inner Panel Brace Upper)	023A36	Bracket(Package Tray Strainer To Floor)	46612
Bracket(Door Lock Control)	219A32	Bracket(Passenger Air Bag Restraint)	045A78
Bracket(Door Outside Handle Mounting)	224A00	Bracket(Quarter Panel)	28424
Bracket(Door Window Regulator Motor Mounting)	23312	Bracket(Quarter Trim Panel Support)	31184
Bracket(Drive Unit)	502E08	Bracket(Quarter Trim Panel To Wheelhouse)	31424
Bracket(Folding Top Lift Cylinder)	50668	Bracket(Quarter Wheelhouse Inner Panel Rear Reinforcement)	277A60
Bracket(Folding Top Number 1 (Front) Bow)	514A30	Bracket(Quarter Wheelhouse To Rear Floor Brace)	287A08
Bracket(Folding Top Side Front Linkage)	50648	Bracket(Quarter Window Glass Lower)	305A04
Bracket(Front Air Deflector End)	002A26	Bracket(Quarter Window Glass)	305A02
Bracket(Front Air End Deflector To Radiator Support)	002A27	Bracket(Quarter Window Guide)	29758
Bracket(Front Door Lower Frame)	211A24	Bracket(Quarter Window Outside Moulding)	292A24
Bracket(Front Door Window Stop)	21760	Bracket(Quarter Window Regulator Cable)	30054
Bracket(Front Door Windows Top - Lower)	21790	Bracket(Rear Door Armrest Center)	27646
Bracket(Front Seat Center Arm Rest Mounting)	63076, 64480	Bracket(Rear Floor Muffler Stop Front)	108A18
Bracket(Front Seat Cushion Extension)	60328	Bracket(Rear Floor Muffler Stop Rear)	109A72
Bracket(Front Seat Headrest Mounting)	610B10	Bracket(Rear Seat Cushion)	606A50
Bracket(Front Seat Track Assist Spring)	61804	Bracket(Rear Seat Frame Rear To Floor)	617C90
Bracket(Front Seat)	618A04		
Bracket(Front Side Member Tie Down)	100A42		

— LAYOUT CONTINUED —

— LAYOUT CONTINUED —

CONT'D

0001

PART NAME	GROUP NUMBER
B CONT'D	
Bracket(Rear Strap Back Hanger)	667A02
Bracket(Rear)	58502P74
Bracket(Reinforcement Outside Trim Panel Side)	537A52
Bracket(Roof Console Front)	519K22
Bracket(Roof Hold Down)	50404
Bracket(Roof Interior Lamp Mounting)	51496, 51536
Bracket(Roof Opening Glass Handle)	502M70
Bracket(Roof Opening Glass Retainer)	501A06
Bracket(Roof Opening Panel Latch)	518A90
Bracket(Roof Opening Reinforcement)	500A58
Bracket(Roof Outside Trim Panel Side)	537A40
Bracket(Roof Side Trim)	519C04
Bracket(Roof Sliding Panel Drive Mounting)	50728
Bracket(Roof Sliding Panel Handle Opening Cover)	518B28
Bracket(Roof Sliding Panel Housing)	51890
Bracket(Ski Carrier Hook Housing)	55010
Bracket(Sliding Sun Roof Rear)	502P74
Bracket(Spare Wheel Cover)	47100
Bracket(Spare Wheel Mounting)	47076
Bracket(Spoiler)	416B82
Bracket(Sunroof Hinge On Roof)	502R00
Bracket(Tailgate Counterbalance Torsion Bar Center)	430A30
Bracket(Utility Compartment Rear)	04599
Bracket(Utility Tray Front)	06204
Bracket(Window Regulator Equalizer Arm)	23230
Bracket Assembly(Folding Top Control Link) And 50445	50444
Bracket Assembly(Luggage Compartment Door Prop)	44588
Bracket Assy(Instrument Panel Radio Mounting)	04452
Bracket Assy.(Compartment Door Lift On Hinge) And 41835	41834
Bracket Assy.(Instrument Panel Side) And 042b83	042B82
Bracket Assy.(Rear Floor Side Member Tie Down) And 101c25	101C24
Bracket Assy.(Floor Side Inner)	108A82
Bracket Assy.(Floor Side Outer Member) And 103b77	103B76
Bracket Assy.(Top Front) And 52207	52206
Bracket Assy.(Top) And 53983	53982
Bracket Assy.(Front Door Window Glass Tube Lower)	234B70
Bracket Assy.(Rear Door Equalizer Arm)	26348
Bracket Assy.(Sliding Panel Headlining)	508A36
Bracket Assy.(Vmv Valve Mounting)	017B46
Bumper(Deflector) And 500a45	500A44
Bumper	265A28, 439A00
Bumper(Auxiliary Floor Panel)	115A72
Bumper(Auxiliary Seat Back Floor Panel)	605A18
Bumper(Auxiliary Seat Back Floor Pivot Arm)	61506
Bumper(Body Side Door)	27232
Bumper(Door Outside Handle Anti-Rattle)	22408
Bumper(Door Window Stop)	21762
Bumper(Door)	23030
Bumper(Folding Top Side Rail)	53055
Bumper(Fuel Filler Door)	405A22
Bumper(Glove Compartment Door)	06066
Bumper(Instrument Panel Ash Receptacle Stop)	048A78
Bumper(Instrument Panel Glove Compartment Door Stop)	06115

— LAYOUT CONTINUED —

PART NAME	GROUP NUMBER
B CONT'D	
Bumper(Liftgate/Luggage Compartment)	40452
Bumper(Luggage Compartment Door Inside)	43634
Bumper(Rear Seat Back Stop)	61082
Bumper(Roof Sliding Panel Stop)	502B12, 502B56
Bumper(Tailgate Latch)	431B62
Bumper Assy.(Front)	101A22
Bush(Retainer Door Trim)	237A60
Bushing(Door Alignment Pin Catch)	23040
Bushing(Door Hinge)	22841
Bushing(Door Latch Rod)	219A38
Bushing(Floor Side Bracket)	613C44
Bushing(Folding Top Hold Down Clamp)	54800
Bushing(Folding Top Spring Rod)	507A24
Bushing(Front Door Latch Bellcrank)	21932
Bushing(Front Seat Back Center Arm Rest Pad)	654A28
Bushing(Front Seat Back Pivot)	61038
Bushing(Front Seat Lumbar Support)	65570
Bushing(Knob Rear Seat Back Release)	616A16
Bushing(Liftgate Latch)	432B00
Bushing(Rear Seat Back Pivot)	613B44
Button(Back Window Regulator)	44084
Button(Door Window Stabilizer)	25754
Button(Inside Visor Latch Release)	04006
Button(Rear Corner Inner Finish Panel)	404B86
Button(Rear Seat Back Latch Release)	62432
Button And Pin Kit(Door Outside Handle)	22454
Button Assy.(Rear Door Outside Handle)	26602
C	
Cable(Folding Top Tension)	52806
Cable(Instrument Panel Glove Compartment Door Check)	060A08
Cable(Quarter Window Regulator)	303A94
Cable(Rear Seat Back Latch)	624A54
Cable(Tailgate Check)	43052
Cable(Wire)	617B26
Cable And Slide Assy.(Sliding Roof) And 502b21	502B20
Cable And Tube(Front Seat Track Adjusting) Through 617b15	617B12
Cable Assy(Storage Compartment Door Latch)	11679
Cable Assy.(Front Seat Adjuster Actuator) And 618c73	618C72
Cable Assy.(Roof Sliding Panel Tension) And 502d41	502D40
Cable Assy.(Door Latch Remote Control)	221A00
Cable Assy.(Luggage Compartment Door Latch)	40180
Cam(Front Seat Lumbar Support) And 65555	65554
Cam(Front Door Window Regulator) And 234b67	234B66
Cam(Front Door Window) 234b19	234B18
Cam(Front Seat Back Adjusting Lumbar)	610C44
Cam(Quarter Window Regulator) And 30531	30530
Cam(Liftgate Door Latch Actuator)	43214
Cap('B' Pillar Seal) And 24443	24442
Cap(Door Frame Front) And 20477	20476
Cap(Door Frame Rear) And 20843	20482
Cap(Folding Top Header Protector) And 53481	53480
Cap(Protective Boot Retainer) And 54547	54546
Cap(Auxiliary Floor Outer Protection)	115K30
Cap(Door Lock Cylinder Case)	22088
Cap(Folding, Top Header)	51538

— LAYOUT CONTINUED —

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There is no text or other markings on the paper.

MASTER PARTS AND ACCESSORIES CATALOG

FORD PARTS AND SERVICE DIVISION

FORM FPS 8470-1-B

GENERAL INSTRUCTIONS

This Ford/Lincoln Mercury Master Parts Catalog contains parts illustrations for A (Ford), B (Tempo), C (EXP), D (Lincoln), E (Taurus), F (Mustang), G (LTD), G (Granada), J (Capri), K (Mark VI), K (Mark VII), L (Pinto), P (Fairmont), S (Thunderbird), W (Escort), W (EXP—B/T 67), X (Fiesta), BT (Festiva), DC (Continental), DT (Lincoln Town Car), MA (Mercury), MB (Topaz), MC (LN7), ME (Sable), MF (Cougar), MG (Monarch), MG (Marquis), ML (Bobcat), MM (Tracer), MP (Zephyr), MV (Versailles), MW (Lynx), MX (Merkur XR4Ti), MY (Scorpio) and ST (Probe) for model years 1980/ for U.S. and Canadian built vehicles.

Use this illustration catalog in conjunction with the text catalog. Form FPS 8470-A (Ford) and FPS 8471-A (Lincoln Mercury).

For greater convenience this catalog is divided into specific sections, such as brakes, front suspension, engine, transmission, etc. For example, FRONT SUSPENSION appears in Section 30, STEERING in Section 35, Rear Axle in Section 40, etc.

A separate catalog which contains the text or descriptive information for the same model years is available as Form FPS 8470-A (Ford) and FPS 8471-A (Lincoln Mercury). The text catalog is divided into sections also and like parts are shown under similar section numbers in both the text and illustration catalogs.

A listing of Ford/Lincoln Mercury group numbers and their related section numbers appears in the General Information Section of the text catalog, Form FPS 8470-A (Ford) and FPS 8471-A (Lincoln Mercury).

Illustrations contain basic group numbers only, therefore, it is necessary to refer to the basic group within the text catalog listing for complete applicable part number.

Please Note:

Illustrations shown per this publication are to be used for text part number basic identification only.

The various parts illustrated in this publication (FPS 8470-1-B) are drawn for multiple vehicle applications and therefore "typical" to the actual part(s) they represent. Consequently, exact detail, measurements and configurations of the actual part cannot be shown for each illustration printed.

Refer to the various SHOP MANUAL type of publications for part removal, specifications, torque and replacement procedures.

The driver's side is the left hand side of the vehicle and determines whether such parts as fenders, lamps, etc. are right or left hand.

Model year application is indicated by showing the first year followed by a diagonal line to indicate continued usage in all subsequent years until the insertion of the last year of usage, which is shown after the diagonal line. If no diagonal line is shown, the part is applicable only to the year shown.

Example —

80/ indicates part used 1980 through subsequent model years.

80/81 indicates part used 1980 through 1981 model years.

80 indicates part used 1980 model year only.

For Certification Label Data, Catalog Model Codes and Body Type Codes refer to the General Information Section of the Text Catalog, Form FPS 8470-A (Ford) and FPS 8471-A (Lincoln Mercury).

MASTER PARTS AND ACCESSORIES CATALOG

FORD PARTS AND SERVICE DIVISION

FORM FPS 8470-1-B

GENERAL INSTRUCTIONS

The various car lines and their body types are identified by vehicle catalog codes and body type codes in the text catalog as follows:

CATALOG CODE	YEAR	VEHICLE	OTHER COMMON SYMBOLS	
A	1980/	Ford		
B	1984/	Tempo		
C	1982/85	EXP	★ Indicates Not Serviced — must be improvised or procured locally	
D	1980/81	Lincoln		
E	1986/	Taurus	BODY TYPE DESCRIPTION	BODY TYPE CODE
F	1980/	Mustang	Five door sedan	58
G	1983/86	LTD		
G	1980/82	Granada	Four door sedan	54
J	1980/86	Capri	Four door station wagon	74
K	1980/83	Mark VI		
K	1984/	Mark VII	Three door fastback	61
L	1980	Pinto	Three door sedan	64
P	1980/83	Fairmont	Three door hatchback coupe	67
S	1980/	Thunderbird		
W	1981/	Escort	Two door hardtop (formal roof)	65
W (B/T 67)	1986/88	EXP	Two door pillared hardtop	66
X	1980	Fiesta	Two door sedan	62
BT	1988/	Festiva	Two door sedan	63
DC	1982/	Continental	Two door sporty coupe	36
DT	1982/	Lincoln Town Car	Two door station wagon	73
MA	1980/	Mercury		
MB	1984/	Topaz		
MC	1982/83	LN7		
ME	1986/	Sable		
MF	1980/	Cougar		
MG	1980	Monarch		
MG	1983/86	Marquis		
ML	1980	Bobcat		
MM	1987/	Tracer		
MP	1980/83	Zephyr		
MV	1980	Versailles		
MW	1981/87	Lynx		
MX	1985/	Merkur XR4Ti		
MY	1988/	Scorpio		
ST	1989	Probe		

1980/89
FORD/LINCOLN MERCURY CARS

**GENERAL
INFORMATION 3**

INDEX
CHASSIS PARTS ILLUSTRATION

Following is a general index of the major groups shown in the Chassis and Body Parts Illustration Sections. For more specific information refer to the Index appearing in front of the Section number listed below:

MAJOR GROUP	● TABBED DIVIDER TITLE	INDEX SECTION
Accelerator Linkage	Fuel	95
Accessories	Listed in their appropriate groups as identified in this index	
Air Cleaner	Fuel	95
Air Conditioner	Air Conditioner Defogger — Defroster (Back Window), Heater, Radios	180
Alternator	Generator, Starter, Distributor	103
Automatic Transmission	Automatic Transmission	A70
Axle (Rear)	Rear Axle, Driveshaft	40
Battery	Generator, Alternator, Starter, Distributor	103
Brake System	Wheel, Brakes	10
Bumpers	Bumpers, Jack, Mirror, Washer, Wipers	175
Carburetor	Fuel	90
Catalytic Converter	Refer to Text Catalog	
Clutch	Standard Transmission, Clutch	70
Cooling System	Cooling, Grille	80
Defogger-Defroster (Back Window)	Air Conditioner Defogger-Defroster (Back Window), Heater, Radios, Shock Absorbers	180
Distributor	Generator, Alternator, Starter, Distributor	103
Driveshaft	Rear Axle, Driveshaft	40
Electrical	Generator, Alternator, Starter, Distributor	103
Electrical	Lamps, Wiring	130
Engine	Engine	60
Exhaust System	Refer to text catalog	
Fan	Cooling, Grille	80
Fenders	Fender, Hood	160
Frame	Frames, Mufflers, Springs	50
Front Suspension	Front Suspension, Steering	30
Fuel Pump	Fuel	90
Fuel System	Fuel	90
Fuel Tank	Fuel	90
Gearshift Lever	Standard Transmission, Clutch	70
Grille	Cooling, Grille	80
Heater	Air Conditioner Defogger-Defroster (Back Window), Heater, Radios	180
Hood	Fender, Hood	160
Horn	Lamps, Wiring	130
Jack	Bumpers, Jack, Mirror, Washer, Wipers	175
Instrument Cluster	Generator, Alternator, Starter, Distributor	103
Lamps	Lamps, Wiring	130
Lever (Gearshift)	Standard Transmission, Clutch	70
Manifolds	Fuel	90
Mirrors	Bumpers, Jack, Mirror, Washer, Wipers	175
Muffler	Refer to text catalog	
Pump (Fuel)	Fuel	90
Pump (Water)	Cooling, Grille	80
Radiator	Cooling, Grille	80
Radios	Air Conditioner Defogger-Defroster (Back Window), Heater, Radios, Shock Absorbers	180
Rear Axle	Rear Axle, Driveshaft	40

1980/89

FORD/LINCOLN MERCURY CARS**INDEX****CHASSIS PARTS ILLUSTRATION — cont'd.**

MAJOR GROUP	• TABBED DIVIDER TITLE	INDEX SECTION
Shock Absorbers (Front)	Front Suspension, Steering	30
Shock Absorbers (Rear)	Frames, Mufflers, Springs	50
Springs	Frames, Mufflers, Springs	50
Stabilizer (Front)	Front Suspension, Steering	30
Stabilizer (Rear)	Frames, Mufflers, Springs	50
Starter	Generator, Alternator, Starter, Distributor	103
Steering	Front Suspension, Steering	30
Suspension (Front)	Front Suspension, Steering	30
Suspension (Rear)	Frames, Mufflers, Springs	50
Tank (Fuel)	Fuel	90
Transmission (Automatic)	Automatic Transmission	A70
Transmission (Standard)	Standard Transmission Clutch	70
Voltage Regulator	Generator, Alternator, Starter, Distributor	103
Water Pump	Cooling, Grille	80
Wheels	Wheels, Brakes	10
Windshield Washer, Wiper	Bumpers, Jack, Mirror, Washer, Wipers	175
Wiring	Lamps, Wiring	130

BODY PARTS ILLUSTRATION INDEX

Auxiliary Seat	Seat	600
Back Window	Back, Luggage Compartment	400
Body Sheet Metal	Body Sheet Metal	Body Sheet Metal
Console	Body Front, Floor	000
Door (Front)	Body Sides, Quarter	230
Door (Rear)	Body Sides, Quarter	230
Exterior Trim	Refer to Exterior Moulding Section of text catalog	
Floor Sheet Metal	Body Sheet Metal	Body Sheet Metal
Folding Top	Back, Luggage Compartment	400
Front Door	Body Sides, Quarter	230
Front Seat	Seat	600
Front Seat Track	Seat	600
Glove Compartment	Body Front, Floor	000
Instrument Panel	Body Front, Floor	000
Interior Trim	Interior Trim	Interior Trim
Liftgate	Back, Luggage Compartment	400
Luggage Compartment Door Mechanism	Back, Luggage Compartment	400
Luggage Compartment Trim	Interior Trim	Interior Trim
Package Tray	Interior Trim	Interior Trim
Quarter Window	Body Sides, Quarter	230
Rear Door	Body Sides, Quarter	230
Rear Seat	Seat	600
Roof	Back, Luggage Compartment	400
Sheet Metal	Body Sheet Metal	Body Sheet Metal
Tailgate	Back, Luggage Compartment	400
Track (Front Seat)	Seat	600
Vent System	Body Front, Floor	000
Windshield	Body Front, Floor	000

1980/89
FORD/LINCOLN MERCURY CARS
PROCEDURE FOR USING CATALOG

**GENERAL
INFORMATION 5**

There are three ways of finding part numbers:

1. By Part Name
2. By Illustration
3. By Identification

Should an inquiry be received for a radiator grille for a 1983 Ford Escort or Mercury Lynx.

BY PART NAME

- A. Refer to the Chassis Alphabetical Index in the Text Catalog (Form FPS 8470-A (Ford) and FPS 8471-A (Lincoln Mercury)
- B. Refer to the alphabetical nomenclature and find the part name "Grille (Radiator)". The group number listed is 8200.
- C. Refer to group number 8200 and locate the year 1983 in the "YEAR" column. Find the vehicle catalog code "W" (for Ford Escort or Mercury Lynx) in the "MODEL/RESTRICTIONS" column.
- D. The part number shown is E3YY-8200-A (Argent & Chrome) or E3YY-8200-B (Black)

BY ILLUSTRATION

- A. Refer to this Illustration Catalog to the divider marked "Cooling-Grille".
- B. Refer to the index immediately behind the divider and find the 1983 illustration indexes.
- C. Under the heading W (Escort) & MW (Lynx) look for "Radiator Grille".
- D. Refer to the illustration designated (on page 10 of illustration Section 82) and find the group number for the Radiator Grille to be 8200.
- E. Refer to group number 8200 in the Text Catalog (Form FPS 8470-A (Ford) and FPS 8471-A (Lincoln Mercury) and locate 1983 in the "YEAR" column. Find the vehicle catalog code "W" (for Ford Escort) or "MW" (for Mercury Lynx) in the "MODEL/RESTRICTIONS" column.
- F. The part number shown is E3YY-8200-A (Argent & Chrome) or E3YY-8200-B (Black).

BY IDENTIFICATION

Certain parts and most major assemblies are identified with a part number shown on an attached tag or plate or on the part itself. Reference to identification numbers is made throughout the catalog and cross reference charts are included in some sections to provide immediate knowledge of the service part number when the identification number is known.

IMPORTANT — Identification tags and plates must be retained with the part or assembly with which they are originally supplied.

HOW TO ORDER PARTS

When ordering parts, always give the complete part number.

In the event the part number is not known, the following information should be included:

- A. Complete description of part.
- B. Model year and body type.
- C. Dimension, number of teeth, size, etc., if possible rough sketch of part.
- D. If applicable to engine, transmission, axle, steering, etc., specify type, such as 302 cubic inch, Automatic Transmission, Power Steering, etc.
- E. Advise how shipment is to be made — Freight, Express, Air, Parcel Post.

EXPLANATION OF SYMBOL ★

★ Symbol indicates part is not supplied for service due to the following:

- a. Part is superseded and replaced as indicated in the description column of the text catalog.
- b. Part can be improvised as indicated in the description column of text catalog.
- c. Due to its function there would be little or no demand.

NOTE — ALWAYS REFER TO THE DESCRIPTION COLUMN OF THE TEXT CATALOG FOR POSSIBLE SUBSTITUTION OR FOR MATERIAL SPECIFICATIONS AND DIMENSIONS WHICH MAY BE HELPFUL IN OBTAINING THE NON-SERVICED PART LOCALLY.

1980/89
FORD/LINCOLN MERCURY CARS

ILLUSTRATION
SECTION 10 **A**

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

THIS ILLUSTRATION INDEX INCLUDES THE FOLLOWING MAJOR GROUPS—

BRAKES

WHEELS

1980

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

A (FORD) & MA (MERCURY)

BRAKES

Disc brake system — rear drum	20	1	P-14679
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake booster installation	20	1	P-14679
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678

WHEELS

Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	2	P-13067

D (LINCOLN)

BRAKES

Brake pedal	23	1	P-15697
Disc brake system	20	6	P-15698
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678

WHEELS

Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	2	P-15703

F (MUSTANG) & J (CAPRI)

BRAKES

Brake and clutch pedal	75	4	P-14688
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake booster installation	20	3	P-14142
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	3	P-14693

WHEELS

Wheels and related parts	10	1	P-10853
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			

G (GRANADA) & MG (MONARCH)

BRAKES

Brake and clutch pedals	75	1	P-11622
Disc brake system	20	2	P-12118
Brake assy. — disc front	21	5	P-12803
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	2	P-13485

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1980 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

G (GRANADA) & MG (MONARCH) — Cont'd

WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	1	P-10853

J (CAPRI) Refer to F (MUSTANG) Index

K (MARK VI)

BRAKES			
Brake pedal	23	1	P-15697
Disc brake system	20	6	P-15698
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake booster installation	20	6	P-15698
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678
WHEELS			
Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and wheel covers	10	2	P-15703

L (PINTO) & ML (BOBCAT)

BRAKES			
Brake and clutch pedals	75	2	P-12634
Disc brake system	20	4	P-12117
Brake assy. — disc front	21	3	P-10860
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	3	P-14735
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and wheel covers	10	1	P-10853

P (FAIRMONT) & MP (ZEPHYR)

BRAKES			
Brake and clutch pedal	75	3	P-14139
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	1	P-10853

S (THUNDERBIRD) & MF (COUGAR)

BRAKES			
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake booster installation	20	3	P-14142
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140

**1980/89
FORD/LINCOLN MERCURY CARS**

ILLUSTRATION
SECTION 10 C

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1980 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

S (THUNDERBIRD) & MF (COUGAR) — Cont'd

WHEELS

Front wheel and related parts	21	6	P-14330
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and wheel covers	10	1	P-17097

X (FIESTA)

BRAKES

Brake and clutch pedal	75	9	P-13729
Disc brake system	20	11	P-13725
Brake assy. — disc front	21	13	P-13724
— drum rear	21	15	P-13723
Brake cylinder assy. — rear	21	15	P-13723
Brake booster installation	23	1	P-13726
Brake master cylinder and reservoir	21	14	P-13727
Parking brake system	26	7	P-13728

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	4	P-13722

MA (MERCURY) Refer to A (FORD) Index

MF (COUGAR—XR7) Refer to S (THUNDERBIRD) Index

MG (MONARCH) Refer to G (GRANADA) Index

ML (BOBCAT) Refer to L (PINTO) Index

MP (ZEPHYR) Refer to P (FAIRMONT) Index

MV (VERSAILLES)

BRAKES

Disc brake system — rear disc	20	5	P-12601
Brake assy. — disc front	21	5	P-12803
— drum rear	21	4	P-11906
Brake master cylinder assy.	21	2	P-5518
Parking brake system — rear disc brakes	26	2	P-13485

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	1	P-10853

1981

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

A (FORD) & MA (MERCURY)

BRAKES

Disc brake system — rear drum	20	1	P-14679
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake booster installation	20	1	P-14679
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1981 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

A (FORD) & MA (MERCURY) — Cont'd

WHEELS

Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	2	P-13067

D (LINCOLN)

BRAKES

Brake pedal	23	1	P-15697
Disc brake system	20	6	P-15698
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678

WHEELS

Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	2	P-15703

F (MUSTANG) & J (CAPRI)

BRAKES

Brake and clutch pedal	75	4	P-14688
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake booster installation	20	3	P-14142
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	3	P-14693

WHEELS

Wheels and related parts	10	1	P-10853
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			

G (GRANADA) & MF (COUGAR EXC. XR7)

BRAKES

Brake and clutch pedal	75	5	P-16398
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	3	P-16396

J (CAPRI) Refer to F (MUSTANG) Index

K (MARK VI)

BRAKES

Brake pedal	23	1	P-15697
Disc brake system	20	6	P-15698
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake booster installation	20	6	P-15698
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678

**1980/89
FORD/LINCOLN MERCURY CARS**

**ILLUSTRATION
SECTION 10 E**

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1981 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

K (MARK VI) — Cont'd

WHEELS

Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and wheel covers	10	2	P-15703

P (FAIRMONT) & MP (ZEPHYR)

BRAKES

Brake and clutch pedal	75	3	P-14139
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	1	P-10853

S (THUNDERBIRD) & MF (COUGAR XR7)

BRAKES

Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake booster installation	20	3	P-14142
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140

WHEELS

Front wheel and related parts	21	6	P-14330
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and wheel covers	10	1	P-17097

W (ESCORT) & MW (LYNX)

BRAKES

Brake and clutch pedal	75	6	P-16350
Disc brake system	20	7	P-16354
Brake assy. — disc front	21	9	P-16356
— drum rear — w/7" brake	21	2	P-17110
— w/8" brake	21	8	P-16377
— rear drum brake mounting	21	10	P-16353
Brake cylinder assy. — rear	21	8	P-16377
Brake booster installation	23	2	P-16351
Brake master cylinder and reservoir	21	10	P-16400
Parking brake system	26	5	P-16352

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	3	P-16347

MA (MERCURY) Refer to A (FORD) Index

MF (COUGAR EXC. XR7) Refer to G (GRANADA) Index

MF (COUGAR XR7) Refer to S (THUNDERBIRD) Index

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1981 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

MP (ZEPHYR) Refer to P (FAIRMONT) Index
--

MW (LYNX) Refer to W (ESCORT) Index
--

1982

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

A (FORD) & MA (MERCURY)

BRAKES

Disc brake system — rear drum	20	1	P-14679
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake booster installation	20	1	P-14679
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678

WHEELS

Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	2	P-13067

C (EXP) & MC (LN7)

BRAKES

Brake and clutch pedal	75	6	P-16350
Disc brake system	20	7	P-16354
Brake assy. — disc front	21	9	P-16356
— drum rear — w/8" brake	21	8	P-16377
— rear drum brake mounting	21	10	P-16353
Brake cylinder assy. — rear	21	8	P-16377
Brake booster installation	23	2	P-16351
Brake master cylinder and reservoir	21	10	P-16400
Parking brake system	26	5	P-16352

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	3	P-16347

F (MUSTANG) & J (CAPRI)

BRAKES

Brake and clutch pedal	75	5	P-16398
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake booster installation	20	3	P-14142
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	3	P-14693

WHEELS

Front wheel and related parts	10	1	P-10853
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			

G (GRANADA) & MF (COUGAR EXC. XR7)

BRAKES

Brake and clutch pedal	75	5	P-16398
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1982 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

G (GRANADA) & MF (COUGAR EXC. XR7) — Cont'd

BRAKES — Cont'd			
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	3	P-16396

J (CAPRI) Refer to F (MUSTANG) Index

K (MARK VI)

BRAKES			
Brake pedal	23	1	P-15697
Disc brake system	20	6	P-15698
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake booster installation	20	6	P-15698
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678
WHEELS			
Hub cap and wheel cover — refer to group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and wheel covers	10	2	P-15703

P (FAIRMONT) & MP (ZEPHYR)

BRAKES			
Brake and clutch pedal	75	5	P-16398
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	1	P-10853

S (THUNDERBIRD) & MF (COUGAR XR7)

BRAKES			
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear	21	1	P-16378
Brake booster installation	20	3	P-14142
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140
WHEELS			
Front wheel and related parts	21	6	P-14330
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and wheel covers	10	1	P-17097

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1982 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

W (ESCORT) & MW (LYNX)

BRAKES

Brake and clutch pedal	75	6	P-16350
Disc brake system	20	7	P-16354
Brake assy. — disc front	21	9	P-16356
— drum rear — w/7" brake	21	2	P-17110
— w/8" brake	21	8	P-16377
— rear drum brake mounting	21	10	P-16353
Brake cylinder assy. — rear	21	8	P-16377
Brake booster installation	23	2	P-16351
Brake master cylinder and reservoir	21	10	P-16400
Parking brake system	26	5	P-16352

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	3	P-16347

DC (CONTINENTAL)

BRAKES

Disc brake system — w/rear disc brake	20	8	P-17079
Brake assy. — disc front	21	6	P-14330
— disc rear	21	11	P-17075
Brake booster installation	20	8	P-17079
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	6	P-17078

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and wheel covers	10	4	P-17098

DT (LINCOLN TOWN CAR)

BRAKES

Brake pedal	23	1	P-15697
Disc brake system	20	6	P-15698
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678

WHEELS

Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	2	P-15703

MA (MERCURY) Refer to A (FORD) Index

MC (LN7) Refer to C (EXP) Index

MF (COUGAR EXC. XR7) Refer to G (GRANADA) Index

MF (COUGAR XR7) Refer to S (THUNDERBIRD) Index

MP (ZEPHYR) Refer to P (FAIRMONT) Index

MW (LYNX) Refer to W (ESCORT) Index

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1984 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

A (FORD) & MA (MERCURY) — Cont'd

WHEELS

Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	2	P-13067

B (TEMPO) & MB (TOPAZ)

BRAKES

Brake and clutch pedal	75	6	P-16350
Disc brake system	20	10	P-17931
Brake assy. — disc front	21	12	P-17923
— drum rear — w/8" brake	21	8	P-16377
— rear drum brake mounting	21	10	P-16353
Brake booster and pedal installation	23	3	P-17930
Brake cylinder assy. — rear drum	21	8	P-16377
Brake master cylinder and reservoir	21	13	P-17929
Parking brake system	26	5	P-16352

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	3	P-16347

C (EXP)

BRAKES

Brake and clutch pedal	75	6	P-16350
Disc brake system	20	7	P-16354
Brake assy. — disc front	21	9	P-16356
— drum rear — w/8" brake	21	8	P-16377
— rear drum brake mounting	21	10	P-16353
Brake booster and pedal installation	23	2	P-16351
Brake cylinder assy. — rear drum	21	8	P-16377
Brake master cylinder and reservoir	21	10	P-16400
Parking brake system	26	5	P-16352

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	3	P-16347

F (MUSTANG) & J (CAPRI)

BRAKES

Brake and clutch pedal	75	5	P-16398
Disc brake system — w/rear drum brake	20	3	P-14142
— w/rear disc brake	20	13	P-18432
Brake assy. — disc front	21	6	P-14330
— disc rear	21	11	P-17075
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake booster installation	20	3	P-14142
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	3	P-14693

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	1	P-10853

**1980/89
FORD/LINCOLN MERCURY CARS**

ILLUSTRATION
SECTION 10 M

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1984 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

G (LTD) & MG (MARQUIS)

BRAKES			
Brake and clutch pedal	75	5	P-16398
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	1	P-17097

J (CAPRI) Refer to F (MUSTANG) Index

K (MARK VII)

BRAKES			
Brake pedal	20	12	P-18316
Disc brake system	20	12	P-18316
Brake assy. — disc front	21	6	P-14330
— disc rear	21	11	P-17075
Brake booster installation	20	12	P-18316
Brake master cylinder assy.	21	13	P-17929
Parking brake system	26	8	P-18315
WHEELS			
Hub cap and wheel cover — refer to group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	4	P-17098

S (THUNDERBIRD) & MF (COUGAR)

BRAKES			
Brake and clutch pedal	75	5	P-16398
Disc brake system	20	9	P-17858
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake booster installation	20	9	P-17858
Brake cylinder assy. — rear drum	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140
WHEELS			
Front wheel and related parts	21	6	P-14330
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	1	P-17097

W (ESCORT) & MW (LYNX)

BRAKES			
Brake and clutch pedal	75	6	P-16350
Disc brake system	20	7	P-16354
Brake assy. — disc front	21	9	P-16356
— drum rear — w/7" brake	21	2	P-17110
— w/8" brake	21	8	P-16377
— rear drum brake mounting	21	10	P-16353
Brake booster and pedal installation	23	2	P-16351
Brake cylinder assy. — rear	21	8	P-16377
Brake master cylinder and reservoir	21	10	P-16400
Parking brake system	26	5	P-16352

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1984 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

W (ESCORT) & MW (LYNX) — Cont'd			
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	3	P-16347
DC (CONTINENTAL)			
BRAKES			
Disc brake system — w/rear disc brake	20	12	P-18316
Brake assy. — disc front	21	6	P-14330
— disc rear	21	11	P-17075
Brake booster installation	20	12	P-18316
Brake master cylinder assy.	21	13	P-17929
Parking brake system	26	8	P-18315
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	4	P-17098
DT (LINCOLN TOWN CAR)			
BRAKES			
Brake pedal	23	1	P-15697
Disc brake system	20	6	P-15698
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678
WHEELS			
Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	2	P-15703
MA (MERCURY) Refer to A (FORD) Index			
MB (TOPAZ) Refer to B (TEMPO) Index			
MF (COUGAR) Refer to S (THUNDERBIRD) Index			
MG (MARQUIS) Refer to G (LTD) Index			
MW (LYNX) Refer to W (ESCORT) Index			

1985

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

A (FORD) & MA (MERCURY)			
BRAKES			
Disc brake system — rear drum	20	1	P-14679
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake booster installation	20	1	P-14679
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678
WHEELS			
Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	2	P-13067

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1985 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

B (TEMPO) & MB (TOPAZ)

BRAKES			
Brake and clutch pedal	75	6	P-16350
Disc brake system	20	10	P-17931
Brake assy. — disc front	21	12	P-17923
— drum rear — w/8" brake	21	8	P-16377
— rear drum brake mounting	21	10	P-16353
Brake booster and pedal installation	23	3	P-17930
Brake cylinder assy. — rear drum	21	8	P-16377
Brake master cylinder and reservoir	21	13	P-17929
Parking brake system	26	5	P-16352
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	3	P-16347

C (EXP)

BRAKES			
Brake and clutch pedal	75	6	P-16350
Disc brake system	20	7	P-16354
Brake assy. — disc front	21	9	P-16356
— drum rear — w/8" brake	21	8	P-16377
— rear drum brake mounting	21	10	P-16353
Brake booster and pedal installation	23	2	P-16351
Brake cylinder assy. — rear drum	21	8	P-16377
Brake master cylinder and reservoir	21	10	P-16400
Parking brake system	26	5	P-16352
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	3	P-16347

F (MUSTANG) & J (CAPRI)

BRAKES			
Brake and clutch pedal	75	5	P-16398
Disc brake system — w/rear drum brake	20	3	P-14142
— w/rear disc brake	20	13	P-18432
Brake assy. — disc front	21	6	P-14330
— disc rear	21	11	P-17075
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake booster installation	20	3	P-14142
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	3	P-14693
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	1	P-10853

G (LTD) & MG (MARQUIS)

BRAKES			
Brake and clutch pedal	75	5	P-16398
Disc brake system	20	3	P-14142
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	4	P-14140

**1980/89
FORD/LINCOLN MERCURY CARS**

ILLUSTRATION
SECTION 10 AA

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1988 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

BT (FESTIVA)

BRAKES

Brake and clutch pedal	75	17	P-20164
Disc brake system	20	24	P-20167
Brake assy. — disc front	21	37	P-20158
— drum rear	21	31	P-20150
— rear drum brake mounting	21	28	P-20149
Brake cylinder assy. — rear	21	31	P-20150
Brake booster installation	21	33	P-20165
Brake master cylinder and reservoir	21	33	P-20165
Parking brake system — w/rear drum brake	26	16	P-20168

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	7	P-20422

DC (CONTINENTAL)

BRAKES

Disc brake system — w/rear disc brake	20	26	P-20833
— anti lock system	21	43	P-21479
Brake anti-lock control details	21	39	P-21200
Brake assy. — disc front	21	21	P-19133
— disc rear — details	21	49	P-23022
— installation	21	38	P-20832
Brake & pedal booster installation	23	7	P-20831
Brake master cylinder assy.	21	13	P-17929
Parking brake system	26	17	P-20835

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	7	P-20826

DT (LINCOLN TOWN CAR)

BRAKES

Brake pedal	23	1	P-15697
Disc brake system	20	6	P-15698
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake master cylinder assy.	21	13	P-17929
Parking brake system	26	1	P-14678

WHEELS

Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	2	P-15703

MA (MERCURY) Refer to A (FORD) Index

MB (TOPAZ) Refer to B (TEMPO) Index

ME (SABLE) Refer to E (TAURUS) Index

MF (COUGAR) Refer to S (THUNDERBIRD) Index

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1988 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

MM (TRACER)

BRAKES

Brake and clutch pedal	75	13	P-20054
Disc brake system	20	19	P-21156
Brake assy. — disc front — B/T 58 & 61	21	25	P-21137
— B/T 74	21	50	P-25719
— disc rear	21	26	P-21130
— drum rear	21	23	P-21136
Brake cylinder assy. — rear	21	23	P-21136
Brake booster installation	20	19	P-21156
Brake master cylinder and reservoir — Canada	21	24	P-21131
— exc. Canada	21	36	P-21157
Wheels and related parts	10	6	P-20049
Parking brake system — w/rear drum brake	26	10	P-21158
— w/rear disc brake	26	11	P-21159

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			

MX (MERKUR XR4Ti)

BRAKES

Brake and clutch pedal — M/T	75	11	P-18708
Brake Pedal Installation — A/T	23	4	P-18709
Disc brake system	20	14	P-18713
Brake assy. — disc front	21	17	P-18714
— drum rear	21	18	P-18715
Brake booster installation	23	4	P-18712
Brake cylinder assy. — rear	21	18	P-18715
Brake master cylinder assy.	21	16	P-18711
Parking brake system	26	9	P-18710

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	5	P-18716

MY (SCORPIO)

BRAKES

Brake and clutch pedal — M/T	75	16	P-20458
Brake Pedal Installation — A/T	23	6	P-20459
Disc Brake System	20	32	P-22081
— anti-skid	20	23	P-20463
Brake assy. — disc front	21	32	P-20505
— disc rear	21	34	P-20504
Brake anti-lock control details	21	35	P-20484
Brake booster installation	21	35	P-20484
Brake master cylinder assy.	21	35	P-20484
Parking brake system	26	15	P-20461

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	6	P-20525

1989

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

A (FORD) & MA (MERCURY)

BRAKES

Disc brake system — rear drum	20	1	P-14679
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378

**1980/89
FORD/LINCOLN MERCURY CARS**

ILLUSTRATION
SECTION 10 CC

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1989 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

A (FORD) & MA (MERCURY) — Cont'd			
BRAKES — Cont'd			
Brake cylinder assy. — rear drum	21	1	P-16378
Brake booster installation	20	1	P-14679
Brake master cylinder assy.	21	42	P-22193
Parking brake system	26	1	P-14678
WHEELS			
Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	2	P-13067
B (TEMPO) & MB (TOPAZ)			
BRAKES			
Brake and clutch pedal	75	6	P-16350
Disc brake system	20	25	P-20828
Brake assy. — disc front	21	12	P-17923
— drum rear — w/8" brake	21	8	P-16377
— rear drum brake mounting — exc. all wheel drive	21	10	P-16353
— w/all wheel drive	21	28	P-19984
Brake booster and pedal installation	23	3	P-17930
Brake cylinder assy. — rear drum	21	8	P-16377
Brake master cylinder and reservoir	21	13	P-17929
Parking brake system	26	5	P-16352
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	3	P-16347
E (TAURUS) & ME (SABLE)			
BRAKES			
Brake and clutch pedal	75	12	P-19107
Disc brake system			
— B/T 54	20	15	P-19105
— B/T 74	20	16	P-19106
Brake assy. — disc front	21	21	P-19133
— disc rear	21	49	P-23022
— drum rear	21	20	P-19131
— rear drum brake mounting	21	16	P-19132
Brake booster and pedal installation	23	5	P-19130
Brake cylinder assy. — rear drum	21	20	P-19131
Brake master cylinder and reservoir	21	13	P-17929
Parking brake system	26	5	P-19108
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	5	P-19078
F (MUSTANG)			
BRAKES			
Brake and clutch pedal	75	5	P-16398
Disc brake system — w/rear drum brake — 4 cyl. 140 (2.3L)	20	21	P-19956
— 8 cyl. 302 (5.0L)	20	22	P-19957
Brake assy. — disc front	21	6	P-14330
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake booster installation	20	3	P-14142
Brake master cylinder assy.	21	13	P-17929
Parking brake system	26	14	P-19961

NOVEMBER, 1993

COPYRIGHT © 1993

FORD MOTOR
COMPANY

DEARBORN, MICHIGAN

FINAL ISSUE

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1989 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

F (MUSTANG) — Cont'd

BRAKES — Cont'd

WHEELS

Hub cap and wheel cover — refer to text group 1130
Jack and spare wheel parts — refer to section 175 index
Wheel and related parts

10 1 P-10853

K (MARK VII)

BRAKES

Brake pedal
Disc brake system — w/rear disc brake
— anti lock system
Brake anti-lock control details
Brake assy. — disc front
— disc rear
Brake booster installation
Brake master cylinder assy.
Parking brake system

20 17 P-19384
20 17 P-19384
21 19 P-18840
21 22 P-19654
21 6 P-14330
21 11 P-17075
20 12 P-18316
21 13 P-17929
26 8 P-18315

WHEELS

Hub cap and wheel cover — refer to group 1130
Jack and spare wheel parts — refer to section 175 index
Wheel and related parts

10 4 P-17098

S (THUNDERBIRD) & MF (COUGAR)

BRAKES

Brake and clutch pedal
Disc brake system — w/rear drum brake
— w/rear disc brake & anti-lock — Page A
— Page B
Brake anti-lock control details
Brake assy. — disc front
— drum rear
— disc rear
— rear drum brake mounting
Brake & pedal booster installation—w/o anti-lock brakes
— w/anti-lock brakes
Brake cylinder assy. — rear drum
Brake master cylinder assy.
Parking brake system — foot control—w/rear disc brake
—w/o rear disc brake
— w/rear disc brake—hand control

75 25 P-21778
20 29 P-21683
20 30 P-21681
20 31 P-21682
21 39 P-21200
21 46 P-21787
21 48 P-21814
21 47 P-21788
21 30 P-21785
23 9 P-21777
23 7 P-20831
21 1 P-16378
21 13 P-17929
26 19 P-21786
26 21 P-21827
26 20 P-21735

WHEELS

Front wheel and related parts
Hub cap and wheel cover — refer to text group 1130
Jack and spare wheel parts — refer to section 175 index
Wheel and related parts

21 6 P-14330
10 1 P-17097

W (ESCORT)

BRAKES

Brake and clutch pedal
Disc brake system
Brake assy. — disc front
— drum rear — w/7" brake
— w/8" brake
— rear drum brake mounting
Brake booster and pedal installation
Brake cylinder assy. — rear
Brake master cylinder and reservoir
Parking brake system

75 6 P-16350
20 18 P-19568
21 12 P-17923
21 2 P-17110
21 8 P-16377
21 10 P-16353
23 3 P-17930
21 8 P-16377
21 13 P-17929
26 5 P-16352

**1980/89
FORD/LINCOLN MERCURY CARS**

ILLUSTRATION
SECTION 10 EE

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1989 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

W (ESCORT) — Cont'd			
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	3	P-16347
BT (FESTIVA)			
BRAKES			
Brake and clutch pedal	75	17	P-20164
Disc brake system	20	24	P-20167
Brake assy. — disc front	21	37	P-20158
— drum rear	21	31	P-20150
— rear drum brake mounting	21	28	P-20149
Brake cylinder assy. — rear	21	31	P-20150
Brake booster installation	21	33	P-20165
Brake master cylinder and reservoir	21	33	P-20165
Parking brake system — w/rear drum brake	26	16	P-20168
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	7	P-20422
DC (CONTINENTAL)			
BRAKES			
Disc brake system — w/rear disc brake	20	26	P-20833
— anti lock system	21	43	P-21479
Brake anti-lock control details	21	39	P-21200
Brake assy. — disc front	21	21	P-19133
— disc rear — details	21	49	P-20322
— installation	21	38	P-20832
Brake pedal & booster installation	23	7	P-20831
Brake master cylinder assy. — anti-lock	21	39	P-21200
Parking brake system	26	17	P-20835
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheel and related parts	10	7	P-20826
DT (LINCOLN TOWN CAR)			
BRAKES			
Brake pedal	23	1	P-15697
Disc brake system	20	6	P-15698
Brake assy. — disc front	21	7	P-14674
— drum rear	21	1	P-16378
Brake cylinder assy. — rear drum	21	1	P-16378
Brake master cylinder assy.	21	2	P-5518
Parking brake system	26	1	P-14678
WHEELS			
Front wheel and related parts	21	7	P-14674
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	2	P-15703
MA (MERCURY) Refer to A (FORD) Index			
MB (TOPAZ) Refer to B (TEMPO) Index			
ME (SABLE) Refer to E (TAURUS) Index			
MF (COUGAR) Refer to S (THUNDERBIRD) Index			

INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1989 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.

MM (TRACER)

BRAKES

Brake and clutch pedal	75	13	P-20054
Disc brake system	20	19	P-21156
Brake assy. — disc front — B/T 58 & 61	21	25	P-21137
— B/T 74	21	50	P-25719
— disc rear	21	26	P-21130
— drum rear	21	23	P-21136
Brake cylinder assy. — rear	21	23	P-21136
Brake booster installation	20	19	P-21156
Brake master cylinder and reservoir — Canada	21	24	P-21131
— exc. Canada	21	36	P-21157
Wheels and related parts	10	6	P-20049
Parking brake system — w/rear drum brake	26	10	P-21158
— w/rear disc brake	26	11	P-21159

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			

MX (MERKUR XR4Ti)

BRAKES

Brake and clutch pedal — M/T	75	11	P-18708
Brake Pedal Installation — A/T	23	4	P-18709
Disc brake system	20	14	P-18713
Brake assy. — disc front	21	17	P-18714
— drum rear	21	18	P-18715
Brake booster installation	23	4	P-18712
Brake cylinder assy. — rear	21	18	P-18715
Brake master cylinder assy.	21	16	P-18711
Parking brake system	26	9	P-18710

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	5	P-18716

MY (SCORPIO)

BRAKES

Brake and clutch pedal — M/T	75	16	P-20458
Brake Pedal Installation — A/T	23	6	P-20459
Disc Brake System	20	32	P-22081
— anti-skid	20	23	P-20463
Brake assy. — disc front	21	32	P-20505
— disc rear	21	34	P-20504
Brake anti-lock control details	21	35	P-20484
Brake booster installation	21	35	P-20484
Brake master cylinder assy.	21	35	P-20484
Parking brake system	26	15	P-20461

WHEELS

Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	6	P-20525

1980/89
FORD/LINCOLN MERCURY CARS

ILLUSTRATION
SECTION 10 GG


INDEX

TITLE	SECTION	PAGE	ILLUS. NO.
-------	---------	------	------------

1989 — Cont'd

NOTE: Indexes are arranged in ALPHABETICAL SEQUENCE by MODEL CODE.


ST (PROBE)			
BRAKES			
Brake and clutch pedal — M/T	75	19	P-21001
Brake pedal instal. — A/T	23	8	P-21078
Disc brake system			
— w/anti-lock	20	27	P-21542
— w/o anti-lock	20	28	P-21543
Brake anti-lock control and wiring	21	45	P-21541
Brake assy. — disc front	21	44	P-21517
— disc rear	21	41	P-21073
— drum rear	21	42	P-21053
Brake cylinder assy. — rear	21	42	P-21053
Brake master cylinder and reservoir	21	40	P-21540
Parking brake system	26	18	P-21700
WHEELS			
Hub cap and wheel cover — refer to text group 1130			
Jack and spare wheel parts — refer to section 175 index			
Wheels and related parts	10	8	P-20992



▲ SERVICED ONLY IN 1A109 KIT


P-17098

WHEELS & RELATED PARTS
1982/87 CONTINENTAL and 1984/ MARK VII




P-13722


WHEELS & RELATED PARTS
1980 FIESTA



WHEELS & RELATED PARTS
1988/ FESTIVA



WHEELS & RELATED PARTS
1988/ CONTINENTAL




P-20992

WHEELS & RELATED PARTS
1989 PROBE

1980/89
FORD/LINCOLN MERCURY CARS

ILLUSTRATION
SECTION 20

1



P-14679

DISC BRAKE SYSTEM
1980/ FORD ≈ 1980/ MERCURY


NOVEMBER, 1993


COPYRIGHT ©1993

FORD MOTOR
COMPANY

—DEARBORN, MICHIGAN


FINAL ISSUE

DISC BRAKE SYSTEM—w/REAR DRUM BRAKE
1980 GRANADA ≈ 1980 MONARCH




P-17931

DISC BRAKE SYSTEM
1984/87 TEMPO ≈ 1984/87 TOPAZ





DISC BRAKE SYSTEM—w/REAR DISC BRAKE—w/o ANTI-SKID
1984/85 CONTINENTAL & MARK VII



P-19105


DISC BRAKE SYSTEM - B/T 54
1986/ TAURUS ≈ 1986/ SABLE





• REFER TO ILLUSTRATION SECTION 21 FOR SERVICED DETAILS
 % CUT FROM 2269 BULK TUBING
 # REFER TO BODY GROUP NUMBER


DISC BRAKE SYSTEM—w/REAR DISC BRAKE
 1987/88 THUNDERBIRD




*THIS IS A COMPLETE PART NUMBER.
THE GROUP NUMBER USED FOR
SEQUENCING IN THE PRICE LIST
APPEARS BETWEEN THE HYPHENS (-).

P-20167


DISC BRAKE SYSTEM
1988/ FESTIVA

DISC BRAKE SYSTEM
1988/ CONTINENTAL


1980/89
FORD/LINCOLN MERCURY CARS

P-22081

DISC BRAKE SYSTEM
1988/ SCORPIO




FRONT DISC BRAKE ASSY.
1980 PINTO ≈ 1980 BOBCAT



†SERVICED IN 2221 KIT

P-12803

FRONT DISC BRAKE ASSY.
1980 GRANADA ≈ 1980 MONARCH & VERSAILLES

1980/89
FORD/LINCOLN MERCURY CARS


% SERVICED IN 2B321 KIT ONLY

● SERVICED IN 2221 CALIPER REPAIR KIT

P-14330


FRONT DISC BRAKE ASSY.

1980/83 FAIRMONT, 1980/ MUSTANG, 1980/88 THUNDERBIRD, 1981/82 GRANADA,
1983/86 LTD, 1980/86 CAPRI, 1980/88 COUGAR, 1980/83 ZEPHYR,
1982/87 CONTINENTAL, 1983/86 MARQUIS & 1984/ MARK VII



P-16377


DRUM BRAKE ASSY. - 8" (SELF ADJUSTING) - REAR ONLY
 1981/ ESCORT, 1982/88 EXP & 1984/ TEMPO ≈ 1981/87 LYNX, 1982/83 LN7 & 1984/ TOPAZ




P-17075

REAR DISC BRAKE ASSY.


1984/86 MUSTANG SVO ≈ 1982/87 CONTINENTAL & 1984/ MARK VII




1987/ MUSTANG, 1984/ TEMPO, 1985/ ESCORT ("FROM 3/85"), 1986/ TAURUS & 1987/ THUNDERBIRD ≈
1984/ TOPAZ, MARK VII & CONTINENTAL, 1985/87 LYNX ("FROM 3/85"), 1986/ SABLE & 1987/ COUGAR



**FRONT DISC BRAKE ASSY.
1980 FIESTA**


1980/89
FORD/LINCOLN MERCURY CARS

P-18711

BRAKE MASTER CYLINDER ASSY.
1985/ MERKUR—XR4Ti


P-19132

REAR DRUM BRAKE MOUNTING & RELATED PARTS
1986/ TAURUS ≈ 1986/ SABLE



P-18840

DISC BRAKE ANTI LOCK WIRING SYSTEM
1985/87 CONTINENTAL & 1985/ MARK VII




P-19131

DRUM BRAKE ASSY. & WHEEL CYLINDER (SELF-ADJUSTING) – REAR ONLY
1986/ TAURUS ≈ 1986/ SABLE

1980/89
FORD/LINCOLN MERCURY CARS

ILLUSTRATION
SECTION 21 21



- SERVICED ONLY IN 2221 ASSY.
- ▲ SERVICED IN 2B321 KIT

P-19133

FRONT DISC BRAKE ASSY.
1986/ TAURUS ≈ 1986/ SABLE & 1988/ CONTINENTAL


NOVEMBER, 1993

COPYRIGHT ©1993


FORD MOTOR
COMPANY

DEARBORN, MICHIGAN

FINAL ISSUE




P-22043



▲ REFER TO GROUP IN SOFT TRIM SECTION

P-22048


INTERIOR TRIM PANELS – B/T 74 – LX – PASSIVE RESTRAINTS – “FROM 3/88”
1988/ ESCORT



† ALSO SERVICED IN 115A70 KIT

P.13761

INTERIOR TRIM PARTS (AUXILIARY FLOOR PANELS)
1980 FIESTA



▲ REFERTO GROUP IN SOFT TRIM SECTION

INTERIOR TRIM PARTS (LUGGAGE C)
1980 FIESTA

Buy Now

